

PUBLISHED: 10-OCT-2019
2020.0 DEFENDER (LE), 413-13

PARKING AID

FRONT INNER PARKING AID SENSOR (G2323759)

mcx30.com


REMOVAL

 NOTES:


- This procedure contains some variation in the illustrations depending on the vehicle specification, but the essential information is always correct.
- This procedure contains illustrations showing certain components removed to provide extra clarity.
- The ignition must be switched off.

1. Raise and support the vehicle on a suitable 2-post lift.
Refer to: [Jacking and Lifting](#) (100-02 Jacking and Lifting, Description and Operation).
2. With assistance, remove the front bumper.
Refer to: [Front Bumper](#) (501-19 Bumpers, Removal and Installation).

3.



Disconnect the electrical connector from the front inner parking aid sensor.



E252595


Release the 2 clips and remove the front inner parking aid sensor.

mcx30.com

1.

⚠ CAUTIONS:

- If a new parking aid sensor is installed, make sure that the membrane and the cylindrical edge of the membrane must be covered with a paint layer of at least 2 mm all the way around as illustrated.
- The whole paint film thickness on the membranes is up to a maximum of 120 micrometers (including the electro-coated layer) to make sure a proper sensor function.
- This is also valid for the multiple layer paints.




Check the paint layer of the parking aid sensor.

2.

⚠ CAUTIONS:

- Inspect the ring, replace if damaged.
- Make sure that the ring is correctly located to the sensor.



Before installing the front inner parking aid sensor, check the condition and the position of the ring.

3.

⚠ NOTE:

Make sure that the sensor is correctly located to the bracket. Audible clicks will be heard to confirm connection.

- Install the front inner parking aid sensor.
- Connect the electrical connector to the front inner parking aid sensor.

4.

With assistance, install the front bumper.

Refer to: [Front Bumper](#) (501-19 Bumpers, Removal and Installation).