

PUBLISHED: 06-APR-2020
2020.0 DEFENDER (LE), 501-29

SIDE PANEL SHEET METAL REPAIRS

B-PILLAR INNER PANEL (G2416087)

mcx30.com


REMOVAL

 NOTE:

In this procedure the B-pillar inner panel is installed in conjunction with:

- B-pillar reinforcement.

1.



The B-pillar inner panel is serviced as indicated.

2.

Before commencing this procedure make sure that you are aware of all Health and Safety requirements. Refer to: [Health and Safety Precautions](#) (100-00 General Information, Description and Operation).

NOTES:

- Where Breakstem Fastener (BSF) removal is instructed remove the fastener shaft with a 4 mm punch and remove the head with a 6.5 mm drill bit. Clean all the drilled holes to make sure they are free from debris.
- Where Self Piercing Rivet (SPR) removal is instructed use either the Jaguar Land Rover (JLR) approved SPR tool or a 5.3 mm drill bit. Clean all the drilled holes to make sure they are free from debris.
- Where Flow Form Rivet (FFR) removal is instructed, remove the head and then remove the shaft with a punch. Clean the holes to make sure they are free from debris.
- Any joints sealed as part of vehicle manufacture must be sealed as part of the repair.
- To make sure that the vehicle is correctly aligned it must be placed on a JLR approved alignment jig.

When installing the B-pillar inner panel make sure that you are aware of the methods, tools and fixings used in this procedure.

Refer to: [Body Repairs](#) (501-25A Body Repairs - General Information, Description and Operation).

Refer to: [Adhesives, Fixings and Consumables](#) (501-25A Body Repairs - General Information, Description and Operation).

4.

For additional information on the fixings required to complete this procedure

Refer to: [Specifications - 110](#) (501-29 Side Panel Sheet Metal Repairs, Specifications).

5.


For additional removal information.

Refer to: [B-Pillar Reinforcement - 110](#) (501-29 Side Panel Sheet Metal Repairs, Removal and Installation).

6.


Release and position the wiring harness to one side.

7.



Remove the Self Piercing Rivets (SPRs) as indicated.

8.




Remove the SPRs as indicated.

9.

NOTE:

Where Flow Form Rivet (FFR) installation is indicated. Make sure that the panel is planished before removal.



Planish the panel as indicated.

10. Carefully separate the joints and remove the B-pillar inner panel.

INSTALLATION

CAUTION:

Where structural adhesive is to be applied between surfaces it is essential compression is applied to the joints during the curing period.

NOTES:


- Breakstem Fastener (BSF) installation involves using the JLR approved BSF installation tool and requires a hole diameter of 6.5 mm.
- Self Piercing Rivet (SPR) installation requires using the JLR approved SPR tool.
- Flow Form Rivet (FFR) installation requires using the JLR approved FFR installation tool.
- Refer to Adhesive, Fixings and Consumables for further information on Flow Form Rivets (FFRs).

1. Remove the rivet remnants.

2. Dress the flanges where necessary.

3. Offer up the new B-pillar inner panel and clamp into position. Check alignment, if correct proceed to next step, if not rectify and check the alignment again before proceeding.

4.




Drill holes where the Breakstem Fasteners (BSFs) are to be installed as indicated.

5.

NOTE:

Make sure that the JLR recommended countersink tool is used for this step.




Countersink the hole to a depth of 2 mm as indicated.

6.


NOTE:

Make sure that the JLR recommended countersink tool is used for this step.



Countersink the hole to a depth of 2 mm as indicated.

7.



Drill holes where the BSFs are to be installed as indicated. Punch calibrated holes where the Flow Form Rivets (FFRs) are to be installed as indicated.

8. Remove the new B-pillar inner panel.


9. Deburr the drilled holes.

10. Clean and prepare the panel surfaces.

11.


 NOTE:

Make sure a continuous bead of adhesive surrounds the fixing holes.



Apply a 5 mm zig zag bead of the JLR recommended bonding material as indicated.


12. Offer up the new B-pillar inner panel and clamp into position. Check alignment, if correct proceed to next step, if not rectify and check the alignment again before proceeding.



Install the BSFs and FFRs as indicated.

NOTE:

Make sure that the Breakstem Fasteners (BSFs) are installed from the outside.



Install the BSFs and SPRs as indicated.

 **NOTE:**

BSF G

BSF M

x2

E252606

16. Remove any excess adhesive.

18. Make sure that any open or exposed panel joints are correctly sealed.

NOTE:

Refer to: [B-Pillar Reinforcement - 110](#) (501-29 Side Panel Sheet Metal Repairs, Removal and Installation).

