

2022 CHEVROLET CORVETTE SERVICE MANUAL

- **SEARCH**

1. **Engine/Propulsion**

2. **Engine Controls and Fuel - 6.2L (LT2)**

3. **Repair Instructions**

- 4.

Fuel Injection Fuel Rail Assembly Replacement - Bank 2

Special Tools

- EN-49245-3 Fuel Injection Seal Installer Sizer
- EN-49245-4 Fuel Injection Seal Installer Sizer
- EN-49248 Injector Rail Assembly Remover
- EN-51105 Injector Seal Installer Adapters


For equivalent regional tools, refer to Special Tools.

Removal Procedure

1. **Danger:**

The noise cancelling foam component **MUST** be replaced if it has been exposed to engine fluids. Failure to replace the noise cancelling foam component that has been exposed to engine fluids may result in an engine fire resulting in catastrophic engine damage, and possible injury or death.

2. Remove the fuel pump insulator. Fuel Pump Insulator Replacement.
3. Remove the positive crankcase ventilation tube. Positive Crankcase Ventilation Foul Air Tube Replacement - Engine Block Valley Cover to Foul Air Tube.
4. Remove the fuel injector intermediate pipe position 1. Fuel Feed Intermediate Pipe Replacement - Position 1.
5. Clean the cylinder head pocket around the injectors of any dirt or buildup.
6. Disconnect the electrical wiring harness connectors from the fuel rail.




7. [Click here for full size](#)

8. Note:

The fuel rail fasteners are retained in the fuel rail by keepers and may be difficult to remove.

9. Remove the 4 fuel injection fuel rail bolts (1) securing the fuel injection fuel rail (2).



10. [Click here for full size](#)

11. Note:

- In some cases, the fuel injectors may be difficult to remove because of heavy carbon build-up or other factors. ⚠ Excessive force


with the removal tool can damage the fuel rail, injectors or both. ⚠️ If injectors are difficult to remove, apply solvent to the base of the injector bores, and allow adequate soaking time, to loosen the fuel injectors.

- Pull the fuel rail and injectors as an assembly.
- To prevent material from entering the combustions chambers make sure the area around each injector is clean and free of debris before the injectors are removed from the injector bores.

12. Install two sets of EN-49248 Injector Rail Assembly Remover (1).

13.

1. Install one remover in each of the fuel rail fastener bores.
2. Remove by turning each section of the EN-49248 Injector Rail Assembly Remover an even amount to pull the fuel rail and injectors out evenly.




14. [Click here for full size](#)

15. Caution:


- Remove the fuel rail assembly carefully in order to prevent damage to the injector electrical connector terminals and the injector spray tips. Support the fuel rail after the fuel rail is removed in order to avoid damaging the fuel rail components.
- Cap the fittings and plug the holes when servicing the fuel system in order to prevent dirt and other contaminants from entering open pipes and passages.

16. Simultaneously lift both ends of the fuel rail (1) and remove the fuel rail assembly from the cylinder head.



17.
[Click here for full size](#)

18. Remove and DISCARD the (2) fuel injector seals (1).



19.
[Click here for full size](#)

20. Note:

Some vehicles were not originally equipped with fuel injector dust seals. A NEW seal must be installed when the injectors are removed.

21. Remove and DISCARD the fuel injector dust seal (1).

22. Note:

Whenever the fuel injectors are removed from the cylinder head or fuel rail, they will need to be rebuilt. Fuel Rail and Injectors Cleaning and Inspection.


23. If replacing the fuel injection fuel rail, remove the fuel injectors. Fuel Injector Replacement.

Installation Procedure

Note:

The injector seals should be clean and free of debris prior to installation.


1. Inspect the fuel injection fuel rail insulators and replace if necessary.
2. If replacing the fuel injection fuel rail, install the fuel injectors. Fuel Injector Replacement.



3.
[Click here for full size](#)
4. Note:

Do NOT use any type of lubricant when installing the NEW seals (2) on the fuel injector.
5. Install EN-51105-1 Injector Seal Installer Adapters Long Protector (3) onto the fuel injector tip, covering the first recessed area closest to the tip. Place a new seal (2) on the EN-51105-1 Injector Seal Installer Adapters Long Protector.
6.
 1. Using EN-49245-3 Fuel Injection Seal Installer Sizer Pusher (1), install the seal onto the second recessed area (4) of the fuel injector.
 2. Note:

The EN-49245-4 Fuel Injection Seal Installer Sizer Pusher is two sided, and either direction will size the seal correctly.
 3. Compress the seal with your fingers, then resize the seal using the EN-49245-4 Fuel Injection Seal Installer Sizer (5).




7. [Click here for full size](#)

8. Note:

Do NOT use any type of lubricant when installing NEW seals (2) on the injector.


9. Install EN-51105-2 Injector Seal Installer Adapters Short Protector (3) onto the fuel injector tip. Place a NEW seal (2) on EN-51105-2 Injector Seal Installer Adapters Short Protector.

- 10.
1. Using EN-49245-3 Fuel Injection Seal Installer Sizer Pusher (1), install the seal onto the first recessed area (4) of the fuel injector.
 2. Note:
The EN-49245-4 Fuel Injection Seal Installer Sizer Pusher is two sided, and either direction will size the seal correctly.
 3. Compress the seal with your fingers, then resize the seal using the EN-49245-4 Fuel Injection Seal Installer Sizer (5).




11. [Click here for full size](#)

12. Install the NEW fuel injector dust seal (1).



13. [Click here for full size](#)
14. Install the fuel rail assembly (1) into the cylinder head.



15. [Click here for full size](#)
16. Note:

The fuel rail fasteners are retained into the rails using keepers. Care should be taken to ensure that the threadlock is installed after the fasteners are installed in their bore.

17. Install the 4 fuel injection fuel rail bolts (1) into the fuel injection fuel rail (2).

18.

1. Apply a 0.5 mm (0.02 in) band of threadlock to the threads of the fuel rail fasteners (1). Adhesives, Fluids, Lubricants, and Sealers
2. Install the fuel injection fuel rail assembly (2) to the cylinder head.
3. Note:

Start the fuel rail fasteners by hand then draw the injector rail down evenly prior to tightening.

4. Caution:

Refer to Fastener Caution.

5. Tighten the 4 fuel injection fuel rail bolts to 25 N-m (18 lb ft).

19. Connect the electrical wiring harness connectors to the fuel rail.

20. Install the NEW fuel injector intermediate pipe position 1. Fuel Feed Intermediate Pipe Replacement - Position 1.

21. Install the positive crankcase ventilation tube. Positive Crankcase Ventilation Foul Air Tube Replacement - Engine Block Valley Cover to Foul Air Tube.

22. Install the fuel pump insulator. Fuel Pump Insulator Replacement.

mcx30.com