

GENERAL INFORMATION

Engine Performance Safety Precautions

- Always refer to Emission Decal in engine compartment before servicing vehicle. If manual and decal differ, always use decal specifications.
 - Do not allow or create a condition of misfire in more than one cylinder for an extended period of time. Damage to converter may occur due to loading converter with unburned air/fuel mixture.
 - Always turn ignition off and disconnect negative battery cable BEFORE disconnecting or connecting computer or other electrical components.
 - DO NOT drop or shock electrical components such as computer, airflow meter, etc.
 - DO NOT use fuel system cleaning compounds that are not recommended by the manufacturer. Damage to gaskets, diaphragm materials and catalytic converter may result.
 - Before performing a compression test or cranking engine using a remote starter switch, disconnect coil wire from distributor and secure it to a good engine ground, or disable ignition.
 - Before disconnecting any fuel system component, ensure fuel system pressure is released.
 - Use a shop towel to absorb any spilled fuel to prevent fire.
 - DO NOT create sparks or have an open flame near battery.
 - If any fuel system components such as hoses or clamps are replaced, ensure they are replaced with components designed for fuel system use.
 - Always reassemble throttle body components with new gaskets, "O" rings and seals.
 - If equipped with an inertia switch, DO NOT reset switch until fuel system has been inspected for leaks.
 - Wear safety goggles when drilling or grinding.
 - Wear proper clothing which protects against chemicals and other hazards.
-