

2010 ENGINE PERFORMANCE

Engine Controls and Fuel - 2.2L or 2.4L - Equinox & Terrain

SYMPTOMS - ENGINE CONTROLS

DIAGNOSTIC INSTRUCTIONS

- Perform the **Diagnostic System Check - Vehicle** prior to using this diagnostic procedure.
- Review **Strategy Based Diagnosis** for an overview of the diagnostic approach.

SYMPTOMS DESCRIPTION

Symptoms covers conditions that are not covered by DTCs. Certain conditions can cause multiple symptoms. These conditions are listed together under Symptoms Testing. Conditions that may only cause specific symptoms are listed separately under Additional Symptoms Testing. Perform the Symptoms Testing before using the Additional Symptoms Testing.

SYMPTOMS DEFINITION

Backfire

The fuel ignites in the intake manifold or in the exhaust system, making a loud popping noise.

Cuts Out, Misses

A steady pulsation or jerking that follows engine speed, which is usually more pronounced as the engine load increases. This condition is not normally felt above 1,500 RPM or 48 km/h (30 mph). The exhaust has a steady spitting sound at idle or at low speed.

Detonation/Spark Knock

A mild to severe ping which usually occurs worse while under acceleration. The engine makes sharp metallic knocks that change with throttle opening.

Dieseling, Run-On

The engine continues to run after the key is turned OFF, but runs very rough.

Engine Control Module (ECM) Commanded Reduced Engine Power

The ECM illuminates the Reduced Engine Power lamp and will limit engine power under potential engine/vehicle damaging or emissions related conditions. A DTC may not be set.

Fuel Odor

A noticeable smell of unburned fuel.

Hard Start

The engine cranks OK, but does not start for a long time. The vehicle does eventually run, or may start but immediately stall.

Hesitation, Sag, Stumble

A momentary lack of response as the accelerator is pushed down. This condition can occur at any vehicle speed. This condition is usually more pronounced when first trying to make the vehicle move, as from a stop. This condition may cause the engine to stall in severe conditions.

Lack of Power, Sluggishness, or Sponginess

The engine delivers less than expected power. Little or no increase in vehicle speed when the accelerator pedal is pushed down part way.

Poor Fuel Economy

Fuel economy, as measured by an actual road test, is noticeably lower than expected. Also, the fuel economy is noticeably lower than it was on this vehicle at one time, as previously shown by an actual road test.

Rough, Unstable, or Incorrect Idle and Stalling

The engine runs unevenly at idle. If severe, the engine or the vehicle may shake. Engine idle speed may vary. Either condition may be severe enough to stall the engine.

Surges/Chuggles

An engine power variation under steady throttle or cruise. Feels like the vehicle speeds up and slows down with no change in the accelerator pedal position.

SYMPTOMS VERIFICATION

Before using the Symptom tables, perform the following inspections:

- Ensure that the malfunction indicator lamp (MIL) is operating correctly. Use the scan tool to command the lamp ON and OFF.
- Ensure that there are no DTCs that are stored.
- Ensure that the scan tool data is within a normal operating range. Refer to **Control Module References** for scan tool information.
- Verify the customer concern.
- Perform the Visual/Physical Inspection in this section. The visual/physical inspection is extremely important, and can lead to correcting a condition without additional testing. It may also help reveal the cause of an intermittent condition.

IDENTIFYING INTERMITTENT CONDITIONS

Many intermittent conditions occur with harness or connector movement due to engine torque, rough pavement, vibration or physical movements of a component. Refer to the following for a list of issues that may cause an intermittent condition:

- Moisture and water intrusion in connectors, terminals, and components
- Incomplete connector mating
- Poor terminal contact
- High circuit or component resistance-High resistance can include any resistance, regardless of the amount, which can interrupt the operation of the component.
- Harness that is too short or tight
- Wire insulation that is chaffed or cut
- High or low ambient temperature
- High or low engine coolant temperatures
- High underhood temperatures
- Heat build up in component or circuit due to circuit resistance, poor terminal contact, or high electrical load
- High or low system voltage
- High vehicle load conditions
- Rough road surfaces
- Electro-magnetic interference (EMI)/circuit interference from relays, solenoids or other electrical surge
- Incorrect installation of aftermarket, add on accessories

Visual/Physical Check

- Ensure that the control module grounds are clean, tight, and correctly located.
- Ensure that the vacuum hoses are not split or kinked, and are properly connected, as shown on the Vehicle Emission Control Information label.
- Ensure that the air filter is clean and free from restrictions.
- Ensure that there is no water intrusion in connectors terminals and components.
- Inspect the air intake ducts for the following conditions:
 - Collapsed
 - Damaged areas
 - Looseness
 - Incorrect installation
 - Leaking
- Inspect for air leaks at the throttle body mounting area, the mass air flow (MAF) sensor and intake manifold sealing surfaces.
- Inspect the wiring harness for the following conditions:
 - Poor connections

- Pinches
- Cuts
- Inspect for loose, damaged, unseated, or missing sensors/components.
- Inspect the terminals for corrosion and correct contact.

SYMPTOMS TESTING

Backfire, Cuts Out/Misses, Detonation/Spark Knock, Dieseling/Run-On, Hard Start, Hesitation/Sag/Stumble, Lack of Power/Sluggishness/Sponginess, Poor Fuel Economy, Rough, Unstable, or Incorrect Idle and Stalling, or Surges/Chuggles

- Test the fuel system for the following:
 - The fuel system for correct operation volume and pressure-Refer to **Fuel System Diagnosis**.
 - The fuel injectors for proper operation-Refer to **Fuel Injector Solenoid Coil Test**.
 - The fuel quality condition-Refer to **Alcohol/Contaminants-in-Fuel Diagnosis**.
- Test ignition system for the following:
 - Spark plugs for incorrect heat range or an abnormal condition-Refer to **SPARK PLUG INSPECTION** and **IGNITION SYSTEM SPECIFICATIONS** .
 - For diagnosis of coolant or oil fouled spark plugs-Refer to **COOLANT IN COMBUSTION CHAMBER** or **OIL CONSUMPTION DIAGNOSIS** .
 - Wet down the secondary ignition system with water from a spray bottle-Wetting down the secondary ignition system may help locate damaged or deteriorated components. Look/listen for arcing or misfiring as the water is applied.
 - Weak spark using the J 26792 Spark Tester-Refer to **Electronic Ignition System Diagnosis**.
- Inspect for the following conditions:
 - The proper operation of the transmission torque converter clutch (TCC) - The scan tool should indicate an engine speed drop when the TCC is commanded ON. Refer to **Torque Converter Diagnosis** .
 - The proper operation of the A/C compressor
 - An engine that runs lean or rich-Observe the Fuel Trim parameters with a scan tool.
 - Slow responding heated oxygen sensors (HO2S). The HO2S should respond quickly to different throttle positions.

CAUTION: Refer to Heated Oxygen and Oxygen Sensor Caution .

- Water intrusion in the HO2S connector

NOTE: **The embossed arrows on the mass air flow (MAF) sensor indicate the direction of the intake air flow. The arrows must point toward the engine.**

- Inspect the MAF sensor installation. A MAF sensor that is incorrectly installed may cause a hard start. Install the MAF in the proper direction. Refer to **MASS AIRFLOW SENSOR WITH INTAKE AIR TEMPERATURE SENSOR REPLACEMENT** .
- Inspect the mass air flow (MAF) sensor connections.
- Engine oil contaminated by fuel
- Vacuum hoses for splits or kinks-Verify that the routing and connections are as shown on the Vehicle Emission Control Information label.
- Knock sensor system for excessive spark retard activity-Observe the Knock Retard parameter on the scan tool for activity more than 0°.
- The exhaust system components for the following:
 - Physical damage or possible internal failure
 - The three-way catalytic converters for a restriction

For more information, refer to **Symptoms - Engine Exhaust** .

- Electromagnetic interference (EMI) on the reference circuit can cause a misfire condition. You can usually detect EMI with a scan tool by monitoring the engine speed parameter. A sudden increase in the engine speed parameter with little change in actual engine speed indicates that EMI is present. Inspect the high voltage components near the ignition control circuit if a condition exists.
- The crankcase ventilation valve for proper operation-Refer to **CRANKCASE VENTILATION SYSTEM INSPECTION/DIAGNOSIS (WITHOUT TURBOCHARGER)** .
- Evaporative emission (EVAP) canister purge solenoid that is stuck open
- The engine cooling system for the following conditions:
 - The thermostat is the correct heat range. Refer to **Thermostat Diagnosis** .
 - Proper engine coolant level-If the level is low, refer to **Loss of Coolant** .
- The crankshaft position sensor for an intermittent condition-Observe the scan tool Crankshaft Position Resync Counter parameter. The Resync Counter parameter should remain at 0 during all operating conditions, and when moving the related harnesses and connectors between the crankshaft position sensor and the ECM.
- Inspect the engine for the following mechanical failures:

Refer to **SYMPTOMS - ENGINE MECHANICAL** .

- Excessive oil in the combustion chamber or leaking valve seals
- Oil Consumption
- Incorrect cylinder compression
- Sticking or leaking valves
- Worn camshaft lobes
- Incorrect valve timing
- Worn rocker arms
- Broken valve springs
- Excessive carbon buildup in the combustion chambers-Clean the chambers with top engine cleaner.

Follow the instructions on the can.

- Incorrect engine parts
- If the above conditions do not address the symptom, refer to the additional symptoms tests.

ADDITIONAL SYMPTOMS TESTS

Hard Start

- Observe the Throttle Body Idle Airflow Compensation parameter with a scan tool. A value greater than 80% may indicate an excessive accumulation of deposits in the throttle bore. Inspect the throttle body and clean, if necessary. Refer to **Throttle Body Inspection and Cleaning**.
- Test the engine coolant temperature (ECT) sensor. Compare the ECT sensor value to the intake air temperature (IAT) sensor value on a cold engine. The ECT and IAT sensor values should be within $\pm 3^{\circ}\text{C}$ (5°F). If the ECT sensor is out of range with the IAT sensor, test the resistance of the ECT sensor. Refer to **Temperature Versus Resistance - Engine Coolant Temperature Sensor** for resistance specifications. Replace the ECT sensor if the resistance is not within specification. Refer to **Engine Coolant Temperature Sensor Replacement (LF1)**. If the sensor is within the specification, test the ECT sensor circuits for high resistance.
- Verify that the fuel system has adequate pressure for engine start-up. With a scan tool, compare the Fuel Pressure Sensor parameter value to the Desired Fuel Pressure parameter value when the ignition key is first turned to ON. Refer to **Fuel System Diagnosis**.
- Inspect for excessive crankshaft endplay that will cause the crankshaft position sensor reluctor wheel to move out of alignment with the crankshaft position sensor. Refer to **Crankshaft and Bearing Cleaning and Inspection**.

Hesitation, Sag, Stumble

- Test the fuel pressure. Refer to **Fuel System Diagnosis**.
- Inspect the mass air flow (MAF) sensor for obstruction, contamination, and damage. Refer to **Mass Airflow Sensor with Intake Air Temperature Sensor Replacement**.
- Test the generator. Refer to **Symptoms - Engine Electrical**. Repair the charging system if the generator output voltage is less than 9 volts or more than 16 volts.
- Inspect for excessive crankshaft endplay that will cause the crankshaft position sensor reluctor wheel to move out of alignment with the crankshaft position sensor. Refer to **Crankshaft and Bearing Cleaning and Inspection**.
- Test the manifold absolute pressure (MAP) sensor. Refer to **DTC P0106 (LF1)**.

NOTE: The following actions may need to be repeated in order to verify an intermittent intake or exhaust camshaft actuator condition.

- Engine warm and idling, verify the correct operation of the camshaft actuator system. Command the intake and exhaust camshaft actuators from 0 degrees to 25 degrees and back to zero while observing the scan tool Intake Camshaft Position Variance and Exhaust Camshaft Position Variance parameters. Each parameter should be less than 2 degrees in each of the commanded states.
 - If any of the parameters is greater than 2 degrees, inspect the suspect camshaft actuator and

camshaft actuator solenoid valve and valve bore for contamination, obstruction, and damage. Refer to **Camshaft Position Actuator Solenoid Valve Replacement** and **Camshaft Actuator System Description** .

Poor Fuel Economy

- Heavy loads being carried or towed
- Acceleration rate too much or too often
- Inspect the brake system for brake drag.
- Inspect for incorrect operation of the speedometer.
- Verify that the engine coolant temperature (ECT) has not shifted in value. Allow the engine to run and reach operating temperature. Observe the ECT Sensor parameter with a scan tool and compare the reading to that parameter listed on the **Engine Control Module Scan Tool Information (LF1,LFW)** or **Engine Control Module Scan Tool Information (LAF)** list. If the reading is not in the range specified in the list, test the resistance of the ECT sensor. Refer to **Temperature Versus Resistance - Engine Coolant Temperature Sensor** for resistance specifications. Replace the ECT sensor if the resistance is not within specification. Refer to **Engine Coolant Temperature Sensor Replacement (LF1)** . If the sensor is within the specification, test the ECT sensor circuits for high resistance.
- Inspect the mass air flow (MAF) sensor for obstruction, contamination, and damage. Refer to **Mass Airflow Sensor with Intake Air Temperature Sensor Replacement** .
- Observe the Throttle Body Idle Airflow Compensation parameter with a scan tool. A value greater than 80% may indicate an excessive accumulation of deposits in the throttle bore. Inspect the throttle body and clean, if necessary. Refer to **Throttle Body Inspection and Cleaning** .

Detonation/Spark Knock

- Inspect for excessive carbon buildup in the combustion chambers. Clean the chambers with Top Engine Cleaner. Follow the instructions on the can.
- Test for an engine overheating condition. Refer to **Engine Overheating** .
- Verify that the engine coolant temperature (ECT) has not shifted in value. Allow the engine to run and reach operating temperature. Observe the ECT Sensor parameter with a scan tool and compare the reading to that parameter listed on the **Engine Control Module Scan Tool Information (LF1,LFW)** or **Engine Control Module Scan Tool Information (LAF)** list. If the reading is not in the range specified in the list, test the resistance of the ECT sensor. Refer to **Temperature Versus Resistance - Engine Coolant Temperature Sensor** for resistance specifications. Replace the ECT sensor if the resistance is not within specification. Refer to **Engine Coolant Temperature Sensor Replacement (LF1)** . If the sensor is within the specification, test the ECT sensor circuits for high resistance.
- If there are no engine mechanical faults, fill the fuel tank with a known high quality fuel that meets the vehicle minimum octane requirements.

Lack of Power, Hesitation, or Cut Out

- Inspect the engine electrical system for correct operation. Refer to **Symptoms - Engine Electrical** .
- Verify that each injector harness is connected to the correct injector.
- Inspect the mass air flow (MAF) sensor for obstruction, contamination, and damage. Refer to **Mass**

Airflow Sensor with Intake Air Temperature Sensor Replacement

NOTE: The following actions may need to be repeated in order to verify an intermittent intake or exhaust camshaft actuator condition.

- Engine warm and idling, verify the correct operation of the camshaft actuator system. Command the intake and exhaust camshaft actuators from 0 degrees to 25 degrees and back to zero while observing the scan tool Intake Camshaft Position Variance and Exhaust Camshaft Position Variance parameters. Each parameter should be less than 2 degrees in each of the commanded states.
 - If any of the parameters is greater than 2 degrees, inspect the suspect camshaft actuator and camshaft actuator solenoid valve and valve bore for contamination, obstruction, and damage. Refer to **Camshaft Position Actuator Solenoid Valve Replacement** and **Camshaft Actuator System Description**.

Rough, Unstable, or Incorrect Idle and Stalling

- Observe the Throttle Body Idle Airflow Compensation parameter with a scan tool. A value greater than 80% may indicate an excessive accumulation of deposits in the throttle bore. Inspect the throttle body and clean, if necessary. Refer to **Throttle Body Inspection and Cleaning**.
- Inspect the mass air flow (MAF) sensor for obstruction, contamination, and damage. Refer to **Mass Airflow Sensor with Intake Air Temperature Sensor Replacement**.
- Inspect the engine mounts.
- Inspect the intake and exhaust manifolds for casting flash.

Surges/Chuggles

- Inspect the mass air flow (MAF) sensor for obstruction, contamination, and damage. Refer to **Mass Airflow Sensor with Intake Air Temperature Sensor Replacement**.
- Test the heated oxygen sensors (HO2S). The HO2S should respond quickly to a change in throttle position. If the HO2S do not respond to different throttle positions, inspect for contamination from fuel, silicon, or the incorrect use of RTV sealant. The sensors may have a white powdery coating and result in a high, but false, signal voltage, which gives a rich exhaust indication. The PCM reduces the amount of fuel delivered to the engine, causing a driveability condition.
- Verify that each injector harness is connected to the correct injector.

Fuel Odor

- Saturated EVAP canister-Refer to **Evaporative Emission Control System Description**.
- A condition with the internal components of the fuel tank assembly-Refer to **Fuel System Description (LF1)**.
- Inspect for damaged or deteriorated fuel lines.

ECM Commanded Reduced Engine Power

Review the Reduced Engine Power Indication History parameter with a scan tool to determine the reason for

the last reduced engine power event.

MALFUNCTION INDICATOR LAMP (MIL) DIAGNOSIS

DIAGNOSTIC INSTRUCTIONS

- Perform the **Diagnostic System Check - Vehicle** prior to using this diagnostic procedure.
- Review **Strategy Based Diagnosis** for an overview of the diagnostic approach.
- **Diagnostic Procedure Instructions** provides an overview of each diagnostic category.

CIRCUIT/SYSTEM DESCRIPTION

Ignition voltage is supplied to the malfunction indicator lamp (MIL). The engine control module (ECM) turns the MIL ON by grounding the MIL control circuit.

DIAGNOSTIC AIDS

If the condition is intermittent, move the related harnesses and connectors with the engine operating. Monitor the scan tool Circuit Test Status parameters for the component. The Circuit Test Status parameter will change from OK or Not run to Fault if there is a condition with the circuit or a connection.

REFERENCE INFORMATION

Schematic Reference

- **Engine Controls Schematics**
- **Instrument Cluster Schematics**

Connector End View Reference

Component Connector End Views

Electrical Information Reference

- **Circuit Testing**
- **Connector Repairs**
- **Testing for Intermittent Conditions and Poor Connections**
- **Wiring Repairs**

Scan Tool Reference

Control Module References for scan tool information

CIRCUIT/SYSTEM VERIFICATION

1. Ignition ON, command the MIL ON and OFF with a scan tool. The MIL should turn ON and OFF as commanded.
2. Ignition ON, observe the scan tool MIL Circuit Test Status parameters. Each of the MIL Circuit Test Status parameters should display OK or Not Run.
3. Operate the vehicle within the Conditions for Running the DTC to verify the DTC does not reset. You may also operate the vehicle within the conditions that you observed from the Freeze Frame/Failure Records data.

CIRCUIT/SYSTEM TESTING

1. If any other indicators are inoperative, refer to **Symptoms - Displays and Gauges** .
2. Ignition OFF, disconnect the ECM harness connector X1.
3. Ignition ON, the MIL should not illuminate.
 - If the MIL illuminates, test the MIL control circuit terminal 46-X1 for a short to ground. If the circuit tests normal, replace the bulb/IPC.
4. Ignition ON, connect a 3 A fused jumper wire between the MIL control circuit terminal 46-X1 and ground. The MIL should illuminate.
 - If the MIL does not illuminate, test the MIL control circuit for a short to voltage or an open/high resistance. If the circuit tests normal, replace the bulb/ IPC.
5. If all circuits test normal, replace the ECM.

REPAIR PROCEDURES

Perform the **Diagnostic Repair Verification** after completing the diagnostic procedure.

- **Instrument Cluster Replacement (Equinox)** or **Instrument Cluster Replacement (Terrain)**
- **Control Module References** for replacement, setup, and programming

SERVICE BAY TEST

DIAGNOSTIC INSTRUCTIONS

- Perform the **Diagnostic System Check - Vehicle** prior to using this diagnostic procedure.
- Review **Strategy Based Diagnosis** for an overview of the diagnostic approach.
- **Diagnostic Procedure Instructions** provides an overview of each diagnostic category.

DESCRIPTION

The purpose of the evaporative emission (EVAP) Service Bay Test is to aid in resetting the EVAP inspection/maintenance system status. For this vehicle that is equipped with the engine off natural vacuum diagnostic, the Service Bay Test uses the scan tool to initiate the engine control module (ECM) regular sequence of EVAP system DTC tests, but with different enable criteria. By using the Service Bay Test the inspection/maintenance indicator can be set without the need for multiple cold soaks.

The scan tool displays for the Service Bay Test are based on the events that occur within the following three categories:

- The engine running portion of the tests-The vehicle must remain at rest, in Park, or in Neutral, during this portion of the test. This test inspects for large leaks, a leaking purge valve and/or vent system restrictions. The scan tool will display test progress or the reason for an abort or failure.
- Drive cycle-The scan tool will display time and distance needed to warm the fuel.
- Ignition OFF-During this portion of the test, the engine controller will remain active for up to 45 minutes when the ignition is turned OFF to allow control of the EVAP canister vent valve and run the engine off natural vacuum test. The engine controller inspects for small leaks during this period by monitoring fuel tank pressure or vacuum. If the system is sealed, there will be a pressure or vacuum change. Pressure or vacuum changes that are less than the calibrated values indicate a leak.

When the EVAP diagnostics are initiated by the Service Bay Test, the scan tool will indicate if the enable conditions listed below are not met, or will display a specific reason if the test aborts. When complete, the display will indicate that the tests passed or failed.

CONDITIONS FOR RUNNING THE TEST

The following conditions must be met in order to enable the Service Bay Test:

- The battery voltage is between 11-18V.
- The engine coolant temperature (ECT) is less than 35°C (95°F) at start-up.
- The EVAP inspection/maintenance system status indicator is set to NO.
- The fuel level is 15-85 percent capacity and cannot be refueled during the tests.
- There are no DTCs displayed.
- The vehicle must be driven for the time and distance specified on the scan tool.
- The ambient air temperature is between 0-40°C (32-104°F).
- The ignition must remain OFF during the engine OFF portion of the test, and the vehicle must remain at rest.

TEST PROCEDURE

NOTE: If the Service Bay Test aborts or fails, a DTC will NOT be set.

1. Install a scan tool.
2. Select the Service Bay Test with the scan tool.

WARNING: Refer to Road Test Warning .

3. Follow the instructions on the scan tool.
 - If the test aborts, correct the condition for running the test, then retest.

- If the test fails, repair the vehicle for the condition indicated by the failure message on the scan tool.
4. Verify that the EVAP inspection/maintenance system status is set to YES.

ENGINE CRANKS BUT DOES NOT RUN

DIAGNOSTIC INSTRUCTIONS

- Perform the **Diagnostic System Check - Vehicle** prior to using this diagnostic procedure.
- Review **Strategy Based Diagnosis** for an overview of the diagnostic approach.
- **Diagnostic Procedure Instructions** provides an overview of each diagnostic category.

CIRCUIT/SYSTEM DESCRIPTION

This Engine Cranks but Does Not Run diagnostic is an organized approach to identify a condition which causes the engine to crank but not start. This diagnostic directs the technician to the appropriate system diagnosis.

DIAGNOSTIC AIDS

Inspect for any of the following conditions:

- The Immobilizer system is not designed to have the key FOB folded 90 degrees when attempting to start the engine. This may cause an intermittent no start condition. If you receive a customer complaint of an intermittent no start condition, verify that the customer is not folding the key while attempting to start the engine. The fob must be parallel to the key to function properly.
- The engine control module (ECM) uses the camshaft position sensors to determine engine speed and position when there is a crankshaft position sensor condition.
- The engine will operate with a crankshaft position sensor condition only if the ECM has stored the learned reference position of the camshafts in memory. With a crankshaft position sensor condition in the signal circuit, the engine will go into a limp home mode after a hard restart. The ECM then calculates engine speed from one of the camshaft position sensors.
- The fuel pump flow control module controls and monitors the operation of the in-tank fuel pump. If the fuel pump flow control module detects a fault, a DTC sets in the fuel pump flow control module. The fuel pump flow control module will then send a serial data message to the engine control module (ECM) requesting the illumination of the malfunction indicator lamp (MIL).
- Insufficient fuel can cause a no start condition. Thoroughly inspect the fuel delivery system for sufficient fuel volume to the fuel injectors. Inspect the fuel supply components for partial blockage or restrictions.
- Fuel injectors with partially blocked and restricted nozzles, or a malfunctioning solenoid, can cause a no start condition. Refer to **Fuel Injector Solenoid Coil Test**.
- There may be fuel spray at the fuel injectors and the indicated fuel pressure may be correct, yet there may not be enough fuel to start the engine. If the fuel injectors and the injector circuit are OK, and fuel spray is detected, the fuel injector ON time may be inadequate. If the engine control module (ECM) receives incorrect inputs from the various information sensors, the fuel delivered by the fuel injectors may be inadequate to start the engine. Check all the engine data parameters with a scan tool and compare the values indicated with the expected values or the values from a known good vehicle.

- Inspect the engine for good secure electrical grounds.
- Water or foreign material in the fuel can cause a no start or engine will not stay running condition. During freezing weather water can freeze inside the fuel system. The engine may start after 30 min in a heated repair shop. The malfunction may not recur until parked overnight in freezing temperatures. Extreme weather conditions can cause contaminated fuel to prevent the vehicle from starting.
- A vehicle that starts and runs after being brought to the repair shop for a no start condition, may have an ignition system that is susceptible to moisture. Spray water on the ignition system components and the wiring in order to check for an engine starting or will not stay running concern.

REFERENCE INFORMATION

Schematic Reference

Engine Controls Schematics

Connector End View Reference

Component Connector End Views

Electrical Information Reference

- Circuit Testing
- Connector Repairs
- Testing for Intermittent Conditions and Poor Connections
- Wiring Repairs

DTC Type Reference

Powertrain Diagnostic Trouble Code (DTC) Type Definitions

Scan Tool Reference

Control Module References for scan tool information

Special Tools

- **CH 48027 or EN-49495:** Digital Pressure Gauge
- **EL 26792:** Spark Tester
- For equivalent regional tools, refer to Special Tools .

CIRCUIT/SYSTEM VERIFICATION

NOTE: This diagnostic assumes the following:

- The battery is completely charged. Refer to Battery Inspection/Test .

- The engine cranking speed is acceptable. Refer to Engine Cranks Slowly .
- There is adequate fuel in the fuel tank.

1. Attempt to start the engine. Observe the DTC information with a scan tool. Verify that DTC P0116, P0118, P0335, P0336, P0513, P0601, P0602, P0603-P0606, P062B, P0627, P0628, P0629, P0633, P069E, P1631, P1649, or U0109 does not set.
 - If any of the listed DTCs are set, refer to Diagnostic Trouble Code (DTC) List - Vehicle .
2. Ignition ON, observe the Theft Deterrent parameter with a scan tool. The parameter should display Disabled.
 - If Enabled is displayed, refer to Diagnostic Trouble Code (DTC) List - Vehicle .

NOTE: **A MAF sensor circuit condition may cause an Engine Cranks But Does Not Run condition without setting a DTC.**

3. Engine cranking, observe the scan tool Mass Airflow Sensor parameter. The parameter should display greater than 0 Hz.
 - If the parameter is not the specified value, refer to DTC P0102 or P0103 for further diagnosis.
4. Test the ignition system for spark. Refer to Electronic Ignition System Diagnosis.
5. Ignition ON, command the fuel pump ON with a scan tool. You should hear the fuel pump turn ON.
 - If the fuel pump does not turn ON, refer to Fuel System Diagnosis.
6. Ignition OFF, install the **CH 48027**: Digital Pressure Gauge.

NOTE:

- The fuel pump may need to be commanded ON a few times, in order to obtain the highest possible fuel pressure.
- DO NOT start the engine for this test.

7. Ignition ON, command an increase in the fuel line pressure with a scan tool. The fuel line pressure should increase to greater than 410 kPa (60 psi) as commanded.
 - If the fuel pressure is not within range, refer to Fuel System Diagnosis.
8. Verify that the following conditions do not exist:
 - Collapsed air intake duct to the throttle body
 - Restricted air filter element
 - Spark plugs for being gas or coolant fouled
 - A skewed engine coolant temperature (ECT) sensor-Refer to Temperature Versus Resistance .
 - Exhaust system restricted-Refer to Restricted Exhaust .
 - Fuel contamination-Refer to Alcohol/Contaminants-in-Fuel Diagnosis.
 - Engine mechanical condition, for example, worn timing chain and gears, low compression-Refer to Symptoms - Engine Mechanical .
 - If you find any of the above conditions, repair as necessary.

Perform the **Diagnostic Repair Verification** after completing the diagnostic procedure.

FUEL PUMP ELECTRICAL CIRCUIT DIAGNOSIS

DIAGNOSTIC INSTRUCTIONS

- Perform the **Diagnostic System Check - Vehicle** prior to using this diagnostic procedure.
- Review **Strategy Based Diagnosis** for an overview of the diagnostic approach.
- **Diagnostic Procedure Instructions** provide an overview of each diagnostic category.

DIAGNOSTIC FAULT INFORMATION

Circuit	Short to Ground	Open or High Resistance	Short to Voltage	Signal Performance
Fuel Pump High Signal	P0231	P023F	P0232	P023F, P2635
Fuel Pump Low Signal	-	P023F	-	P023F, P2635

CIRCUIT/SYSTEM DESCRIPTION

The engine control module (ECM) supplies voltage to the fuel pump control module when the ECM detects that the ignition is on. The voltage from the ECM to the fuel pump control module remains active for two seconds, unless the engine is in crank or run. While this voltage is being received, the fuel pump control module closes the ground switch of the fuel pump and also supplies a varying voltage to the fuel tank pump module in order to maintain the desired fuel rail pressure.

REFERENCE INFORMATION

Schematic Reference

Engine Controls Schematics

Connector End View Reference

Component Connector End Views

Description and Operation

Fuel System Description

Electrical Information Reference

- **Circuit Testing**
- **Connector Repairs**
- **Testing for Intermittent Conditions and Poor Connections**
- **Wiring Repairs**

DTC Type Reference

Powertrain Diagnostic Trouble Code (DTC) Type Definitions

Scan Tool Reference

Control Module References for scan tool information

CIRCUIT/SYSTEM VERIFICATION

Ignition ON, command the fuel pump ON and OFF using the scan tool ECM output control. The fuel pump should turn on and off.

CIRCUIT/SYSTEM TESTING

1. Ignition OFF, disconnect the harness connector at the G12 fuel pump.
2. Connect a test lamp between the control circuit terminal 1 and ground.
3. Ignition ON, command the G12 fuel pump ON and OFF using a scan tool ECM fuel pump output control. The test lamp should turn ON and OFF, as commanded.
 - If the test lamp is always ON, test the control circuit for a short to voltage. If the circuit tests normal, replace the K27 fuel pump control module.
 - If the test lamp is always OFF, test the control circuit for a short to ground or an open/high resistance. If the circuit tests normal, replace the K27 fuel pump control module.
4. Ignition OFF, connect a test lamp between the control circuit terminal 1 and the low reference circuit terminal 2.
5. Ignition ON, command the G12 fuel pump ON using a scan tool. The test lamp should illuminate.
 - If the test lamp does not illuminate, test the low reference circuit terminal 1 for a short to voltage or an open/high resistance. If the circuit tests normal, replace the K27 fuel pump control module.
6. If all circuits test normal, replace the G12 fuel pump.

REPAIR PROCEDURES

Perform the Diagnostic Repair Verification after completing the diagnostic procedure.

Control Module References for fuel pump control module replacement, setup, and programming

FUEL SYSTEM DIAGNOSIS

DIAGNOSTIC INSTRUCTIONS

- Perform the Diagnostic System Check - Vehicle prior to using this diagnostic procedure.
- Review Strategy Based Diagnosis for an overview of the diagnostic approach.
- Diagnostic Procedure Instructions provides an overview of each diagnostic category.

CIRCUIT/SYSTEM DESCRIPTION

The engine control module (ECM) supplies voltage to the fuel pump control module when the ECM detects that the ignition is ON. The voltage from the ECM to the fuel pump control module remains active for 2 s, unless the engine is in Crank or Run. While this voltage is being received, the fuel pump control module closes the ground switch of the fuel pump and also supplies a varying voltage to the fuel tank module in order to maintain the desired fuel rail pressure.

The fuel system is an electronic returnless on-demand design. A returnless fuel system reduces the internal temperature of the fuel tank by not returning hot fuel from the engine to the fuel tank. Reducing the internal temperature of the fuel tank results in lower evaporative emissions.

An electric turbine style fuel pump attaches to the primary fuel pump module inside the fuel tank. The fuel pump supplies fuel through the fuel feed pipe to the high pressure fuel pump. The high pressure fuel pump supplies fuel to a variable-pressure fuel rail. Fuel enters the combustion chamber through precision multi-hole fuel injectors. The high pressure fuel pump, fuel rail pressure, fuel injection timing, and injection duration are controlled by the engine control module (ECM).

The primary fuel tank module also contains a primary jet pump and a secondary jet pump. Fuel pump flow loss, caused by vapor expulsion in the pump inlet chamber, is diverted to the primary jet pump and the secondary jet pump through a restrictive orifice located on the pump cover. The primary jet pump fills the reservoir of the primary fuel tank module. The secondary jet pump creates a venturi action which causes the fuel to be drawn from the secondary side of the fuel tank, through the fuel transfer pipe, to the primary side of the fuel tank.

REFERENCE INFORMATION

Description and Operation

Fuel System Description

Electrical Information Reference

- **Circuit Testing**
- **Connector Repairs**
- **Testing for Intermittent Conditions and Poor Connections**
- **Wiring Repairs**

Scan Tool Reference

Control Module References for scan tool information

Special Tools

- **CH 48027:** Digital Pressure Gauge
- **J 37287:** Fuel Line Shut-off Adapter

CIRCUIT/SYSTEM VERIFICATION

NOTE:

- Repair all fuel system related DTCs before performing this diagnostic.
- Inspect the fuel system for damage or external leaks before proceeding.
- Verify that adequate fuel is in the fuel tank before proceeding.
- The Fuel Pump Enable may need to be commanded ON a few times in order to obtain the highest possible fuel pressure.
- Before proceeding with this test review the User Manual CH 48027-5 for Safety Information and Instructions.

1. Ignition OFF, all accessories OFF, install a **CH 48027: Gauge**. Refer to **Fuel Pressure Gauge Installation and Removal**.

NOTE: High fuel pressure readings may result due to hot soak fuel boiling. With the engine OFF, the fuel pressure may increase to the setting of the pressure relief regulator valve, approximately 580 kPa (84 psi).

2. Ignition ON, engine OFF, command the Fuel Pump Enable ON with a scan tool. Verify the fuel pressure is between 276-448 kPa (40-65 psi) and does not decrease more than 34 kPa (5 psi) in 1 min.
3. Engine idling at normal operating temperature, verify the scan tool Fuel Pump Control Module Fuel Pressure Sensor parameter is between 276-324 kPa (40-47 psi).

CIRCUIT/SYSTEM TESTING

NOTE:

- The Fuel Pump Enable may need to be commanded ON a few times in order to obtain the highest possible fuel pressure.
- DO NOT start the engine.
- High fuel pressure readings may result due to hot soak fuel boiling. With the engine OFF, the fuel pressure may increase to the setting of the pressure relief regulator valve, approximately 580 kPa (84 psi).

1. Ignition ON, engine OFF, command the Fuel Pump Enable ON with a scan tool and observe the fuel pressure gauge while the fuel pump is operating. Verify the fuel pressure is between 276-448 kPa (40-65 psi).
 - If the fuel pressure is less than the specified range, test, inspect, and repair the items listed below. If all items test normal, replace the primary fuel tank module.
 - Restricted fuel feed pipe
 - Inspect the harness connectors and the ground circuits of the fuel pump for poor connections.
2. Verify that the fuel pressure does not decrease more than 34 kPa (5 psi) in 1 min.
 - If the fuel pressure decreases more than the specified value, perform the following procedure:
 1. Ignition OFF, relieve the fuel pressure. Refer to **Fuel Pressure Relief**.
 2. Install the **J 37287: Adapter** between the chassis fuel feed hose and the engine compartment

fuel feed pipe.

3. Open the valve on the **J 37287: Adapter**.
4. Ignition ON, command the Fuel Pump Enable ON with a scan tool and bleed the air from the **CH 48027: Gauge**.
5. Command the Fuel Pump Enable ON and then OFF with a scan tool.
6. Close the valve on the **J 37287: Adapter**.
7. Monitor the fuel pressure for 1 min.
 - If the fuel pressure does not decrease more than 34 kPa (5 psi) within the specified time, replace the primary fuel tank module.
3. Relieve the fuel pressure to 69 kPa (10 psi). Verify that the fuel pressure does not decrease more than 14 kPa (2 psi) in 5 min.
 - If the fuel pressure decreases more than the specified value, replace the primary fuel tank module.
4. Operate the vehicle within the conditions of the customer's concern while monitoring the fuel pressure with the **CH 48027: Gauge**. The fuel pressure should not drop off during acceleration, cruise or hard cornering.
 - If the fuel pressure drops off, test, inspect, and repair the items listed below. If all items test normal, replace the primary fuel tank module.
 - Restricted fuel feed pipe
 - Inspect the harness connectors and the ground circuits of the fuel pump for poor connections
5. If the fuel system tests normal, refer to **Symptoms - Engine Controls**.

REPAIR PROCEDURES

Perform the **Diagnostic Repair Verification** after completing the diagnostic procedure.

- **Fuel Feed Pipe Replacement (LAF)**
- **Fuel Tank Fuel Pump Module Replacement**

FUEL INJECTOR SOLENOID COIL TEST

DIAGNOSTIC INSTRUCTIONS

- Perform the **Diagnostic System Check - Vehicle** prior to using this diagnostic procedure.
- Review **Strategy Based Diagnosis** for an overview of the diagnostic approach.
- **Diagnostic Procedure Instructions** provides an overview of each diagnostic category.

CIRCUIT/SYSTEM DESCRIPTION

The engine control module (ECM) supplies a separate high voltage supply circuit and a high voltage control circuit for each fuel injector. The injector high voltage supply circuit and the high voltage control circuit are both controlled by the ECM. The ECM energizes each fuel injector by grounding the control circuit. The ECM controls each fuel injector with 65 V. This is controlled by a boost capacitor in the ECM. During the 65 V boost phase, the capacitor is discharged through the injector high voltage supply circuit, allowing for initial injector

opening. The injector is then held open with 12 V. A fuel injector coil winding resistance that is too high or too low will affect the engine driveability. The fuel injector coil windings are affected by temperature. The resistance of the fuel injector coil windings will increase as the temperature of the fuel injector increases.

REFERENCE INFORMATION

Schematic Reference

Engine Controls Schematics

Electrical Information Reference

- Circuit Testing
- Connector Repairs
- Testing for Intermittent Conditions and Poor Connections
- Wiring Repairs

COMPONENT TESTING

NOTE:

- The resistance test must be performed at the fuel injector or mis-diagnosis will occur.
- The DMM and test leads must be calibrated to 0 ohms in order to prevent mis-diagnosis.

1. Remove the intake manifold and disconnect the appropriate Q17 fuel injector.
2. Test for 1.9-2.3 ohms at 20°C (68°F) between the high voltage supply circuit terminal 2 and the high voltage control circuit terminal 1 at the fuel injector.
 - If not within the specified range, replace the Q17 fuel injector.
3. Measure the resistance between each terminal at the Q17 fuel injector and the Q17 fuel injector housing/case. The DMM should display OL ohms.
 - If less than the specified value, replace the Q17 fuel injector.

REPAIR PROCEDURES

Perform the Diagnostic Repair Verification after completing the diagnostic procedure.

Direct Fuel Injector Replacement (LAF)

ALCOHOL/CONTAMINANTS-IN-FUEL DIAGNOSIS

DIAGNOSTIC INSTRUCTIONS

- Perform the Diagnostic System Check - Vehicle prior to using this diagnostic procedure.
- Review Strategy Based Diagnosis for an overview of the diagnostic approach.

- **Diagnostic Procedure Instructions** provides an overview of each diagnostic category.

TEST DESCRIPTION

Water contamination in the fuel system may cause driveability conditions such as hesitation, stalling, no start, or misfires in one or more cylinders. Water may collect near a single fuel injector at the lowest point in the fuel injection system and cause a misfire in that cylinder. If the fuel system is contaminated with water, inspect the fuel system components for rust or deterioration.

Ethanol concentrations of greater than 10 percent can cause driveability conditions and fuel system deterioration. Fuel with more than 10 percent ethanol could result in driveability conditions such as hesitation, lack of power, stalling, or no start. Excessive concentrations of ethanol used in vehicles not designed for it may cause fuel system corrosion, deterioration of rubber components, and fuel filter restriction.

REFERENCE INFORMATION

Special Tool

CH 44175-A: Fuel Composition Tester

For equivalent regional tools, refer to **Special Tools** .

SYSTEM VERIFICATION

The fuel sample should be drawn from the bottom of the tank so that any water present in the tank will be detected. The sample should be bright and clear.

- If the sample appears cloudy, or contaminated with water, as indicated by a water layer at the bottom of the sample, perform the Particulate Contaminants in Fuel Testing Procedure.
- If alcohol contamination is suspected, perform the Alcohol in Fuel Testing procedure.

ALCOHOL IN FUEL TESTING WITH SPECIAL TOOL

1. Test the fuel composition using the **CH 44175-A:** Fuel Composition Tester and the Instruction Manual.
2. If water appears in the fuel sample, clean the fuel system.
3. Subtract 50 from the reading on the DMM in order to obtain the percentage of alcohol in the fuel sample.
4. If the fuel sample contains more than 15 percent ethanol, add fresh, regular gasoline to the vehicle's fuel tank.
5. Test the fuel composition.
6. If testing shows the ethanol percentage is still more than 15 percent, replace the fuel in the vehicle.

ALCOHOL IN FUEL TESTING WITHOUT SPECIAL TOOL

1. Using a 100 ml (3.38 oz) specified cylinder with 1 ml (0.034 oz) graduation marks, fill the cylinder with fuel to the 90 ml (3.04 oz) mark.

2. Add 10 ml (0.34 oz) of water in order to bring the total fluid volume to 100 ml (3.38 oz) and install a stopper.
3. Shake the cylinder vigorously for 10-15 seconds.
4. Carefully loosen the stopper in order to release the pressure.
5. Re-install the stopper and shake the cylinder vigorously again for 10-15 seconds.
6. Put the cylinder on a level surface for approximately 5 minutes in order to allow adequate liquid separation. If alcohol is present in the fuel, the volume of the lower layer, which would now contain both alcohol and water, will be more than 10 ml (0.34 oz). For example, if the volume of the lower layer is increased to 15 ml (0.51 oz), this indicates at least 5 percent alcohol in the fuel. The actual amount of alcohol may be somewhat more because this procedure does not extract all of the alcohol from the fuel.

PARTICULATE CONTAMINANTS IN FUEL TESTING PROCEDURE

1. Using an approved fuel container, draw approximately 0.5 liter (0.53 qt) of fuel.
2. Place the container on a level surface for approximately 5 minutes in order to allow settling of the particulate contamination. Particulate contamination will show up in various shapes and colors. Sand will typically be identified by a white or light brown crystals. Rubber will appear as black and irregular particles.
3. Observe the fuel sample. If any physical contaminants or water are present, clean the fuel system.

REPAIR PROCEDURES

Perform the **Diagnostic Repair Verification** after completing the diagnostic procedure.

Fuel System Cleaning

ELECTRONIC IGNITION SYSTEM DIAGNOSIS

DIAGNOSTIC INSTRUCTIONS

- Perform the **Diagnostic System Check - Vehicle** prior to using this diagnostic procedure.
- Review **Strategy Based Diagnosis** for an overview of the diagnostic approach.
- **Diagnostic Procedure Instructions** provide an overview of each diagnostic category.

CIRCUIT/SYSTEM DESCRIPTION

The ignition system uses individual ignition coil/module assemblies for each cylinder. The engine control module (ECM) controls the individual coils by transmitting timing pulses on the ignition control circuit of each ignition coil/module to enable a spark event.

DIAGNOSTIC AIDS

- Depending on location in the spliced ignition voltage circuit, a slight resistance can cause a misfire or a crank/no start concern. A voltage drop test will pinpoint this condition.
- A slight to moderate resistance on any ignition control circuit can cause a misfire before DTC P0351-

P0354 sets.

- Extended engine cranking time, may foul the spark plugs with excessive fuel.

REFERENCE INFORMATION

Schematic Reference

Engine Controls Schematics

Connector End View Reference

Component Connector End Views

Electrical Information Reference

- **Circuit Testing**
- **Connector Repairs**
- **Testing for Intermittent Conditions and Poor Connections**
- **Wiring Repairs**

Scan Tool Reference

Control Module References for scan tool information

Special Tools

J 26792: HEI Spark Tester

CIRCUIT/SYSTEM TESTING

1. Ignition OFF, disconnect the harness connector at the affected T8 ignition coil/modules.
2. Ignition OFF, all vehicle systems OFF. This may take up to 2 minutes. Test for less than 5 ohms between the ground circuit terminal A/1 and ground.
 - If greater than the specified range, test the ground circuit for an open/high resistance.
3. Test for less than 5 ohms between the low reference circuit terminal B/2 and ground.
 - If greater than the specified range, test the low reference circuit for an open/high resistance. If the circuit tests normal, replace the K20 ECM.
4. Ignition ON, verify that a test lamp illuminates between the ignition circuit terminal D/4 and ground.
 - If the test lamp does not illuminate, test the ignition circuit for a short to ground or an open/high resistance.
5. Exchange the affected T8 ignition coil/module with the T8 ignition coil/module of a good cylinder.
6. Start the engine, and observe the scan tool Misfire Current Cylinder parameters.
 - If the misfire transfers with the suspect T8 ignition coil/module, replace as needed.
7. If the circuits test normal, test or replace the spark plug/s.

COMPONENT TESTING

Use the **J 26792**: Spark Tester to verify the output of each ignition coil/module.

REPAIR PROCEDURES

Perform the **Diagnostic Repair Verification** after completing the diagnostic procedure.

- **Ignition Coil Replacement**
- **Spark Plug Replacement**

EVAPORATIVE EMISSION SYSTEM DIAGNOSIS

OPERATING INSTRUCTIONS FOR THE EVAPORATIVE EMISSION SYSTEM TESTER (EEST)

Vehicle Setup

NOTE: A large difference between the vehicle temperature and shop temperature will seriously affect the accuracy of the tests. Always allow enough time, at least 15 minutes, for the vehicle temperature to adjust to the shop temperature. Refer to Temperature Variation Instructions for more information about vehicle versus shop temperatures.

1. Engine OFF, open the hood. Position a large fan to blow air under the vehicle onto the fuel tank area.
2. Connect the red battery clip from the tester to the positive battery terminal.

NOTE: The vehicle battery must be fully charged for optimum tester performance.

3. Connect the black battery clip from the tester to chassis ground.

FLOWMETER TEST - LEAK DETECTION

1. Open the Nitrogen tank valve and turn the NITROGEN/SMOKE valve on the front control panel to NITROGEN.
2. Connect the hose to the correct test orifice on the bottom front of the tester. For orifice size, refer to the GM Service manual for the vehicle being tested. The vehicle specific information can be found in service procedures for DTCs that relate to evaporative emission (EVAP) system leaks.
3. Press and release the remote switch to activate the tester.
4. Position the sliding red flag on the flowmeter to align with the floating indicator. When the red flag is set, press and release the remote switch to deactivate the tester.
5. Remove the hose from the test orifice and install the hose onto the vehicle. For proper connection location, and the special tool numbers for any adapters that may be required, refer to the service procedures for DTCs that relate to EVAP system leaks.
6. Ignition ON, seal the EVAP system per instructions in the service procedures for DTCs that relate to EVAP system leaks. Most systems can be sealed using a scan tool output control for the EVAP canister

vent solenoid valve, other systems require that the vent system be plugged.

NOTE:

- **Larger volume fuel tanks, and/or those with lower fuel levels, may require several minutes to fill with nitrogen.**
- **Static buildup may cause the float indicator to stick. It may be necessary to tap on the flowmeter to free up the float.**

7. Press and release the remote switch to activate the nitrogen flow and fill the system.
8. Compare the stable floating indicator position to the red flag.
 - ABOVE the red flag, the result is UNACCEPTABLE, FAIL-Go to Smoke Procedure
 - BELOW the red flag, the result is ACCEPTABLE, PASS-Test complete
9. Press and release the remote switch to deactivate the tester.

SMOKE PROCEDURE - LOCATE THE LEAK

NOTE:

It is not recommended to use the tester in an outside repair bay area because wind and sunlight may affect temperature and your ability to see the smoke.

1. Turn OFF any fans that may cause air movement around or near the vehicle.

NOTE:

Completely unwind the nitrogen/smoke hose from the bracket to optimize the tester's performance.

2. Connect the nitrogen/smoke hose to the vehicle as directed in the service procedures. Some vehicles require that the nitrogen/smoke hose be connected at the front of the EVAP system at the EVAP service port. An adapter may be necessary. Other vehicles require the connection be made at the rear of the system using an adapter at the fuel fill cap. Consult the service procedures for DTCs that relate to evaporative emission (EVAP) system leaks for vehicle specific instructions regarding connection location and adapters.
3. Open the nitrogen tank valve and turn the NITROGEN/SMOKE valve on the control panel to SMOKE.

NOTE:

The remote switch operates in a push ON, push OFF fashion.

4. Press and release the remote switch to activate the tester and inject smoke into the EVAP system.
5. Verify smoke has filled the EVAP system by opening the system opposite the end where smoke is injected. When injecting smoke at the service port, remove the fuel fill cap, or temporarily leave the EVAP canister vent valve open, until smoke is observed. Then close the system and continue testing. If using a special tool fuel fill cap adapter at the filler neck, vent the system at the service port until smoke is observed then close the system to continue with the test.

NOTE:

Inject smoke in less than 2-minute cycles for optimum tester performance.

6. Press and release the remote switch to deactivate the tester.

NOTE: For optimum visual smoke performance, deactivate the smoke flow and allow the system pressure to drop. Allowing the smoke to exit small holes at a low flow rate greatly enhances visibility.

7. Introduce smoke into the system for an additional 60 seconds. Continue introducing smoke at 15-second intervals, as necessary.
8. Using the a high-intensity white light, inspect the entire EVAP system path, and look for the source of the leak indicated by the exiting smoke. Introduce smoke at 15-second intervals, as needed, until leak source is identified.

TEMPERATURE VARIATION INSTRUCTIONS

The Concern

Ideal circumstances for conducting the EVAP Flowmeter Test require equal temperatures between the nitrogen gas and the vehicle EVAP system. Significant differences in temperature between them can result in a flow or pressure change during testing, causing misleading results. Typically, the Evaporative Emissions System Tester is stored indoors, approximately 21°C (70°F). Vehicles brought in for diagnosis may have an EVAP system at significantly different temperatures -40 to +43°C (-40 to +110°F).

For Example

NOTE: With no temperature difference between the nitrogen gas and EVAP system, the resulting vehicle EVAP system pressure will remain stable at 13 inches H2O once pressurized, providing no leaks are present.

When the EVAP Flowmeter Tests are performed with significant differences in temperature between the nitrogen gas and the vehicle EVAP system, the following results can occur:

- An increase in flow during the flowmeter test can be caused by a vehicle's warm EVAP system cooling down.
- A decrease in flow during the flowmeter test can be caused by a vehicle's cool EVAP system warming up.

The Solution

When working on a vehicle with significant temperature differences between the vehicle EVAP system and the nitrogen gas, allow the vehicle EVAP system temperature to stabilize as close as possible to the temperature of the nitrogen gas before conducting the Flowmeter Test.

INSPECTION/MAINTENANCE SYSTEM CHECK

DIAGNOSTIC INSTRUCTIONS

- Perform the **Diagnostic System Check - Vehicle** prior to using this diagnostic procedure.
- Review **Strategy Based Diagnosis** for an overview of the diagnostic approach.
- **Diagnostic Procedure Instructions** provides an overview of each diagnostic category.

DESCRIPTION

Several states require that a vehicle pass on-board diagnostic (OBD) system tests and the inspection/maintenance (I/M) emission inspection in order to renew license plates. This is accomplished by viewing the I/M System Status display on a scan tool. Using a scan tool, the technician can observe the I/M System Status in order to verify that the vehicle meets the criteria that complies with the local area requirements. While testing in the I/M System Status mode, some DTCs may occur that are called I/M Test DTCs. An I/M Test DTC is defined as a fault code that is currently commanding the MIL ON, and is stored in non-volatile memory. The intended use of this data is to prevent vehicles from passing I/M inspection without proper repair to the vehicle. These fault codes are not erasable from any scan tool command or erasable by disconnecting power to the controller. The I/M Test DTCs will be supported by all emissions related ECUs such as ECMs, TCMs, FPCMs, etc. An I/M Test DTC will not be stored or erased from the ECU except at the end of trip processing which occurs 5 s after ignition OFF.

CONDITIONS FOR UPDATING THE I/M SYSTEM STATUS

Each system requires at least one, and sometimes several, diagnostic tests. The results of these tests are reported by a diagnostic trouble code (DTC). A system monitor is complete when either all of the DTCs comprising the monitor have Run and Passed, or any one of the DTCs comprising the monitor have illuminated the malfunction indicator lamp (MIL). Once all of the tests are completed, the I/M System Status display will indicate YES in the Completed column.

For example, when the HO2S Heater Monitor indicates YES, either all of the oxygen sensor heater tests have passed or one of the tests has illuminated the MIL. If the vehicle has four heated oxygen sensors, either all four heater circuit tests have passed or one of the heater circuit tests has illuminated the MIL. The I/M System Status will indicate NO under the Completed column when any of the required tests for that system have not run. The following is a list of conditions that would set the I/M System Status indicator to NO:

- The vehicle is new from the factory and has not yet been driven through the necessary drive conditions to complete the tests.
- The battery has been disconnected or discharged below operating voltage.
- The control module power or ground has been interrupted.
- The control module has been reprogrammed.
- The control module DTCs have been cleared as part of a service procedure.

CONDITIONS FOR CLEARING I/M TEST DTCs

1. Only the OBD II System can erase the I/M Test DTC. The OBD II system must determine that the malfunction that caused the I/M Test DTC to be stored is no longer present and is not commanding the MIL. Each of the following represents ways to clear an I/M Test DTC:
 - If the MIL goes out due to 3 passing drive cycles, scan tool code clear is not used, the I/M Test DTC is erased at power down of the last drive cycle.
 - If a scan tool code clear is used to turn OFF the MIL, the I/M Test DTC is not erased, the DTC must PASS and not FAIL. The I/M Test DTC is erased at power down of the drive cycle.
 - If the controller is reflashed/reprogrammed, all I/M Test DTCs are erased.
2. For the OBD II System to run a single drive cycle for clearing an I/M Test DTC, all of the following

conditions must occur:

- Cumulative time of engine run time is greater than 600 s.
- Cumulative vehicle operation above 40 km/h (25 mph) for over 300 s.
- Continuous vehicle idle for greater than 30 s.
- Turn ignition OFF for 5 s and allow the code to clear.

MONITORED EMISSION CONTROL SYSTEMS

The OBD II system monitors all emission control systems that are on-board. Not all vehicles need every possible emission control system. For example, a vehicle may not be equipped with secondary air injection (AIR) or exhaust gas recirculation (EGR). The OBD II regulations require monitoring of the following; if equipped:

- The air conditioning system
- The catalytic converter efficiency
- Comprehensive component monitoring-Emission related inputs and outputs
- The evaporative emission (EVAP) system
- The fuel delivery system
- Heated catalyst monitoring
- Misfire monitoring
- The oxygen sensor system (O2S or HO2S)
- The oxygen sensor heater system (HO2S heater)

For the specific DTCs required for each system, refer to **Inspection/Maintenance System DTC Table**. Systems such as misfire and comprehensive components may not be listed in a system status list. These tests run continuously and do not require an I/M System Status indicator.

DIAGNOSTIC AIDS

The I/M System Status display provides an indication of when the control module has completed the required tests. This does not necessarily mean that the test has passed, only that a decision was made. If the diagnostic fails, a DTC will indicate the failure. If a failure indication is present for a DTC associated with one of the I/M regulated systems, it may prevent other required tests from running. For example, a DTC for the control circuit of the EVAP purge solenoid may not be listed in the Inspection/Maintenance System DTC Table because it is a continuous test. If this DTC is set, the Active Tests for the EVAP system may not run.

The I/M System Status information may be useful for a technician to determine if diagnostics have run when verifying repairs.

CIRCUIT/SYSTEM VERIFICATION

Review the I/M System Status indicators. All I/M System Status indicators should report YES, and no I/M Test DTCs should be present.

CIRCUIT/SYSTEM TESTING

NOTE: Many DTC related repairs will instruct the technician to clear the DTC information. Clearing the DTC will reset the I/M System Status indicators to NO. Performing the I/M Complete System Set Procedure will set each of the I/M System Status indicators to YES.

1. Observe the Engine DTC information with a scan tool. Verify no DTCs are present.
 - If a DTC is set that would prevent the I/M System Status tests from completing, diagnose that DTC before continuing. Refer to **Diagnostic Trouble Code (DTC) List - Vehicle**.
2. Review applicable service bulletins for software updates that would prevent the I/M System Status tests from completing.
 - If a control module re-program or other repair is required, perform the **Inspection/Maintenance Complete System Set Procedure**.
3. Observe the I/M System Status indicators.
 - If any I/M System Status indicators report NO, perform the **Inspection/Maintenance Complete System Set Procedure**.
4. Observe the I/M Test DTC information with a scan tool. Verify there are no I/M Test DTCs present.
 - If an I/M Test DTC is set and all of the I/M System Status indicators are Yes, there is no need to perform the Complete System Set Procedure. Diagnose the DTC using the **Diagnostic Trouble Code (DTC) List - Vehicle** and refer to Conditions for Clearing the I/M Test DTCs.
 - If an I/M Test DTC is set and the I/M System Status indicators are NO, diagnosis the DTC and perform the **Inspection/Maintenance Complete System Set Procedure**.

INSPECTION/MAINTENANCE COMPLETE SYSTEM SET PROCEDURE

DIAGNOSTIC INSTRUCTIONS

- Perform the **Diagnostic System Check - Vehicle** prior to using this diagnostic procedure.
- Review **Strategy Based Diagnosis** for an overview of the diagnostic approach.
- **Diagnostic Procedure Instructions** provides an overview of each diagnostic category.

DESCRIPTION

The purpose of the Inspection/Maintenance Complete System Set Procedure is to satisfy the enable criteria necessary to execute all of the I/M readiness diagnostics and complete the drive cycles for those particular diagnostics. When all I/M monitored diagnostic tests are completed, the I/M System Status indicators are set to YES. Perform the Inspection/Maintenance Complete System Set Procedure if any I/M System Status indicators are set to NO.

Inspection/Maintenance Data List

To determine if the inspection/maintenance readiness diagnostic tests can be run this ignition cycle, use a scan tool to observe the inspection/maintenance monitor enabled parameters in the inspection/maintenance Data List.

CONDITIONS FOR MEETING A COLD START

- The ignition voltage between 11-18 V.
- The barometric pressure is more than 75 kPa (10.9 psi).
- The start-up engine coolant temperature is between 4-30°C (39-86°F).
- The start-up intake air temperature is between 4-30°C (39-86°F).
- The difference between the IAT and the ECT is less than or equal to 6°C (43°F).
- The ambient air temperature is between 4-30°C (39-86°F).
- The fuel level is between 15-85 %.

CIRCUIT/SYSTEM VERIFICATION

Review the inspection/maintenance system status indicators with a scan tool. All I/M system status indicators should report YES, and no I/M Test DTCs should be present.

INSPECTION/MAINTENANCE SYSTEM SET PROCEDURE

NOTE: Whenever the ignition is turned ON, ignition positive voltage is supplied to the heated oxygen sensor (HO2S) heaters. After verifying the enable criteria, turn OFF the ignition for approximately 5 min to allow the sensors to cool before continuing with the test. When the engine is started, DO NOT turn the engine OFF for the remaining portion of the set procedure.

1. Ensure that the vehicle meets the conditions for a cold start listed above.
2. The evaporative emission inspection/maintenance system status indicator should display YES.
 - If the inspection/maintenance system status indicator displays NO, perform the Service Bay Test, if applicable. If the Service Bay Test is NOT available, it may take up to 6 drive cycles, with up to 17 h between drive cycles, for the inspection/maintenance system status indicator to transition to YES.
3. The O2S Heater inspection/maintenance system status indicator should display YES.
 - If the O2S Heater inspection/maintenance system status indicator displays NO, ensure that the ignition has been turned OFF for at least 10 h.
4. Turn OFF all accessories; HVAC system, other electrical loads, including aftermarket/add-on equipment, etc.
5. Set the vehicle parking brake and ensure the vehicle is in Park for automatic transmission or Neutral for manual transmission.
6. Turn OFF all accessories; HVAC system, other electrical loads, including aftermarket/add-on equipment, etc.
7. Start and idle the engine for at least 2 min and until 65°C (149°F) is achieved.
8. Run the engine for 6.5 min within the following conditions:
 - MAF parameter between 4-30 g/s
 - Engine speed steady between 1,000-3,000 RPM
9. Return the engine to idle for 1 minute.

10. Apply and hold the brake pedal, and shift to Drive for automatic transmission, or apply the clutch pedal for manual transmission and operate the vehicle within the following conditions for 2 min:
 - Depress the accelerator pedal until throttle position sensor angle is more than 2 %.
 - Mass air flow signal between 15-30 g/s
 - RPM steady between 1,200-2,000 RPM

NOTE: **DO NOT touch the accelerator pedal during the idle period. A change in throttle position sensor angle or an increase in engine speed may invalidate this portion of the test.**

11. Release the accelerator pedal and shift the vehicle to Park for automatic transmission, or Neutral and release the clutch pedal for manual transmission, and allow the engine to idle for 2 min.
12. Quickly depress the accelerator pedal until throttle position sensor angle is more than 8 % and return to idle, repeat 3 times.
13. Allow engine to idle for at least 2 min.

WARNING: Refer to Road Test Warning .

14. Release the parking brake and drive vehicle at 24 km/h (15 mph) or slower for 2 min.
15. Continue to drive the vehicle for at least 5.5 mi between 45-112 km/h (28-70 mph) with the vehicle reaching at least 80 km/h (50 mph).
16. Release the accelerator pedal for at least 2 s. This will allow the vehicle to enter decel fuel cut-off.
17. Depress the accelerator pedal until the throttle position sensor angle is increased 3-20 % and maintain a safe speed for 1 min.
18. Safely stop the vehicle, with the engine in Drive for automatic transmission or in Neutral with the clutch pedal depressed and parking brake applied for manual transmission, idle for 2 min.
19. Shift to Park for automatic and apply the parking brake, or neutral and release clutch pedal for manual.

NOTE: **DO NOT disturb the vehicle or turn ON the ignition until told to do so. Disturbing the vehicle may invalidate this portion of the test.**

20. Turn OFF the ignition and exit the vehicle. Do NOT disturb the vehicle for 60 min.
21. Observe the Inspection/Maintenance System Status with a scan tool. All of the Inspection/Maintenance System Status indicators should display YES.
 - If the evaporative emission Inspection/Maintenance System Status indicator displays NO, turn OFF the ignition for 17 h, ensure that the vehicle meets the conditions for a cold start, and repeat steps 12-18 six more times, or until the evaporative emission Inspection/Maintenance System Status indicator transitions to YES. If the indicator continues to display NO, refer to the **Inspection/Maintenance System DTC Table** to identify the DTCs that did not run. Follow the Conditions for Running the DTC in order to set the evaporative emission Inspection/Maintenance System Status indicator
 - If any of the Inspection/Maintenance System Status display NO, refer to the

Inspection/Maintenance System DTC Table for the indicator which did not display YES. The Inspection/Maintenance System DTC Table identifies the DTCs associated with each Inspection/Maintenance System Status Indicator. Follow the Conditions for Running the DTC in order to set the associated status indicator.

NOTE: **An I/M Test DTC will not be stored or erased from the ECU except at the end of trip processing which occurs 5 s after ignition OFF.**

22. Observe the I/M Test DTC information with a scan tool. Verify there are no I/M Test DTCs present.
 - If an I/M Test DTC is set, diagnose the DTC using the **Diagnostic Trouble Code (DTC) List - Vehicle** and refer to **Inspection/Maintenance System Check** for clearing I/M Test DTCs.
 - If an I/M Test DTC is set and the I/M System Status indicators are NO, diagnosis the DTC and perform the **Inspection/Maintenance Complete System Set Procedure**.
23. Observe the engine DTC information with a scan tool. Verify no DTCs are present.
 - If a DTC is set, diagnose using the **Diagnostic Trouble Code (DTC) List - Vehicle** . After repairs, perform the **Inspection/Maintenance Complete System Set Procedure** to verify no further DTCs are set.

INSPECTION/MAINTENANCE SYSTEM DTC TABLE

System	DTCs Required to Set System Status to YES
If an I/M System Status indicator did NOT update to YES during the <u>Inspection/Maintenance Complete System Set Procedure</u> , review each indicator and reference this table to determine each DTC associated with the I/M System Status Indicator. Each DTC listed below has specific conditions that must be met for the diagnostic to run. Included within the conditions are additional DTCs, which if set, may inhibit the DTCs listed below from running. Reviewing and operating the vehicle within the Conditions for Running for each DTC listed below will allow the I/M System Status Indicators to transition to YES.	
Catalyst	<u>DTC P0420</u>
EVAP	• <u>DTC P0442</u> • <u>DTC P0446</u> • <u>DTC P0451-P0454</u> • <u>DTC P0455</u> • <u>DTC P0496</u>
Oxygen Sensor	<u>DTC P0133, P0134, P013A, P013B, P013E, P013F, P0140, P1133, P2270, P2271, or P2A00 (LAF)</u>
Oxygen Sensor Heater	<u>DTC P0030, P0036, P0053, P0054, P0135, or P0141</u>
Camshaft System	<u>DTC P0011 or P0014</u>