

GENERAL INFORMATION

Trouble Shooting - Basic Procedures

* PLEASE READ THIS FIRST *

NOTE: This is **GENERAL** information. This article is not intended to be specific to any unique situation or individual vehicle configuration. The purpose of this Trouble Shooting information is to provide a list of common causes to problem symptoms. For model-specific Trouble Shooting, refer to **SUBJECT**, **DIAGNOSTIC**, or **TESTING** articles available in the section(s) you are accessing.

ACCESSORIES & ELECTRICAL

CHARGING SYSTEM TROUBLE SHOOTING

NOTE: This is **GENERAL** information. This article is not intended to be specific to any unique situation or individual vehicle configuration. The purpose of this Trouble Shooting information is to provide a list of common causes to problem symptoms. For model-specific Trouble Shooting, refer to **SUBJECT**, **DIAGNOSTIC**, or **TESTING** articles available in the section(s) you are accessing.

NOTE: This is **GENERAL** information. This article is not intended to be specific to any unique situation or individual vehicle configuration. The purpose of this Trouble Shooting information is to provide a list of common causes to problem symptoms. For model-specific Trouble Shooting, refer to **SUBJECT**, **DIAGNOSTIC**, or **TESTING** articles available in the section(s) you are accessing.

BASIC CHARGING SYSTEM TROUBLE SHOOTING CHART

CONDITION & POSSIBLE CAUSE	CORRECTION
Vehicle Will Not Start	
Dead battery	Check battery cells, alternator belt tension and alternator output
Loose or corroded battery connections	Check all charging system connections
Ignition circuit or switch malfunction	Check and replace as necessary
Alternator Light Stays On With Engine Running	
Loose or worn alternator drive belt	Check alternator drive tension and condition, See Belt Adjustment in TUNE-UP article in the TUNE-UP section
Loose alternator wiring connections	Check all charging system connections
Short in alternator light wiring	See Indicator Warning Lights in STANDARD INSTRUMENTS in the ACCESSORIES & EQUIPMENT section
Defective alternator stator or diodes	See Bench Tests in ALTERNATOR article

CONDITION & POSSIBLE CAUSE		CORRECTION
Defective regulator		See Regulator Check in ALTERNATOR article
Alternator Light Stays Off With Ignition Switch ON		
Blown fuse		See WIRING DIAGRAMS
Defective alternator		See Testing in ALTERNATOR article
Defective indicator light bulb or socket		See Indicator Warning Lights in STANDARD INSTRUMENTS in the ACCESSORIES & EQUIPMENT section
Alternator Light Stays OFF With Ignition Switch ON		
Short in alternator wiring		See On-Vehicle Tests in ALTERNATOR article
Defective rectifier bridge		See Bench Tests in ALTERNATOR article
Lights or Fuses Burn Out Frequently		
Defective alternator wiring		See On-Vehicle Tests in ALTERNATOR article
Defective regulator		See Regulator Check in ALTERNATOR article
Defective battery		Check and replace as necessary
Ammeter Gauge Shows Discharge		
Loose or worn drive belt		Check alternator drive belt tension and condition. See Belt Adjustment in TUNE-UP article in the TUNE-UP section
Defective wiring		Check all wires and wire connections
Defective alternator or regulator		See Bench Tests and On-Vehicle Tests in ALTERNATOR article
Defective ammeter, or improper ammeter wiring connection		See Testing in STANDARD INSTRUMENTS in the ACCESSORIES & EQUIPMENT section
Noisy Alternator		
Loose drive pulley		Tighten drive pulley attaching nut
Loose mounting bolts		Tighten all alternator mounting bolts
Worn or dirty bearings		See Bearing Replacement ALTERNATOR article
Defective diodes or stator		See Bench Test in ALTERNATOR article
Battery Does Stay Charged		
Loose or worn drive belt		Check alternator drive belt tension and condition. See Belt Adjustment in appropriate TUNE-UP article in the TUNE-UP section
Loose or corroded battery connections		Check all charging system connections

CONDITION & POSSIBLE CAUSE	CORRECTION
Loose alternator connections	Check all charging system connections
Defective alternator or battery	See On-Vehicle Tests and Bench Tests in ALTERNATOR article
Add-on electrical accessories exceeding alternator capacity	Install larger alternator
Battery Overcharged-Uses Too Much Water	
Defective battery	Check alternator output and repair as necessary
Defective alternator	See On-Vehicle Test and Bench Tests in ALTERNATOR article
Excessive alternator voltage	Check alternator output and repair as necessary

IGNITION SYSTEM TROUBLE SHOOTING

NOTE:

This is **GENERAL** information. This article is not intended to be specific to any unique situation or individual vehicle configuration. The purpose of this Trouble Shooting information is to provide a list of common causes to problem symptoms. For model-specific Trouble Shooting, refer to **SUBJECT**, **DIAGNOSTIC**, or **TESTING** articles available in the section(s) you are accessing.

Ignition Secondary Trouble Shooting Chart




Fig. 1: Ignition Secondary Trouble Shooting Chart

Ignition Primary Trouble Shooting Chart




Fig. 2: Ignition Primary Trouble Shooting Chart

STARTER TROUBLE SHOOTING

NOTE: This is **GENERAL** information. This article is not intended to be specific to any unique situation or individual vehicle configuration. The purpose of this Trouble Shooting information is to provide a list of common causes to problem symptoms. For model-specific Trouble Shooting, refer to **SUBJECT**, **DIAGNOSTIC**, or **TESTING** articles available in the section(s) you are accessing.

BASIC STARTER TROUBLE SHOOTING CHART

CONDITION & POSSIBLE CAUSE	CORRECTION
Starter Fails to Operate	

CONDITION & POSSIBLE CAUSE		CORRECTION
Dead battery or bad connections between starter and battery		Check battery charge and all wires and connections to starter
Ignition switch faulty or misadjusted		Adjust or replace ignition switch
Open circuit between starter switch ignition terminal on starter relay		Check and repair wires and connections as necessary
Starter relay or starter defective		See Testing in STARTER article
Open solenoid pull-in wire		Testing in STARTER article
Starter Does Not Operate and Headlights Dim		
Weak battery or dead cell		Charge or replace battery as necessary
Loose or corroded battery connections		Check that battery connections are clean and tight
Internal ground in starter windings		See Testing in STARTER article
Grounded starter fields		See Testing in STARTERS
Armature rubbing on pole		See STARTER article shoes
Starter Turns but Engine Does Not Rotate		
Starter clutch slipping		See STARTER article
Broken clutch housing		See STARTER article
Pinion shaft rusted or dry		See STARTER article
Engine basic timing incorrect		See Ignition Timing in TUNE-UP article
Broken teeth on engine flywheel		Replace flywheel and check for starter pinion gear damage
Starter Will Not Crank Engine		
Faulty overrunning clutch		See STARTER article
Broken clutch housing		See STARTER article
Broken flywheel teeth		Replace flywheel and check for starter pinion gear damage
Armature shaft sheared or reduction gear teeth stripped		See STARTER article
Weak battery		Charge or replace battery as necessary
Faulty solenoid		See On-Vehicle Tests in STARTER article
Poor grounds		Check all ground connections for tight and clean connections
Ignition switch faulty or misadjusted		Adjust or replace ignition switch as necessary
Starter Cranks Engine Slowly		
Battery weak or defective		Charge or replace battery as necessary
Engine overheated		See ENGINE COOLING SYSTEM article
Engine oil too heavy		Check that proper viscosity oil is used

CONDITION & POSSIBLE CAUSE	CORRECTION
Poor battery-to-starter connections	Check that all between battery and starter are clean and tight
Current draw too low or too high	See Bench Tests in STARTER article
Bent armature, loose pole shoes screws or worn bearing	See STARTER article
Burned solenoid contacts	Replace solenoid
Faulty starter	Replace starter
Starter Engages Engine Only Momentarily	
Engine timing too far advanced	See Ignition Timing in TUNE-UP article
Overrunning clutch not engaging properly	Replace overrunning clutch. See STARTER article
Broken starter clutch	See STARTER article
Broken teeth on engine flywheel	Replace flywheel and check starter pinion gear for damage
Weak drive assembly thrust spring	See STARTER article
Weak hold-in coil	See Bench Tests in STARTER article
Starter Drive Will Not Engage	
Defective point assembly	See Testing in STARTER article
Poor point assembly ground	See Testing in STARTER article
Defective pull-in coil	Replace starter solenoid
Starter Relay Does Not Close	
Dead battery	Charge or replace battery as necessary
Faulty wiring	Check all wiring and connections leading to relay
Neutral safety switch faulty	Replace neutral safety switch
Starter relay faulty	Replace starter relay
Starter Drive Will Not Disengage	
Starter motor loose on mountings	Tighten starter attach bolts
Worn drive end bushing	See STARTER article
Damaged engine flywheel teeth	Replace flywheel and starter pinion gear for damage
Drive yolk return spring broken or missing	Replace return spring
Faulty ignition switch	Replace ignition switch
Insufficient clearance between winding leads to solenoid terminal and main contact in solenoid	Replace starter solenoid
Starter clutch not disengaging	Replace starter clutch
Ignition starter switch	Replace ignition switch contacts sticking
Starter Relay Operates but Solenoid Does Not	
Faulty solenoid switch, switch connections or relay	Check all wiring between relay and solenoid or replace relay or solenoid as necessary

CONDITION & POSSIBLE CAUSE	CORRECTION
Broken lead or loose soldered connections	Repair wire or wire connections as necessary
Solenoid Plunger Vibrates When Switch is Engaged	
Weak battery	Charge or replace battery as necessary
Solenoid contacts corroded	Clean contacts or replace solenoid
Faulty wiring	Check all wiring leading to solenoid
Broken connections inside switch cover	Repair connections or replace solenoid
Open hold-in wire	solenoid
Low Current Draw	
Worn brushes or weak brush springs	Replace brushes or brush springs as necessary
High Pitched Whine During Cranking Before Engine Fires but Engine Fires and Cranks Normally	
Distance too great between starter pinion and flywheel	Align starter or check that correct starter and flywheel are being used
High Pitched Whine After Engine Fires With Key released. Engine Fires and Cranks Normally	
Distance too small between starter pinion and flywheel	Flywheel runout contributes to the intermittent nature

AIR CONDITIONING & HEAT

AIR CONDITIONING TROUBLE SHOOTING

WARNING: This is **GENERAL** information. This article is not intended to be specific to any unique situation or individual vehicle configuration. The purpose of this Trouble Shooting information is to provide a list of common causes to problem symptoms. For model-specific Trouble Shooting, refer to **SUBJECT**, **DIAGNOSTIC**, or **TESTING** articles available in the section(s) you are accessing.

BASIC AIR CONDITIONING TROUBLE SHOOTING CHART

CONDITION	POSSIBLE CAUSE
Compressor Not Working	Compressor clutch circuit open.
.....	Compressor clutch coil inoperative.
.....	Poor clutch ground connection.
.....	Fan belts loose.
.....	Thermostatic switch inoperative.
.....	Thermostatic switch not adjusted.
.....	Ambient temperature switch open.
.....	Superheat fuse blown.
Excessive Noise or Vibration	Missing or loose mounting bolts.
.....	Bad idler pulley bearings.
.....	Fan belts not tightened correctly.
.....	Compressor clutch contacting body.
.....	Excessive system pressure.
.....	Compressor oil level low.
.....	Damaged clutch bearings.
.....	Damaged reed valves.
.....	Damaged compressor.

CONDITION	POSSIBLE CAUSE
Insufficient or No Cooling; Compressor Working	Expansion valve inoperative.
.....	Heater control valve stuck open.
.....	Low system pressure.
.....	Blocked condenser fins.
.....	Blocked evaporator fins.
.....	Vacuum system leak.
.....	Vacuum motors inoperative.
.....	Control cables improperly adjusted.
.....	Restricted air inlet.
.....	Mode doors binding.
.....	Blower motor inoperative.
.....	Temperature above system capacity.

HEATER SYSTEM TROUBLE SHOOTING

NOTE: This is **GENERAL** information. This article is not intended to be specific to any unique situation or individual vehicle configuration. The purpose of this Trouble Shooting information is to provide a list of common causes to problem symptoms. For model-specific Trouble Shooting, refer to **DIAGNOSTIC**, or **TESTING** articles available in the section(s) you are accessing.

BASIC HEATER SYSTEM TROUBLE SHOOTING CHART

CONDITION	POSSIBLE CAUSE
Insufficient, Erratic, or No Heat	Low Coolant Level
.....	Incorrect thermostat.
.....	Restricted coolant flow through core.
.....	Heater hoses plugged.
.....	Misadjusted control cable.
.....	Sticking heater control valve.
.....	Vacuum hose leaking.
.....	Vacuum hose blocked.
.....	Vacuum motors inoperative.
.....	Blocked air inlet.
.....	Inoperative heater blower motor.
.....	Oil residue on heater core fins.
.....	Dirt on heater core fins.
Too Much Heat	Improperly adjusted cables.
.....	Sticking heater control valve.
.....	No vacuum to heater control valve.
.....	Temperature door stuck open.
Air Flow Changes During Acceleration	Vacuum system leak.
.....	Bad check valve or reservoir.
Air From Defroster At All Times	Vacuum system leak.
.....	Improperly adjusted control cables.
.....	Inoperative vacuum motor.
Blower Does Not Operate Correctly	Blown fuse.
.....	Blower motor windings open.
.....	Resistors burned out.
.....	Motor ground connection loose.
.....	Wiring harness connections loose.

CONDITION	POSSIBLE CAUSE
.....	Blower motor switch inoperative.
.....	Blower relay inoperative.
.....	Fan binding or foreign object in housing.
.....	Fan blades broken or bent.

BRAKES

BRAKE SYSTEM TROUBLE SHOOTING

NOTE: This is **GENERAL** information. This article is not intended to be specific to any unique situation or individual vehicle configuration. The purpose of this Trouble Shooting information is to provide a list of common causes to problem symptoms. For model-specific Trouble Shooting, refer to **SUBJECT**, **DIAGNOSTIC**, or **TESTING** articles available in the section(s) you are accessing.

BRAKE SYSTEM TROUBLE SHOOTING CHART

CONDITION & POSSIBLE CAUSE	CORRECTION
Brakes Pull Left or Right	
Incorrect tire pressure	Inflate tires to proper pressure
Front end out of alignment	See WHEEL ALIGNMENT
Mismatched tires	Check tires sizes
Restricted brake lines or hoses	Check hose routing
Loose or malfunctioning caliper	See DISC BRAKES or BRAKE SYSTEM
Bent shoe or oily linings	See DRUM BRAKES or BRAKE SYSTEM
Malfunctioning rear brakes	See DRUM, DISC BRAKES or BRAKE SYSTEM
Loose suspension parts	See SUSPENSION
Noises Without Brakes Applied	
Front linings worn out	Replace linings
Dust or oil on drums or rotors	See DRUM, DISC BRAKES or BRAKE SYSTEM
Noises With Brakes Applied	
Insulator on outboard shoe damaged	See DISC BRAKES or BRAKE SYSTEM
Incorrect pads or linings	Replace pads or linings
Brake Rough, Chatters or Pulsates	
Excessive lateral runout	Check rotor runout
Parallelism not to specifications	Reface or replace rotor
Wheel bearings not adjusted	See SUSPENSION
Rear drums out-of-round	Reface or replace drums
Disc pad reversed, steel against rotor	Remove and reinstall pad
Excessive Pedal Effort	
Malfunctioning power unit	See POWER BRAKES or BRAKE SYSTEM
Partial system failure	Check fluid and pipes
Worn disc pad or lining	Replace pad or lining
Caliper piston stuck or sluggish	See DISC BRAKES or BRAKE SYSTEM

CONDITION & POSSIBLE CAUSE		CORRECTION
Master cylinder piston stuck		See MASTER CYLINDERS or BRAKE SYSTEM
Brake fade due to incorrect pads for linings		Replace pads or linings
Linings or pads glazed		Replace pads or linings
Worn drums		Reface or replace drums
Excessive Pedal Travel		
Partial brake system failure		Check fluid and pipes
Insufficient fluid in master cylinder		See MASTER CYLINDERS or BRAKE SYSTEM
Air trapped in system		See BRAKE BLEEDING or BRAKE SYSTEM
Rear brakes not adjusted		See Adjustments in DRUM BRAKES or BRAKE SYSTEM
Bent shoe or lining		See DRUM BRAKES or BRAKE SYSTEM
Plugged master cylinder cap		See MASTER CYLINDERS or BRAKE SYSTEM
Improper brake fluid		Replace brake fluid
Pedal Travel Decreasing		
Compensating port plugged		See MASTER CYLINDERS or BRAKE SYSTEM
Swollen cup in master cylinder		See MASTER CYLINDERS or BRAKE SYSTEM
Master cylinder piston not returning		See MASTER CYLINDERS or BRAKE SYSTEM
Weak shoe retracting springs		See DRUM BRAKES BRAKE SYSTEM
Wheel cylinder piston sticking		See DRUM BRAKES or BRAKE SYSTEM
Dragging Brakes		
Master cylinder pistons not returning		See MASTER CYLINDERS BRAKE SYSTEM
Restricted brake lines or hoses		Check line routing
Incorrect parking brake adjustment		See DRUM BRAKES BRAKE SYSTEM
Parking Brake cables frozen		See DRUM BRAKES BRAKE SYSTEM
Incorrect installation of inboard disc pad		Remove and replace correctly
Power booster output rod too long		See POWER BRAKE UNITS BRAKE SYSTEM
Brake pedal not returning freely		See DISC, DRUM BRAKES BRAKE SYSTEM
Brakes Grab or Uneven Braking Action		
Malfunction of combination valve		See CONTROL VALVE or BRAKE SYSTEM

CONDITION & POSSIBLE CAUSE	CORRECTION
Malfunction of power brake unit	See POWER BRAKE UNITS or BRAKE SYSTEM
Binding brake pedal	See DISC, DRUM BRAKES or BRAKE SYSTEM
Pulsation or Roughness	
Uneven pad wear caused by caliper	See DISC BRAKES or BRAKE SYSTEM
Uneven rotor wear	See DISC BRAKES or BRAKE SYSTEM
Drums out-of-round	Reface or replace drums

ENGINE MECHANICAL

COOLING SYSTEM TROUBLE SHOOTING

NOTE: This is **GENERAL** information. This article is not intended to be specific to any unique situation or individual vehicle configuration. The purpose of this Trouble Shooting information is to provide a list of common causes to problem symptoms. For model-specific Trouble Shooting, refer to **SUBJECT**, **DIAGNOSTIC**, or **TESTING** articles available in the section(s) you are accessing.

COOLING SYSTEM TROUBLE SHOOTING

CONDITION & POSSIBLE CAUSE	CORRECTION
Overheating	
Coolant Leak	Fill/Pressure Test System
A/C Condenser Fins Clogged	Remove/Clean Condenser
Radiator Fins Clogged	Remove/Clean Radiator
Thermostat Stuck Closed	Replace Thermostat
Clogged Cooling System Passages	Clean/Flush Cooling System
Water Pump Malfunction	Replace Water Pump
Fan Clutch Malfunction	Replace Fan Clutch
Retarded Ignition Timing	Reset Ignition Timing
Cooling Fan Malfunction	Test Cooling Fan/Circuit
Cooling Fan Motor Malfunction	Test Fan Motor
Cooling Fan Relay Malfunction	Test Fan Relay
Faulty Radiator Cap	Replace Radiator Cap
Broken/Slipping Fan Belt	Replace Fan Belt
Restricted Exhaust	Repair Exhaust System
Corrosion	
Impurities In Coolant	Clean/Flush System
Coolant Leakage	
Damaged hose	Replace Hose
Leaky Water Pump	Replace Water Pump
Damaged Radiator Seam	Replace/Repair Radiator
Leaky Thermostat Cover	Replace Thermostat Cover
Cylinder Head Problem	Check Head/Head Gasket
Leaky Freeze Plugs	Replace Freeze Plugs
Recovery System Inoperative	
Loose and/or Defective Radiator Cap	Replace Radiator Cap
Overflow Tube Clogged and/or Leaking	Repair Tube

CONDITION & POSSIBLE CAUSE	CORRECTION
Recovery Bottle Vent Restricted	Clean Vent
No Heater Core Flow	
Collapsed Heater Hose	Replace Heater Hose
Plugged Heater Core	Clean/Replace Heater Core
Faulty Heater Valve	Replace Heater Valve

GASOLINE ENGINE - MECHANICAL TROUBLE SHOOTING

NOTE: This is **GENERAL** information. This article is not intended to be specific to any unique situation or individual vehicle configuration. The purpose of this Trouble Shooting information is to provide a list of common causes to problem symptoms. For model-specific Trouble Shooting, refer to **SUBJECT**, **DIAGNOSTIC**, or **TESTING** articles available in the section(s) you are accessing.

BASIC GASOLINE ENGINE - MECHANICAL TROUBLE SHOOTING CHART

CONDITION & POSSIBLE CAUSE	CORRECTION
Engine Lopes At Idle	
Intake manifold-to-head leaks	Replace manifold gasket, See ENGINES
Blown head gasket	Replace head gasket, See ENGINES
Worn timing gears, chain or sprocket	Replace gears, chain or sprocket
Worn camshaft lobes	Replace camshaft, See ENGINES
Overheated engine	Check cooling system, See COOLING
Blocked crankcase vent valve	Remove restriction
Leaking EGR valve	Repair leak and/or replace valve
Faulty fuel pump	Replace fuel pump
Engine Has Low Power	
Leaking fuel pump	Repair leak and/or replace fuel pump
Excessive piston-to-bore clearance	Install larger pistons, See ENGINES
Sticking valves or weak valve springs	Check valve train components, See ENGINES
Incorrect valve timing	Reset valve timing, See ENGINES
Worn camshaft lobes	Replace camshaft, See ENGINES
Blown head gasket	Replace head gasket. See ENGINES .
Clutch slipping	Adjust pedal and/or replace components, See ENGINES
Engine overheating	Check cooling system, See COOLING
Auto. Trans. pressure regulator valve faulty	Replace pressure regulator valve
Auto. Trans. fluid level too low	Add fluid as necessary

CONDITION & POSSIBLE CAUSE		CORRECTION
Improper vacuum diverter valve operation		Replace vacuum diverter valve
Vacuum leaks		Inspect vacuum system and repair as required
Leaking piston rings		Replace piston rings, See ENGINES
Faulty High Speed Operation		
Low fuel pump volume		Replace fuel pump
Leaking valves or worn		Replace valves and/or springs, See ENGINES
Incorrect valve timing		Reset valve timing, See ENGINES
Intake manifold restricted		Remove restriction
Worn distributor shaft		Replace distributor
Faulty Acceleration		
Improper fuel pump stroke		Remove pump and reset pump stroke
Incorrect ignition timing		Reset ignition timing, See TUNE-UP
Leaking valves		Replace valves, See ENGINES
Worn fuel pump diaphragm or piston		Replace diaphragm or piston
Intake Backfire		
Improper ignition timing		Reset ignition timing, See TUNE-UP
Faulty accelerator pump discharge		Replace accelerator pump
Improper choke operation		Check choke and adjust as required
Defective EGR valve		Replace EGR valve
Fuel mixture too lean		Reset air/fuel mixture, See TUNE-UP
Choke valve initial clearance too large		Reset choke valve initial clearance
Exhaust Backfire		
Vacuum leak		Inspect and repair vacuum system
Faulty vacuum diverter valve		Replace vacuum diverter valve
Faulty choke operation		Check choke and adjust as required
Exhaust system leak		repair exhaust system leak
Engine Detonation		
Ignition timing too far advanced		Reset ignition timing, See TUNE-UP
Faulty ignition system		Check ignition timing, See TUNE-UP
Spark plugs loose or faulty		Retighten or replace plugs
Fuel delivery system clogged		Inspect lines, pump and filter for clog
EGR valve inoperative		Replace EGR valve
PCV system inoperative		Inspect and/or replace hoses or valve
Vacuum leaks		Check vacuum system and repair leaks

CONDITION & POSSIBLE CAUSE	CORRECTION
Excessive combustion chamber deposits	Remove built-up deposits
Leaking, sticking or broken valves	Inspect and/or replace valves
External Oil Leakage	
Fuel pump improperly seated or worn gasket	Remove pump, replace gasket and seat properly
Oil pan gasket broken or pan bent	Straighten pan and replace gasket
Timing chain cover gasket broken	Replace timing chain cover gasket
Rear main oil seal worn	Replace rear main oil seal
Oil pan drain plug not seated properly	Remove and reinstall drain plug
Camshaft bearing drain hole blocked	Remove restriction
Oil pressure sending switch leaking	Remove and reinstall sending switch
Excessive Oil Consumption	
Worn valve stems or guides	Replace stems or guides, See ENGINES
Valve "O" ring seals damaged	Replace "O" ring seals, See ENGINES
Plugged oil drain back holes	Remove restrictions
Improper PCV valve operation	Replace PCV valve
Engine oil level too high	Remove excess oil
Engine oil too thin	Replace thicker oil
Valve stem oil deflectors damaged	Replace oil deflectors
Incorrect piston rings	Replace piston rings, See ENGINES
Piston ring gaps not staggered	Reinstall piston rings, See ENGINES
Insufficient piston ring tension	Replace rings, See ENGINES
Piston ring grooves or oil return slots clogged	Replace piston rings, See ENGINES
Piston rings sticking in grooves	Replace piston rings, See ENGINES
Piston ring grooves excessively worn	Replace piston and rings, See ENGINES
Compression rings installed upside down	Replace compression rings correctly, See ENGINES
Worn or scored cylinder walls	Rebore cylinders or replace block
Mismatched oil ring expander and rail	Replace oil ring expander and rail, See ENGINES
Intake gasket dowels too long	Replace intake gasket dowels
Excessive main or connecting rod bearing clearance	Replace main or connecting rod bearings, See ENGINES
No Oil Pressure	
Low oil level	Add oil to proper level
Oil pressure sender or gauge broken	Replace sender or gauge
Oil pump malfunction	Remove and overhaul oil pump, See ENGINES

CONDITION & POSSIBLE CAUSE		CORRECTION
Oil pressure relief valve sticking		Remove and reinstall valve
Oil pump passages blocked		Overhaul oil pump, See ENGINES
Oil pickup screen or tube blocked		Remove restriction
Loose oil inlet tube		Tighten oil inlet tube
Loose camshaft bearings		Replace camshaft bearings, See ENGINES
Internal leakage at oil passages		Replace block or cylinder head
Low Oil Pressure		
Low engine oil level		Add oil to proper level
Engine oil too thin		Remove and replace with thicker oil
Excessive oil pump clearance		Reduce oil pump clearance, See ENGINES
Oil pickup tube or screen blocked		Remove restrictions
Main, rod or cam bearing clearance excessive		Replace bearing to reduce clearance, See ENGINES
High Oil Pressure		
Improper grade of oil		Replace with proper oil
Oil pressure relief valve stuck closed		Eliminate binding
Oil pressure sender or gauge faulty		Replace sender or gauge
Noisy Main Bearings		
Inadequate oil supply		Check oil delivery to main bearings
Excessive main bearing clearance		Replace main bearings, See ENGINES
Excessive crankshaft end play		Replace crankshaft, See ENGINES
Loose flywheel or torque converter		Tighten attaching bolts
Loose or damaged vibration damper		Tighten or replace vibration damper
Crankshaft journals out-of-round		Re-grind crankshaft journals
Excessive belt tension		Loosen belt tension
Noisy Connecting Rods		
Excessive bearing clearance or missing bearing		Replace bearing, See ENGINES
Crankshaft rod journal out-of-round		Re-grind crankshaft journal
Misaligned connecting rod or cap		Remove rod or cap and realign
Incorrectly tightened rod bolts		Remove and re-tighten rod bolts
Noisy Pistons and Rings		
Excessive piston-to-bore clearance		Install larger pistons, See ENGINES
Bore tapered or out-of-round		Rebore block
Piston ring broken		Replace piston rings, See ENGINES
Piston pin loose or seized		Replace piston pin, See ENGINES
Connecting rods misaligned		Realign connecting rods

CONDITION & POSSIBLE CAUSE	CORRECTION
Ring side clearance too loose or tight	Replace with larger or smaller rings
Carbon build-up on piston	Remove carbon
Noisy Valve Train	
Worn or bent push rods	Replace push rods, See ENGINES
Worn rocker arms or bridged pivots	Replace push rods, See ENGINES
Dirt or chips in valve lifters	Remove lifters and remove dirt/chips
Excessive valve lifter leak-down	Replace valve lifters, See ENGINES
Valve lifter face worn	Replace valve lifters, See ENGINES
Broken or cocked valve springs	Replace or reposition springs
Too much valve stem-to-guide clearance	Replace valve guides, See ENGINES
Valve bent	Replace valve, See ENGINES
Loose rocker arms	Retighten rocker arms, See ENGINES
Excessive valve seat run-out	Reface valve seats, See ENGINES
Missing valve lock	Install new valve lock
Excessively worn camshaft lobes	Replace camshaft, See ENGINES
Plugged valve lifter oil holes	Eliminate restriction or replace lifter
Faulty valve lifter check ball	Replace lifter check ball, See ENGINES
Rocker arm nut installed upside down	Remove and reinstall correctly
Valve lifter incorrect for engine	Remove and replace valve lifters
Faulty push rod seat or lifter plunger	Replace plunger or push rod
Noisy Valves	
Improper valve lash	Re-adjust valve lash, See ENGINES
Worn or dirty valve lifters	Clean and/or replace lifters
Worn valve guides	Replace valve guides, See ENGINES
Excessive valve seat or face run-out	Reface seats or valve face
Worn camshaft lobes	Replace camshaft, See ENGINES
Loose rocker arm studs	Re-tighten rocker arm studs, See ENGINES
Bent push rods	Replace push rods, See ENGINES
Broken valve springs	Replace valve springs, See ENGINES
Burned, Sticking or Broken Valves	
Weak valve springs or warped valves	Replace valves and/or springs, See ENGINES

CONDITION & POSSIBLE CAUSE	CORRECTION
Improper lifter clearance	Re-adjust clearance or replace lifters
Worn guides or improper guide clearance	Replace valve guides, See ENGINES
Out-of-round valve seats or improper seat width	Re-grind valve seats
Gum deposits on valve stems, seats or guide	Remove deposits
Improper spark timing	Re-adjust spark timing
Broken Pistons/Rings	
Undersize pistons	Replace with larger pistons, See ENGINES
Wrong piston rings	Replace with correct rings, See ENGINES
Out-of-round cylinder bore	Re-bore cylinder bore
Improper connecting rod alignment	Remove and realign connecting rods
Excessively worn ring grooves	Replace pistons, See ENGINES
Improperly assembled piston pins	Re-assemble pin-to-piston, See ENGINES
Insufficient ring gap clearance	Install new rings, See ENGINES
Engine overheating	Check cooling system
Incorrect ignition timing	Re-adjust ignition timing, See TUNE-UP
Excessive Exhaust Noise	
Leaks at manifold to head, or to pipe	Replace manifold or pipe gasket
Exhaust manifold cracked or broken	Replace exhaust manifold, See ENGINES

ENGINE PERFORMANCE

CARBURETOR TROUBLE SHOOTING:

NOTE: This is **GENERAL** information. This article is not intended to be specific to any unique situation or individual vehicle configuration. The purpose of this Trouble Shooting information is to provide a list of common causes to problem symptoms. For model-specific Trouble Shooting, refer to **SUBJECT**, **DIAGNOSTIC**, or **TESTING** articles available in the section(s) you are accessing.

BASIC COLD START SYMPTOMS TROUBLE SHOOTING CHART

CONDITION & POSSIBLE CAUSE	CORRECTION
Engine Won't Start	
Choke not closing	Check choke operation, see FUEL SYSTEMS
Choke linkage bent	Check linkage, see FUEL SYSTEM
Engine Starts, Then Dies	
Choke vacuum kick setting too wide	Check setting and adjust see, FUEL SYSTEMS
Fast idle RPM too low	Reset RPM to specification, see TUNE-UP
Fast idle cam index incorrect	Reset fast idle cam index, see FUEL SYSTEMS

CONDITION & POSSIBLE CAUSE		CORRECTION
Vacuum leak		Inspect vacuum system for leaks
Low fuel pump outlet		Repair or replace pump, see FUEL SYSTEMS
Low carburetor fuel level		Check float setting see FUEL SYSTEM
Engine Quits Under Load		
Choke vacuum kick setting incorrect		Reset vacuum kick setting, see FUEL SYSTEMS
Fast idle cam index incorrect		Reset fast idle cam index, see FUEL SYSTEM
Incorrect hot fast idle speed RPM		Reset fast idle RPM, see TUNE-UP
Engine Starts, Runs Up, Then Idles, Slowly With Black Smoke		
Choke vacuum kick set too narrow		Reset vacuum kick, see FUEL SYSTEMS
Fast idle cam index incorrect		Reset fast idle cam index, see FUEL SYSTEMS
Hot fast idle RPM too low		Reset fast idle RPM, see TUNE-UP

BASIC HOT START SYMPTOMS TROUBLE SHOOTING CHART

CONDITION & POSSIBLE CAUSE	CORRECTION
Engine Won't Start	
Engine flooded	Allow fuel to evaporate

BASIC COLD ENGINE DRIVEABILITY SYMPTOMS TROUBLE SHOOTING CHART

CONDITION & POSSIBLE CAUSE	CORRECTION
Engine Stalls in Gear	
Choke vacuum kick setting incorrect	Reset choke vacuum kick, see FUEL SYSTEMS
Fast idle RPM incorrect	Reset fast idle RPM, see TUNE-UP
Fast idle cam index incorrect	Reset fast idle cam see FUEL SYSTEMS
Acceleration Sag or Stall	
Defective choke control switch	Replace choke control switch
Choke vacuum kick setting incorrect	Reset choke vacuum kick see, FUEL SYSTEMS
Float level incorrect (too low)	Adjust float level, FUEL SYSTEMS
Accelerator pump defective	Repair or replace pump see FUEL SYSTEMS
Secondary throttles not closed	Inspect lockout adjustment, see FUEL SYSTEMS
Sag or Stall After Warmup	
Defective choke control switch	Replace choke control switch, see FUEL SYSTEMS
Defective accelerator pump	Replace pump, see FUEL SYSTEMS
Float level incorrect (too low)	Adjust float level, see FUEL SYSTEMS
Backfiring & Black Smoke	

CONDITION & POSSIBLE CAUSE	CORRECTION
Plugged heat crossover system	Remove restriction

BASIC WARM ENGINE DRIVEABILITY SYMPTOMS TROUBLE SHOOTING CHART

CONDITION & POSSIBLE CAUSE	CORRECTION
Hesitation With Small Amount of Gas Pedal Movement	
Vacuum leak	Inspect vacuum lines
Accelerator pump weak or inoperable	Replace pump, see FUEL SYSTEMS
Float level setting too low	Reset float level, see FUEL SYSTEMS
Metering rods sticking or binding	Inspect and/or replace rods, see FUEL SYSTEMS
Carburetor idle or transfer system plugged	Inspect system and remove restriction
Frozen or binding heated air inlet	Inspect heated air door for binding
Hesitation With Heavy Gas Pedal Movement	
Defective accelerator pump	Replace pump, see FUEL SYSTEMS
Metering rod carrier sticking or binding	Remove restriction
Large vacuum leak	Inspect vacuum system and repair leak
Float level setting too low	Reset float level, see FUEL SYSTEMS
Defective fuel pump, lines or filter	Inspect pump, lines and filter
Air door setting incorrect	Adjust air door setting, see FUEL

DIESEL ENGINE TROUBLE SHOOTING

NOTE: This is **GENERAL** information. This article is not intended to be specific to any unique situation or individual vehicle configuration. The purpose of this Trouble Shooting information is to provide a list of common causes to problem symptoms. For model-specific Trouble Shooting, refer to **SUBJECT**, **DIAGNOSTIC**, or **TESTING** articles available in the section(s) you are accessing.

NOTE: Diesel engines mechanical diagnosis is the same as gasoline engines for items such as noisy valves, bearings, pistons, etc. The following trouble shooting covers only items pertaining to diesel engines.

BASIC DIESEL ENGINE TROUBLE SHOOTING CHART

CONDITION & POSSIBLE CAUSE	CORRECTION
Engine Won't Crank	
Bad battery connections or dead batteries	Check connections and/or replace batteries
Bad starter connections or bad starter	Check connections and/or replace starter
Engine Cranks Slowly, Won't Start	
Bad battery connections or dead batteries	Check connections and/or replace batteries
Engine oil too heavy	Replace engine oil
Engine Cranks Normally, But Will Not Start	
Glow plugs not functioning	Check glow plug system, see FUEL SYSTEMS

CONDITION & POSSIBLE CAUSE		CORRECTION
Glow plug control not functioning		Check controller, see FUEL SYSTEMS
Fuel not injected into cylinders		Check fuel injectors, see FUEL SYSTEMS
No fuel to injection pump		Check fuel delivery system
Fuel filter blocked		Replace fuel filter
Fuel tank filter blocked		Replace fuel tank filter
Fuel pump not operating		Check pump operation and/or replace pump
Fuel return system blocked		Inspect system and remove restriction
No voltage to fuel solenoid		Check solenoid and connections
Incorrect or contaminated fuel		Replace fuel
Incorrect injection pump timing		Re-adjust pump timing, see FUEL SYSTEMS
Low compression		Check valves, pistons, rings, see ENGINES
Injection pump malfunction		Inspect and/or replace injection pump
Engine Starts, Won't Idle		
Incorrect slow idle adjustment		Reset idle adjustment, see TUNE-UP
Fast idle solenoid malfunctioning		Check solenoid and connections
Fuel return system blocked		Check system and remove restrictions
Glow plugs go off too soon		See glow plug diagnosis in FUEL SYSTEMS
Injection pump timing incorrect		Reset pump timing, see FUEL SYSTEMS
No fuel to injection pump		Check fuel delivery system
Incorrect or contaminated fuel		Replace fuel
Low compression		Check valves, piston, rings, see ENGINES
Injection pump malfunction		Replace injection pump, see FUEL SYSTEMS
Fuel solenoid closes in RUN position		Check solenoid and connections
Engines Starts/Idles Rough W/out Smoke or Noise		
Incorrect slow idle adjustment		Reset slow idle, see TUNE-UP
Injection line fuel leaks		Check lines and connections
Fuel return system blocked		Check lines and connections
Air in fuel system		Bleed air from system
Incorrect or contaminated fuel		Replace fuel
Injector nozzle malfunction		Check nozzles, see FUEL SYSTEMS
Engines Starts and Idles Rough W/out Smoke or Noise, But Clears After Warm-Up		
Injection pump timing incorrect		Reset pump timing, see FUEL SYSTEMS
Engine not fully broken in		Put more miles on engine
Air in system		Bleed air from system

CONDITION & POSSIBLE CAUSE		CORRECTION
Injector nozzle malfunction		Check nozzles, see FUEL SYSTEMS
Engine Idles Correctly, Misfires Above Idle		
Blocked fuel filter		Replace fuel filter
Injection pump timing incorrect		Reset pump timing, see FUEL SYSTEMS
Incorrect or contaminated fuel		Replace fuel
Engine Won't Return To Idle		
Fast idle adjustment incorrect		Reset fast idle, see TUNE-UP
Internal injection pump malfunction		Replace injection pump, see FUEL SYSTEMS
External linkage binding		Check linkage and remove binding
Fuel Leaks On Ground		
Loose or broken fuel line		Check lines and connections
Internal injection pump seal leak		Replace injection pump, see FUEL SYSTEMS
Cylinder Knocking Noise		
Injector nozzles sticking open		Test injectors, see FUEL SYSTEMS
Very low nozzle opening pressure		Test injectors and/or replace
Loss of Engine Power		
Restricted air intake		Remove restriction
EGR valve malfunction		Replace EGR valve
Blocked or damaged exhaust system		Remove restriction and/or replace components
Blocked fuel tank filter		Replace filter
Restricted fuel filter		Remove restriction and/or replace filter
Block vent in gas cap		Remove restriction and/or replace cap
Tank-to-injection pump fuel supply blocked		Check fuel lines and connections
Blocked fuel return system		Remove restriction
Incorrect or contaminated fuel		Replace fuel
Blocked injector nozzles		Check nozzle for blockage, see FUEL SYSTEMS
Low compression		Check valves, rings, pistons, see ENGINES
Loud Engine Noise With Black Smoke		
Basic timing incorrect		Reset timing, see FUEL SYSTEMS
EGR valve malfunction		Replace EGR valve
Internal injection pump malfunction		Replace injection pump, see FUEL SYSTEMS
Incorrect injector pump housing pressure		Check pressure, see FUEL SYSTEMS
Engine Overheating		
Cooling system leaks		Check cooling system and repair leaks
Belt slipping or damaged		Check tension and/or replace belt

CONDITION & POSSIBLE CAUSE		CORRECTION
Thermostat stuck closed		Remove and replace thermostat, see ENGINE COOLING
Head gasket leaking		Replace head gasket
Oil Light on at Idle		
Low oil pump pressure		Check oil pump operation, see ENGINES
Oil cooler or line restricted		Remove restriction and/or replace cooler
Engine Won't Shut Off		
Injector pump fuel solenoid does not return fuel valve to OFF position		Remove and check solenoid and replace if needed

VACUUM PUMP DIAGNOSIS

CONDITION & POSSIBLE CAUSE		CORRECTION
Excessive Noise		
Loose pump-to-drive assembly screws		Tighten screws
Loose tube on pump assembly		Tighten tube
Valves not functioning properly		Replace valves
Oil Leakage		
Loose end plug		Tighten end plug
Bad seal crimp		Remove and re-crimp seal

FUEL INJECTION TROUBLE SHOOTING

NOTE: This is **GENERAL** information. This article is not intended to be specific to any unique situation or individual vehicle configuration. The purpose of this Trouble Shooting information is to provide a list of common causes to problem symptoms. For model-specific Trouble Shooting, refer to **SUBJECT**, **DIAGNOSTIC**, or **TESTING** articles available in the section(s) you are accessing.

BASIC FUEL INJECTION TROUBLE SHOOTING CHART

CONDITION & POSSIBLE CAUSE		CORRECTION
Engine Won't Start (Crankes Normally)		
Cold start valve inoperative		Test valve and circuit
Poor connection;vacuum or wiring		Check vacuum and electrical connections
Contaminated fuel		Test fuel for water or alcohol
Defective fuel pump relay or circuit		Test relay and wiring
Battery too low		Charge and test battery
Low fuel pressure		Test pressure regulator and fuel pump, check for restricted lines and filters
No distributor reference pulses		Repair ignition system as necessary
Open coolant temperature sensor circuit		Test sensor and wiring
Shorted W.O.T. switch in T.P.S.		Disconnect W.O.T. switch, engine should start
Defective ECM		Replace ECM
Fuel tank residual pressure valve leaks		Test for fuel pressure drop after shut down
Hard Starting		

CONDITION & POSSIBLE CAUSE	CORRECTION
Disconnected hot air tube to air cleaner	Reconnect tube and test control valve
Defective Idle Air Control (IAC) valve	Test valve operation and circuit
Shorted, open or misadjusted T.P.S.	Test and adjust or replace T.P.S.
EGR valve open	Test EGR valve and control circuit
Poor Oxygen sensor signal	Test for shorted or circuit
Incorrect mixture from PCV system	Test PCV for flow, check sealing of oil filter cap
Poor High Speed Operation	
Low fuel pump volume	Faulty pump or restricted fuel lines or filters
Poor MAP sensor signal	Test MAP sensor, vacuum hose and wiring
Poor Oxygen sensor signal	Test for shorted or open sensor or circuit
Open coolant temperature sensor circuit	Test sensor and wiring
Faulty ignition operation	Check wires for cracks or poor connections, test secondary voltage with oscilloscope
Contaminated fuel	Test fuel for water or alcohol
Intermittent ECM ground	Test ECM ground connection for resistance
Restricted air cleaner	Replace air cleaner
Restricted exhaust system	Test for exhaust manifold back pressure
Poor MAF sensor signal	Check leakage between sensor and manifold
Poor VSS signal	If tester for ALCL hook-up is available check that VSS reading matches speedometer
Ping or Knock on Acceleration	
Poor Knock sensor signal	Test for shorted or open sensor or circuit
Poor Baro sensor signal	Test for shorted or open sensor or circuit
Improper ignition timing	See VEHICLE EMISSION CONTROL LABEL (where applicable)
Check for engine overheating problems	Low coolant, loose belts or electric cooling fan inoperative

NOTE: For additional electronic fuel injection trouble shooting information, see the appropriate article in the **ENGINE PERFORMANCE** section (not all vehicles have Computer Engine Control articles). Information is provided there for diagnosing fuel system problems on vehicles with electronic fuel injection.

IGNITION SYSTEM TROUBLE SHOOTING

NOTE:

This is **GENERAL** information. This article is not intended to be specific to any unique situation or individual vehicle configuration. The purpose of this Trouble Shooting information is to provide a list of common causes to problem symptoms. For model-specific Trouble Shooting, refer to **SUBJECT**, **DIAGNOSTIC**, or **TESTING** articles available in the section(s) you are accessing.

Ignition Secondary Trouble Shooting Chart




Fig. 3: Ignition Secondary Trouble Shooting Chart

Ignition Primary Trouble Shooting Chart




Fig. 4: Ignition Primary Trouble Shooting Chart

STARTER TROUBLE SHOOTING

NOTE: This is **GENERAL** information. This article is not intended to be specific to any unique situation or individual vehicle configuration. The purpose of this Trouble Shooting information is to provide a list of common causes to problem symptoms. For model-specific Trouble Shooting, refer to **SUBJECT**, **DIAGNOSTIC**, or **TESTING** articles available in the section(s) you are accessing.

BASIC STARTER TROUBLE SHOOTING CHART

CONDITION & POSSIBLE CAUSE	CORRECTION
Starter Fails to Operate	

CONDITION & POSSIBLE CAUSE	CORRECTION
Dead battery or bad connections between starter and battery	Check battery charge and all wires and connections to starter
Ignition switch faulty or misadjusted	Adjust or replace ignition switch
Open circuit between starter switch ignition terminal on starter relay	Check and repair wires and connections as necessary
Starter relay or starter defective	See Testing in STARTER article
Open solenoid pull-in wire	See Testing in STARTER article
Starter Does Not Operate and Headlights Dim	
Weak battery or dead cell	Charge or replace battery as necessary
Loose or corroded battery connections	Check that battery connections are clean and tight
Internal ground in starter windings	See Testing in STARTER article
Grounded starter fields	See Testing in STARTERS
Armature rubbing on pole shoes	See STARTER article
Starter Turns but Engine Does Not Rotate	
Starter clutch slipping	See STARTER article
Broken clutch housing	See STARTER article
Pinion shaft rusted or dry	See STARTER article
Engine basic timing incorrect	See Ignition Timing in TUNE-UP article
Broken teeth on engine flywheel	Replace flywheel and check for starter pinion gear damage
Starter Will Not Crank Engine	
Faulty overrunning clutch	See STARTER article
Broken clutch housing	See STARTER article
Broken flywheel teeth	Replace flywheel and check for starter pinion gear damage
Armature shaft sheared or reduction gear teeth stripped	See STARTER article
Weak battery	Charge or replace battery as necessary
Faulty solenoid	See On-Vehicle Tests in STARTER article
Poor grounds	Check all ground connections for tight and clean connections
Ignition switch faulty or misadjusted	Adjust or replace ignition switch as necessary
Starter Cranks Engine Slowly	
Battery weak or defective	Charge or replace battery as necessary
Engine overheated	See ENGINE COOLING SYSTEM article
Engine oil too heavy	Check that proper viscosity oil is used

CONDITION & POSSIBLE CAUSE	CORRECTION
Poor battery-to-starter connections	Check that all between battery and starter are clean and tight
Current draw too low or too high	See Bench Tests in STARTER article
Bent armature, loose pole shoes screws or worn bearings	See STARTER article
Burned solenoid contacts	Replace solenoid
Faulty starter	Replace starter
Starter Engages Engine Only Momentarily	
Engine timing too far advanced	See Ignition Timing in TUNE-UP article
Overrunning clutch not engaging properly	Replace overrunning clutch. See STARTER article
Broken starter clutch	See STARTER article
Broken teeth on engine flywheel	Replace flywheel and check starter pinion gear for damage
Weak drive assembly thrust spring	See STARTER article
Weak hold-in coil	See Bench Tests in STARTER article
Starter Drive Will Not Engage	
Defective point assembly	See Testing in STARTER article
Poor point assembly ground	See Testing in STARTER article
Defective pull-in coil	Replace starter solenoid
Starter Relay Does Not Close	
Dead battery	Charge or replace battery as necessary
Faulty wiring	Check all wiring and connections leading to relay
Neutral safety switch faulty	Replace neutral safety switch
Starter relay faulty	Replace starter relay
Starter Drive Will Not Disengage	
Starter motor loose on mountings	Tighten starter attach bolts
Worn drive end bushing	See STARTER article
Damaged engine flywheel teeth	Replace flywheel and starter pinion gear for damage
Drive yolk return spring broken or missing	Replace return spring
Faulty ignition switch	Replace ignition switch
Insufficient clearance between winding leads to solenoid terminal and main contact in solenoid	Replace starter solenoid
Starter clutch not disengaging	Replace starter clutch
Ignition starter switch contacts sticking	Replace ignition switch
Starter Relay Operates but Solenoid Does Not	
Faulty solenoid switch, switch connections or relay	Check all wiring between relay and solenoid or replace relay or solenoid as necessary

CONDITION & POSSIBLE CAUSE	CORRECTION
Broken lead or loose soldered connections	Repair wire or wire connections as necessary
Solenoid Plunger Vibrates When Switch is Engaged	
Weak battery	Charge or replace battery as necessary
Solenoid contacts corroded	Clean contacts or replace solenoid
Faulty wiring	Check all wiring leading to solenoid
Broken connections inside switch cover	Repair connections or replace solenoid
Open hold-in wire	Replace solenoid
Low Current Draw	
Worn brushes or weak	Replace brushes or brush springs as necessary
High Pitched Whine During Cranking Before Engine Fires but Engine Fires and Cranks Normally	
Distance too great between starter pinion and flywheel	Align starter or check that correct starter and flywheel are being used
High Pitched Whine After Engine Fires With Key released. Engine Fires and Cranks Normally	
Distance too small between starter pinion and flywheel	Flywheel runout contributes to the intermittent nature

TUNE-UP TROUBLE SHOOTING - GAS ENGINE VEHICLES

NOTE: This is **GENERAL** information. This article is not intended to be specific to any unique situation or individual vehicle configuration. The purpose of this Trouble Shooting information is to provide a list of common causes to problem symptoms. For model-specific Trouble Shooting, refer to **SUBJECT**, **DIAGNOSTIC**, or **TESTING** articles available in the section(s) you are accessing.

BASIC SPARK PLUG TROUBLE SHOOTING CHARTS

CONDITION & POSSIBLE CAUSE	CORRECTION
Normal Spark Plug Condition	
Light Tan or Gray deposits	No Action
Electrode not burned or fouled	No Action
Gap tolerance not changed	No Action
Cold Fouling or Carbon Deposits	
Overrich air/fuel mixture	Adjust air/fuel mixture, see ENGINE PERFORMANCE section
Faulty choke	Replace choke assembly, see ENGINE PERFORMANCE section
Clogged air filter	Clean and/or replace air filter
Incorrect idle speed or dirty carburetor	Reset idle speed and/ or clean carburetor
Faulty ignition wires	Replace ignition wiring
Prolonged operation at idle	Shut engine off during long idle
Sticking valves or worn valve guide seals	Check valve train
Wet Fouling or Oil Deposits	

CONDITION & POSSIBLE CAUSE		CORRECTION
Worn rings and pistons		Install new rings and pistons
Excessive cylinder wear		Rebore or replace block
Excessive valve guide clearance		Worn or loose bearing
Gap Bridged		
Deposits in combustion chamber becoming fused to electrode		Clean combustion chamber of deposits
Blistered Electrode		
Engine overheating		Check cooling system
Wrong type of fuel		Replace with correct fuel
Loose spark plugs		Retighten spark plugs
Over-advanced ignition timing		Reset ignition timing see ENGINE PERFORMANCE
Pre-Ignition or Melted Electrodes		
Incorrect type of fuel		Replace with correct fuel
Incorrect ignition timing		Reset ignition timing see ENGINE PERFORMANCE
Burned valves		Replace valves
Engine Overheating		Check cooling system
Wrong type of spark plug, too hot		Replace with correct spark plug, see ENGINE PERFORMANCE
Chipped Insulators		
Severe detonation		Check for over-advanced timing or combustion
Improper gapping procedure		Re-gap spark plugs
Rust Colored Deposits		
Additives in unleaded fuel		Try different fuel brand
Water In Combustion Chamber		
Blown head gasket or cracked head		Repair or replace head or head gasket

NOTE: Before diagnosing an electronic ignition system, ensure that all wiring is connected properly between distributor, wiring connector and spark plugs. Ignition problem will show up either as: Engine Will Not Start or Engine Runs Rough.

BASIC ELECTRONIC IGNITION TROUBLE SHOOTING CHARTS

CONDITION & POSSIBLE CAUSE		CORRECTION
Engine Won't Start		
Open circuit between distributor and bulkhead connector		Repair circuit
Open circuit between bulkhead connector and ignition switch		Repair circuit
Open circuit between ignition switch and starter solenoid		Repair circuit
Engine Runs Rough		
Fuel lines leaking or clogged		Tighten fitting, remove restriction
Initial timing incorrect		Reset ignition timing see ENGINE PERFORMANCE
Centrifugal advance malfunction		Repair distributor advance
Defective spark plugs or wiring		Replace plugs or plug wiring
Component Failure		

CONDITION & POSSIBLE CAUSE	CORRECTION
Spark arc-over on cap, rotor or coil	Replace cap, rotor or coil
Defective pick-up coil	Replace pick-up coil
Defective ignition coil	Replace ignition coil
Defective vacuum unit	Replace vacuum unit
Defective control module	Replace control module

BASIC ELECTRONIC IGNITION TROUBLE SHOOTING CHARTS - USING OSCILLOSCOPE PATTERNS

CONDITION & POSSIBLE CAUSE	CORRECTION
Firing Voltage Lines are the Same, but Abnormally High	
Retarded ignition timing	Reset ignition timing, see ENGINE PERFORMANCE section
Fuel mixture too lean	Readjust carburetor, see ENGINE PERFORMANCE
High resistance in coil wire	Replace coil wire
Corrosion in coil tower terminal	Clean and/or replace coil
Corrosion in distributor coil terminal	Clean and/or replace distributor cap
Firing Voltage Lines are the Same but Abnormally Low	
Fuel mixture too rich	Readjust carburetor, see ENGINE PERFORMANCE
Breaks in coil wire causing arcing	Replace coil wire
Cracked coil tower causing arcing	Replace coil
Low coil output	Replace coil
Low engine compression	Determine cause and repair
One or More, But Not All Firing Voltage Lines are Higher Than Others	
Carburetor idle mixture not balanced	Readjust carburetor, see ENGINE PERFORMANCE
EGR valve stuck open	Clean and/or replace valve
High resistance in spark plug wires	Replace spark plug wires
Cracked or broken spark plug insulator	Replace spark plugs
Intake vacuum leak	Repair leak
Defective spark plugs	Replace spark plugs
Corroded spark plug terminals	Replace spark plugs
One or More, But Not All Firing Voltage Lines Are Lower Than Others	
Curb idle mixture not balanced	Readjust carburetor, see ENGINE PERFORMANCE
Breaks in plug wires	Replace plug wires causing arcing
Cracked coil tower causing arcing	Replace coil
Low compression	Determine cause and repair
Defective spark plugs	Replace spark plugs
Corroded spark plugs	Replace spark plugs
Cylinders Not Firing	
Cracked distributor cap terminals	Replace distributor cap
Shorted spark plug wire	Determine cause and repair

CONDITION & POSSIBLE CAUSE	CORRECTION
Mechanical problem in engine	Determine cause and repair
Defective spark plugs	Replace spark plugs
Spark plugs fouled	Replace spark plugs

BASIC DRIVEABILITY PROBLEMS TROUBLE SHOOTING

CONDITION & POSSIBLE CAUSE	CORRECTION
Hard Starting	
Binding carburetor linkage	Eliminate binding
Binding choke linkage	Eliminate binding
Binding choke piston	Eliminate binding
Restricted choke vacuum	Check vacuum lines for blockage
Worn or dirty needle valve and seat	Clean carburetor, see ENGINE PERFORMANCE
Float sticking	Readjust or replace float see the ENGINE PERFORMANCE section
Incorrect choke adjustment	Reset choke adjustment see ENGINE PERFORMANCE
Defective coil	Replace coil
Improper spark plug gap	Regap spark plugs
Incorrect ignition timing	Reset ignition timing see ENGINE PERFORMANCE
Detonation	
Over-advanced ignition timing	Reset ignition timing see ENGINE PERFORMANCE
Defective spark plugs	Replace spark plugs
Fuel lines clogged	Clean fuel lines
EGR system malfunction	Check and repair EGR system
PCV system malfunction	Repair PCV system
Vacuum leaks	Check and repair vacuum system
Loose fan belts	Tighten or replace fan belts, see ENGINE PERFORMANCE
Restricted airflow	Remove restriction
Vacuum advance malfunction	Check distributor operation
Dieseling	
Binding carburetor linkage	Eliminate binding
Binding throttle linkage	Eliminate binding
Binding choke linkage or fast idle cam	Eliminate binding
Defective idle solenoid	Replace idle solenoid see ENGINE PERFORMANCE
Improper base idle speed	Reset idle speed, see ENGINE PERFORMANCE

CONDITION & POSSIBLE CAUSE		CORRECTION
Incorrect ignition timing		Reset ignition timing see ENGINE PERFORMANCE
Incorrect idle mixture setting		Reset idle mixture, see ENGINE PERFORMANCE
Faulty Acceleration		
Incorrect ignition timing		Reset ignition timing see ENGINE PERFORMANCE
Engine cold and choke too lean		Adjust choke and allow engine to warm-up
Defective spark plugs		Replace spark plugs
Defective coil		Replace coil
Faulty Low Speed Operation		
Clogged idle transfer slots		Clean idle transfer slots, see FUEL
Restricted idle air bleeds and passages		Disassemble and clean carburetor, see FUEL
Clogged air cleaner		Replace air filter
Defective spark plugs		Replace spark plugs
Defective ignition wires		Replace ignition wire see ENGINE PERFORMANCE
Defective distributor cap		Replace distributor cap
Faulty High Speed Operation		
Incorrect ignition timing		Reset ignition timing see ENGINE PERFORMANCE
Defective distributor centrifugal advance		Replace advance mechanism
Defective distributor vacuum advance		Replace advance unit
Incorrect spark plugs or plug gap		Check gap and/or replace spark plugs
Faulty choke operation		Check choke and repair as required
Clogged vacuum passages		Remove restrictions
Improper size or clogged main jet		Check jet size and clean, see FUEL
Restricted air cleaner		Check filter and replace as necessary
Defective distributor cap, rotor or coil		Replace cap, rotor or coil
Misfire at All Speeds		
Defective spark plugs		Replace spark plugs
Defective spark plug wires		Replace spark plug wires
Defective distributor cap, rotor, or coil		Replace cap, rotor, or coil
Cracked or broken vacuum hoses		Replace vacuum hoses
Vacuum leaks		Repair vacuum leaks
Fuel lines clogged		Remove restriction
Hesitation		
Cracked or broken vacuum		Replace vacuum hoses hoses
Vacuum leaks		Repair Vacuum leaks
Binding carburetor linkage		Eliminate binding
Binding throttle linkage		Eliminate binding

CONDITION & POSSIBLE CAUSE	CORRECTION
Binding choke linkage or fast idle cam	Eliminate binding
Improper float setting	Readjust float setting, see FUEL
Cracked or broken ignition wires	Replace ignition wires
Rough Idle, Missing or Stalling	
Incorrect curb idle or fast idle speed	Reset idle speed, see ENGINE PERFORMANCE
Incorrect basic timing	Reset ignition timing see ENGINE PERFORMANCE
Improper idle mixture adjustment	Reset idle mixture, see ENGINE PERFORMANCE
Improper feedback system operation	Check feedback system see ENGINE PERFORMANCE
Incorrect spark plug gap	Reset spark plug gap, see ENGINE PERFORMANCE
Moisture in ignition components	Dry components
Loose or broken ignition wires	Replace ignition wires
Damaged distributor cap or rotor	Replace distributor cap or rotor
Faulty ignition coil	Replace ignition coil
Fuel filter clogged or worn	Replace fuel filter
Damaged idle mixture screw	Replace idle mixture screw, see FUEL
Improper fast idle cam adjustment	Reset fast idle cam adjustment, see TUNE-see ENGINE PERFORMANCE
Improper EGR valve operation	Replace EGR valve
Faulty PCV valve air flow	Replace PCV valve
Choke binding or improper choke setting	Reset choke or eliminate binding
Vacuum leak	Repair vacuum leak
Improper float bowl fuel level	Reset float adjustment, see FUEL
Clogged air bleed or idle passages	Clean carburetor passages, see FUEL
Clogged or worn air cleaner filter	Replace air filter
Faulty choke vacuum diaphragm	Replace diaphragm, see ENGINE PERFORMANCE
Exhaust manifold heat valve inoperative	Replace heat valve
Improper distributor spark advance	Check distributor operation
Leaking valves or valve components	Check and repair valvetrain
Improper carburetor mounting	Remove and remount carburetor
Excessive play in distributor shaft	Replace distributor
Loose or corroded wiring connections	Repair or replace as required

CONDITION & POSSIBLE CAUSE	CORRECTION
Engine Surges	
Improper PCV valve airflow	Replace PCV valve
Vacuum leaks	Repair vacuum leaks
Clogged air bleeds	Remove restriction
EGR valve malfunction	Replace EGR valve
Restricted air cleaner filter	Replace air filter
Cracked or broken vacuum hoses	Replace vacuum hoses
Cracked or broken ignition wires	Replace ignition wires
Vacuum advance malfunction	Check unit and replace as necessary
Defective or fouled spark plugs	Replace spark plugs
Ping or Spark Knock	
Incorrect ignition timing	Reset ignition timing see ENGINE PERFORMANCE
Distributor centrifugal or vacuum advance malfunction	Check operation and replace as necessary
Carburetor setting too lean	Readjust mixture setting, see ENGINE PERFORMANCE
Vacuum leak	Eliminate vacuum leak
EGR valve malfunction	Replace EGR valve
Poor Gasoline Mileage	
Cracked or broken vacuum hoses	Replace vacuum hoses hoses
Vacuum leaks	Repair vacuum leaks
Defective ignition wires	Replace wires
Incorrect choke setting	Readjust setting, see ENGINE PERFORMANCE
Defective vacuum advance	Replace vacuum advance
Defective spark plugs	Replace spark plugs
Binding carburetor power piston	Eliminate binding
Dirt in carburetor jets	Clean and/or replace jets
Incorrect float adjustment	Readjust float setting, see FUEL
Defective power valve	Replace power valve, see ENGINE PERFORMANCE
Incorrect idle speed	Readjust idle speed
Engine Stalls	
Improper float level	Readjust float level
Leaking needle valve and seat	Replace needle valve and seat
Vacuum leaks	Eliminate vacuum leaks

VACUUM PUMP - DIESEL TROUBLE SHOOTING

NOTE:

This is **GENERAL** information. This article is not intended to be specific to any unique situation or individual vehicle configuration. The purpose of this Trouble Shooting information is to provide a list of common causes to problem symptoms. For model-specific Trouble Shooting, refer to **SUBJECT**, **DIAGNOSTIC**, or **TESTING** articles available in the section(s) you are accessing.

NOTE: Diesel engines mechanical diagnosis is the same as gasoline engines for items such as noisy valves, bearings, pistons, etc. The following trouble shooting covers only items pertaining to diesel engines.

VACUUM PUMP (DIESEL) TROUBLE SHOOTING CHART

CONDITION & POSSIBLE CAUSE	CORRECTION
Excessive Noise	
Loose pump-to-drive assembly screws	Tighten screws
Loose tube on pump assembly	Tighten tube
Valves not functioning properly	Replace valves
Oil Leakage	
Loose end plug	Tighten end plug
Bad seal crimp	Remove and re-crimp seal

MANUAL TRANSMISSION

MANUAL TRANSMISSION TROUBLE SHOOTING

NOTE: This is **GENERAL** information. This article is not intended to be specific to any unique situation or individual vehicle configuration. The purpose of this Trouble Shooting information is to provide a list of common causes to problem symptoms. For model-specific Trouble Shooting, refer to **SUBJECT**, **DIAGNOSTIC**, or **TESTING** articles available in the section(s) you are accessing.

MANUAL TRANSMISSION/TRANSAXLE TROUBLE SHOOTING

Condition	Possible Cause
Noisy In Forward Gears	Low gear oil level, Loose bell housing bolts, Worn bearings or gears
Clunk On Deceleration (FWD Only)	Loose engine mounts, Worn inboard CV joints, Worn differential pinion shaft, Side gear hub counterbore in case worn oversize
Gear Clash When Shifting Forward Gears	Clutch Out Of Adjustment, Shift linkage damaged or out of adjustment, Gears or synchronizers damaged, Low gear oil level
Transmission Noisy When Moving (RWD Only) Quiet In Neutral With Clutch Engaged	Worn rear outputshaft bearing
Gear Rattle	Worn bearings, Wrong gear oil, Low gear oil, Worn gears
Steady Ticking At Idle (Increases With RPM)	Broken tooth on gear
Gear Clash When Shifting Forward Gears	Worn or broken synchronizers
Loud Whine In Reverse	Normal condition (1)
Noise When Stepping On Clutch	Bad release bearing, Worn pilot bearing
Ticking Or Screeching As Clutch Is Engaged	Faulty release bearing, Uneven pressure plate fingers
Click Or Snap When Clutch Is Engaged	Worn clutch fork, Worn or broken front bearing retainer
Transmission Shifts Hard	Clutch not releasing, Shift mechanism binding, Clutch installed backwards
Will Not Shift Into One Gear, Shifts Into All Others	Bent shift fork, Worn detent balls
Locked Into Gear, Cannot Shift	Clutch adjustment, Worn detent balls

Condition	Possible Cause
Transmission Jumps Out Of Gear	Pilot bearing worn, Bent shift fork, Worn gear teeth or face, Excessive gear train end play, Worn synchronizers, Missing detent ball spring, Shift mechanism worn or out of adjustment, Engine or transmission mount bolts loose or out of adjustment, Transmission not aligned
Shift Lever Rattle	Worn shift lever or detents, Worn shift forks, Worn synchronizers sleeve
Shift Lever Hops Under Acceleration	Worn engine or transmission mounts
(1) Most units use spur cut gears in reverse and are noisy	

POWERTRAIN

CLUTCH TROUBLE SHOOTING

NOTE: This is **GENERAL** information. This article is not intended to be specific to any unique situation or individual vehicle configuration. The purpose of this Trouble Shooting information is to provide a list of common causes to problem symptoms. For model-specific Trouble Shooting, refer to **SUBJECT**, **DIAGNOSTIC**, or **TESTING** articles available in the section(s) you are accessing.

BASIC CLUTCH TROUBLE SHOOTING CHART

CONDITION & POSSIBLE CAUSE	CORRECTION
Chattering or Grabbing	
Incorrect clutch adjustment	Adjust clutch
Oil, grease or glaze on facings	Disassemble and clean or replace
Loose "U" joint flange	See DRIVE AXLES article
Worn input shaft spline	Replace input shaft
Binding pressure plate	Replace pressure plate
Binding release lever	See CLUTCH article
Binding clutch disc hub	Replace clutch disc
Unequal pressure plate contact	Replace worn/misaligned components
Loose/bent clutch disc	Replace clutch disc
Incorrect transmission alignment	Realign transmission
Worn pressure plate, disc or flywheel	Replace damaged components
Broken or weak pressure springs	Replace pressure plate
Sticking clutch pedal	Lubricate clutch pedal & linkage
Incorrect clutch disc facing	Replace clutch disc
Engine loose in chassis	Tighten all mounting bolts
Failure to Release	
Oil or grease on clutch facings	Clean or replace clutch clutch disc
Incorrect release lever or pedal adjustment	See CLUTCH article
Worn or broken clutch facings	Replace clutch disc
Bent clutch disc or pressure plate	Replace damaged components
Clutch disc hub binding on input shaft	Clean or replace clutch disc and/or input shaft
Binding pilot bearing	Replace pilot bearing

CONDITION & POSSIBLE CAUSE		CORRECTION
Sticking release bearing sleeve		Replace release bearing and/or sleeve
Binding clutch cable		See CLUTCH article
Defective clutch master		Replace master cylinder
Defective clutch slave		Replace slave cylinder
Air in hydraulic system		Bleed hydraulic system
Rattling		
Weak or broken release lever spring		Replace spring and check alignment
Damaged pressure plate		Replace pressure plate
Broken clutch return spring		Replace return spring
Worn splines on clutch disc or input shaft		Replace clutch disc and/or input shaft
Worn clutch release bearing		Replace release bearing
Dry or worn pilot bearing		Lubricate or replace pilot bearing
Unequal release lever contact		Align or replace release lever
Incorrect pedal free play		Adjust free play
Warped or damaged clutch disc		Replace damaged components
Slipping		
Pressure springs worn or		Release pressure plate
Oily, greasy or worn facings		Clean or replace clutch disc
Incorrect clutch alignment		Realign clutch assembly
Warped clutch disc or pressure plate		Replace damaged components
Binding release levers or clutch pedal		Lubricate and/or replace release components
Squeaking		
Worn or damaged release		Replace release bearing
Dry or worn pilot or release bearing		Lubricate or replace assembly
Pilot bearing turning in crankshaft		Replace pilot bearing and/or crankshaft
Worn input shaft bearing		Replace bearing and seal
Incorrect transmission alignment		Realign transmission
Dry release fork between pivot		Lubricate release fork and pivot
Heavy and/or Stiff Pedal		
Sticking release bearing sleeve		Replace release bearing and/or sleeve
Dry or binding clutch pedal hub		Lubricate and align components
Floor mat interference with pedal		Lay mat flat in proper area
Dry or binding ball/fork pivots		Lubricate and align components
Faulty clutch cable		Replace clutch cable
Noisy Clutch Pedal		
Faulty interlock switch		Replace interlock switch
Self-adjuster ratchet noise		Lubricate or replace self-adjuster
Speed control interlock switch		Lubricate or replace interlock switch

CONDITION & POSSIBLE CAUSE	CORRECTION
Clutch Pedal Sticks Down	
Binding clutch cable	See CLUTCH article
Springs weak in pressure plate	Replace pressure plate
Binding in clutch linkage	Lubricate and free linkage
Noisy	
Dry release bearing	Lubricate or replace release bearing
Dry or worn pilot bearing	Lubricate or replace bearing
Worn input shaft bearing	Replace bearing
Transmission Click	
Weak springs in pressure	Replace pressure plate plate
Release fork loose on ball stud	Replace release fork and/or ball stud
Oil on clutch disc damper	Replace clutch disc
Broken spring in slave cylinder	Replace slave cylinder

DRIVE AXLE - NOISE DIAGNOSIS

Unrelated Noises

Some driveline trouble symptoms are also common to the engine, transmission, wheel bearings, tires, and other parts of the vehicle. Ensure cause of trouble actually is in the drive axle before adjusting, repairing, or replacing any of its parts.

Non-Drive Axle Noises

A few conditions can sound just like drive axle noise and have to be considered in pre-diagnosis. The 4 most common noises are exhaust, tires, CV/universal joints and wheel trim rings.

In certain conditions, the pitch of the exhaust gases may e gear whine. At other times, it may be mistaken for a wheel bearing rumble.

Tires, especially radial and snow, can have a high-pitched tread whine or roar, similar to gear noise. Also, some non-standard tires with an unusual tread construction may emit a roar or whine.

Defective CV/universal joints may cause clicking noises or excessive driveline play that can be improperly diagnosed as drive axle problems.

Trim and moldings also can cause a whistling or whining noise. Ensure none of these components are causing the noise before disassembling the drive axle.

Gear Noise

A "howling" or "whining" noise from the ring and pinion gear can be caused by an improper gear pattern, gear damage, or improper bearing preload. It can occur at various speeds and driving conditions, or it can be continuous.

Before disassembling axle to diagnose and correct gear ke sure that tires, exhaust, and vehicle trim have been checked as possible causes.

Chuckle

This is a particular rattling noise that sounds like a stick against the spokes of a spinning bicycle wheel. It occurs while decelerating from 40 MPH and usually can be heard until vehicle comes to a complete stop. The frequency varies with the speed of the vehicle.

A chuckle that occurs on the driving phase is usually caused ive clearance due to differential gear wear, or by a damaged tooth on the coast side of the pinion or ring gear. Even a very small tooth nick or a ridge on the edge of a gear tooth is enough the cause the noise.

This condition can be corrected simply by cleaning the gear tooth nick or ridge with a small grinding wheel. If either gear is damaged or scored badly, the gear set must be replaced. If metal has broken loose, the carrier and housing must be cleaned to remove particles that could cause damage.

Knock

This is very similar to a chuckle, though it may be louder, and occur on acceleration or deceleration. Knock can be caused by a gear tooth that is damaged on the drive side of the ring and pinion gears. Ring gear bolts that are hitting the carrier casting can cause knock. Knock can also be due to excessive end play in the axle shafts.

Clunk

Clunk is a metallic noise heard when an automatic transmission is engaged in Reverse or Drive, or when throttle is applied or released. It is caused by backlash somewhere in the driveline, but not necessarily in the axle. To determine whether driveline clunk is caused by the axle, check the total axle backlash as follows:

1. Raise vehicle on a frame or twinpost hoist so that drive wheels are free. Clamp a bar between axle companion flange and a part of the frame or body so that flange cannot move.
2. On conventional drive axles, lock the left wheel to keep it from turning. On all models, turn the right wheel slowly until it is felt to be in Drive condition. Hold a chalk marker on side of tire about 12" from center of wheel. Turn wheel in the opposite direction until it is again felt to be in Drive condition.
3. Measure the length of the chalk mark, which is the total axle backlash. If backlash is one inch or less, drive axle is not the source of clunk noise.

Bearing Whine

Bearing whine is a high-pitched sound similar to a whistle. It is usually caused by malfunctioning pinion bearings. Pinion bearings operate at drive shaft speed. Roller wheel bearings may whine in a similar manner if they run completely dry of lubricant. Bearing noise will occur at all driving speeds. This distinguishes it from gear whine, which usually comes and goes as speed changes.

Bearing Rumble

Bearing rumble sounds like marbles being tumbled. It is usually caused by a malfunctioning wheel bearing. The lower pitch is because the wheel bearing turns at only about 1/3 of drive shaft speed.

Chatter On Turns

This is a condition where the entire front or rear of vehicle vibrates when vehicle is moving. The vibration is plainly felt as well as heard. Extra differential thrust washers installed during axle repair can cause a condition of partial lock-up that creates this chatter.

Axle Shaft Noise

Axle shaft noise is similar to gear noise and pinion bearing whine. Axle shaft bearing noise will normally distinguish itself from gear noise by occurring in all driving modes (Drive, cruise, coast and float), and will persist with transmission in Neutral while vehicle is moving at problem speed.

If vehicle displays this noise condition, remove suspect parts, replace wheel seals and install a new set of bearings. Re-evaluate vehicle for noise before removing any internal components.

Vibration

Vibration is a high-frequency trembling, shaking or grinding condition (felt or heard) that may be constant or variable in level and can occur during the total operating speed range of the vehicle.

The types of vibrations that can be felt in the vehicle can be divided into 3 main groups:

- Vibrations of various unbalanced rotating parts of the vehicle.
- Resonance vibrations of the body and frame structures caused by rotating of unbalanced parts.

- Tip-in moans of resonance vibrations from stressed engine or exhaust system mounts or driveline flexing modes.

DRIVE AXLE - RWD TROUBLE SHOOTING

NOTE: This is **GENERAL** information. This article is not intended to be specific to any unique situation or individual vehicle configuration. The purpose of this Trouble Shooting information is to provide a list of common causes to problem symptoms. For model-specific Trouble Shooting, refer to **SUBJECT**, **DIAGNOSTIC**, or **TESTING** articles available in the section(s) you are accessing. For definitions of listed noises or sounds, see [DRIVE AXLE - NOISE DIAGNOSIS](#) under POWERTRAIN.

DRIVE AXLE (RWD) TROUBLE SHOOTING

CONDITION & POSSIBLE CAUSE	CORRECTION
Knocking or Clunking	
Differential Side Gear Clearance	Check Clearance
Worn Pinion Shaft	Replace Pinion Shaft
Axle Shaft End Play	Check End Play
Missing Gear Teeth	Check Differential/Replace Gear
Wrong Axle Backlash	Check Backlash
Misaligned Driveline	Realign Driveline
Clinking During Engagement	
Side Gear Clearance	Check Clearance
Ring and Pinion Backlash	Check Backlash
Worn/Loose Pinion Shaft	Replace Shaft/Bearing
Bad "U" Joint	Replace "U" Joint
Sticking Slip Yoke	Lube Slip Yoke
Broken Rear Axle Mount	Replace Mount
Loose Drive Shaft Flange	Check Flange
Click/Chatter On Turns	
Differential Side Gear Clearance	Check Clearance
Wrong Turn On Plates (1)	Replace Clutch Plates
Wrong Differential Lubricant (1)	Change Lubricant
Knock Or Click	
Flat Spot on Rear Wheel Bearing	Replace Wheel Bearing
Low Vibration At All Speeds	
Faulty Wheel Bearing	Replace Wheel Bearing
Faulty "U" Joint	Replace "U" Joint
Faulty Drive Shaft	Balance Drive Shaft
Faulty Companion Flange	Replace Flange
Faulty Slip Yoke Flange	Replace Flange
(1) Limited slip differential only.	

FWD AXLE SHAFTS & CV JOINTS TROUBLE SHOOTING

NOTE: This is **GENERAL** information. This article is not intended to be specific to any unique situation or individual vehicle configuration. The purpose of this Trouble Shooting information is to provide a list of common causes to problem symptoms. For model-specific Trouble Shooting, refer to **SUBJECT**, **DIAGNOSTIC**, or **TESTING** articles available in the section(s) you are accessing.

BASIC FWD AXLE SHAFTS & CV JOINTS TROUBLE SHOOTING CHART

--	--

CONDITION	POSSIBLE CAUSE
Grease Leaks	CV boot torn or cracked
Clicking Noise on Cornering	Damaged outer CV
Clunk Noise on Acceleration	Damaged inner CV
Vibration or Shudder on Acceleration	Sticking, damaged or worn CV Misalignment or spring height

STEERING & SUSPENSION

MANUAL STEERING GEAR TROUBLE SHOOTING

NOTE: This is **GENERAL** information. This article is not intended to be specific to any unique situation or individual vehicle configuration. The purpose of this Trouble Shooting information is to provide a list of common causes to problem symptoms. For model-specific Trouble Shooting, refer to **SUBJECT**, **DIAGNOSTIC**, or **TESTING** articles available in the section(s) you are accessing.

BASIC MANUAL STEERING GEAR TROUBLE SHOOTING CHART

CONDITION & POSSIBLE CAUSE	CORRECTION
Rattle or Chucking Noise in Rack and Pinion	
Rack and pinion mounting bracket loose	Tighten all mounting bolts
Lack of/or incorrect lubricant	Correct as necessary
Steering gear mounting bolts loose	Tighten all mounting bolts
Excessive Play	
Front wheel bearing improperly adjusted	See FRONT SUSPENSION article
Loose or worn steering linkage	See STEERING LINKAGE article
Loose or worn steering gear shift	See MANUAL STEERING GEAR article
Steering arm loose on gear shaft	See MANUAL STEERING GEAR article
Steering gear housing bolts loose	Tighten all mounting bolts
Steering gear adjustment too loose	See MANUAL STEERING GEAR article
Steering arms loose on knuckles	Tighten and check steering linkage
Rack and pinion mounting loose	Tighten all mounting bolts
Rack and pinion out of adjustment	See adjustment in STEERING article
Tie rod end loose	Tighten and check steering linkage
Excessive Pitman shaft-to-ball nut lash	Repair as necessary
Poor Returnability	
Lack of lubricant in ball joint or linkage	Lubricate and service systems
Binding in linkage or ball joints	See STEERING LINKAGE and SUSPENSION article
Improper front end alignment	See WHEEL ALIGNMENT article
Improper tire pressure	Inflate to proper pressure
Tie rod binding	Inflate to proper pressure
Shaft seal rubbing shaft	See STEERING COLUMN article

CONDITION & POSSIBLE CAUSE	CORRECTION
Excessive Vertical Motion	
Improper tire pressure	Inflate to proper pressure
Tires, wheels or rotors out of balance	Balance tires then check wheels and rotors
Worn or faulty shock absorbers	Check and replace if necessary
Loose tie rod ends or steering	Tighten or replace if necessary
Loose or worn wheel bearings	See SUSPENSION article
Steering Pulls to One Side	
Improper tire pressure	Inflate to proper pressure
Front tires are different sizes	Rotate or replace if necessary
Wheel bearings not adjusted properly	See FRONT SUSPENSION article
Bent or broken suspension components	See FRONT SUSPENSION article
Improper wheel alignment	See WHEEL ALIGNMENT article
Brakes dragging	See BRAKES article
Instability	
Low or uneven tire pressure	Inflate to proper pressure
Loose or worn wheel bearings	See FRONT SUSPENSION article
Loose or worn idler arm bushing	See FRONT SUSPENSION article
Loose or worn strut bushings	See FRONT SUSPENSION article
Incorrect front wheel alignment	See WHEEL ALIGNMENT article
Steering gear not centered	See MANUAL STEERING GEARS article
Springs or shock	Check and replace if necessary
Improper cross shaft	See MANUAL STEERING GEARS article

POWER STEERING TROUBLE SHOOTING

NOTE: This is **GENERAL** information. This article is not intended to be specific to any unique situation or individual vehicle configuration. The purpose of this Trouble Shooting information is to provide a list of common causes to problem symptoms. For model-specific Trouble Shooting, refer to **SUBJECT**, **DIAGNOSTIC**, or **TESTING** articles available in the section(s) you are accessing.

BASIC POWER STEERING TROUBLE SHOOTING CHART

CONDITION & POSSIBLE CAUSE	CORRECTION
Rattle or Chucking Noise	
Pressure hoses touching engine parts	Adjust to proper clearance
Loose Pitman shaft	Adjust or replace if necessary
Tie rods ends or Pitman arm loose	Tighten and check system
Rack and pinion mounts loose	Tighten all mounting bolts

CONDITION & POSSIBLE CAUSE	CORRECTION
Free play in worm gear	See POWER STEERING GEAR article
Loose sector shaft or thrust bearing adjustment	See POWER STEERING GEAR
Free play in pot coupling	See STEERING COLUMN article
Worn shaft serrations	See STEERING COLUMN article
Growl in Steering Pump	
Excessive pressure in hoses	Restricted hoses, see POWER STEERING GEAR article
Scored pressure plates	See POWER STEERING GEAR article
Scored thrust plates or rotor	See POWER STEERING GEAR article
Extreme wear of cam ring	See POWER STEERING GEAR article
Rattle in Steering Pump	
Vanes not installed	See POWER STEERING PUMP article
Vanes sticking in rotor	See POWER STEERING PUMP article
Swish noise in Pump	
Defective flow control valve	See POWER STEERING PUMP article
Groan in Steering Pump	
Air in fluid	See POWER STEERING PUMP article
Poor pressure hose connection	Tighten and check, replace if necessary
Squawk When Turning	
Damper "O" ring on valve spool cut	See POWER STEERING PUMP article
Moan or Whine in Pump	
Pump shaft bearing scored	Replace bearing and fluid
Air in fluid or fluid level low	See POWER STEERING PUMP article
Hose or column grounded	Check and replace if necessary
Cover "O" ring missing or damaged	See POWER STEERING PUMP article
Valve cover baffle missing or damaged	See POWER STEERING PUMP article
Interference of components in pump	See POWER STEERING PUMP article
Loose or poor bracket alignment	Correct or replace if necessary
Hissing When Parking	
Internal leakage in steering gear	Check valved assembly first
Chirp in Steering Pump	
Loose or worn power steering belt	Adjust or replace if necessary
Buzzing When Not Steering	

CONDITION & POSSIBLE CAUSE		CORRECTION
Noisy pump		See POWER STEERING PUMP article
Free play in steering shaft bearing		See STEERING COLUMN article
Bearing loose on shaft serrations		See STEERING COLUMN article
Clicking Noise in Pump		
Pump slippers too long		See POWER STEERING PUMP article
Broken slipper springs		See POWER STEERING PUMP article
Excessive wear or nicked rotors		See POWER STEERING PUMP article
Damaged cam contour		See POWER STEERING PUMP article
Poor Return of Wheel		
Wheel rubbing against turn signal		See STEERING COLUMN SWITCHES article
Flange rubbing steering gear adjuster		See STEERING COLUMN article
Tight or frozen steering shaft bearing		See STEERING COLUMN article
Steering gear out of adjustment		See POWER STEERING GEAR article
Sticking or plugged spool valve		See POWER STEERING PUMP article
Improper front end alignment		See WHEEL ALIGNMENT article
Wheel bearings worn or loose		See FRONT SUSPENSION article
Ties rods or ball joints binding		Check and replace if necessary
Intermediate shaft joints binding		See STEERING COLUMN article
Kinked pressure hoses		Correct or replace if necessary
Loose housing head spanner nut		See POWER STEERING GEAR article
Damaged valve lever		See POWER STEERING GEAR article
Sector shaft adjusted too tight		See ADJUSTMENTS in POWER STEERING GEAR article
Worm thrust bearing adjusted too tight		See ADJUSTMENTS in POWER STEERING GEAR article
Reaction ring sticking in cylinder		See POWER STEERING GEAR article
Reaction ring sticking in housing head		See POWER STEERING GEAR article
Steering pump internal leakage		See POWER STEERING PUMP article
Steering gear-to-column misalignment		See STEERING COLUMN article
Lack of lubrication in linkage		Service front suspension

CONDITION & POSSIBLE CAUSE	CORRECTION
Lack of lubrication in ball joints	Service front suspension
Increased Effort When Turning Wheel Fast Foaming, Milky Power Steering Fluid, Low Fluid Level or Low Pressure	
High internal pump leakage	See POWER STEERING PUMP article
Power steering pump belt slipping	Adjust or replace if necessary
Low fluid level	Check and fill to proper level
Engine idle speed too low	Adjust to correct setting
Air in pump fluid system	See POWER STEERING PUMP article
Pump output low	See POWER STEERING PUMP article
Steering gear malfunctioning	See POWER STEERING GEAR article
Wheel Surges or Jerks	
Low fluid level	Check and fill to proper level
Loose fan belt	Adjust or replace if necessary
Insufficient pump pressure	See POWER STEERING PUMP article
Sticky flow control valve	See POWER STEERING PUMP article
Linkage hitting oil pan at full turn	Replace bent components
Kick Back or Free Play	
Air in pump fluid system	See POWER STEERING PUMP article
Worn poppet valve in steering gear	See POWER STEERING PUMP article
Excessive over center lash	See POWER STEERING GEAR article
Thrust bearing out of adjustment	See POWER STEERING GEAR article
Free play in pot coupling	See POWER STEERING PUMP article
Steering gear coupling loose on shaft	See POWER STEERING PUMP article
Steering disc mounting bolts loose	Tighten or replace if necessary
Coupling loose on worm shaft	Tighten or replace if necessary
Improper sector shaft adjustment	See POWER STEERING GEAR article
Excessive worm piston side play	See POWER STEERING GEAR article
Damaged valve lever	See POWER STEERING GEAR article
Universal joint loose	Tighten or replace if necessary
Defective rotary valve	See POWER STEERING GEAR article
No Power When Parking	

CONDITION & POSSIBLE CAUSE		CORRECTION
Sticking flow control valve		See POWER STEERING PUMP article
Insufficient pump pressure output		See POWER STEERING PUMP article
Excessive internal pump leakage		See POWER STEERING PUMP article
Excessive internal gear leakage		See POWER STEERING PUMP article
Flange rubs against gear adjust plug		See STEERING COLUMN article
Loose pump belt		Adjust or replace if necessary
Low fluid level		Check and add proper amount of fluid
Engine idle too low		Adjust to correct setting
Steering gear-to-column misaligned		See STEERING COLUMN article
No Power, Left Turn		
Left turn reaction seal "O" ring worn		See POWER STEERING GEAR article
Left turn reaction seal damaged/missing		See POWER STEERING GEAR article
Cylinder head "O" ring damaged		See POWER STEERING PUMP article
No Power, Right Turns		
Column pot coupling bottomed		See STEERING COLUMN article
Right turn reaction seal "O" ring worn		See POWER STEERING GEAR article
Right turn reaction seal damaged		See POWER STEERING GEAR article
Internal leakage through piston end plug		See POWER STEERING GEAR article
Internal leakage through side plugs		See POWER STEERING GEAR article
Lack of Effort in Turning		
Left and/or right reaction seal sticking in cylinder head		Replace, see POWER STEERING GEAR article
Wanders to One Side		
Front end alignment incorrect		See WHEEL ALIGNMENT article
Unbalanced steering gear valve		See POWER STEERING GEAR article
Low Pressure Due to Steering Pump		
Flow control valve stuck or inoperative		See POWER STEERING PUMP article
Pressure plate not flat against cam ring		See POWER STEERING PUMP article
Extreme wear of cam ring		Replace and check adjustments
Scored plate, thrust plate or rotor		See POWER STEERING PUMP article
Vanes not installed properly		See POWER STEERING PUMP article

CONDITION & POSSIBLE CAUSE	CORRECTION
Vanes sticking in rotor slots	See POWER STEERING PUMP article
Cracked/broken thrust or pressure plate	See POWER STEERING PUMP article

STEERING COLUMN TROUBLE SHOOTING

NOTE: This is **GENERAL** information. This article is not intended to be specific to any unique situation or individual vehicle configuration. The purpose of this Trouble Shooting information is to provide a list of common causes to problem symptoms. For model-specific Trouble Shooting, refer to **SUBJECT**, **DIAGNOSTIC**, or **TESTING** articles available in the section(s) you are accessing.

BASIC STEERING COLUMN TROUBLE SHOOTING CHART

CONDITION & POSSIBLE CAUSE	CORRECTION
Noise in Steering	
Coupling pulled apart	See STEERING COLUMNS article
Column not correctly aligned	See STEERING COLUMNS article
Broken lower joint	Replace joint
Horn contact ring not	See STEERING COLUMN article
Bearing not lubricated	See STEERING COLUMN article
Shaft snap ring not properly seated	Reseat or replace snap ring
Plastic spherical joint not lubricated	See STEERING COLUMN article
Shroud or housing loose	Tighten holding screws
Lock plate retaining ring not seated	See STEERING COLUMN article
Loose sight shield	Tighten holding screws
High Steering Shaft Effort	
Column assembly misaligned	See STEERING COLUMN article
Improperly installed dust shield	Adjust or replace
Tight steering universal joint	See STEERING COLUMN article
High Shift Effort	
Column is out of alignment	See STEERING COLUMN article
Improperly installed dust shield	Adjust or replace
Seals or bearings not lubricated	See STEERING COLUMNS article
Mounting bracket screws too long	Replace with new shorter screws
Burrs on shift tube	Remove burrs or replace tube
Lower bowl bearing assembled wrong	See STEERING COLUMN article
Shift tube bent or broken	Replace as necessary
Improper adjustment of shift levers	See STEERING COLUMN article
Improper Trans. Shifting	
Sheared shift tube joint	Replace as necessary

CONDITION & POSSIBLE CAUSE	CORRECTION
Sheared lower shaft lever	Replace as necessary
Improper shift lever adjustment	See STEERING COLUMN article
Improper gate plate adjustment	See STEERING COLUMN article
Excess Play in Column	
Instrument panel bracket bolts loose	Tighten bolts and check bracket
Broken weld nut on jacket	See STEERING COLUMN article
Instrument bracket capsule sheared	See STEERING COLUMN article
Column bracket/jacket bolts loose	Tighten bolts and check bracket
Steering Locks in Gear	
Release lever mechanism	See STEERING COLUMN article

SUSPENSION TROUBLE SHOOTING

NOTE: This is **GENERAL** information. This article is not intended to be specific to any unique situation or individual vehicle configuration. The purpose of this Trouble Shooting information is to provide a list of common causes to problem symptoms. For model-specific Trouble Shooting, refer to **SUBJECT**, **DIAGNOSTIC**, or **TESTING** articles available in the section(s) you are accessing.

BASIC SUSPENSION TROUBLE SHOOTING CHART

CONDITION & POSSIBLE CAUSE	CORRECTION
Front End Noise	
Loose or worn wheel	See Wheel Bearing Adjustment in SUSPENSION
Worn shocks or shock mountings	Replace struts or strut mountings
Worn struts or strut mountings	Replace struts or strut mountings
Loose or worn lower control arm	See SUSPENSION
Loose steering gear-to-frame bolts	See STEERING
Worn control arm bushings	See SUSPENSION
Ball joints not lubricated	Lubricate ball joints & see Ball Joint Checking in SUSPENSION
Front Wheel Shake, Shimmy, or Vibration	
Tires or wheels out of balance	Check tire balance
Incorrect wheel alignment	See WHEEL ALIGNMENT
Drive shaft unbalanced	Check drive shaft balance
Loose or worn wheel bearings	See WHEEL ALIGNMENT
Loose or worn tie rod ends	See SUSPENSION
Worn upper ball joints	See Ball Joint Checking in SUSPENSION
Worn shock absorbers	Replace shock absorbers
Worn strut bushings	Replace strut bushings
Car Pulls to One Side	

CONDITION & POSSIBLE CAUSE		CORRECTION
Mismatched or uneven tires		Check tire condition
Broken or sagging springs		See SUSPENSION
Loose or worn strut bushings		See SUSPENSION
Improper wheel alignment		See WHEEL ALIGNMENT
Improper rear axle alignment		Check rear axle alignment
Power steering gear unbalanced		See STEERING
Front brakes dragging		See BRAKES
Abnormal Tire Wear		
Unbalanced tires		Check tire balance & rotation
Sagging or broken springs		See SUSPENSION
Incorrect front end alignment		See WHEEL ALIGNMENT
Faulty shock absorbers		Replace shock absorbers
Scuffed Tires		
Toe-In incorrect		See WHEEL ALIGNMENT
Suspension arm bent or twisted		See appropriate SUSPENSION article
Springs Bottom or Sag		
Bent or broken springs		See SUSPENSION
Leaking or worn shock absorbers		Replace shock absorbers
Frame misalignment		Check frame for damage
Spring Noises		
Loose "U" Bolts		See SUSPENSION
Loose or worn bushings		See SUSPENSION
Worn or missing interliners		See SUSPENSION
Shock Absorber Noise		
Loose shock mountings		Check & tighten mountings
Worn bushings		Replace bushings
Air in system		Bleed air from system
Undercoating on shocks		Remove undercoating
Car Leans or Sways on Corners		
Loose stabilizer bar		See SUSPENSION
Faulty shocks or mountings		Replace shocks or mountings
Broken or sagging springs		See SUSPENSION
Shock Absorbers Leaking		
Worn seals or reservoir tube crimped		See SUSPENSION
Broken Springs		
Loose "U" bolts		See SUSPENSION
Inoperative shock absorbers		Replace shock absorbers

WHEEL ALIGNMENT TROUBLE SHOOTING

NOTE:

This is **GENERAL** information. This article is not intended to be specific to any unique situation or individual vehicle configuration. The purpose of this Trouble Shooting information is to provide a list of common causes to problem symptoms. For model-specific Trouble Shooting, refer to **SUBJECT**, **DIAGNOSTIC**, or **TESTING** articles available in the section(s) you are accessing.

BASIC WHEEL ALIGNMENT TROUBLE SHOOTING CHART

CONDITION & POSSIBLE CAUSE	CORRECTION
Premature Tire Wear	
Improper tire inflation	Check tire pressure
Front alignment out of tolerance	See ALIGNMENT SPECS in WHEEL ALIGNMENT section
Suspension components worn	See SUSPENSION section
Steering system components worn	See STEERING section
Improper standing height	See WHEEL ALIGNMENT
Uneven or sagging springs	See SUSPENSION section
Bent wheel	See WHEEL ALIGNMENT
Improper torsion bar adjustment	See SUSPENSION section
Loose or worn wheel bearings	See WHEEL BEARING ADJ. in SUSPENSION section
Worn or defective shock	Replace shock absorbers
Tires out of balance	Check tire balance
Pulls to One Side	
Improper tire inflation	Check tire pressure
Brake dragging	See BRAKE section
Mismatched tires	See WHEEL ALIGNMENT
Broken or sagging spring	See SUSPENSION section
Broken torsion bar	See SUSPENSION section
Power steering valve not centered	See STEERING section
Front alignment out of tolerance	See WHEEL ALIGNMENT section
Defective wheel bearing	See WHEEL BEARINGS in SUSPENSION section
Uneven sway bar links	See SUSPENSION section
Frame bent	Check for frame damage
Steering system bushing worn	See STEERING section
Hard Steering	
Idler arm bushing too tight	See STEERING LINKAGE in STEERING section
Ball joint tight or seized	See SUSPENSION section
Steering linkage too tight	See STEERING LINKAGE in STEERING section
Power steering fluid low	Add proper amount of fluid
Power steering drive belt loose	See STEERING section
Power steering pump defective	See STEERING section
Steering gear out of adjustment	See STEERING section
Incorrect wheel alignment	See WHEEL ALIGNMENT
Damaged steering gear	See STEERING section
Damaged suspension	See SUSPENSION section
Bent steering knuckle or supports	See SUSPENSION section
Vehicle "Wanders"	
Strut rod or control arm bushing worn	See SUSPENSION section

CONDITION & POSSIBLE CAUSE	CORRECTION
Loose or worn wheel bearings	See WHEEL BEARINGS in SUSPENSION section
Improper tire inflation	Check tire pressure
Stabilizer bar missing or defective	See SUSPENSION section
Wheel alignment out of tolerance	See Adjustment in WHEEL ALIGNMENT section
Broken spring	See SUSPENSION section
Defective shock absorber	Replace shock absorbers
Worn steering & suspension components	See SUSPENSION section
Front End Shimmy	
Tire out of balance/round	Check tire balance
Excessive wheel runout	See WHEEL ALIGNMENT
Insufficient or improper caster	See WHEEL ALIGNMENT section
Worn suspension or steering components	See SUSPENSION section
Defective shock absorbers	Replace shock absorber
Wheel bearings worn or loose	See WHEEL BEARING ADJ. in SUSPENSION section
Power steering reaction Bracket loose	See STEERING section
Steering gear box (rack) mounting loose	See STEERING section
Steering gear adjustment loose	See STEERING section
Worn spherical joints	See SUSPENSION section
Toe-In Not Adjustable	
Lower control arm bent	See SUSPENSION section
Frame bent	Check frame for damage
Camber Not Adjustable	
Control arm bent	See SUSPENSION section
Frame bent	Check frame for damage
Hub & bearing not seated properly	See SUSPENSION section