

2018 GENERAL INFORMATION

Vehicle Diagnostic Information - Diagnostic Information And Procedures - Traverse

DIAGNOSTIC INFORMATION AND PROCEDURES

STRATEGY BASED DIAGNOSIS

The goal of Strategy Based Diagnosis is to provide guidance when you create a plan of action for each specific diagnostic situation. Following a similar plan for each diagnostic situation, you will achieve maximum efficiency when you diagnose and repair vehicles. Although each of the Strategy Based Diagnosis steps are numbered, you are not required to complete every step in order to successfully diagnose a customer concern. The first step of your diagnostic process should always be Understand and Verify the Customer's Concern. The final step of your diagnostic process should be to Repair and verify the Fix. Refer to the steps listed below for the correct Strategy Based Diagnosis.

NOTE: For additional information on the following steps refer to the corresponding numbered paragraphs listed below.

1. Understand and verify the customers concern.
2. Verify the vehicle is not operating as designed:
 - **If the vehicle is operating as designed review the suggestions listed below:**
 - Check Identical Vehicle
 - Customer Misunderstanding of System - Explain operation to customer or refer to owners or service information.
 - Customer dissatisfaction - Submit a Field Product Report
 - **Go to next step: If the vehicle is not operating as designed**
3. Perform preliminary checks - Visual inspections and operational
 - **If the customers concern is found, refer to step 7**
 - **Go to next step: If the customers concern is not found**
4. Perform the Diagnostic System Check - Vehicle, determine the diagnostic service category to perform.
 - **If the customers concern is found, refer to step 7**
 - **Go to next step: If the customers concern is not found**
5. Check for related Bulletins, Recalls and Preliminary Information.
 - **If the customers concern is found, refer to step 7**
 - **Go to next step: If the customers concern is not found**
6. Follow the diagnostic path listed below:
 1. Current DTC - Follow DTC Diagnostics
 2. Symptom no DTC - Follow Symptom Diagnostics
 3. No published diagnostic - Analyze and develop diagnostics or call Technical Assistance
 4. Intermittent/History DTC - See diagnostic detail below
7. Isolate the root cause then repair and verify the fix.
8. Re-examine the concern.
 - **If the vehicle is not repaired, refer to step 1**
 - **Go to next step: If the vehicle is repaired**
9. All OK.

Additional Information

1. Understand and Verify the Customer's Concern: The first part of this step is to obtain as much information as possible from the customer. Are there aftermarket accessories on the vehicle? When does the condition occur? Where does the condition occur? How long does the condition last? How often does the condition occur? In order to verify the concern, the technician should be familiar with the normal operation of the system and refer to the owner or service information for any information needed.
2. Vehicle Operating as Designed: This condition exists when the vehicle is found to operate normally. The condition described by the customer may be normal. Compare with another like vehicle that is operating normally under the same conditions described by the customer. Explain your findings and the operation of the system to the customer. If the customer is dissatisfied submit a Field Product Report.
3. Preliminary Checks: Conduct a thorough visual inspection. Review the service history. Detect unusual sounds or odors. Gather diagnostic trouble code (DTC) information in order to achieve an effective repair.
4. Perform Published Diagnostic System Check- Vehicle: The [Diagnostic System Check - Vehicle](#) verifies the proper operation of the system. This will lead the technician in an organized approach to diagnostics and identify what category of diagnostic to perform.
5. Check for related Bulletins, Recalls and Preliminary Information (PI).
6. Diagnostic categories:
 1. Current DTC: Follow the designated DTC diagnostic in order to make an effective repair. Refer to [Diagnostic Trouble Code \(DTC\) List - Vehicle](#).
 2. Symptom - No DTC: Select the appropriate symptom diagnostic. Follow the diagnostic steps or suggestions in order to complete the repair. Refer to [Symptoms - Vehicle](#).
 3. No Published Diagnostics: Analyze the Concern. Develop a plan for the diagnostics. The service information schematics will help you to see system power, ground, input, and output circuits. You can also identify splices and other areas where multiple circuits are tied together. Look at component locations to see if components, connectors or harnesses may be exposed to extreme temperature, moisture, or corrosives (road salt, battery acid, oil or other fluids). Utilize the wiring diagrams, system description and operation, and system circuit description.
 4. Intermittent/History DTC: An intermittent condition is one that does not occur continuously, may be difficult to duplicate, and will only occur when certain conditions are met. Generally, an intermittent is caused by faulty electrical connections and wiring, malfunctioning components, electromagnetic/radio frequency interference, driving conditions, or aftermarket equipment. The following approaches/tools may prove to be beneficial in locating and repairing an intermittent condition or history DTC.
 - Combining technicians knowledge with the available service information.
 - Evaluate the symptoms and conditions described by the customer.

North America - The GM Customer Concern Verification Sheets have been designed to improve communications between the service customer and the technician. The more clearly the technician understands the concern and its symptoms, the more likely the concern will be fixed right the first time. The blank CCVS can be found in GM Global Connect under Service, Service Forms.

 - Follow the suggestions on [Testing for Intermittent Conditions and Poor Connections](#).
 - Use a tool with data capturing capabilities like scan tool, digital multi-meter, or (if available) a vehicle data recorder.
7. Isolate the Root Cause then Repair and Verify Fix: After isolating the root cause, make the repairs and validate for the correct operation by performing the [Diagnostic Repair Verification](#). Verifying that the DTC or symptom has been corrected may involve road testing the vehicle.
8. Re-examine the Concern: If a technician cannot successfully find or isolate the concern, a re-evaluation is necessary. Re-verify the concern. The concern could be an intermittent or normal condition.

DIAGNOSTIC PROCEDURE INSTRUCTIONS

The following is an instructional overview of all categories which may be included in a diagnostic procedure.

Diagnostic Instructions

- A link to the [Diagnostic System Check - Vehicle](#) is provided here. This procedure should be performed prior to performing other diagnostic procedures, as this prevents misdiagnosis where there are integrated system dependencies.
- A link to the [Strategy Based Diagnosis](#) is provided here. This provides an overview on how a technician should diagnose a vehicle.
- A link to the [Diagnostic Procedure Instructions](#) is provided here. This information is an instructional overview of all categories which may be included in a diagnostic procedure.

DTC Descriptor

Lists all DTCs and descriptors that are diagnosed within the procedure.

If the DTC supports symptom bytes they will either be listed with the DTC or there will be a link to the symptom byte list.

Diagnostic Fault Information

The Diagnostic Fault Information table identifies each circuit that makes up an electrical subsystem and the associated circuit faults. DTCs and symptoms are listed in the table for all circuit fault modes. This information can be used to diagnose an electrical fault, or as a quick visual aid showing how the different DTCs and symptoms apply for the subsystem being diagnosed.

All DTCs and symptoms shown in this table are not necessarily diagnosed during this procedure.

An example table from an engine coolant temperature (ECT) procedure:

Circuit	Short to Ground	Open/High Resistance	Short to Voltage	Signal Performance
Signal	P0117	P0118, P0119	P0118*, P0119	P0128, P111E
Low Reference	-	P0118, P0119	-	P0128
*Internal control module or component damage may occur if the circuit shorts to B+.				

Typical Scan Tool Data

The Typical Scan Tool Data table identifies a scan tool data parameter and its value in reference to potential circuit faults.

An example table from an ECT procedure:

ECT Sensor

Circuit	Short to Ground	Open	Short to Voltage
Operating Conditions: Engine = Idling - At normal operating temperature. Parameter Normal Range: 88 to 105Â°C (190 to 221Â°F)			
Signal	140Â°C (248Â°F)	-40Â°C (-40Â°F)	-40Â°C (-40Â°F)
Low Reference	-	-40Â°C (-40Â°F)	-

Circuit/System Description

Circuit/System Description identifies circuits, components, and describes how the circuit/system normally functions.

Conditions for Running the DTC

Conditions for Running the DTC, identifies what conditions must be present to allow the diagnostic to run.

Conditions for Setting the DTC

Conditions for Setting the DTC, identifies the conditions that must be present in order to fail the diagnostic and when to set the DTC.

Actions Taken When the DTC Sets

Actions Taken When the DTC sets, identifies the default actions taken when a control module sets a DTC.

Conditions for Clearing the DTC

Conditions for Clearing the DTC, identifies the conditions that must be met in order to clear the DTC.

Diagnostic Aids

Diagnostic Aids are suggestions which explain other methods to diagnose the condition. It also provides unique information about the system to assist the technician in finding and repairing a vehicle condition.

Reference Information

Reference Information includes links providing additional information to be used with the diagnostic procedure.

For example:

- Schematic Reference
- Connector End View Reference
- Component View Reference
- Description and Operation
- Electrical Information Reference
- DTC Type Reference
- Scan Tool Reference
- Special Tools

Circuit/System Verification

The Circuit/System Verification, when supported, needs to be performed prior to the Circuit/System Testing. It will determine the following conditions:

- If a higher priority concern needs to be addressed first (E.g. other DTCs)
- If other conditions are present (E.g. low fluid level)
- If the condition is current
- If the condition is intermittent
- If the system is all Ok

NOTE: Any diagnostic step that asks if a DTC is "set" refers to a Set, Current, Present, Active DTC status. This does not include any other DTC status. For example History, Not Run, Passed and Failed.

Circuit/System Verification is a non-intrusive procedure outlining how to verify that a system or a portion of a system is functioning correctly. During the verification process, the vehicle is kept intact and tested as a complete system. The verification is used to assist the technician in determining whether a condition is current, intermittent, or not present (All Ok). When a condition is determined to be intermittent a technician can use the [Testing for Intermittent Conditions and Poor Connections](#) link in Electrical Information Reference for additional testing information.

The technician should be able to identify if the fault is occurring on the input (signal) circuit or on the output (control) circuit when applicable.

Component Codes

The component codes are a language independent method of identifying a common component between different areas in the service information. The component codes work regardless on how the actual component name was translated.

The component codes used on the schematics will have the base code with an extension to identify location or quantity. For example the ABS wheel speed sensors are identified on the schematic with a base code (B5) and a location extension (LF, RF, LR, and RR) as seen below:

- B5LF Wheel Speed Sensor - Left Front
- B5RF Wheel Speed Sensor - Right Front
- B5LR Wheel Speed Sensor - Left Rear
- B5RR Wheel Speed Sensor - Right Rear

The diagnostic procedures will use the base code (B5) for a wheel speed sensor but may or may not use the extension identifying location (LF, RF, LR, and RR).

Example:

Disconnect the harness connector at the appropriate B5 Wheel Speed Sensor.

Or

Disconnect the appropriate electrical connector: B5 Wheel Speed Sensor

This is done so the diagnostic procedure can be common for all four wheel speed sensors and not have to take into account part location or quantity.

When the diagnostic states "the appropriate" it is up to the technician to identify which component is being diagnosed either by the symptom (Driver's door lock is inoperative) or the DTC descriptor (DTC C0585 04: Left Rear Door Latch Circuit Open).

Circuit/System Testing

NOTE: **Performing the Circuit/System Verification category first will aid in determining if a vehicle condition currently exists.**

Circuit/System Testing is a step by step, positive-flow, testing sequence which allows the technician to perform each test step, in sequence, until a fault is detected. If the result of a numbered test step is NOT achieved, the Right Repair Arrow below the failed test will identify what actions need to take place. If the result of a numbered test step is achieved, the normal flow is to proceed to the next numbered test step, as indicated by the Down Pass Arrow.

Intrusive diagnostics are performed to locate the system fault. System harness connections are disconnected from the component or control module to test individual circuit functions. The component or control module will be used to assist in verifying the circuit function. When a test does not pass, the repair steps (Right Repair Arrow) will indicate what circuit faults to test. For example a short to voltage, short to ground, or open/high resistance.

When testing for individual circuit faults, the technician is expected to perform terminal inspections such as connection surfaces and terminal tension at both the harness and the component or control module. When a condition is determined to be intermittent a technician can use the [Testing for Intermittent Conditions and Poor Connections](#) , or [Circuit Testing](#) link in Electrical Information Reference for additional information.

The component and control module will also be diagnosed during the test steps. A retest of a component or control module should always be performed before replacement. For example, reconnect all components and control modules and retest the system to verify the condition still exists before replacing components or control modules.

Component Testing

Component Testing may offer a static and/or dynamic component tests. These tests can be used to verify if a component is operating correctly to avoid unnecessary replacement.

Testing control modules in this category will not be offered. In most cases, the control module is used to verify the harness circuits in the Circuit/System Testing category and a retest of the control module should always be performed before replacement.

Repair Instructions

Repair Instructions provides a link to [Diagnostic Repair Verification](#). This link describes how to verify the vehicle is repaired.

All links to repair, replacement, or programming procedures are located here.

Repair Verification

Repair Verification describes how to verify the vehicle is repaired when additional instructions are needed beyond what is in the Diagnostic Repair Verification.

DIAGNOSTIC SYSTEM CHECK INSTRUCTIONS

The following is an overview of instructions for the general information and 14 step System Verification included in the Diagnostic System Check - Vehicle procedure.

Diagnostic Instructions

A link to [Strategy Based Diagnosis](#) is provided as an overview on how a technician should diagnose a vehicle.

A link to the Diagnostic System Check Instructions is provided. This provides an overview of instructions and examples for the general information and 14 step System Verification included in the Diagnostic System Check - Vehicle procedure. The examples in this document are intended to give the technician a general idea of what the test step is referring to. They are not intended to list every possible condition or situation.

Diagnostic Systems Check steps are listed by priority to guide the technician to the appropriate diagnostic procedure to correct the customer concern. There are many ways to determine the priority of diagnosing a vehicle concern. Some faults can cause customer perceived symptoms in areas unrelated to the fault. Using an example from the System Check, after reading DTCs, the technician is asked to verify there are no Electronic Control Unit Internal Performance Faults present. It is important that any internal performance issues are addressed prior to continuing through the System Check. There is no benefit addressing other DTCs that could be set due to an internal fault to a control module. If the fault is present, performing the diagnostic procedure for that fault will likely correct the customer perceived concern and possibly eliminate other DTCs that may be set.

Not all steps of the Diagnostic System Check have to be performed. The Diagnostic System Check tries to prioritize the test steps with the highest priority faults first. The technician is then lead to another document to do the actual diagnosis or repair. The strategy is to repair higher level faults that may be the cause of other system or component level symptoms. Additionally, the Diagnostic System Check can only be used for a single fault at a time. If additional faults are present, the technician must perform the diagnostic system check for each concern until all customer concerns are corrected.

Once a repair has been completed, General Motors diagnostic strategy is to always have the technician verify that the customer concern has been corrected. This is to prevent comebacks and to ensure customer satisfaction with their dealership experience. Therefore a link has been provided to [Diagnostic Repair Verification](#) procedure for the technician to verify the customer concern has been corrected.

There are some assumptions made when General Motors prepares service information. They include the following areas which are presumed to function as designed:

- The 12-volt battery is fully charged. General Motors assumes the majority of vehicles brought in for repair will be able to start and be driven into the service stall. If the vehicle has a dead battery, it is slow cranking or for any other reason the technician feels the customer concern may be battery related, a link is provided to [Battery Inspection/Test](#) . This procedure will guide the technician through inspecting and verifying the battery functions properly.
- Fuses should not be open. General Motors does not call out in diagnostic procedures to verify a fuse. The technician is expected to find an open fuse when the diagnostic test step states to check

for an open circuit condition. Therefore a link has been provided to [Power Distribution Wiring Schematics](#) , and [Electrical Center Identification Views](#) for technicians to reference power sources and fuse locations if they feel there may be loss of power due to an open fuse condition.

- Ground circuits are clean, tight, and in the correct location. General Motors assumes that the original ground circuits have not been compromised. The technician is expected to find a poor ground connection when the diagnostic test step states to test the ground circuit for an open/high resistance. Therefore a link has been provided to [Ground Distribution Wiring Schematics](#) , and [Harness Routing Views](#) for technicians to reference ground locations and which ground circuits may be related to the customer concern.
- All connectors/terminals fully seated in the area of concern. General Motors assumes that all connections are properly installed. The technician is expected to find an open or poor connection when the diagnostic test step asks to test the circuit for an open/high resistance. Therefore a link has been provided to [COMPONENT CONNECTOR END VIEWS - INDEX](#) for technicians to reference which connections may be related to the customer concern.
- There are no aftermarket devices that affect the operation of the system. General Motors can only author diagnostic and repair information for vehicle systems and components that are original equipment or genuine GM Accessories. Aftermarket equipment can negatively affect original equipment operation and lead a technician's diagnosis of a concern in the wrong direction. Therefore a link has been provided to [Checking Aftermarket Accessories](#) that guides a technician through the possible causes of vehicle problems related to aftermarket accessories.
- The scan tool powers up. General Motors assumes that power is available at the Data Link Connector and the scan tool will power on. Therefore a link has been provided to [Scan Tool Does Not Power Up](#) if the technician finds that the scan tool does not power on.

Diagnostic System Check

1. **VERIFY CUSTOMER CONCERN** - This step is to obtain as much information as possible from the customer. Are there aftermarket accessories on the vehicle? When does the condition occur? Where does the condition occur? How long does the condition last? How often does the condition occur? Review the service history of the vehicle for previous repairs that could help diagnose the current concern.

Now that the technician understands the customer concern, they should validate the concern on the vehicle. In order to verify the concern, the technician should be familiar with the normal operation of the system and refer to the owner or service information for any information needed. Inspect the visible system components for obvious damage or conditions that could cause the concern. Conduct a thorough visual inspection. Detect unusual sounds or odors.

The condition described by the customer may be normal. If the technician finds the vehicle to operate normally, compare with another like vehicle that is operating normally, under the same conditions described by the customer. If this is the case, explain your findings and the operation of the system to the customer. If the customer is dissatisfied, submit a Field Product Report.

2. **BULLETIN SEARCH** - By searching for related bulletins, recall/field actions and preliminary information documents, a procedure for a known field issue may resolve the customer concern with little or no diagnosis necessary saving the technician diagnostic time.
3. **MECHANICAL CONCERNS** - This step is designed to take the technician directly to a list of symptom diagnostic procedures. The technician is asked to verify the symptoms exhibited by the system are mechanical in nature and not related to an electrical system, see some examples below. If the technician feels the concern could be related to an electrical system, they should continue through the Diagnostic System Check to verify the electrical functionality of vehicle. If the technician feels the concern is exclusively related to a mechanical system, a link to [Symptoms - Vehicle](#) is provided to select the appropriate symptom diagnostic procedure for the customer concern.

Examples:

- Brake noise or diagnosing irregular pad wear
- Water leak diagnosis
- Engine or transmission fluid leak diagnosis
- Manual window or door lock diagnosis

- Vehicle vibration diagnosis
 - Exhaust noise or leak diagnosis
4. **VEHICLE POWER UP VERIFICATION** - The technician is asked in this step to verify the vehicle powers up. The technician should look for clues that multiple vehicle systems are receiving vehicle power mode messages, such as the cluster waking up, the radio powers on, the HVAC blower is operational, windshield wipers turn on, etc, with the ignition On. This would be a rare condition as both the power mode master and back-up power mode master would have to be inoperable, however, if the vehicle does not power up, a link to [Power Mode Mismatch](#) is provided.
 5. **CONTROL MODULE COMMUNICATION and DTC CHECK** - The technician is asked in this step to record the following three pieces of data on the Repair Order; any control module that the scan tool determined is not communicating, any DTC and symptom byte set current or history, and the control module that has set the DTC.

This is considered a setup step for the rest of the Diagnostic System Check. The technician is not expected to do anything other than record the three pieces of data provided by the scan tool on the Repair Order. This provides the information needed to complete the rest of the diagnostic system check.

To complete this step, the technician is asked to utilize the scan tool Vehicle DTC Information function. This function will query every possible control module on the vehicle requesting all DTCs. During the DTC query, the scan tool will try to establish communication with each control module. If the scan tool can communicate with the control module during the DTC request, it will display PRESENT and provide the number of DTCs set in the control module. If the scan tool cannot communicate with a control module, it will only display NOT COMMUNICATING. Since the scan tool cannot determine if a given control module should be present or not, the technician is asked in a future step to verify that the vehicle was not built with control modules listed as NOT COMMUNICATING.

If the scan tool cannot establish communications with ALL of the vehicles control modules, a link to [Data Link References](#) is provided. A faulty control module or fault with the serial data circuit can cause no communication with all of the control modules on the vehicle. If any control module communicates on the serial data circuit, continue through the Diagnostic System check, as a future step will address any specific non communicating or group of non communicating control modules.

Once the scan tool has completed the routine, the technician should review each control module that has set a DTC and document them on the Repair Order. When reviewing the DTCs, the technician should take notice if any DTCs are powertrain related, and if so, navigate in the scan tool to the Powertrain area and utilize the Capture Info function. This will upload any Freeze Frame/Failure Records stored in the control module to the scan tool in case the data is lost from the control module. As an example, if the technician commands a Clear DTCs function on a powertrain controller, all diagnostic information stored in the controller is erased. This includes Freeze Frame/Failure Records and Inspection/Maintenance System Status indicators, if required for your region.

6. **CONTROL MODULE INTERNAL PERFORMANCE FAULTS** - The technician is asked to review the DTCs recorded in step 5 and verify there are no control module internal performance faults set current. This type of fault may be the cause of other symptoms or DTCs displayed by the vehicle. By addressing this fault first, the technician may find the other concerns are resolved. The technician should always follow the diagnostic procedure for these types of faults prior to replacing any control module. If the technician finds a control module has an internal performance fault, a link is provided to [Diagnostic Trouble Code \(DTC\) List - Vehicle](#) to select the appropriate DTC diagnostic procedure.

Examples:

- B1000 Electronic Control Unit Performance
- B101D ECU Hardware Performance
- C0550 Electronic Control Unit Performance
- C056D ECU Hardware Performance

- C0570 Auxiliary Electronic Control Unit Performance
 - P0606 Control Module Internal Performance
 - P0607 Control Module Performance
7. CONTROL MODULE COMMUNICATION VERIFICATION - This step is used to ensure the control modules that are NOT COMMUNICATING were not built on the vehicle. To understand if the vehicle was built with that option, we provide a link to the [Data Link References](#) , document where Regular Production Options (RPOs) are listed next to the names of optional ECU's and can be compared to those the vehicle was built with. If the technician determines that a control that is NOT COMMUNICATING should be present, the technician is asked to follow the appropriate diagnostic procedure listed in the [Data Link References](#) document.
 8. COMMUNICATION and POWER MODE FAULTS - This step is asking the technician to look for communication DTCs or DTCs related to control modules powering up based on power mode, communication enable or wake-up circuits. See in the below table some examples of the DTCs the technician should diagnose prior to continuing through the Diagnostic System Check. The technician should review the list of DTCs recorded in step 4 and verify that none of these type of DTCs are present. If so, the technician is referred to the [Diagnostic Trouble Code \(DTC\) List - Vehicle](#) to select the appropriate DTC diagnostic procedure.

Examples:

- U0140 Lost Communication With Body Control Module
 - U0164 Lost Communication With HVAC Control Module
 - U0170 Lost Communication With Passenger Presence Detection Module
 - U0402 Invalid Data Received From Transmission Control Module
 - U0452 Invalid Data Received From Inflatable Restraint Sensing and Diagnostic Module
 - U1814 Powertrain High Speed Communication Enable Circuit
 - B1428 Ignition Switched Power Run/Crank Relay Circuit
 - B137B Accessory Power Module Wake Up Circuit
 - C0897 Control Module Power Moding
 - P2536 Ignition Accessory Switch Circuit
9. POWER MODE VERIFICATION - This step verifies the Power Mode Master is receiving the proper output state of the ignition switch/push button switch. The technician should use the main power mode input, this being either the ignition key or, on vehicles equipped with Passive Entry Passive Start, the push button switch. The test should not be performed using a key fob, if the MIL is illuminated the powertrain controller may disable this input. The technician is asked to perform the test with the driver door open. This ensures the retained accessory power mode is inactive during this test which could result in different scan tool readings. The technician is only asked to verify the current Power Mode parameter in the power mode data display list. If the parameter does not match the actual ignition switch position, a link is provided to perform the [Power Mode Mismatch](#) diagnostic procedure.
 10. PROACTIVE ALERT IDENTIFIERS - The technician is asked in this step to verify there are no Proactive Alert Identifiers set. These identifiers are displayed on the scan tool and will only appear when the OnStar subscription is active and the customer has opted into the Proactive Alert service.
 11. ENGINE CRANK and RUN VERIFICATION - Here the technician is asked to verify that the engine cranks and runs. The technician should use the main power mode input, this being either the ignition key or, on vehicles equipped with Passive Entry Passive Start, the push button switch, to complete this step. The test should not be performed using a key fob, if the MIL is illuminated the powertrain controller may disable this input. The technician should know at this point whether the engine cranks and runs without having to actually performing this test step. One of the follow has probably already occurred and this step can be skipped: The technician drove the vehicle into the stall or verified when checking the Crank and Run parameter in step 8. If the technician has not already somehow verified the engine cranks in previous steps, the technician should perform this test step. Regardless of how this step was performed, if the engine does not crank, a link is provided to [Engine Does Not Crank](#), or if the engine cranks but does not run, a link is provided to [Engine Cranks But Does Not Run](#) for the technician to choose the correct diagnostic procedure for the actual engine application being used.

12. REMAINING DTC REVIEW - Here the technician is asked to review any remaining DTCs that were not addressed in previous steps. The technician is asked first to verify there are no control module supply voltage, system voltage or 5 V circuit DTCs present. Control modules, systems or components with insufficient or zero voltage can cause one or multiple symptoms to exist on the vehicle. Control module voltage issues could also be the cause of failures during a programming event. The technician should correct voltage issues prior to addressing any programming or configuration DTCs. The technician should then check for any ECU programming, setup or configuration DTCs. By programming software or configuring a control module, the technician could correct the customer concern unobtrusively. The remaining DTCs, which are usually specific system or component faults, are diagnosed last. They can include ECU input and output circuit DTCs or individual circuit faults that usually cause single symptoms or failure modes on the vehicle and can be fixed following the proper DTC diagnostic procedure. In general, the technician should think about what DTCs or faults could be caused by another DTC or fault. A failed sensor may set a component DTC and then the system may set a DTC indicating the system cannot operate properly. By correcting the sensor fault, the system may now operate properly and the system level DTC will transition to history. Refer to the examples within each category below to understand the differences between these DTCs. If DTCs of these type are current, the technician is referred to [**Diagnostic Trouble Code \(DTC\) List - Vehicle**](#) to choose the correct DTC diagnostic procedure.

1. Voltage DTCs

- B1325 Device Power 1 Circuit
- C0875 Device Voltage Reference Input 2 Circuit
- C1001 Adaptive Cruise Control Indicators Supply Voltage Circuit
- P0641 5-Volt Reference Circuit
- P0787 Downshift Timing Solenoid Control Circuit Low Voltage

2. Programming, Setup, Configuration or Software Performance DTCs

- B3943 Steering Column Lock has Not Learned Column Integration Module
- B101E ECU Software Performance
- B1019 System Configuration Error
- C0558 Calibration Data Not Programmed
- P0630 VIN Not Programmed or Mismatched - Powertrain Control Module (PCM)

3. Component related DTCs

- B0013 Driver Frontal Deployment Loop Stage 2
- B0163 Passenger Compartment Temp Sensor Circuit
- C0045 Left Rear Wheel Speed Sensor Circuit
- P0565 Cruise Control Switch Circuit
- P0751 1-2 Shift Solenoid (SS) Valve Performance

4. System related DTCs

- B1010 System Sensors Data Mismatch
- C0176 System Thermal Error
- C0561 System Disabled Information Stored
- P1564 Vehicle Acceleration Too High - Cruise Control Disabled
- P1625 Transmission Control Module (TCM) System Reset

5. Any other remaining DTCs - The technician should diagnose and correct any other DTCs that are left that were not from the categories above.

13. EMISSION RELATED INSPECTION/MAINTENANCE TESTING CONCERNS - Several regions require that a vehicle pass on-board diagnostic system tests and the inspection/maintenance emission tests in order to renew license plates or vehicle registration. This is accomplished by viewing the Inspection/Maintenance System Status display on a scan tool. Using a scan tool, the technician can observe the Inspection/Maintenance System Status in order to verify that the vehicle meets the criteria that comply with the local area requirements. If inspection and maintenance checks are required in your region, and the customer concern is related to not passing an Inspection/Maintenance test, a link is provided to [**Inspection/Maintenance System Check**](#) where the technician can choose the appropriate Inspection/Maintenance System Check for the actual engine application being used.

14. SYMPTOM DIAGNOSIS - At this step, the diagnostics are assuming that the only information the technician has available to diagnose the customer concern are symptoms of a problem. There are no DTCs set current or history. There may be a Driver Information Center display message or a system indicator to aid in identifying the root cause. The technician should evaluate the symptoms and conditions described by the customer and perform the symptoms diagnostics for the area of customer concern. A link is provided to [Symptoms - Vehicle](#) which contains a list of all symptoms related to this service information publication.

DIAGNOSTIC STARTING POINT - VEHICLE

Begin the system diagnosis with [Diagnostic System Check - Vehicle](#). The Diagnostic System Check - Vehicle will provide a complete strategy to locate and repair a mechanical or electrical vehicle fault. Not following this strategy may cause additional diagnostic time and/or misdiagnosis.

The Diagnostic System Check - Vehicle will provide the following strategy:

- When to verify the customer concern and identify related bulletins, recalls and preliminary information
- When to identify a control module that is not communicating, a control module that has set a DTC, and the DTC diagnostic priority
- When to address power mode concerns
- When to verify the engine cranks and runs
- When to diagnose symptom related concerns

DIAGNOSTIC SYSTEM CHECK - VEHICLE

Diagnostic Instructions

- Review [Strategy Based Diagnosis](#) for an overview of the diagnostic approach.
- [Diagnostic System Check Instructions](#) provides an overview of each diagnostic step.
- Continue through the Diagnostic System Check until you are directed to follow a particular diagnostic or repair procedure. Once a repair has been completed, perform the [Diagnostic Repair Verification](#) and verify the customer concern has been corrected.

The diagnostic procedures within this information are developed on the assumption that the following areas function as designed:

- The 12 V battery is fully charged and cables are clean and tight. Refer to [Battery Inspection/Test](#).
- Fuses are not open. Refer to [Power Distribution Wiring Schematics](#), and [Electrical Center Identification Views](#).
- Ground circuits for the area of customer concern are clean, tight, and in the correct location. Refer to [Ground Distribution Wiring Schematics](#), and [Harness Routing Views](#).
- All connectors/terminals fully seated in the area of concern. Refer to [COMPONENT CONNECTOR END VIEWS - INDEX](#).
- There are no aftermarket devices that affect the operation of the system. Refer to [Checking Aftermarket Accessories](#).
- The scan tool powers up. Refer to [Scan Tool Does Not Power Up](#).

Diagnostic System Check

1. VERIFY CUSTOMER CONCERN - Understand and validate the customer concern. Inspect the visible system components for obvious damage or conditions that may cause the concern.
2. BULLETIN SEARCH - Check for related bulletins, recall/field actions and preliminary information.
3. MECHANICAL CONCERNS - Verify the symptom is not exclusively a mechanical concern.
 - **If the symptom is exclusively a mechanical concern**

Refer to [Symptoms - Vehicle](#).

- **Go to next step: If the symptom is not a mechanical concern**

NOTE: Do not clear any DTCs unless instructed to do so by a diagnostic procedure. If any DTC is Powertrain related, select Capture Info to store DTC and Freeze Frame/Failure Records to the scan tool.

4. VEHICLE POWER UP VERIFICATION - Vehicle in Service Mode, verify the vehicle powers up.

- **If the vehicle does not power up**

Refer to [Power Mode Mismatch](#) .

- **Go to next step: If the vehicle powers up**

5. CONTROL MODULE COMMUNICATION and DTC CHECK - Using a scan tool, perform the Vehicle DTC Information function and verify at least one control module communicates with the scan tool. Record on the Repair Order the following information:

- Any control module that is not communicating.
- Any DTC, including symptom byte, and the control module that has set the DTC.
- **If the scan tool does not communicate with any control module on the vehicle**

Refer to [Data Link References](#) .

- **Go to next step: If the scan tool communicates with any control module**

6. CONTROL MODULE INTERNAL PERFORMANCE FAULTS - Verify there are no current control module Internal Hardware Performance DTCs set.

- **If any DTC of this type is set**

Refer to [Diagnostic Trouble Code \(DTC\) List - Vehicle](#).

- **Go to next step: If no DTC of this type is set**

7. CONTROL MODULE COMMUNICATION VERIFICATION - Verify the vehicle is built with any control module listed as not communicating, refer to [Data Link References](#) . All control modules should be communicating, as equipped.

- **If the vehicle is built with a control module that is not communicating**

Refer to [Data Link References](#) .

- **Go to next step: If all control modules the vehicle is built with are communicating**

8. COMMUNICATION and POWERMODE FAULTS - Verify there are no current control module Power Mode or Communication DTCs set.

- **If any DTC of this type is set**

Refer to [Diagnostic Trouble Code \(DTC\) List - Vehicle](#).

- **Go to next step: If no DTC of this type is set**

NOTE: The engine may start during this test. Ensure the vehicle is out of gear and the parking brake is applied. Turn the engine OFF as soon as the crank power mode parameter has been observed.

9. POWER MODE VERIFICATION - Driver door open, observe each scan tool Power Mode data parameter while cycling through all power modes. Verify all Power Mode data parameters match the actual ignition switch/push button switch selection.

- **If any Power Mode data parameter does not match**

Refer to [Power Mode Mismatch](#) .

- **Go to next step: If all Power Mode data parameters match**

10. PROACTIVE ALERT IDENTIFIERS - The technician is asked in this step to verify there are no Proactive Alert Identifiers set. These identifiers are displayed on the scan tool and will only appear when the OnStar subscription is active and the customer has opted into the Proactive Alert service.
- **If any Proactive Alert Identifier is set**
- Refer to: [Proactive Alerts List](#)
- **Go to next step: If no Proactive Alert Identifier is set**
11. ENGINE CRANK and RUN VERIFICATION - Verify that the engine cranks and runs.
- **If the engine does not crank**
- Refer to [Engine Does Not Crank](#).
- **If the engine does not run**
- Refer to [Engine Cranks But Does Not Run](#).
- **Go to next step: If the engine cranks and runs**
12. REMAINING DTC REVIEW - Verify there are no other DTCs set.
- **If other DTCs are set**
- Diagnose them in the order listed below. Refer to [Diagnostic Trouble Code \(DTC\) List - Vehicle](#).
1. Voltage DTCs
 2. Programming, Setup or Configuration or Software Performance DTCs
 3. Component related DTCs
 4. System related DTCs
 5. Any remaining DTCs
- **Go to next step: If no other DTCs are set**
13. EMISSION RELATED INSPECTION/MAINTENANCE TESTING CONCERNS - If inspection and maintenance checks are required in your region, verify the customer concern is not related to inspection/maintenance testing.
- **If the customer concern is related to inspection/maintenance testing**
- Refer to [Inspection/Maintenance System Check](#).
- **Go to next step: If the customer concern is not related to inspection/maintenance testing**
14. SYMPTOM DIAGNOSIS - Diagnose any remaining customer concern. Refer to [Symptoms - Vehicle](#).

POWERTRAIN DIAGNOSTIC TROUBLE CODE (DTC) TYPE DEFINITIONS

Emissions Related DTCs

Action Taken When the DTC Sets - Type A

- The control module illuminates the malfunction indicator lamp (MIL) when the diagnostic runs and fails.
- The control module records the operating conditions at the time the diagnostic fails. The control module stores this information in the Freeze Frame/Failure Records.

Action Taken When the DTC Sets - Type B

- The control module illuminates the MIL on the second consecutive ignition cycle that the diagnostic runs and fails.
- The control module records the operating conditions at the time the diagnostic fails. The first time the diagnostic fails, the control module stores this information in the Failure Records. If the

diagnostic reports a failure on the second consecutive ignition cycle, the control module records the operating conditions at the time of the failure. The control module writes the operating conditions to the Freeze Frame and updates the Failure Records.

- The following applies to misfire DTCs:
 - If the control module detects a low level or an emission level misfire condition during 2 consecutive trips, the control module illuminates the MIL.
 - If the control module detects a high level or catalyst damaging misfire, the control module flashes the MIL at a rate of once per second.
 - If the control module detects a misfire during 2 non-consecutive trips, the stored conditions are compared with the current conditions. The control module illuminates the MIL when the following conditions occur:
 - The engine load is within 20 percent of the previous test that failed.
 - The engine speed is within 375 RPM of the previous test that failed.
 - The engine coolant temperature is in the same range of the previous test that failed.
- The following applies to fuel trim DTCs:
 - If the control module detects a fuel trim condition during 2 consecutive trips, the control module illuminates the MIL.
 - If the control module detects a fuel trim condition during 2 non-consecutive trips, the stored conditions are compared with the current conditions. The control module illuminates the MIL when the following conditions occur:
 - The engine load is within 20 percent of the previous test that failed.
 - The engine speed is within 375 RPM of the previous test that failed.
 - The engine coolant temperature is in the same range of the previous test that failed.

Conditions for Clearing the MIL/DTC - Type A or Type B

- The control module turns OFF the MIL after 4 consecutive ignition cycles that the diagnostic runs and does not fail.
- A current DTC, Last Test Failed, clears when the diagnostic runs and passes.
- A history DTC clears after 40 consecutive warm-up cycles, if no failures are reported by this or any other emission related diagnostic.
- Clear the MIL and the DTC with a scan tool.

Non-Emissions Related DTCs

Action Taken When the DTC Sets - Type C

- The control module stores the DTC information into memory when the diagnostic runs and fails.
- The MIL will not illuminate.
- The control module records the operating conditions at the time the diagnostic fails. The control module stores this information in the Failure Records.
- The driver information center, if equipped, may display a message.

Conditions for Clearing the DTC - Type C

- A current DTC Last Test Failed clears when the diagnostic runs and passes.
- A history DTC clears after 40 consecutive warm-up cycles, if no failures are reported by this or any other non-emission related diagnostic.
- Clear the DTC with a scan tool.

DIAGNOSTIC TROUBLE CODE (DTC) LIST - VEHICLE

This master list includes all applicable diagnostic trouble codes in alphanumeric order.

DTC	Diagnostic Procedure
B0005	Wiring Systems and Power Management - DTC B0005

DTC	Diagnostic Procedure
B0012	Supplemental Restraints - <u>DTC B0012 or B0013</u>
B0013	Supplemental Restraints - <u>DTC B0012 or B0013</u>
B0014	Supplemental Restraints - <u>DTC B0014 or B0021</u>
B0015	Supplemental Restraints - <u>DTC B0015, B001A, B001B, or B0022</u>
B0016	Supplemental Restraints - <u>DTC B0016, B0018, B0023, or B0025</u>
B0018	Supplemental Restraints - <u>DTC B0016, B0018, B0023, or B0025</u>
B0019	Supplemental Restraints - <u>DTC B0019 or B0020</u>
B001A	Supplemental Restraints - <u>DTC B0015, B001A, B001B, or B0022</u>
B001B	Supplemental Restraints - <u>DTC B0015, B001A, B001B, or B0022</u>
B001E	Supplemental Restraints - <u>DTC B001E</u>
B0020	Supplemental Restraints - <u>DTC B0019 or B0020</u>
B0021	Supplemental Restraints - <u>DTC B0014 or B0021</u>
B0022	Supplemental Restraints - <u>DTC B0015, B001A, B001B, or B0022</u>
B0023	Supplemental Restraints - <u>DTC B0016, B0018, B0023, or B0025</u>
B0025	Supplemental Restraints - <u>DTC B0016, B0018, B0023, or B0025</u>
B0052	Supplemental Restraints - <u>DTC B0052</u>
B0071	Supplemental Restraints - <u>DTC B0071</u>
B0072	Seat Belts - <u>DTC B0072 or B0073</u>
B0073	Seat Belts - <u>DTC B0072 or B0073</u>
B0081	Supplemental Restraints - <u>DTC B0081 (Inflatable Restraint Sensing and Diagnostic Module)</u> <u>DTC B0081 (Passenger Presence Module)</u>
B0082	Supplemental Restraints - <u>DTC B0082</u>
B0083	Supplemental Restraints - <u>DTC B0083 or B0084</u>
B0084	Supplemental Restraints - <u>DTC B0083 or B0084</u>
B0085	Supplemental Restraints - <u>DTC B0085 or B0088</u>
B0086	Supplemental Restraints - <u>DTC B0086 or B0087</u>
B0087	Supplemental Restraints - <u>DTC B0086 or B0087</u>
B0088	Supplemental Restraints - <u>DTC B0085 or B0088</u>
B0091	Supplemental Restraints - <u>DTC B0091</u>
B0092	Supplemental Restraints - <u>DTC B0092 or B0093</u>
B0093	Supplemental Restraints - <u>DTC B0092 or B0093</u>
B0163	HVAC - Automatic - <u>DTC B0163 or B0183</u>
B0173	HVAC - Automatic - <u>DTC B0173, B0178, B0509, B0514, B0519, B3583, or B3933</u>
B0178	HVAC - Automatic - <u>DTC B0173, B0178, B0509, B0514, B0519, B3583, or B3933</u>
B0183	HVAC - Automatic - <u>DTC B0163 or B0183</u>
B018A	HVAC - Automatic - <u>DTC B018A, B048C, B048F, or B1395</u>
B0193	HVAC - Automatic - <u>DTC B0193</u>
B0208	HVAC - Automatic - <u>DTC B0208</u>
B0223	HVAC - Automatic - <u>DTC B0223, B022A, B0233, B023A, B0408, B0418, B0428, or B3531</u>
B022A	HVAC - Automatic - <u>DTC B0223, B022A, B0233, B023A, B0408, B0418, B0428, or B3531</u>
B0233	HVAC - Automatic - <u>DTC B0223, B022A, B0233, B023A, B0408, B0418, B0428, or B3531</u>
B023A	HVAC - Automatic - <u>DTC B0223, B022A, B0233, B023A, B0408, B0418, B0428, or B3531</u>
B0283	Fixed and Moveable Windows - <u>DTC B0283</u>
B0408	HVAC - Automatic - <u>DTC B0223, B022A, B0233, B023A, B0408, B0418, B0428, or B3531</u>
B040A	HVAC - Automatic - <u>DTC B040A</u>
B0418	HVAC - Automatic - <u>DTC B0223, B022A, B0233, B023A, B0408, B0418, B0428, or B3531</u>

DTC	Diagnostic Procedure
B0428	HVAC - Automatic - <u>DTC B0223, B022A, B0233, B023A, B0408, B0418, B0428, or B3531</u>
B048C	HVAC - Automatic - <u>DTC B018A, B048C, B048F, or B1395</u>
B048F	HVAC - Automatic - <u>DTC B018A, B048C, B048F, or B1395</u>
B0509	HVAC - Automatic - <u>DTC B0173, B0178, B0509, B0514, B0519, B3583, or B3933</u>
B0514	HVAC - Automatic - <u>DTC B0173, B0178, B0509, B0514, B0519, B3583, or B3933</u>
B0519	HVAC - Automatic - <u>DTC B0173, B0178, B0509, B0514, B0519, B3583, or B3933</u>
B0550	Displays and Gauges - <u>DTC B0550</u>
B0560	Active Noise Cancellation - <u>DTC B0560</u>
B059A	Seat Belts - <u>DTC B059A</u>
B067F	Supplemental Restraints - <u>DTC B067F or B0680</u>
B0680	Supplemental Restraints - <u>DTC B067F or B0680</u>
B071F	Displays and Gauges - <u>DTC B071F</u>
B0931	Displays and Gauges - <u>DTC B0931</u>
B094B	Driver Assistance Systems - <u>DTC B094B or B094C</u>
B094C	Driver Assistance Systems - <u>DTC B094B or B094C</u>
B094D	Driver Assistance Systems - <u>DTC B094D or B094E</u>
B094E	Driver Assistance Systems - <u>DTC B094D or B094E</u>
B0958	Driver Assistance Systems - <u>DTC B0958, B0959, B0960, or B0961</u>
B0959	Driver Assistance Systems - <u>DTC B0958, B0959, B0960, or B0961</u>
B0960	Driver Assistance Systems - <u>DTC B0958, B0959, B0960, or B0961</u>
B0961	Driver Assistance Systems - <u>DTC B0958, B0959, B0960, or B0961</u>
B096B	Parking Assistance Systems - <u>DTC B096B</u>
B0987	Driver Assistance Systems - <u>DTC B0987</u>
B0996	Immobilizer - <u>DTC B0996</u>
B0997	Cellular, Entertainment, and Navigation - <u>DTC B0997</u>
B1000	Data Communications - <u>DTC B1000</u>
B1001	Data Communications - <u>DTC B1001</u>
B1001	Supplemental Restraints - <u>DTC B1001 (Passenger Presence System), DTC B1001 (Inflatable Restraint Sensing and Diagnostic Module)</u>
B1011	Driver Assistance Systems - <u>DTC B1011</u>
B1015	Cellular, Entertainment, and Navigation - <u>DTC B1015</u>
B1015	Driver Assistance Systems - <u>DTC B1015</u>
B1015	Parking Assistance Systems - <u>DTC B1015</u>
B1019	Vehicle Access - <u>DTC B1019 - Liftgate Control Module</u>
B1019	Supplemental Restraints - <u>DTC B1019</u>
B101D	Data Communications - <u>DTC B101D</u>
B101D	Driver Assistance Systems - <u>DTC B101D (Frontview Camera Module or Frontview Camera - Windshield)</u>
B101E	Data Communications - <u>DTC B101E</u>
B1020	HVAC - Automatic - <u>DTC B1020</u>
B1023	Steering Wheel and Column - <u>DTC B1023</u>
B1024	Cellular, Entertainment, and Navigation - <u>DTC B1024 (Audio Amplifier) DTC B1024 (Human Machine Interface Control Module)</u>
B1025	Cellular, Entertainment, and Navigation - <u>DTC B1025-B1135 (UQF without NKC), DTC B1025-B1135 (UQF with NKC), DTC B1025-B1135 (UQA)</u>
B1026	Cellular, Entertainment, and Navigation - <u>DTC B1025-B1135 (UQF without NKC), DTC B1025-B1135 (UQF with NKC), DTC B1025-B1135 (UQA)</u>
B1027	Cellular, Entertainment, and Navigation - <u>DTC B1025-B1135 (UQF without NKC), DTC B1025-B1135 (UQF with NKC), DTC B1025-B1135 (UQA)</u>
B1028	Cellular, Entertainment, and Navigation - <u>DTC B1025-B1135 (UQF without NKC), DTC B1025-B1135 (UQF with NKC), DTC B1025-B1135 (UQA)</u>

[illegible]

[illegible]

DTC	Diagnostic Procedure
B127B	Image Display Cameras- DTC B127B (IO5/IO6 with MAH/MBC) DTC B127B (IO5/IO6 without MAH/MBC)
B127C	Active Noise Cancellation - DTC B1277, B127C, B127D, or B126F
B127D	Active Noise Cancellation - DTC B1277, B127C, B127D, or B126F
B127E	Cellular, Entertainment, and Navigation - DTC B127E (without MAH/MBC) DTC B127E (with MAH/MBC)
B1325	12 V Starting and Charging - DTC B1325, B1327, B1328, B1330, B1390, B1395, B1400, B1410, B1415, B1424, B1425, B1439, B1517, C0800, C0805, C0870, C0880, C0895, C0899, C0900, C1300, P0560-P0563, P0611, P1002, P129B, P129C, P1465, P1466, P15AE, P15AF, P17B0-P17B2, P17DD-P17DF, P1A0C, P1A0D, P1E19, P1E1A, or U2800
B1327	12 V Starting and Charging - DTC B1325, B1327, B1328, B1330, B1390, B1395, B1400, B1410, B1415, B1424, B1425, B1439, B1517, C0800, C0805, C0870, C0880, C0895, C0899, C0900, C1300, P0560-P0563, P0611, P1002, P129B, P129C, P1465, P1466, P15AE, P15AF, P17B0-P17B2, P17DD-P17DF, P1A0C, P1A0D, P1E19, P1E1A, or U2800
B1328	12 V Starting and Charging - DTC B1325, B1327, B1328, B1330, B1390, B1395, B1400, B1410, B1415, B1424, B1425, B1439, B1517, C0800, C0805, C0870, C0880, C0895, C0899, C0900, C1300, P0560-P0563, P0611, P1002, P129B, P129C, P1465, P1466, P15AE, P15AF, P17B0-P17B2, P17DD-P17DF, P1A0C, P1A0D, P1E19, P1E1A, or U2800
B1330	12 V Starting and Charging - DTC B1325, B1327, B1328, B1330, B1390, B1395, B1400, B1410, B1415, B1424, B1425, B1439, B1517, C0800, C0805, C0870, C0880, C0895, C0899, C0900, C1300, P0560-P0563, P0611, P1002, P129B, P129C, P1465, P1466, P15AE, P15AF, P17B0-P17B2, P17DD-P17DF, P1A0C, P1A0D, P1E19, P1E1A, or U2800
B133B	Image Display Cameras - DTC B133B
B1370	Wiring Systems and Power Management - DTC B1370 (Instrument Cluster)
B1390	12 V Starting and Charging - DTC B1325, B1327, B1328, B1330, B1390, B1395, B1400, B1410, B1415, B1424, B1425, B1439, B1517, C0800, C0805, C0870, C0880, C0895, C0899, C0900, C1300, P0560-P0563, P0611, P1002, P129B, P129C, P1465, P1466, P15AE, P15AF, P17B0-P17B2, P17DD-P17DF, P1A0C, P1A0D, P1E19, P1E1A, or U2800
B1395	Lighting - DTC B1395
B1395	HVAC - Automatic - DTC B018A, B048C, B048F, or B1395
B1395	12 V Starting and Charging - DTC B1325, B1327, B1328, B1330, B1390, B1395, B1400, B1410, B1415, B1424, B1425, B1439, B1517, C0800, C0805, C0870, C0880, C0895, C0899, C0900, C1300, P0560-P0563, P0611, P1002, P129B, P129C, P1465, P1466, P15AE, P15AF, P17B0-P17B2, P17DD-P17DF, P1A0C, P1A0D, P1E19, P1E1A, or U2800
B1400	12 V Starting and Charging - DTC B1325, B1327, B1328, B1330, B1390, B1395, B1400, B1410, B1415, B1424, B1425, B1439, B1517, C0800, C0805, C0870, C0880, C0895, C0899, C0900, C1300, P0560-P0563, P0611, P1002, P129B, P129C, P1465, P1466, P15AE, P15AF, P17B0-P17B2, P17DD-P17DF, P1A0C, P1A0D, P1E19, P1E1A, or U2800
B1405	Parking Assistance Systems - DTC B1405
B1405	Power Seats - DTC B1405, B1825, B2355, B2365, or B2375
B1410	12 V Starting and Charging - DTC B1325, B1327, B1328, B1330, B1390, B1395, B1400, B1410, B1415, B1424, B1425, B1439, B1517, C0800, C0805, C0870, C0880, C0895, C0899, C0900, C1300, P0560-P0563, P0611, P1002, P129B, P129C, P1465, P1466, P15AE, P15AF, P17B0-P17B2, P17DD-P17DF, P1A0C, P1A0D, P1E19, P1E1A, or U2800
B1415	12 V Starting and Charging - DTC B1325, B1327, B1328, B1330, B1390, B1395, B1400, B1410, B1415, B1424, B1425, B1439, B1517, C0800, C0805, C0870, C0880, C0895, C0899, C0900, C1300, P0560-P0563, P0611, P1002, P129B, P129C, P1465, P1466, P15AE, P15AF, P17B0-P17B2, P17DD-P17DF, P1A0C, P1A0D, P1E19, P1E1A, or U2800

DTC	Diagnostic Procedure
B1424	12 V Starting and Charging - DTC B1325, B1327, B1328, B1330, B1390, B1395, B1400, B1410, B1415, B1424, B1425, B1439, B1517, C0800, C0805, C0870, C0880, C0895, C0899, C0900, C1300, P0560-P0563, P0611, P1002, P129B, P129C, P1465, P1466, P15AE, P15AF, P17B0-P17B2, P17DD-P17DF, P1A0C, P1A0D, P1E19, P1E1A, or U2800
B1425	12 V Starting and Charging - DTC B1325, B1327, B1328, B1330, B1390, B1395, B1400, B1410, B1415, B1424, B1425, B1439, B1517, C0800, C0805, C0870, C0880, C0895, C0899, C0900, C1300, P0560-P0563, P0611, P1002, P129B, P129C, P1465, P1466, P15AE, P15AF, P17B0-P17B2, P17DD-P17DF, P1A0C, P1A0D, P1E19, P1E1A, or U2800
B1439	12 V Starting and Charging - DTC B1325, B1327, B1328, B1330, B1390, B1395, B1400, B1410, B1415, B1424, B1425, B1439, B1517, C0800, C0805, C0870, C0880, C0895, C0899, C0900, C1300, P0560-P0563, P0611, P1002, P129B, P129C, P1465, P1466, P15AE, P15AF, P17B0-P17B2, P17DD-P17DF, P1A0C, P1A0D, P1E19, P1E1A, or U2800
B1446	Cellular, Entertainment, and Navigation - DTC B1446 or B1447 (UE1) DTC B1446 or B1447 (UE3) DTC B1446 or B1447 (UI3)
B1447	Cellular, Entertainment, and Navigation - DTC B1446 or B1447 (UE1) DTC B1446 or B1447 (UE3) DTC B1446 or B1447 (UI3)
B144C	Steering Wheel and Column - DTC B144C
B1474	Vehicle Access - DTC B1474 or B3849
B1480	Lighting - DTC B1480
B1517	12 V Starting and Charging - DTC B1325, B1327, B1328, B1330, B1390, B1395, B1400, B1410, B1415, B1424, B1425, B1439, B1517, C0800, C0805, C0870, C0880, C0895, C0899, C0900, C1300, P0560-P0563, P0611, P1002, P129B, P129C, P1465, P1466, P15AE, P15AF, P17B0-P17B2, P17DD-P17DF, P1A0C, P1A0D, P1E19, P1E1A, or U2800
B151A	12 V Starting and Charging - DTC B151A
B1527	12 V Starting and Charging - DTC B1527
B1534	Vehicle Access - DTC B1534 or B1535
B1535	Vehicle Access - DTC B1534 or B1535
B153A	Vehicle Access - DTC B153A - Liftgate Latch Switches Malfunction
B153E	Vehicle Access - DTC B153E - Liftgate Angle Sensor Malfunction
B153F	Vehicle Access - DTC B153F - Liftgate Object Sensor Malfunction
B154A	Mirrors - DTC B154A or B154B
B154B	Mirrors - DTC B154A or B154B
B172E	Driver Assistance Systems - DTC B172E or B172F
B172F	Driver Assistance Systems - DTC B172E or B172F
B1735	Power Seats - DTC B1735, B1740, B1745, B1750, B1755, B1760, B1815, or B1820
B1740	Power Seats - DTC B1735, B1740, B1745, B1750, B1755, B1760, B1815, or B1820
B1745	Power Seats - DTC B1735, B1740, B1745, B1750, B1755, B1760, B1815, or B1820
B1750	Power Seats - DTC B1735, B1740, B1745, B1750, B1755, B1760, B1815, or B1820
B1755	Power Seats - DTC B1735, B1740, B1745, B1750, B1755, B1760, B1815, or B1820
B1760	Power Seats - DTC B1735, B1740, B1745, B1750, B1755, B1760, B1815, or B1820
B1815	Power Seats - DTC B1735, B1740, B1745, B1750, B1755, B1760, B1815, or B1820
B1820	Power Seats - DTC B1735, B1740, B1745, B1750, B1755, B1760, B1815, or B1820
B1825	Power Seats - DTC B1405, B1825, B2355, B2365, or B2375
B191A	Seat Heating and Cooling - DTC B191A or B191B

DTC	Diagnostic Procedure
B191B	Seat Heating and Cooling - <u>DTC B191A or B191B</u>
B2355	Power Seats - <u>DTC B1405, B1825, B2355, B2365, or B2375</u>
B2365	Power Seats - <u>DTC B1405, B1825, B2355, B2365, or B2375</u>
B2375	Power Seats - <u>DTC B1405, B1825, B2355, B2365, or B2375</u>
B2455	Cellular, Entertainment, and Navigation - <u>DTC B2455 (without UE3), DTC B2455 (UE3)</u>
B245A	Cellular, Entertainment, and Navigation - <u>DTC B245A</u>
B245B	Cellular, Entertainment, and Navigation - <u>DTC B245B</u>
B245C	Cellular, Entertainment, and Navigation - <u>DTC B245C</u>
B2462	Cellular, Entertainment, and Navigation - <u>DTC B2462 (without IO5/IO6), DTC B2462 (IO5/IO6)</u>
B2470	Cellular, Entertainment, and Navigation - <u>DTC B2470</u>
B2476	Cellular, Entertainment, and Navigation - <u>DTC B2476 or B2482</u>
B2482	Cellular, Entertainment, and Navigation - <u>DTC B2476 or B2482</u>
B2494	Vehicle Access - <u>DTC B2494 - Liftgate Handle Switch Malfunction (Without TB5), DTC B2494 - Liftgate Handle Switch Malfunction (With TB5)</u>
B2495	Vehicle Access - <u>DTC B2495 or B24A0</u>
B24A0	Vehicle Access - <u>DTC B2495 or B24A0</u>
B2515	Steering Wheel and Column - <u>DTC B2515</u>
B2530	Lighting - <u>DTC B2530</u>
B2540	Lighting - <u>DTC B2540</u>
B2545	Lighting - <u>DTC B2545</u>
B255F	Lighting - <u>DTC B255F</u>
B256A	Lighting - <u>DTC B256A</u>
B2575	Lighting - <u>DTC B2575 or B2699</u>
B257A	Lighting - <u>DTC B257A</u>
B2580	Lighting - <u>DTC B2580</u>
B2585	Lighting - <u>DTC B2585 or B3867</u>
B2610	Lighting - <u>DTC B2610</u>
B2615	Lighting - <u>DTC B2615</u>
B2625	Lighting - <u>DTC B2625</u>
B2645	Lighting - <u>DTC B2645</u>
B2699	Lighting - <u>DTC B2575 or B2699</u>
B269A	HVAC - Automatic - <u>DTC B269A, B269C, or B269D</u>
B269C	HVAC - Automatic - <u>DTC B269A, B269C, or B269D</u>
B269D	HVAC - Automatic - <u>DTC B269A, B269C, or B269D</u>
B270A	Shift Lock Control - <u>DTC B270A</u>
B273A	Antilock Brake System - <u>DTC B273A</u>
B2740	Lighting - <u>DTC B2740</u>
B2745	Antilock Brake System - <u>DTC B2745</u>
B2750	Horns and Pedestrian Alerts - <u>DTC B2750</u>
B2755	Power Seats - <u>DTC B2755 or B2765</u>
B2765	Power Seats - <u>DTC B2755 or B2765</u>
B285A	Steering Wheel and Column - <u>DTC B285A</u>
B2897	Steering Wheel and Column - <u>DTC B2897</u>
B2910	Steering Wheel and Column - <u>DTC B2910</u>
B291B	Theft Deterrent - <u>DTC B291B</u>
B2955	Immobilizer - <u>DTC B2955</u>
B297B	Vehicle Access - <u>DTC B297B or B297C</u>
B297C	Vehicle Access - <u>DTC B297B or B297C</u>
B3006	Bolted Exterior Body Panels and Closures - <u>DTC B3006</u>
B302A	Immobilizer - <u>DTC B302A</u>

DTC	Diagnostic Procedure
B3031	Immobilizer - DTC B3031
B3055	Immobilizer - DTC B3055
B305A	Steering Wheel and Column - DTC B305A
B305C	Immobilizer - DTC B305C
B305D	Remote Functions - DTC B305D
B3060	Immobilizer - DTC B3060
B3101	Remote Functions - DTC B3101
B3105	Remote Functions - DTC B3105
B3106	Remote Functions - DTC B3106
B3109	Remote Functions - DTC B3109-B3113
B310D	Remote Functions - DTC B310D-B310F
B310E	Remote Functions - DTC B310D-B310F
B310F	Remote Functions - DTC B310D-B310F
B3110	Remote Functions - DTC B3109-B3113
B3111	Remote Functions - DTC B3109-B3113
B3112	Remote Functions - DTC B3109-B3113
B3113	Remote Functions - DTC B3109-B3113
B3119	Remote Functions - DTC B3119
B3120	Remote Functions - DTC B3120
B3121	Remote Functions - DTC B3121
B3122	Remote Functions - DTC B3122
B3123	Remote Functions - DTC B3123
B3124	Remote Functions - DTC B3124
B3125	Vehicle Access - DTC B3125, B3130, or B3135
B3130	Vehicle Access - DTC B3125, B3130, or B3135
B3135	Vehicle Access - DTC B3125, B3130, or B3135
B3140	Vehicle Access - DTC B3140, B3145, B3150, or B3155
B3145	Vehicle Access - DTC B3140, B3145, B3150, or B3155
B3150	Vehicle Access - DTC B3140, B3145, B3150, or B3155
B3155	Vehicle Access - DTC B3140, B3145, B3150, or B3155
B316B	Fixed and Moveable Windows - DTC B316B, B317A, B318A, or B319A (Without Express Up/Down Windows) , DTC B316B, B317A, B318A, or B319A (With Driver Express Up/Down Window)
B317A	Fixed and Moveable Windows - DTC B316B, B317A, B318A, or B319A (Without Express Up/Down Windows) , DTC B316B, B317A, B318A, or B319A (With Driver Express Up/Down Window)
B318A	Fixed and Moveable Windows - DTC B316B, B317A, B318A, or B319A (Without Express Up/Down Windows) , DTC B316B, B317A, B318A, or B319A (With Driver Express Up/Down Window)
B319A	Fixed and Moveable Windows - DTC B316B, B317A, B318A, or B319A (Without Express Up/Down Windows) , DTC B316B, B317A, B318A, or B319A (With Driver Express Up/Down Window)
B3205	Fixed and Moveable Windows - DTC B3205
B323A	Vehicle Access - DTC B323A-B323C
B323B	Vehicle Access - DTC B323A-B323C
B323C	Vehicle Access - DTC B323A-B323C
B323E	Lighting - DTC B323E
B3245	Vehicle Access - DTC B324A or B3245
B324A	Vehicle Access - DTC B324A or B3245
B3531	HVAC - Automatic - DTC B0223, B022A, B0233, B023A, B0408, B0418, B0428, or B3531
B3567	Displays and Gauges - DTC B3567
B356A	Driver Assistance Systems - DTC B356A

DTC	Diagnostic Procedure
B3583	HVAC - Automatic - <u>DTC B0173, B0178, B0509, B0514, B0519, B3583, or B3933</u>
B3588	Lighting - <u>DTC B3588</u>
B3596	Lighting - <u>DTC B3596</u>
B3600	Lighting - <u>DTC B3600</u>
B3622	Secondary and Configurable Customer Controls - <u>DTC B3622 (with X88)</u> <u>DTC B3622 (with W49)</u>
B3650	Lighting - <u>DTC B3650</u>
B3664	Sunroof - <u>DTC B3664</u>
B3697	Sunroof - <u>DTC B3697</u>
B370B	Wipers and Washers - <u>DTC B370B</u>
B3715	Wipers and Washers - <u>DTC B3715 or B3875</u>
B3794	Cruise Control - <u>Cruise Control Malfunction - DTC B3794, P0564, P0565, P0567, P0568, P056C, P0580, P0581, P155A-P155C, or P162C</u>
B3806	Lighting - <u>DTC B3806</u>
B380A	Lighting - <u>DTC B380A or B380B</u>
B380B	Lighting - <u>DTC B380A or B380B</u>
B3811	Wipers and Washers - <u>DTC B3811</u>
B3849	Vehicle Access - <u>DTC B1474 or B3849</u>
B384A	Vehicle Access - <u>DTC B384A</u>
B3867	Lighting - <u>DTC B2585 or B3867</u>
B3873	Wipers and Washers - <u>DTC B3873</u>
B3875	Wipers and Washers - <u>DTC B3715 or B3875</u>
B3881	Lighting - <u>DTC B3881 or B3882</u>
B3882	Lighting - <u>DTC B3881 or B3882</u>
B3883	Lighting - <u>DTC B3883</u>
B3884	Lighting - <u>DTC B3884</u>
B389A	Immobilizer - <u>DTC B389A</u>
B3902	Immobilizer - <u>DTC B3902</u>
B390A	Driver Assistance Systems - <u>DTC B390A</u>
B390C	Driver Assistance Systems - <u>DTC B390C</u>
B390D	Driver Assistance Systems - <u>DTC B390D</u>
B390F	Image Display Cameras - <u>DTC B390F</u>
B3920	Power Seats - <u>DTC B3920</u>
B3924	Immobilizer - <u>DTC B3924-B3928</u>
B3925	Immobilizer - <u>DTC B3924-B3928</u>
B3926	Immobilizer - <u>DTC B3924-B3928</u>
B3927	Immobilizer - <u>DTC B3924-B3928</u>
B3928	Immobilizer - <u>DTC B3924-B3928</u>
B3933	HVAC - Automatic - <u>DTC B0173, B0178, B0509, B0514, B0519, B3583, or B3933</u>
B3935	Immobilizer - <u>DTC B3935</u>
B3938	Vehicle Access - <u>DTC B3938</u>
B393B	HVAC - Automatic - <u>DTC B393B</u>
B3948	Lighting - <u>DTC B3948 or B3949</u>
B3949	Lighting - <u>DTC B3948 or B3949</u>
B3950	Lighting - <u>DTC B3950 or B3951</u>
B3951	Lighting - <u>DTC B3950 or B3951</u>
B395A	Image Display Cameras - <u>DTC B395A</u>
B395B	Image Display Cameras - <u>DTC B395B</u>
B395C	Image Display Cameras - <u>DTC B395C</u>
B395D	Image Display Cameras - <u>DTC B395D</u>
B396A	Vehicle Access - <u>DTC B396A - Liftgate Motor Power Open/Close Malfunction</u>

DTC	Diagnostic Procedure
B396C	Vehicle Access - DTC B396C or B396D - Liftgate Interior Release Open/Close Switch Malfunction
B396D	Vehicle Access - DTC B396C or B396D - Liftgate Interior Release Open/Close Switch Malfunction
B396E	Vehicle Access - DTC B396E - Liftgate Close Switch Malfunction
B3976	Immobilizer - DTC B3976
B3978	Immobilizer - DTC B3978-B3982
B3979	Immobilizer - DTC B3978-B3982
B3980	Immobilizer - DTC B3978-B3982
B3981	Immobilizer - DTC B3978-B3982
B3982	Immobilizer - DTC B3978-B3982
B3984	Immobilizer - DTC B3984
B399A	Image Display Cameras - DTC B399A
B399B	Image Display Cameras - DTC B399B
B399C	Image Display Cameras - DTC B399C
B399D	Image Display Cameras - DTC B399D
C0035	Antilock Brake System - DTC C0035-C0050
C0036	Antilock Brake System - DTC C0035-C0050
C0037	Antilock Brake System - DTC C0035-C0050
C0038	Antilock Brake System - DTC C0035-C0050
C0039	Antilock Brake System - DTC C0035-C0050
C0040	Antilock Brake System - DTC C0035-C0050
C0041	Antilock Brake System - DTC C0035-C0050
C0042	Antilock Brake System - DTC C0035-C0050
C0043	Antilock Brake System - DTC C0035-C0050
C0044	Antilock Brake System - DTC C0035-C0050
C0045	Antilock Brake System - DTC C0035-C0050
C0046	Antilock Brake System - DTC C0035-C0050
C0047	Antilock Brake System - DTC C0035-C0050
C0048	Antilock Brake System - DTC C0035-C0050
C0049	Antilock Brake System - DTC C0035-C0050
C0050	Antilock Brake System - DTC C0035-C0050
C0110	Antilock Brake System DTC C0110
C0131	Antilock Brake System - DTC C0131
C0161	Antilock Brake System DTC C0161
C0176	Power Steering - DTC C0176
C0186	Antilock Brake System - DTC C0186, C0187, C018A, C018B, C0196, C019A, C019B, C027E, C027F, or C0287
C0187	Antilock Brake System - DTC C0186, C0187, C018A, C018B, C0196, C019A, C019B, C027E, C027F, or C0287
C018A	Antilock Brake System - DTC C018A, C019A, or C027F
C018A	Antilock Brake System - DTC C0186, C0187, C018A, C018B, C0196, C019A, C019B, C027E, C027F, or C0287
C018B	Antilock Brake System - DTC C0186, C0187, C018A, C018B, C0196, C019A, C019B, C027E, C027F, or C0287
C0196	Antilock Brake System - DTC C0186, C0187, C018A, C018B, C0196, C019A, C019B, C027E, C027F, or C0287
C019A	Antilock Brake System - DTC C018A, C019A, or C027F
C019A	Antilock Brake System - DTC C0186, C0187, C018A, C018B, C0196, C019A, C019B, C027E, C027F, or C0287
C019B	Antilock Brake System - DTC C0186, C0187, C018A, C018B, C0196, C019A, C019B, C027E, C027F, or C0287
C0242	Antilock Brake System - DTC C0242

DTC	Diagnostic Procedure
C0245	Antilock Brake System DTC C0245
C0252	Antilock Brake System - DTC C0252
C025E	Hydraulic Brakes - DTC C025E
C0267	Hydraulic Brakes - DTC C0267
C0273	Hydraulic Brakes - DTC C0273
C0274	Antilock Brake System - DTC C0274, C0275, or C0280
C0275	Antilock Brake System - DTC C0274, C0275, or C0280
C0277	Lighting - DTC C0277 or C0890
C027B	Hydraulic Brakes - DTC C027B
C027D	Park Brake - DTC C027D
C027E	Antilock Brake System - DTC C0186, C0187, C018A, C018B, C0196, C019A, C019B, C027E, C027F, or C0287
C027F	Antilock Brake System - DTC C018A, C019A, or C027F
C027F	Antilock Brake System - DTC C0186, C0187, C018A, C018B, C0196, C019A, C019B, C027E, C027F, or C0287
C0280	Antilock Brake System - DTC C0274, C0275, or C0280
C0287	Antilock Brake System - DTC C0186, C0187, C018A, C018B, C0196, C019A, C019B, C027E, C027F, or C0287
C028D	Park Brake - DTC C028D
C028F	Park Brake - DTC C028F
C0293	Park Brake - DTC C0293
C0297	Lighting - DTC C0297
C0299	Hydraulic Brakes - DTC C0299
C0393	Rear Drive Axle - DTC C0393 (G99)
C0407	Rear Drive Axle - DTC C0407
C0460	Power Steering - DTC C0460
C0545	Power Steering - DTC C0545
C0550	Data Communications - DTC C0550
C0558	Antilock Brake System - DTC C0558
C0561	Antilock Brake System - DTC C0561
C0569	Tire Pressure Monitoring - DTC C0569
C056D	Data Communications - DTC C056D
C056E	Park Brake - DTC C056E
C056E	Data Communications - DTC C056E
C056E	Power Steering - DTC C056E
C0710	Antilock Brake System - DTC C0710
C0750	Tire Pressure Monitoring - DTC C0750, C0755, C0760, or C0765
C0755	Tire Pressure Monitoring - DTC C0750, C0755, C0760, or C0765
C0760	Tire Pressure Monitoring - DTC C0750, C0755, C0760, or C0765
C0765	Tire Pressure Monitoring - DTC C0750, C0755, C0760, or C0765
C0775	Tire Pressure Monitoring - DTC C0775
C0800	12 V Starting and Charging - DTC B1325, B1327, B1328, B1330, B1390, B1395, B1400, B1410, B1415, B1424, B1425, B1439, B1517, C0800, C0805, C0870, C0880, C0895, C0899, C0900, C1300, P0560-P0563, P0611, P1002, P129B, P129C, P1465, P1466, P15AE, P15AF, P17B0-P17B2, P17DD-P17DE, P1A0C, P1A0D, P1E19, P1E1A, or U2800
C0805	12 V Starting and Charging - DTC B1325, B1327, B1328, B1330, B1390, B1395, B1400, B1410, B1415, B1424, B1425, B1439, B1517, C0800, C0805, C0870, C0880, C0895, C0899, C0900, C1300, P0560-P0563, P0611, P1002, P129B, P129C, P1465, P1466, P15AE, P15AF, P17B0-P17B2, P17DD-P17DE, P1A0C, P1A0D, P1E19, P1E1A, or U2800

DTC	Diagnostic Procedure
C0870	12 V Starting and Charging - DTC B1325, B1327, B1328, B1330, B1390, B1395, B1400, B1410, B1415, B1424, B1425, B1439, B1517, C0800, C0805, C0870, C0880, C0895, C0899, C0900, C1300, P0560-P0563, P0611, P1002, P129B, P129C, P1465, P1466, P15AE, P15AF, P17B0-P17B2, P17DD-P17DF, P1A0C, P1A0D, P1E19, P1E1A, or U2800
C0880	12 V Starting and Charging - DTC B1325, B1327, B1328, B1330, B1390, B1395, B1400, B1410, B1415, B1424, B1425, B1439, B1517, C0800, C0805, C0870, C0880, C0895, C0899, C0900, C1300, P0560-P0563, P0611, P1002, P129B, P129C, P1465, P1466, P15AE, P15AF, P17B0-P17B2, P17DD-P17DF, P1A0C, P1A0D, P1E19, P1E1A, or U2800
C0890	Lighting - DTC C0277 or C0890
C0895	12 V Starting and Charging - DTC B1325, B1327, B1328, B1330, B1390, B1395, B1400, B1410, B1415, B1424, B1425, B1439, B1517, C0800, C0805, C0870, C0880, C0895, C0899, C0900, C1300, P0560-P0563, P0611, P1002, P129B, P129C, P1465, P1466, P15AE, P15AF, P17B0-P17B2, P17DD-P17DF, P1A0C, P1A0D, P1E19, P1E1A, or U2800
C0899	12 V Starting and Charging - DTC B1325, B1327, B1328, B1330, B1390, B1395, B1400, B1410, B1415, B1424, B1425, B1439, B1517, C0800, C0805, C0870, C0880, C0895, C0899, C0900, C1300, P0560-P0563, P0611, P1002, P129B, P129C, P1465, P1466, P15AE, P15AF, P17B0-P17B2, P17DD-P17DF, P1A0C, P1A0D, P1E19, P1E1A, or U2800
C0900	12 V Starting and Charging - DTC B1325, B1327, B1328, B1330, B1390, B1395, B1400, B1410, B1415, B1424, B1425, B1439, B1517, C0800, C0805, C0870, C0880, C0895, C0899, C0900, C1300, P0560-P0563, P0611, P1002, P129B, P129C, P1465, P1466, P15AE, P15AF, P17B0-P17B2, P17DD-P17DF, P1A0C, P1A0D, P1E19, P1E1A, or U2800
C122F	Rear Drive Axle - DTC C122F
C1230	Rear Drive Axle - DTC C1230 or C1231 (G99)
C1231	Rear Drive Axle - DTC C1230 or C1231 (G99)
C1244	Rear Drive Axle - DTC C1244, C1245, or C124B
C1245	Rear Drive Axle - DTC C1244, C1245, or C124B
C124B	Rear Drive Axle - DTC C1244, C1245, or C124B
C124F	Antilock Brake System - DTC C124F or C1250-C1254
C1250	Antilock Brake System - DTC C124F or C1250-C1254
C1251	Antilock Brake System - DTC C124F or C1250-C1254
C1252	Antilock Brake System - DTC C124F or C1250-C1254
C1253	Antilock Brake System - DTC C124F or C1250-C1254
C1254	Antilock Brake System - DTC C124F or C1250-C1254
C1260	Rear Drive Axle - DTC C1260-C1267
C1261	Rear Drive Axle - DTC C1260-C1267
C1262	Rear Drive Axle - DTC C1260-C1267
C1263	Rear Drive Axle - DTC C1260-C1267
C1264	Rear Drive Axle - DTC C1260-C1267
C1265	Rear Drive Axle - DTC C1260-C1267
C1266	Rear Drive Axle - DTC C1260-C1267
C1267	Rear Drive Axle - DTC C1260-C1267
C1282	Rear Drive Axle - DTC C1282
C1290	Rear Drive Axle - DTC C1290-C1295
C1291	Rear Drive Axle - DTC C1290-C1295
C1292	Rear Drive Axle - DTC C1290-C1295
C1293	Rear Drive Axle - DTC C1290-C1295
C1294	Rear Drive Axle - DTC C1290-C1295
C1295	Rear Drive Axle - DTC C1290-C1295
C1296	Rear Drive Axle - DTC C1296
C12A1	Rear Drive Axle - DTC C12A1 or C12A9 (G99)

DTC	Diagnostic Procedure
C12A9	Rear Drive Axle - DTC C12A1 or C12A9 (G99)
C1300	12 V Starting and Charging - DTC B1325, B1327, B1328, B1330, B1390, B1395, B1400, B1410, B1415, B1424, B1425, B1439, B1517, C0800, C0805, C0870, C0880, C0895, C0899, C0900, C1300, P0560-P0563, P0611, P1002, P129B, P129C, P1465, P1466, P15AE, P15AF, P17B0-P17B2, P17DD-P17DE, P1A0C, P1A0D, P1E19, P1E1A, or U2800
C1586	Park Brake - DTC C1586
C1587	Park Brake - DTC C1587
C1588	Park Brake - DTC C1588
P0010	Engine Controls and Fuel - 2.0L (LTG) - DTC P0010, P0013, or P2088-P2091
P0010	Engine Controls and Fuel - 3.6L (LFY) - DTC P0010, P0011, P0013, P0014, P0020, P0021, P0023, P0024, or P2088-P2095
P0011	Engine Controls and Fuel - 2.0L (LTG) - DTC P0011 or P0014
P0011	Engine Controls and Fuel - 3.6L (LFY) - DTC P0010, P0011, P0013, P0014, P0020, P0021, P0023, P0024, or P2088-P2095
P0013	Engine Controls and Fuel - 2.0L (LTG) - DTC P0010, P0013, or P2088-P2091
P0013	Engine Controls and Fuel - 3.6L (LFY) - DTC P0010, P0011, P0013, P0014, P0020, P0021, P0023, P0024, or P2088-P2095
P0014	Engine Controls and Fuel - 2.0L (LTG) - DTC P0011 or P0014
P0014	Engine Controls and Fuel - 3.6L (LFY) - DTC P0010, P0011, P0013, P0014, P0020, P0021, P0023, P0024, or P2088-P2095
P0016	Engine Controls and Fuel - 2.0L (LTG) - DTC P0016 or P0017
P0016	Engine Controls and Fuel - 3.6L (LFY) - DTC P0016, P0017, P0018, or P0019
P0017	Engine Controls and Fuel - 2.0L (LTG) - DTC P0016 or P0017
P0017	Engine Controls and Fuel - 3.6L (LFY) - DTC P0016, P0017, P0018, or P0019
P0018	Engine Controls and Fuel - 3.6L (LFY) - DTC P0016, P0017, P0018, or P0019
P0019	Engine Controls and Fuel - 3.6L (LFY) - DTC P0016, P0017, P0018, or P0019
P0020	Engine Controls and Fuel - 3.6L (LFY) - DTC P0010, P0011, P0013, P0014, P0020, P0021, P0023, P0024, or P2088-P2095
P0021	Engine Controls and Fuel - 3.6L (LFY) - DTC P0010, P0011, P0013, P0014, P0020, P0021, P0023, P0024, or P2088-P2095
P0023	Engine Controls and Fuel - 3.6L (LFY) - DTC P0010, P0011, P0013, P0014, P0020, P0021, P0023, P0024, or P2088-P2095
P0024	Engine Controls and Fuel - 3.6L (LFY) - DTC P0010, P0011, P0013, P0014, P0020, P0021, P0023, P0024, or P2088-P2095
P0030	Engine Controls and Fuel - 2.0L (LTG) - DTC P0030-P0032, P0036-P0038, P0054, P0135, P0141, P103B, or P103C
P0030	Engine Controls and Fuel - 3.6L (LFY) - DTC P0030-P0032, P0036-P0038, P0050-P0054, P0056-P0060, P0135, P0141, P0155, P0161, P103B, or P103C
P0031	Engine Controls and Fuel - 2.0L (LTG) - DTC P0030-P0032, P0036-P0038, P0054, P0135, P0141, P103B, or P103C
P0031	Engine Controls and Fuel - 3.6L (LFY) - DTC P0030-P0032, P0036-P0038, P0050-P0054, P0056-P0060, P0135, P0141, P0155, P0161, P103B, or P103C
P0032	Engine Controls and Fuel - 2.0L (LTG) - DTC P0030-P0032, P0036-P0038, P0054, P0135, P0141, P103B, or P103C
P0032	Engine Controls and Fuel - 3.6L (LFY) - DTC P0030-P0032, P0036-P0038, P0050-P0054, P0056-P0060, P0135, P0141, P0155, P0161, P103B, or P103C
P0033	Engine Controls and Fuel - 2.0L (LTG) - DTC P0033-P0035
P0034	Engine Controls and Fuel - 2.0L (LTG) - DTC P0033-P0035
P0035	Engine Controls and Fuel - 2.0L (LTG) - DTC P0033-P0035
P0036	Engine Controls and Fuel - 2.0L (LTG) - DTC P0030-P0032, P0036-P0038, P0054, P0135, P0141, P103B, or P103C
P0036	Engine Controls and Fuel - 3.6L (LFY) - DTC P0030-P0032, P0036-P0038, P0050-P0054, P0056-P0060, P0135, P0141, P0155, P0161, P103B, or P103C

DTC	Diagnostic Procedure
P0037	Engine Controls and Fuel - 2.0L (LTG) - <u>DTC P0030-P0032, P0036-P0038, P0054, P0135, P0141, P103B, or P103C</u>
P0037	Engine Controls and Fuel - 3.6L (LFY) - <u>DTC P0030-P0032, P0036-P0038, P0050-P0054, P0056-P0060, P0135, P0141, P0155, P0161, P103B, or P103C</u>
P0038	Engine Controls and Fuel - 2.0L (LTG) - <u>DTC P0030-P0032, P0036-P0038, P0054, P0135, P0141, P103B, or P103C</u>
P0038	Engine Controls and Fuel - 3.6L (LFY) - <u>DTC P0030-P0032, P0036-P0038, P0050-P0054, P0056-P0060, P0135, P0141, P0155, P0161, P103B, or P103C</u>
P0050	Engine Controls and Fuel - 3.6L (LFY) - <u>DTC P0030-P0032, P0036-P0038, P0050-P0054, P0056-P0060, P0135, P0141, P0155, P0161, P103B, or P103C</u>
P0051	Engine Controls and Fuel - 3.6L (LFY) - <u>DTC P0030-P0032, P0036-P0038, P0050-P0054, P0056-P0060, P0135, P0141, P0155, P0161, P103B, or P103C</u>
P0052	Engine Controls and Fuel - 3.6L (LFY) - <u>DTC P0030-P0032, P0036-P0038, P0050-P0054, P0056-P0060, P0135, P0141, P0155, P0161, P103B, or P103C</u>
P0053	Engine Controls and Fuel - 3.6L (LFY) - <u>DTC P0030-P0032, P0036-P0038, P0050-P0054, P0056-P0060, P0135, P0141, P0155, P0161, P103B, or P103C</u>
P0054	Engine Controls and Fuel - 3.6L (LFY) - <u>DTC P0030-P0032, P0036-P0038, P0050-P0054, P0056-P0060, P0135, P0141, P0155, P0161, P103B, or P103C</u>
P0054	Engine Controls and Fuel - 2.0L (LTG) - <u>DTC P0030-P0032, P0036-P0038, P0054, P0135, P0141, P103B, or P103C</u>
P0056	Engine Controls and Fuel - 3.6L (LFY) - <u>DTC P0030-P0032, P0036-P0038, P0050-P0054, P0056-P0060, P0135, P0141, P0155, P0161, P103B, or P103C</u>
P0057	Engine Controls and Fuel - 3.6L (LFY) - <u>DTC P0030-P0032, P0036-P0038, P0050-P0054, P0056-P0060, P0135, P0141, P0155, P0161, P103B, or P103C</u>
P0058	Engine Controls and Fuel - 3.6L (LFY) - <u>DTC P0030-P0032, P0036-P0038, P0050-P0054, P0056-P0060, P0135, P0141, P0155, P0161, P103B, or P103C</u>
P0059	Engine Controls and Fuel - 3.6L (LFY) - <u>DTC P0030-P0032, P0036-P0038, P0050-P0054, P0056-P0060, P0135, P0141, P0155, P0161, P103B, or P103C</u>
P0060	Engine Controls and Fuel - 3.6L (LFY) - <u>DTC P0030-P0032, P0036-P0038, P0050-P0054, P0056-P0060, P0135, P0141, P0155, P0161, P103B, or P103C</u>
P0068	Engine Controls and Fuel - 2.0L (LTG) - <u>DTC P0068 or P1101</u>
P0068	Engine Controls and Fuel - 3.6L (LFY) - <u>DTC P0068 or P1101</u>
P0071	Displays and Gauges - <u>DTC P0071-P0074</u>
P0072	Displays and Gauges - <u>DTC P0071-P0074</u>
P0073	Displays and Gauges - <u>DTC P0071-P0074</u>
P0074	Displays and Gauges - <u>DTC P0071-P0074</u>
P0089	Engine Controls and Fuel - 2.0L (LTG) - <u>DTC P0089, P00C6, P228C, P228D, or P2C1E-P2C20</u>
P0089	Engine Controls and Fuel - 3.6L (LFY) - <u>DTC P0089, P00C6, P228C, P228D, or P2C1E-P2C20</u>
P0090	Engine Controls and Fuel - 2.0L (LTG) - <u>DTC P0090-P0092, P00C8, P00C9, or P00CA</u>
P0090	Engine Controls and Fuel - 3.6L (LFY) - <u>DTC P0090-P0092, P00C8, P00C9, or P00CA</u>
P0091	Engine Controls and Fuel - 2.0L (LTG) - <u>DTC P0090-P0092, P00C8, P00C9, or P00CA</u>
P0091	Engine Controls and Fuel - 3.6L (LFY) - <u>DTC P0090-P0092, P00C8, P00C9, or P00CA</u>
P0092	Engine Controls and Fuel - 2.0L (LTG) - <u>DTC P0090-P0092, P00C8, P00C9, or P00CA</u>
P0092	Engine Controls and Fuel - 3.6L (LFY) - <u>DTC P0090-P0092, P00C8, P00C9, or P00CA</u>
P0096	Engine Controls and Fuel - 2.0L (LTG) - <u>DTC P0096 or P0111</u>
P0096	Engine Controls and Fuel - 3.6L (LFY) - <u>DTC P0096 or P0111</u>
P0097	Engine Controls and Fuel - 2.0L (LTG) - <u>DTC P0097, P0098, or P0099</u>

DTC	Diagnostic Procedure
P0097	Engine Controls and Fuel - 3.6L (LFY) - <u>DTC P0097, P0098, or P0099</u>
P0098	Engine Controls and Fuel - 2.0L (LTG) - <u>DTC P0097, P0098, or P0099</u>
P0098	Engine Controls and Fuel - 3.6L (LFY) - <u>DTC P0097, P0098, or P0099</u>
P0099	Engine Controls and Fuel - 2.0L (LTG) - <u>DTC P0097, P0098, or P0099</u>
P0099	Engine Controls and Fuel - 3.6L (LFY) - <u>DTC P0097, P0098, or P0099</u>
P00C6	Engine Controls and Fuel - 2.0L (LTG) - <u>DTC P0089, P00C6, P228C, P228D, or P2C1E-P2C20</u>
P00C6	Engine Controls and Fuel - 3.6L (LFY) - <u>DTC P0089, P00C6, P228C, P228D, or P2C1E-P2C20</u>
P00C7	Engine Controls and Fuel - 2.0L (LTG) - <u>DTC P00C7</u>
P00C7	Engine Controls and Fuel - 3.6L (LFY) - <u>DTC P00C7</u>
P00C8	Engine Controls and Fuel - 2.0L (LTG) - <u>DTC P0090-P0092, P00C8, P00C9, or P00CA</u>
P00C8	Engine Controls and Fuel - 3.6L (LFY) - <u>DTC P0090-P0092, P00C8, P00C9, or P00CA</u>
P00C9	Engine Controls and Fuel - 2.0L (LTG) - <u>DTC P0090-P0092, P00C8, P00C9, or P00CA</u>
P00C9	Engine Controls and Fuel - 3.6L (LFY) - <u>DTC P0090-P0092, P00C8, P00C9, or P00CA</u>
P00CA	Engine Controls and Fuel - 2.0L (LTG) - <u>DTC P0090-P0092, P00C8, P00C9, or P00CA</u>
P00CA	Engine Controls and Fuel - 3.6L (LFY) - <u>DTC P0090-P0092, P00C8, P00C9, or P00CA</u>
P00E9	Engine Controls and Fuel - 2.0L (LTG) - <u>DTC P00E9</u>
P00EA	Engine Controls and Fuel - 2.0L (LTG) - <u>DTC P00EA-P00EC</u>
P00EB	Engine Controls and Fuel - 2.0L (LTG) - <u>DTC P00EA-P00EC</u>
P00EC	Engine Controls and Fuel - 2.0L (LTG) - <u>DTC P00EA-P00EC</u>
P00F4	Engine Controls and Fuel - 2.0L (LTG) - <u>DTC P00F4-P00F6</u>
P00F4	Engine Controls and Fuel - 3.6L (LFY) - <u>DTC P00F4-P00F6</u>
P00F5	Engine Controls and Fuel - 2.0L (LTG) - <u>DTC P00F4-P00F6</u>
P00F5	Engine Controls and Fuel - 3.6L (LFY) - <u>DTC P00F4-P00F6</u>
P00F6	Engine Controls and Fuel - 2.0L (LTG) - <u>DTC P00F4-P00F6</u>
P00F6	Engine Controls and Fuel - 3.6L (LFY) - <u>DTC P00F4-P00F6</u>
P00FF	Engine Controls and Fuel - 2.0L (LTG) - <u>DTC P00FF, P069E, P06EC, P0700, P0800, P0AC4, P1700, P1E00, P2561, P25A2, P25AF, P25C9, P26C8, or P26C9</u>
P00FF	Engine Controls and Fuel - 3.6L (LFY) - <u>DTC P00FF, P069E, P06EC, P0700, P0800, P0AC4, P1700, P1E00, P2561, P25A2, P25AF, P25C9, P26C8, or P26C9</u>
P0101	Engine Controls and Fuel - 2.0L (LTG) - <u>DTC P0101</u>
P0101	Engine Controls and Fuel - 3.6L (LFY) - <u>DTC P0101</u>
P0102	Engine Controls and Fuel - 2.0L (LTG) - <u>DTC P0102 or P0103</u>
P0102	Engine Controls and Fuel - 3.6L (LFY) - <u>DTC P0102 or P0103</u>
P0103	Engine Controls and Fuel - 2.0L (LTG) - <u>DTC P0102 or P0103</u>
P0103	Engine Controls and Fuel - 3.6L (LFY) - <u>DTC P0102 or P0103</u>
P0106	Engine Controls and Fuel - 2.0L (LTG) - <u>DTC P0106</u>
P0106	Engine Controls and Fuel - 3.6L (LFY) - <u>DTC P0106</u>
P0107	Engine Controls and Fuel - 2.0L (LTG) - <u>DTC P0107 or P0108</u>
P0107	Engine Controls and Fuel - 3.6L (LFY) - <u>DTC P0107 or P0108</u>
P0108	Engine Controls and Fuel - 2.0L (LTG) - <u>DTC P0107 or P0108</u>
P0108	Engine Controls and Fuel - 3.6L (LFY) - <u>DTC P0107 or P0108</u>
P0111	Engine Controls and Fuel - 2.0L (LTG) - <u>DTC P0096 or P0111</u>
P0111	Engine Controls and Fuel - 3.6L (LFY) - <u>DTC P0096 or P0111</u>
P0112	Engine Controls and Fuel - 2.0L (LTG) - <u>DTC P0112, P0113, or P0114</u>
P0112	Engine Controls and Fuel - 3.6L (LFY) - <u>DTC P0112, P0113, or P0114</u>

DTC	Diagnostic Procedure
P0113	Engine Controls and Fuel - 2.0L (LTG) - DTC P0112, P0113, or P0114
P0113	Engine Controls and Fuel - 3.6L (LFY) - DTC P0112, P0113, or P0114
P0114	Engine Controls and Fuel - 2.0L (LTG) - DTC P0112, P0113, or P0114
P0114	Engine Controls and Fuel - 3.6L (LFY) - DTC P0112, P0113, or P0114
P0117	Engine Controls and Fuel - 2.0L (LTG) - DTC P0117, P0118, or P0119
P0117	Engine Controls and Fuel - 3.6L (LFY) - DTC P0117, P0118, or P0119
P0118	Engine Controls and Fuel - 2.0L (LTG) - DTC P0117, P0118, or P0119
P0118	Engine Controls and Fuel - 3.6L (LFY) - DTC P0117, P0118, or P0119
P0119	Engine Controls and Fuel - 2.0L (LTG) - DTC P0117, P0118, or P0119
P0119	Engine Controls and Fuel - 3.6L (LFY) - DTC P0117, P0118, or P0119
P0121	Engine Controls and Fuel - 2.0L (LTG) - DTC P0121-P0123, P0222, P0223, P16A0-P16A2, or P2135
P0121	Engine Controls and Fuel - 3.6L (LFY) - DTC P0121-P0123, P0222, P0223, P16A0-P16A2, or P2135
P0122	Engine Controls and Fuel - 2.0L (LTG) - DTC P0121-P0123, P0222, P0223, P16A0-P16A2, or P2135
P0122	Engine Controls and Fuel - 3.6L (LFY) - DTC P0121-P0123, P0222, P0223, P16A0-P16A2, or P2135
P0123	Engine Controls and Fuel - 2.0L (LTG) - DTC P0121-P0123, P0222, P0223, P16A0-P16A2, or P2135
P0123	Engine Controls and Fuel - 3.6L (LFY) - DTC P0121-P0123, P0222, P0223, P16A0-P16A2, or P2135
P0128	Engine Controls and Fuel - 2.0L (LTG) - DTC P0128
P0128	Engine Controls and Fuel - 3.6L (LFY) - DTC P0128
P0131	Engine Controls and Fuel - 2.0L (LTG) - DTC P0131, P0132, P015A, P015B, P223C, or P223E
P0131	Engine Controls and Fuel - 3.6L (LFY) - DTC P0131, P0132, P0137, P0138, P0151, P0152, P0157, or P0158
P0132	Engine Controls and Fuel - 2.0L (LTG) - DTC P0131, P0132, P015A, P015B, P223C, or P223E
P0132	Engine Controls and Fuel - 3.6L (LFY) - DTC P0131, P0132, P0137, P0138, P0151, P0152, P0157, or P0158
P0133	Engine Controls and Fuel - 3.6L (LFY) - DTC P0133, P013A-P013F, P014A, P014B, P0153, P015A-P015D, or P2270-P2273
P0135	Engine Controls and Fuel - 2.0L (LTG) - DTC P0030-P0032, P0036-P0038, P0054, P0135, P0141, P103B, or P103C
P0135	Engine Controls and Fuel - 3.6L (LFY) - DTC P0030-P0032, P0036-P0038, P0050-P0054, P0056-P0060, P0135, P0141, P0155, P0161, P103B, or P103C
P0137	Engine Controls and Fuel - 2.0L (LTG) - DTC P0137, P0138, P013A, P013B, P013E, P013F, P2270, or P2271
P0137	Engine Controls and Fuel - 3.6L (LFY) - DTC P0131, P0132, P0137, P0138, P0151, P0152, P0157, or P0158
P0138	Engine Controls and Fuel - 2.0L (LTG) - DTC P0137, P0138, P013A, P013B, P013E, P013F, P2270, or P2271
P0138	Engine Controls and Fuel - 3.6L (LFY) - DTC P0131, P0132, P0137, P0138, P0151, P0152, P0157, or P0158
P013A	Engine Controls and Fuel - 3.6L (LFY) - DTC P0133, P013A-P013F, P014A, P014B, P0153, P015A-P015D, or P2270-P2273
P013A	Engine Controls and Fuel - 2.0L (LTG) - DTC P0137, P0138, P013A, P013B, P013E, P013F, P2270, or P2271
P013B	Engine Controls and Fuel - 3.6L (LFY) - DTC P0133, P013A-P013F, P014A, P014B, P0153, P015A-P015D, or P2270-P2273
P013B	Engine Controls and Fuel - 2.0L (LTG) - DTC P0137, P0138, P013A, P013B, P013E, P013F, P2270, or P2271

DTC	Diagnostic Procedure
P013C	Engine Controls and Fuel - 3.6L (LFY) - DTC P0133 , P013A-P013F , P014A , P014B , P0153 , P015A-P015D , or P2270-P2273
P013D	Engine Controls and Fuel - 3.6L (LFY) - DTC P0133 , P013A-P013F , P014A , P014B , P0153 , P015A-P015D , or P2270-P2273
P013E	Engine Controls and Fuel - 3.6L (LFY) - DTC P0133 , P013A-P013F , P014A , P014B , P0153 , P015A-P015D , or P2270-P2273
P013E	Engine Controls and Fuel - 2.0L (LTG) - DTC P0137 , P0138 , P013A , P013B , P013E , P013F , P2270 , or P2271
P013F	Engine Controls and Fuel - 3.6L (LFY) - DTC P0133 , P013A-P013F , P014A , P014B , P0153 , P015A-P015D , or P2270-P2273
P013F	Engine Controls and Fuel - 2.0L (LTG) - DTC P0137 , P0138 , P013A , P013B , P013E , P013F , P2270 , or P2271
P0141	Engine Controls and Fuel - 2.0L (LTG) - DTC P0030-P0032 , P0036-P0038 , P0054 , P0135 , P0141 , P103B , or P103C
P0141	Engine Controls and Fuel - 3.6L (LFY) - DTC P0030-P0032 , P0036-P0038 , P0050-P0054 , P0056-P0060 , P0135 , P0141 , P0155 , P0161 , P103B , or P103C
P014A	Engine Controls and Fuel - 3.6L (LFY) - DTC P0133 , P013A-P013F , P014A , P014B , P0153 , P015A-P015D , or P2270-P2273
P014B	Engine Controls and Fuel - 3.6L (LFY) - DTC P0133 , P013A-P013F , P014A , P014B , P0153 , P015A-P015D , or P2270-P2273
P0151	Engine Controls and Fuel - 3.6L (LFY) - DTC P0131 , P0132 , P0137 , P0138 , P0151 , P0152 , P0157 , or P0158
P0152	Engine Controls and Fuel - 3.6L (LFY) - DTC P0131 , P0132 , P0137 , P0138 , P0151 , P0152 , P0157 , or P0158
P0153	Engine Controls and Fuel - 3.6L (LFY) - DTC P0133 , P013A-P013F , P014A , P014B , P0153 , P015A-P015D , or P2270-P2273
P0155	Engine Controls and Fuel - 3.6L (LFY) - DTC P0030-P0032 , P0036-P0038 , P0050-P0054 , P0056-P0060 , P0135 , P0141 , P0155 , P0161 , P103B , or P103C
P0157	Engine Controls and Fuel - 3.6L (LFY) - DTC P0131 , P0132 , P0137 , P0138 , P0151 , P0152 , P0157 , or P0158
P0158	Engine Controls and Fuel - 3.6L (LFY) - DTC P0131 , P0132 , P0137 , P0138 , P0151 , P0152 , P0157 , or P0158
P015A	Engine Controls and Fuel - 3.6L (LFY) - DTC P0133 , P013A-P013F , P014A , P014B , P0153 , P015A-P015D , or P2270-P2273
P015A	Engine Controls and Fuel - 2.0L (LTG) - DTC P0131 , P0132 , P015A , P015B , P223C , or P223E
P015B	Engine Controls and Fuel - 3.6L (LFY) - DTC P0133 , P013A-P013F , P014A , P014B , P0153 , P015A-P015D , or P2270-P2273
P015B	Engine Controls and Fuel - 2.0L (LTG) - DTC P0131 , P0132 , P015A , P015B , P223C , or P223E
P015C	Engine Controls and Fuel - 3.6L (LFY) - DTC P0133 , P013A-P013F , P014A , P014B , P0153 , P015A-P015D , or P2270-P2273
P015D	Engine Controls and Fuel - 3.6L (LFY) - DTC P0133 , P013A-P013F , P014A , P014B , P0153 , P015A-P015D , or P2270-P2273
P0161	Engine Controls and Fuel - 3.6L (LFY) - DTC P0030-P0032 , P0036-P0038 , P0050-P0054 , P0056-P0060 , P0135 , P0141 , P0155 , P0161 , P103B , or P103C
P0171	Engine Controls and Fuel - 2.0L (LTG) - DTC P0171 or P0172
P0171	Engine Controls and Fuel - 3.6L (LFY) - DTC P0171 , P0172 , P0174 , or P0175
P0172	Engine Controls and Fuel - 2.0L (LTG) - DTC P0171 or P0172
P0172	Engine Controls and Fuel - 3.6L (LFY) - DTC P0171 , P0172 , P0174 , or P0175
P0174	Engine Controls and Fuel - 3.6L (LFY) - DTC P0171 , P0172 , P0174 , or P0175
P0175	Engine Controls and Fuel - 3.6L (LFY) - DTC P0171 , P0172 , P0174 , or P0175
P0182	Engine Controls and Fuel - 3.6L (LFY) - DTC P0182 , P0183 , P0187 , P0188 , P0191 , P0192 , P111E , P126E , P126F , P127C , P128A , P128B , P16E4 , or P16E5 (LFY)

DTC	Diagnostic Procedure
P0183	Engine Controls and Fuel - 3.6L (LFY) - <u>DTC P0182, P0183, P0187, P0188, P0191, P0192, P111F, P126E, P126F, P127C, P128A, P128B, P16E4, or P16E5 (LFY)</u>
P0187	Engine Controls and Fuel - 3.6L (LFY) - <u>DTC P0182, P0183, P0187, P0188, P0191, P0192, P111F, P126E, P126F, P127C, P128A, P128B, P16E4, or P16E5 (LFY)</u>
P0188	Engine Controls and Fuel - 3.6L (LFY) - <u>DTC P0182, P0183, P0187, P0188, P0191, P0192, P111F, P126E, P126F, P127C, P128A, P128B, P16E4, or P16E5 (LFY)</u>
P018B	Engine Controls and Fuel - 2.0L (LTG) - <u>DTC P018B-P018D</u>
P018B	Engine Controls and Fuel - 3.6L (LFY) - <u>DTC P018B-P018D</u>
P018C	Engine Controls and Fuel - 2.0L (LTG) - <u>DTC P018B-P018D</u>
P018C	Engine Controls and Fuel - 3.6L (LFY) - <u>DTC P018B-P018D</u>
P018D	Engine Controls and Fuel - 2.0L (LTG) - <u>DTC P018B-P018D</u>
P018D	Engine Controls and Fuel - 3.6L (LFY) - <u>DTC P018B-P018D</u>
P0191	Engine Controls and Fuel - 2.0L (LTG) - <u>DTC P0191 or P0192</u>
P0191	Engine Controls and Fuel - 3.6L (LFY) - <u>DTC P0182, P0183, P0187, P0188, P0191, P0192, P111F, P126E, P126F, P127C, P128A, P128B, P16E4, or P16E5 (LFY)</u>
P0192	Engine Controls and Fuel - 2.0L (LTG) - <u>DTC P0191 or P0192</u>
P0192	Engine Controls and Fuel - 3.6L (LFY) - <u>DTC P0182, P0183, P0187, P0188, P0191, P0192, P111F, P126E, P126F, P127C, P128A, P128B, P16E4, or P16E5 (LFY)</u>
P0201	Engine Controls and Fuel - 2.0L (LTG) - <u>DTC P0201-P0204, P0261, P0262, P0264, P0265, P0267, P0268, P0270, P0271, P1248, P1249, P124A, P124B, P2147, P2148, P2150, P2151, P2153, P2154, P2156, or P2157</u>
P0201	Engine Controls and Fuel - 3.6L (LFY) - <u>DTC P0201, P0202, P0203, P0204, P0205, P0206, P0261, P0262, P0264, P0265, P0267, P0268, P0270, P0271, P0273, P0274, P0276, or P0277</u>
P0202	Engine Controls and Fuel - 2.0L (LTG) - <u>DTC P0201-P0204, P0261, P0262, P0264, P0265, P0267, P0268, P0270, P0271, P1248, P1249, P124A, P124B, P2147, P2148, P2150, P2151, P2153, P2154, P2156, or P2157</u>
P0202	Engine Controls and Fuel - 3.6L (LFY) - <u>DTC P0201, P0202, P0203, P0204, P0205, P0206, P0261, P0262, P0264, P0265, P0267, P0268, P0270, P0271, P0273, P0274, P0276, or P0277</u>
P0203	Engine Controls and Fuel - 2.0L (LTG) - <u>DTC P0201-P0204, P0261, P0262, P0264, P0265, P0267, P0268, P0270, P0271, P1248, P1249, P124A, P124B, P2147, P2148, P2150, P2151, P2153, P2154, P2156, or P2157</u>
P0203	Engine Controls and Fuel - 3.6L (LFY) - <u>DTC P0201, P0202, P0203, P0204, P0205, P0206, P0261, P0262, P0264, P0265, P0267, P0268, P0270, P0271, P0273, P0274, P0276, or P0277</u>
P0204	Engine Controls and Fuel - 2.0L (LTG) - <u>DTC P0201-P0204, P0261, P0262, P0264, P0265, P0267, P0268, P0270, P0271, P1248, P1249, P124A, P124B, P2147, P2148, P2150, P2151, P2153, P2154, P2156, or P2157</u>
P0204	Engine Controls and Fuel - 3.6L (LFY) - <u>DTC P0201, P0202, P0203, P0204, P0205, P0206, P0261, P0262, P0264, P0265, P0267, P0268, P0270, P0271, P0273, P0274, P0276, or P0277</u>
P0205	Engine Controls and Fuel - 3.6L (LFY) - <u>DTC P0201, P0202, P0203, P0204, P0205, P0206, P0261, P0262, P0264, P0265, P0267, P0268, P0270, P0271, P0273, P0274, P0276, or P0277</u>
P0206	Engine Controls and Fuel - 3.6L (LFY) - <u>DTC P0201, P0202, P0203, P0204, P0205, P0206, P0261, P0262, P0264, P0265, P0267, P0268, P0270, P0271, P0273, P0274, P0276, or P0277</u>
P0222	Engine Controls and Fuel - 2.0L (LTG) - <u>DTC P0121-P0123, P0222, P0223, P16A0-P16A2, or P2135</u>
P0222	Engine Controls and Fuel - 3.6L (LFY) - <u>DTC P0121-P0123, P0222, P0223, P16A0-P16A2, or P2135</u>

[illegible]

DTC	Diagnostic Procedure
P0270	Engine Controls and Fuel - 3.6L (LFY) - <u>DTC P0201, P0202, P0203, P0204, P0205, P0206, P0261, P0262, P0264, P0265, P0267, P0268, P0270, P0271, P0273, P0274, P0276, or P0277</u>
P0271	Engine Controls and Fuel - 2.0L (LTG) - <u>DTC P0201-P0204, P0261, P0262, P0264, P0265, P0267, P0268, P0270, P0271, P1248, P1249, P124A, P124B, P2147, P2148, P2150, P2151, P2153, P2154, P2156, or P2157</u>
P0271	Engine Controls and Fuel - 3.6L (LFY) - <u>DTC P0201, P0202, P0203, P0204, P0205, P0206, P0261, P0262, P0264, P0265, P0267, P0268, P0270, P0271, P0273, P0274, P0276, or P0277</u>
P0273	Engine Controls and Fuel - 3.6L (LFY) - <u>DTC P0201, P0202, P0203, P0204, P0205, P0206, P0261, P0262, P0264, P0265, P0267, P0268, P0270, P0271, P0273, P0274, P0276, or P0277</u>
P0274	Engine Controls and Fuel - 3.6L (LFY) - <u>DTC P0201, P0202, P0203, P0204, P0205, P0206, P0261, P0262, P0264, P0265, P0267, P0268, P0270, P0271, P0273, P0274, P0276, or P0277</u>
P0276	Engine Controls and Fuel - 3.6L (LFY) - <u>DTC P0201, P0202, P0203, P0204, P0205, P0206, P0261, P0262, P0264, P0265, P0267, P0268, P0270, P0271, P0273, P0274, P0276, or P0277</u>
P0277	Engine Controls and Fuel - 3.6L (LFY) - <u>DTC P0201, P0202, P0203, P0204, P0205, P0206, P0261, P0262, P0264, P0265, P0267, P0268, P0270, P0271, P0273, P0274, P0276, or P0277</u>
P0299	Engine Controls and Fuel - 2.0L (LTG) - <u>DTC P0234 or P0299</u>
P0300	Engine Controls and Fuel - 2.0L (LTG) - <u>DTC P0300-P0304</u>
P0300	Engine Controls and Fuel - 3.6L (LFY) - <u>DTC P0300-P0306</u>
P0301	Engine Controls and Fuel - 2.0L (LTG) - <u>DTC P0300-P0304</u>
P0301	Engine Controls and Fuel - 3.6L (LFY) - <u>DTC P0300-P0306</u>
P0302	Engine Controls and Fuel - 2.0L (LTG) - <u>DTC P0300-P0304</u>
P0302	Engine Controls and Fuel - 3.6L (LFY) - <u>DTC P0300-P0306</u>
P0303	Engine Controls and Fuel - 2.0L (LTG) - <u>DTC P0300-P0304</u>
P0303	Engine Controls and Fuel - 3.6L (LFY) - <u>DTC P0300-P0306</u>
P0304	Engine Controls and Fuel - 2.0L (LTG) - <u>DTC P0300-P0304</u>
P0304	Engine Controls and Fuel - 3.6L (LFY) - <u>DTC P0300-P0306</u>
P0305	Engine Controls and Fuel - 3.6L (LFY) - <u>DTC P0300-P0306</u>
P0306	Engine Controls and Fuel - 3.6L (LFY) - <u>DTC P0300-P0306</u>
P0315	Engine Controls and Fuel - 2.0L (LTG) - <u>DTC P0315</u>
P0315	Engine Controls and Fuel - 3.6L (LFY) - <u>DTC P0315</u>
P0324	Engine Controls and Fuel - 3.6L (LFY) - <u>DTC P0324-P0328, P0330-P0333, P06B6, or P06B7</u>
P0324	Engine Controls and Fuel - 2.0L (LTG) - <u>DTC P0324, P0326, P0331, P06B6, or P06B7</u>
P0325	Engine Controls and Fuel - 3.6L (LFY) - <u>DTC P0324-P0328, P0330-P0333, P06B6, or P06B7</u>
P0325	Engine Controls and Fuel - 2.0L (LTG) - <u>DTC P0325, P0327, P0328, P0330, P0332, or P0333</u>
P0326	Engine Controls and Fuel - 3.6L (LFY) - <u>DTC P0324-P0328, P0330-P0333, P06B6, or P06B7</u>
P0326	Engine Controls and Fuel - 2.0L (LTG) - <u>DTC P0324, P0326, P0331, P06B6, or P06B7</u>
P0327	Engine Controls and Fuel - 3.6L (LFY) - <u>DTC P0324-P0328, P0330-P0333, P06B6, or P06B7</u>
P0327	Engine Controls and Fuel - 2.0L (LTG) - <u>DTC P0325, P0327, P0328, P0330, P0332, or P0333</u>
P0328	Engine Controls and Fuel - 3.6L (LFY) - <u>DTC P0324-P0328, P0330-P0333, P06B6, or P06B7</u>

DTC	Diagnostic Procedure
P0328	Engine Controls and Fuel - 2.0L (LTG) - <u>DTC P0325, P0327, P0328, P0330, P0332, or P0333</u>
P0330	Engine Controls and Fuel - 3.6L (LFY) - <u>DTC P0324-P0328, P0330-P0333, P06B6, or P06B7</u>
P0330	Engine Controls and Fuel - 2.0L (LTG) - <u>DTC P0325, P0327, P0328, P0330, P0332, or P0333</u>
P0331	Engine Controls and Fuel - 3.6L (LFY) - <u>DTC P0324-P0328, P0330-P0333, P06B6, or P06B7</u>
P0331	Engine Controls and Fuel - 2.0L (LTG) - <u>DTC P0324, P0326, P0331, P06B6, or P06B7</u>
P0332	Engine Controls and Fuel - 3.6L (LFY) - <u>DTC P0324-P0328, P0330-P0333, P06B6, or P06B7</u>
P0332	Engine Controls and Fuel - 2.0L (LTG) - <u>DTC P0325, P0327, P0328, P0330, P0332, or P0333</u>
P0333	Engine Controls and Fuel - 3.6L (LFY) - <u>DTC P0324-P0328, P0330-P0333, P06B6, or P06B7</u>
P0333	Engine Controls and Fuel - 2.0L (LTG) - <u>DTC P0325, P0327, P0328, P0330, P0332, or P0333</u>
P0335	Engine Controls and Fuel - 2.0L (LTG) - <u>DTC P0335 or P0336</u>
P0335	Engine Controls and Fuel - 3.6L (LFY) - <u>DTC P0335 or P0336</u>
P0336	Engine Controls and Fuel - 2.0L (LTG) - <u>DTC P0335 or P0336</u>
P0336	Engine Controls and Fuel - 3.6L (LFY) - <u>DTC P0335 or P0336</u>
P0340	Engine Controls and Fuel - 2.0L (LTG) - <u>DTC P0340, P0341, P0365, or P0366</u>
P0340	Engine Controls and Fuel - 3.6L (LFY) - <u>DTC P0340, P0341, P0345, P0346, P0365, P0366, P0390, or P0391</u>
P0341	Engine Controls and Fuel - 2.0L (LTG) - <u>DTC P0340, P0341, P0365, or P0366</u>
P0341	Engine Controls and Fuel - 3.6L (LFY) - <u>DTC P0340, P0341, P0345, P0346, P0365, P0366, P0390, or P0391</u>
P0345	Engine Controls and Fuel - 3.6L (LFY) - <u>DTC P0340, P0341, P0345, P0346, P0365, P0366, P0390, or P0391</u>
P0346	Engine Controls and Fuel - 3.6L (LFY) - <u>DTC P0340, P0341, P0345, P0346, P0365, P0366, P0390, or P0391</u>
P034A	Engine Controls and Fuel - 2.0L (LTG) - <u>DTC P034A or P034B</u>
P034A	Engine Controls and Fuel - 3.6L (LFY) - <u>DTC P034A or P034B</u>
P034B	Engine Controls and Fuel - 2.0L (LTG) - <u>DTC P034A or P034B</u>
P034B	Engine Controls and Fuel - 3.6L (LFY) - <u>DTC P034A or P034B</u>
P0351	Engine Controls and Fuel - 2.0L (LTG) - <u>DTC P0351-P0354, P2300, P2301, P2303, P2304, P2306, P2307, P2309, or P2310</u>
P0351	Engine Controls and Fuel - 3.6L (LFY) - <u>DTC P0351-P0356, P2300, P2301, P2303, P2304, P2306, P2307, P2309, P2310, P2312, P2313, P2315, or P2316</u>
P0352	Engine Controls and Fuel - 2.0L (LTG) - <u>DTC P0351-P0354, P2300, P2301, P2303, P2304, P2306, P2307, P2309, or P2310</u>
P0352	Engine Controls and Fuel - 3.6L (LFY) - <u>DTC P0351-P0356, P2300, P2301, P2303, P2304, P2306, P2307, P2309, P2310, P2312, P2313, P2315, or P2316</u>
P0353	Engine Controls and Fuel - 2.0L (LTG) - <u>DTC P0351-P0354, P2300, P2301, P2303, P2304, P2306, P2307, P2309, or P2310</u>
P0353	Engine Controls and Fuel - 3.6L (LFY) - <u>DTC P0351-P0356, P2300, P2301, P2303, P2304, P2306, P2307, P2309, P2310, P2312, P2313, P2315, or P2316</u>
P0354	Engine Controls and Fuel - 2.0L (LTG) - <u>DTC P0351-P0354, P2300, P2301, P2303, P2304, P2306, P2307, P2309, or P2310</u>
P0354	Engine Controls and Fuel - 3.6L (LFY) - <u>DTC P0351-P0356, P2300, P2301, P2303, P2304, P2306, P2307, P2309, P2310, P2312, P2313, P2315, or P2316</u>
P0355	Engine Controls and Fuel - 3.6L (LFY) - <u>DTC P0351-P0356, P2300, P2301, P2303, P2304, P2306, P2307, P2309, P2310, P2312, P2313, P2315, or P2316</u>

DTC	Diagnostic Procedure
P0356	Engine Controls and Fuel - 3.6L (LFY) - <u>DTC P0351-P0356, P2300, P2301, P2303, P2304, P2306, P2307, P2309, P2310, P2312, P2313, P2315, or P2316</u>
P0365	Engine Controls and Fuel - 2.0L (LTG) - <u>DTC P0340, P0341, P0365, or P0366</u>
P0365	Engine Controls and Fuel - 3.6L (LFY) - <u>DTC P0340, P0341, P0345, P0346, P0365, P0366, P0390, or P0391</u>
P0366	Engine Controls and Fuel - 2.0L (LTG) - <u>DTC P0340, P0341, P0365, or P0366</u>
P0366	Engine Controls and Fuel - 3.6L (LFY) - <u>DTC P0340, P0341, P0345, P0346, P0365, P0366, P0390, or P0391</u>
P0390	Engine Controls and Fuel - 3.6L (LFY) - <u>DTC P0340, P0341, P0345, P0346, P0365, P0366, P0390, or P0391</u>
P0391	Engine Controls and Fuel - 3.6L (LFY) - <u>DTC P0340, P0341, P0345, P0346, P0365, P0366, P0390, or P0391</u>
P0420	Engine Controls and Fuel - 2.0L (LTG) - <u>DTC P0420</u>
P0420	Engine Controls and Fuel - 3.6L (LFY) - <u>DTC P0420 or P0430</u>
P0430	Engine Controls and Fuel - 3.6L (LFY) - <u>DTC P0420 or P0430</u>
P0442	Engine Controls and Fuel - 2.0L (LTG) - <u>DTC P0442</u>
P0442	Engine Controls and Fuel - 3.6L (LFY) - <u>DTC P0442</u>
P0443	Engine Controls and Fuel - 2.0L (LTG) - <u>DTC P0443, P0458, or P0459</u>
P0443	Engine Controls and Fuel - 3.6L (LFY) - <u>DTC P0443, P0458, or P0459</u>
P0446	Engine Controls and Fuel - 2.0L (LTG) - <u>DTC P0446</u>
P0446	Engine Controls and Fuel - 3.6L (LFY) - <u>DTC P0446</u>
P0449	Engine Controls and Fuel - 2.0L (LTG) - <u>DTC P0449, P0498, or P0499</u>
P0449	Engine Controls and Fuel - 3.6L (LFY) - <u>DTC P0449, P0498, or P0499</u>
P0451	Engine Controls and Fuel - 2.0L (LTG) - <u>DTC P0451-P0454</u>
P0451	Engine Controls and Fuel - 3.6L (LFY) - <u>DTC P0451-P0454</u>
P0452	Engine Controls and Fuel - 2.0L (LTG) - <u>DTC P0451-P0454</u>
P0452	Engine Controls and Fuel - 3.6L (LFY) - <u>DTC P0451-P0454</u>
P0453	Engine Controls and Fuel - 2.0L (LTG) - <u>DTC P0451-P0454</u>
P0453	Engine Controls and Fuel - 3.6L (LFY) - <u>DTC P0451-P0454</u>
P0454	Engine Controls and Fuel - 2.0L (LTG) - <u>DTC P0451-P0454</u>
P0454	Engine Controls and Fuel - 3.6L (LFY) - <u>DTC P0451-P0454</u>
P0455	Engine Controls and Fuel - 2.0L (LTG) - <u>DTC P0455</u>
P0455	Engine Controls and Fuel - 3.6L (LFY) - <u>DTC P0455</u>
P0458	Engine Controls and Fuel - 2.0L (LTG) - <u>DTC P0443, P0458, or P0459</u>
P0458	Engine Controls and Fuel - 3.6L (LFY) - <u>DTC P0443, P0458, or P0459</u>
P0459	Engine Controls and Fuel - 2.0L (LTG) - <u>DTC P0443, P0458, or P0459</u>
P0459	Engine Controls and Fuel - 3.6L (LFY) - <u>DTC P0443, P0458, or P0459</u>
P0461	Displays and Gauges - <u>DTC P0461-P0464 (without F48)</u>
P0461	Displays and Gauges - <u>DTC P0461-P0464, P2066, P2067, or P2068 (with F48)</u>
P0462	Displays and Gauges - <u>DTC P0461-P0464 (without F48)</u>
P0462	Displays and Gauges - <u>DTC P0461-P0464, P2066, P2067, or P2068 (with F48)</u>
P0463	Displays and Gauges - <u>DTC P0461-P0464 (without F48)</u>
P0463	Displays and Gauges - <u>DTC P0461-P0464, P2066, P2067, or P2068 (with F48)</u>
P0464	Displays and Gauges - <u>DTC P0461-P0464 (without F48)</u>
P0464	Displays and Gauges - <u>DTC P0461-P0464, P2066, P2067, or P2068 (with F48)</u>
P0480	Engine Heating and Cooling - <u>DTC P0480, P0691, or P0692</u>
P0496	Engine Controls and Fuel - 2.0L (LTG) - <u>DTC P0496</u>
P0496	Engine Controls and Fuel - 3.6L (LFY) - <u>DTC P0496</u>
P0498	Engine Controls and Fuel - 2.0L (LTG) - <u>DTC P0449, P0498, or P0499</u>
P0498	Engine Controls and Fuel - 3.6L (LFY) - <u>DTC P0449, P0498, or P0499</u>
P0499	Engine Controls and Fuel - 2.0L (LTG) - <u>DTC P0449, P0498, or P0499</u>
P0499	Engine Controls and Fuel - 3.6L (LFY) - <u>DTC P0449, P0498, or P0499</u>
P0506	Engine Controls and Fuel - 2.0L (LTG) - <u>DTC P0506 or P0507</u>

DTC	Diagnostic Procedure
P0506	Engine Controls and Fuel - 3.6L (LFY) - DTC P0506 or P0507
P0507	Engine Controls and Fuel - 2.0L (LTG) - DTC P0506 or P0507
P0507	Engine Controls and Fuel - 3.6L (LFY) - DTC P0506 or P0507
P050D	Engine Controls and Fuel - 2.0L (LTG) - DTC P050D
P050D	Engine Controls and Fuel - 3.6L (LFY) - DTC P050D
P050F	Hydraulic Brakes - DTC P050F
P0513	Immobilizer - DTC P0513
P0520	Displays and Gauges - DTC P0520
P0521	Displays and Gauges - DTC P0521 (with LFY)
P0521	Displays and Gauges - DTC P0521, P0522, or P0523 (without LFY)
P0522	Displays and Gauges - DTC P0521, P0522, or P0523 (without LFY)
P0523	Displays and Gauges - DTC P0521, P0522, or P0523 (without LFY)
P0532	HVAC - Automatic - DTC P0532 or P0533
P0533	HVAC - Automatic - DTC P0532 or P0533
P0556	Hydraulic Brakes - DTC P0556, P0557, or P0558
P0557	Hydraulic Brakes - DTC P0556, P0557, or P0558
P0558	Hydraulic Brakes - DTC P0556, P0557, or P0558
P0560	12 V Starting and Charging - DTC B1325, B1327, B1328, B1330, B1390, B1395, B1400, B1410, B1415, B1424, B1425, B1439, B1517, C0800, C0805, C0870, C0880, C0895, C0899, C0900, C1300, P0560-P0563, P0611, P1002, P129B, P129C, P1465, P1466, P15AE, P15AF, P17B0-P17B2, P17DD-P17DE, P1A0C, P1A0D, P1E19, P1E1A, or U2800
P0561	12 V Starting and Charging - DTC B1325, B1327, B1328, B1330, B1390, B1395, B1400, B1410, B1415, B1424, B1425, B1439, B1517, C0800, C0805, C0870, C0880, C0895, C0899, C0900, C1300, P0560-P0563, P0611, P1002, P129B, P129C, P1465, P1466, P15AE, P15AF, P17B0-P17B2, P17DD-P17DE, P1A0C, P1A0D, P1E19, P1E1A, or U2800
P0561	12 V Starting and Charging - DTC P0561
P0562	12 V Starting and Charging - DTC B1325, B1327, B1328, B1330, B1390, B1395, B1400, B1410, B1415, B1424, B1425, B1439, B1517, C0800, C0805, C0870, C0880, C0895, C0899, C0900, C1300, P0560-P0563, P0611, P1002, P129B, P129C, P1465, P1466, P15AE, P15AF, P17B0-P17B2, P17DD-P17DE, P1A0C, P1A0D, P1E19, P1E1A, or U2800
P0563	12 V Starting and Charging - DTC B1325, B1327, B1328, B1330, B1390, B1395, B1400, B1410, B1415, B1424, B1425, B1439, B1517, C0800, C0805, C0870, C0880, C0895, C0899, C0900, C1300, P0560-P0563, P0611, P1002, P129B, P129C, P1465, P1466, P15AE, P15AF, P17B0-P17B2, P17DD-P17DE, P1A0C, P1A0D, P1E19, P1E1A, or U2800
P0564	Cruise Control - Cruise Control Malfunction - DTC B3794, P0564, P0565, P0567, P0568, P056C, P0580, P0581, P155A-P155C, or P162C
P0565	Cruise Control - Cruise Control Malfunction - DTC B3794, P0564, P0565, P0567, P0568, P056C, P0580, P0581, P155A-P155C, or P162C
P0567	Cruise Control - Cruise Control Malfunction - DTC B3794, P0564, P0565, P0567, P0568, P056C, P0580, P0581, P155A-P155C, or P162C
P0568	Cruise Control - Cruise Control Malfunction - DTC B3794, P0564, P0565, P0567, P0568, P056C, P0580, P0581, P155A-P155C, or P162C
P056C	Cruise Control - Cruise Control Malfunction - DTC B3794, P0564, P0565, P0567, P0568, P056C, P0580, P0581, P155A-P155C, or P162C
P0571	Cruise Control - DTC P0571
P0572	Cruise Control - DTC P0572 or P0573
P0573	Cruise Control - DTC P0572 or P0573
P0575	Cruise Control - DTC P0575
P057B	Engine Controls and Fuel - 2.0L (LTG) - DTC P057B-P057E
P057B	Engine Controls and Fuel - 3.6L (LFY) - DTC P057B-P057E
P057C	Engine Controls and Fuel - 2.0L (LTG) - DTC P057B-P057E

DTC	Diagnostic Procedure
P057C	Engine Controls and Fuel - 3.6L (LFY) - DTC P057B-P057E
P057D	Engine Controls and Fuel - 2.0L (LTG) - DTC P057B-P057E
P057D	Engine Controls and Fuel - 3.6L (LFY) - DTC P057B-P057E
P057E	Engine Controls and Fuel - 2.0L (LTG) - DTC P057B-P057E
P057E	Engine Controls and Fuel - 3.6L (LFY) - DTC P057B-P057E
P0580	Cruise Control - Cruise Control Malfunction - DTC B3794, P0564, P0565, P0567, P0568, P056C, P0580, P0581, P155A-P155C, or P162C
P0581	Cruise Control - Cruise Control Malfunction - DTC B3794, P0564, P0565, P0567, P0568, P056C, P0580, P0581, P155A-P155C, or P162C
P058A	12 V Starting and Charging - DTC P058A-P058F, P16D4-P16D6, P16DC-P16DF, or P16E1-P16E3
P058B	12 V Starting and Charging - DTC P058A-P058F, P16D4-P16D6, P16DC-P16DF, or P16E1-P16E3
P058C	12 V Starting and Charging - DTC P058A-P058F, P16D4-P16D6, P16DC-P16DF, or P16E1-P16E3
P058D	12 V Starting and Charging - DTC P058A-P058F, P16D4-P16D6, P16DC-P16DF, or P16E1-P16E3
P058E	12 V Starting and Charging - DTC P058A-P058F, P16D4-P16D6, P16DC-P16DF, or P16E1-P16E3
P058F	12 V Starting and Charging - DTC P058A-P058F, P16D4-P16D6, P16DC-P16DF, or P16E1-P16E3
P059F	Bumpers and Fascias - DTC P059F or P151E
P05AE	Bumpers and Fascias - DTC P05AE or P151E
P05CC	Engine Controls and Fuel - 2.0L (LTG) - DTC P05CC or P05CE
P05CE	Engine Controls and Fuel - 2.0L (LTG) - DTC P05CC or P05CE
P0601	Engine Controls and Fuel - 2.0L (LTG) - DTC P0601-P0604, P0606, P062B, P062F, P0630, P064D, P16F3, or P262B
P0601	Engine Controls and Fuel - 3.6L (LFY) - DTC P0601-P0604, P0606, P062B, P062F, P0630, P16F3, or P262B
P0601	Data Communications - DTC P0601-P0607, P060A-P060C, P0610, P062F, P16E9-P16F3, P262B, or P30D6-P30DD
P0601	Automatic Transmission - 9T65 (M3V) - DTC P0601-P0604, P0606, P062F, P16F3, or P16FB
P0602	Engine Controls and Fuel - 2.0L (LTG) - DTC P0601-P0604, P0606, P062B, P062F, P0630, P064D, P16F3, or P262B
P0602	Engine Controls and Fuel - 3.6L (LFY) - DTC P0601-P0604, P0606, P062B, P062F, P0630, P16F3, or P262B
P0602	Data Communications - DTC P0601-P0607, P060A-P060C, P0610, P062F, P16E9-P16F3, P262B, or P30D6-P30DD
P0602	Automatic Transmission - 9T65 (M3V) - DTC P0601-P0604, P0606, P062F, P16F3, or P16FB
P0603	Engine Controls and Fuel - 2.0L (LTG) - DTC P0601-P0604, P0606, P062B, P062F, P0630, P064D, P16F3, or P262B
P0603	Engine Controls and Fuel - 3.6L (LFY) - DTC P0601-P0604, P0606, P062B, P062F, P0630, P16F3, or P262B
P0603	Data Communications - DTC P0601-P0607, P060A-P060C, P0610, P062F, P16E9-P16F3, P262B, or P30D6-P30DD
P0603	Automatic Transmission - 9T65 (M3V) - DTC P0601-P0604, P0606, P062F, P16F3, or P16FB
P0604	Engine Controls and Fuel - 2.0L (LTG) - DTC P0601-P0604, P0606, P062B, P062F, P0630, P064D, P16F3, or P262B
P0604	Engine Controls and Fuel - 3.6L (LFY) - DTC P0601-P0604, P0606, P062B, P062F, P0630, P16F3, or P262B
P0604	Data Communications - DTC P0601-P0607, P060A-P060C, P0610, P062F, P16E9-P16F3, P262B, or P30D6-P30DD

DTC	Diagnostic Procedure
P0604	Automatic Transmission - 9T65 (M3V) - DTC P0601-P0604 , P0606 , P062F , P16F3 , or P16FB
P0605	Data Communications - DTC P0601-P0607 , P060A-P060C , P0610 , P062F , P16E9-P16F3 , P262B , or P30D6-P30DD
P0606	Data Communications - DTC P0601-P0607 , P060A-P060C , P0610 , P062F , P16E9-P16F3 , P262B , or P30D6-P30DD
P0606	Engine Controls and Fuel - 2.0L (LTG) - DTC P0601-P0604 , P0606 , P062B , P062F , P0630 , P064D , P16F3 , or P262B
P0606	Engine Controls and Fuel - 3.6L (LFY) - DTC P0601-P0604 , P0606 , P062B , P062F , P0630 , P16F3 , or P262B
P0606	Automatic Transmission - 9T65 (M3V) - DTC P0601-P0604 , P0606 , P062F , P16F3 , or P16FB
P0607	Data Communications - DTC P0601-P0607 , P060A-P060C , P0610 , P062F , P16E9-P16F3 , P262B , or P30D6-P30DD
P060A	Data Communications - DTC P0601-P0607 , P060A-P060C , P0610 , P062F , P16E9-P16F3 , P262B , or P30D6-P30DD
P060B	Data Communications - DTC P0601-P0607 , P060A-P060C , P0610 , P062F , P16E9-P16F3 , P262B , or P30D6-P30DD
P060C	Data Communications - DTC P0601-P0607 , P060A-P060C , P0610 , P062F , P16E9-P16F3 , P262B , or P30D6-P30DD
P0611	12 V Starting and Charging - DTC B1325 , B1327 , B1328 , B1330 , B1390 , B1395 , B1400 , B1410 , B1415 , B1424 , B1425 , B1439 , B1517 , C0800 , C0805 , C0870 , C0880 , C0895 , C0899 , C0900 , C1300 , P0560-P0563 , P0611 , P1002 , P129B , P129C , P1465 , P1466 , P15AE , P15AF , P17B0-P17B2 , P17DD-P17DE , P1A0C , P1A0D , P1E19 , P1E1A , or U2800
P0615	12 V Starting and Charging - DTC P0615 , P0616 , or P0617
P0616	12 V Starting and Charging - DTC P0615 , P0616 , or P0617
P0617	12 V Starting and Charging - DTC P0615 , P0616 , or P0617
P0621	12 V Starting and Charging - DTC P0621
P0622	12 V Starting and Charging - DTC P0622
P0625	12 V Starting and Charging - DTC P0625 or P0626
P0626	12 V Starting and Charging - DTC P0625 or P0626
P0627	Engine Controls and Fuel - 2.0L (LTG) - DTC P0627-P0629
P0627	Engine Controls and Fuel - 3.6L (LFY) - DTC P0627-P0629
P0628	Engine Controls and Fuel - 2.0L (LTG) - DTC P0627-P0629
P0628	Engine Controls and Fuel - 3.6L (LFY) - DTC P0627-P0629
P0629	Engine Controls and Fuel - 2.0L (LTG) - DTC P0627-P0629
P0629	Engine Controls and Fuel - 3.6L (LFY) - DTC P0627-P0629
P062B	Engine Controls and Fuel - 2.0L (LTG) - DTC P0601-P0604 , P0606 , P062B , P062F , P0630 , P064D , P16F3 , or P262B
P062B	Engine Controls and Fuel - 3.6L (LFY) - DTC P0601-P0604 , P0606 , P062B , P062F , P0630 , P16F3 , or P262B
P062F	Data Communications - DTC P0601-P0607 , P060A-P060C , P0610 , P062F , P16E9-P16F3 , P262B , or P30D6-P30DD
P062F	Automatic Transmission - 9T65 (M3V) - DTC P0601-P0604 , P0606 , P062F , P16F3 , or P16FB
P062F	Engine Controls and Fuel - 2.0L (LTG) - DTC P0601-P0604 , P0606 , P062B , P062F , P0630 , P064D , P16F3 , or P262B
P062F	Engine Controls and Fuel - 3.6L (LFY) - DTC P0601-P0604 , P0606 , P062B , P062F , P0630 , P16F3 , or P262B
P0630	Engine Controls and Fuel - 2.0L (LTG) - DTC P0601-P0604 , P0606 , P062B , P062F , P0630 , P064D , P16F3 , or P262B
P0630	Engine Controls and Fuel - 3.6L (LFY) - DTC P0601-P0604 , P0606 , P062B , P062F , P0630 , P16F3 , or P262B
P0633	Immobilizer - DTC P0633

DTC	Diagnostic Procedure
P0641	Engine Controls and Fuel - 2.0L (LTG) - DTC P0641, P0651, P0697, P06A3, or P06D2
P0641	Engine Controls and Fuel - 3.6L (LFY) - DTC P0641, P0651, P0697, or P06A3
P0645	HVAC - Automatic - DTC P0645, P0646, or P0647
P0646	HVAC - Automatic - DTC P0645, P0646, or P0647
P0647	HVAC - Automatic - DTC P0645, P0646, or P0647
P064D	Engine Controls and Fuel - 2.0L (LTG) - DTC P0601-P0604, P0606, P062B, P062F, P0630, P064D, P16F3, or P262B
P0650	Engine Controls and Fuel - 2.0L (LTG) - DTC P0650, P263A, or P263B
P0650	Engine Controls and Fuel - 3.6L (LFY) - DTC P0650, P263A, or P263B
P0651	Engine Controls and Fuel - 2.0L (LTG) - DTC P0641, P0651, P0697, P06A3, or P06D2
P0651	Engine Controls and Fuel - 3.6L (LFY) - DTC P0641, P0651, P0697, or P06A3
P0658	Automatic Transmission - 9T65 (M3V) - DTC P0658, P0659, P2727, P2729, P2730, P2736, P2738, P2739, P2826, P2827, P282F, or P2830
P0685	Engine Controls and Fuel - 2.0L (LTG) - DTC P0685-P0687, P0689, P0690, or P1682
P0685	Engine Controls and Fuel - 3.6L (LFY) - DTC P0685-P0687, P0689, P0690, or P1682
P0686	Engine Controls and Fuel - 2.0L (LTG) - DTC P0685-P0687, P0689, P0690, or P1682
P0686	Engine Controls and Fuel - 3.6L (LFY) - DTC P0685-P0687, P0689, P0690, or P1682
P0687	Engine Controls and Fuel - 2.0L (LTG) - DTC P0685-P0687, P0689, P0690, or P1682
P0687	Engine Controls and Fuel - 3.6L (LFY) - DTC P0685-P0687, P0689, P0690, or P1682
P0689	Engine Controls and Fuel - 2.0L (LTG) - DTC P0685-P0687, P0689, P0690, or P1682
P0689	Engine Controls and Fuel - 3.6L (LFY) - DTC P0685-P0687, P0689, P0690, or P1682
P0689	Automatic Transmission - 9T65 (M3V) - DTC P0658, P0659, P2727, P2729, P2730, P2736, P2738, P2739, P2826, P2827, P282F, or P2830
P0690	Engine Controls and Fuel - 2.0L (LTG) - DTC P0685-P0687, P0689, P0690, or P1682
P0690	Engine Controls and Fuel - 3.6L (LFY) - DTC P0685-P0687, P0689, P0690, or P1682
P0691	Engine Heating and Cooling - DTC P0480, P0691, or P0692
P0692	Engine Heating and Cooling - DTC P0480, P0691, or P0692
P0697	Engine Controls and Fuel - 2.0L (LTG) - DTC P0641, P0651, P0697, P06A3, or P06D2
P0697	Engine Controls and Fuel - 3.6L (LFY) - DTC P0641, P0651, P0697, or P06A3
P069E	Engine Controls and Fuel - 2.0L (LTG) - DTC P00FE, P069E, P06EC, P0700, P0800, P0AC4, P1700, P1E00, P2561, P25A2, P25AF, P25C9, P26C8, or P26C9
P069E	Engine Controls and Fuel - 3.6L (LFY) - DTC P00FE, P069E, P06EC, P0700, P0800, P0AC4, P1700, P1E00, P2561, P25A2, P25AF, P25C9, P26C8, or P26C9
P06A3	Engine Controls and Fuel - 2.0L (LTG) - DTC P0641, P0651, P0697, P06A3, or P06D2
P06A3	Engine Controls and Fuel - 3.6L (LFY) - DTC P0641, P0651, P0697, or P06A3
P06B6	Engine Controls and Fuel - 3.6L (LFY) - DTC P0324-P0328, P0330-P0333, P06B6, or P06B7
P06B6	Engine Controls and Fuel - 2.0L (LTG) - DTC P0324, P0326, P0331, P06B6, or P06B7
P06B7	Engine Controls and Fuel - 3.6L (LFY) - DTC P0324-P0328, P0330-P0333, P06B6, or P06B7

DTC	Diagnostic Procedure
P06B7	Engine Controls and Fuel - 2.0L (LTG) - DTC P0324, P0326, P0331, P06B6, or P06B7
P06D2	Engine Controls and Fuel - 2.0L (LTG) - DTC P0641, P0651, P0697, P06A3, or P06D2
P06DA	Engine Mechanical - 2.0L (LTG) - DTC P06DA-P06DC
P06DB	Engine Mechanical - 2.0L (LTG) - DTC P06DA-P06DC
P06DC	Engine Mechanical - 2.0L (LTG) - DTC P06DA-P06DC
P06DD	Engine Mechanical - 2.0L (LTG) - DTC P06DD or P06DE
P06DE	Engine Mechanical - 2.0L (LTG) - DTC P06DD or P06DE
P06EC	Engine Controls and Fuel - 2.0L (LTG) - DTC P00FE, P069E, P06EC, P0700, P0800, P0AC4, P1700, P1E00, P2561, P25A2, P25AF, P25C9, P26C8, or P26C9
P06EC	Engine Controls and Fuel - 3.6L (LFY) - DTC P00FE, P069E, P06EC, P0700, P0800, P0AC4, P1700, P1E00, P2561, P25A2, P25AF, P25C9, P26C8, or P26C9
P0700	Engine Controls and Fuel - 2.0L (LTG) - DTC P00FE, P069E, P06EC, P0700, P0800, P0AC4, P1700, P1E00, P2561, P25A2, P25AF, P25C9, P26C8, or P26C9
P0700	Engine Controls and Fuel - 3.6L (LFY) - DTC P00FE, P069E, P06EC, P0700, P0800, P0AC4, P1700, P1E00, P2561, P25A2, P25AF, P25C9, P26C8, or P26C9
P0703	Cruise Control - DTC P0703
P0707	Automatic Transmission - 9T65 (M3V) - DTC P0707, P0708, P2802, P2803, or P2805
P0708	Automatic Transmission - 9T65 (M3V) - DTC P0707, P0708, P2802, P2803, or P2805
P0711	Automatic Transmission - 9T65 (M3V) - DTC P0711-P0713
P0712	Automatic Transmission - 9T65 (M3V) - DTC P0711-P0713
P0713	Automatic Transmission - 9T65 (M3V) - DTC P0711-P0713
P0716	Automatic Transmission - 9T65 (M3V) - DTC P0716, P0717, P07BF, or P07C0
P0717	Automatic Transmission - 9T65 (M3V) - DTC P0716, P0717, P07BF, or P07C0
P0721	Automatic Transmission - 9T65 (M3V) - DTC P0721-P0723, P077C, or P077D
P0722	Automatic Transmission - 9T65 (M3V) - DTC P0721-P0723, P077C, or P077D
P0723	Automatic Transmission - 9T65 (M3V) - DTC P0721-P0723, P077C, or P077D
P0741	Automatic Transmission - 9T65 (M3V) - DTC P0741, P2817, or P2818
P0746	Automatic Transmission - 9T65 (M3V) - DTC P0746 or P0747
P0747	Automatic Transmission - 9T65 (M3V) - DTC P0746 or P0747
P0776	Automatic Transmission - 9T65 (M3V) - DTC P0776 or P0777
P0777	Automatic Transmission - 9T65 (M3V) - DTC P0776 or P0777
P077C	Automatic Transmission - 9T65 (M3V) - DTC P0721-P0723, P077C, or P077D
P077D	Automatic Transmission - 9T65 (M3V) - DTC P0721-P0723, P077C, or P077D
P0796	Automatic Transmission - 9T65 (M3V) - DTC P0796 or P0797
P0797	Automatic Transmission - 9T65 (M3V) - DTC P0796 or P0797
P07BF	Automatic Transmission - 9T65 (M3V) - DTC P0716, P0717, P07BF, or P07C0
P07C0	Automatic Transmission - 9T65 (M3V) - DTC P0716, P0717, P07BF, or P07C0
P0800	Engine Controls and Fuel - 2.0L (LTG) - DTC P00FE, P069E, P06EC, P0700, P0800, P0AC4, P1700, P1E00, P2561, P25A2, P25AF, P25C9, P26C8, or P26C9
P0800	Engine Controls and Fuel - 3.6L (LFY) - DTC P00FE, P069E, P06EC, P0700, P0800, P0AC4, P1700, P1E00, P2561, P25A2, P25AF, P25C9, P26C8, or P26C9
P0815	Automatic Transmission - 9T65 (M3V) - DTC P0815, P0816, or P0826
P0816	Automatic Transmission - 9T65 (M3V) - DTC P0815, P0816, or P0826
P0826	Automatic Transmission - 9T65 (M3V) - DTC P0815, P0816, or P0826
P0856	Antilock Brake System - DTC P0856
P0960	Automatic Transmission - 9T65 (M3V) - DTC P0960, P0962-P0964, P0966-P0968, P0970, P0971, P2670, P2671, P2718, P2720, P2721, P2812, P2814, P2815, P281B, P281D, or P281E

DTC	Diagnostic Procedure
P0962	Automatic Transmission - 9T65 (M3V) - DTC P0960 , P0962-P0964 , P0966-P0968 , P0970 , P0971 , P2670 , P2671 , P2718 , P2720 , P2721 , P2812 , P2814 , P2815 , P281B , P281D , or P281E
P0963	Automatic Transmission - 9T65 (M3V) - DTC P0960 , P0962-P0964 , P0966-P0968 , P0970 , P0971 , P2670 , P2671 , P2718 , P2720 , P2721 , P2812 , P2814 , P2815 , P281B , P281D , or P281E
P0964	Automatic Transmission - 9T65 (M3V) - DTC P0960 , P0962-P0964 , P0966-P0968 , P0970 , P0971 , P2670 , P2671 , P2718 , P2720 , P2721 , P2812 , P2814 , P2815 , P281B , P281D , or P281E
P0966	Automatic Transmission - 9T65 (M3V) - DTC P0960 , P0962-P0964 , P0966-P0968 , P0970 , P0971 , P2670 , P2671 , P2718 , P2720 , P2721 , P2812 , P2814 , P2815 , P281B , P281D , or P281E
P0967	Automatic Transmission - 9T65 (M3V) - DTC P0960 , P0962-P0964 , P0966-P0968 , P0970 , P0971 , P2670 , P2671 , P2718 , P2720 , P2721 , P2812 , P2814 , P2815 , P281B , P281D , or P281E
P0968	Automatic Transmission - 9T65 (M3V) - DTC P0960 , P0962-P0964 , P0966-P0968 , P0970 , P0971 , P2670 , P2671 , P2718 , P2720 , P2721 , P2812 , P2814 , P2815 , P281B , P281D , or P281E
P0970	Automatic Transmission - 9T65 (M3V) - DTC P0960 , P0962-P0964 , P0966-P0968 , P0970 , P0971 , P2670 , P2671 , P2718 , P2720 , P2721 , P2812 , P2814 , P2815 , P281B , P281D , or P281E
P0971	Automatic Transmission - 9T65 (M3V) - DTC P0960 , P0962-P0964 , P0966-P0968 , P0970 , P0971 , P2670 , P2671 , P2718 , P2720 , P2721 , P2812 , P2814 , P2815 , P281B , P281D , or P281E
P0AC4	Engine Controls and Fuel - 2.0L (LTG) - DTC P00FE , P069E , P06EC , P0700 , P0800 , P0AC4 , P1700 , P1E00 , P2561 , P25A2 , P25AF , P25C9 , P26C8 , or P26C9
P0AC4	Engine Controls and Fuel - 3.6L (LFY) - DTC P00FE , P069E , P06EC , P0700 , P0800 , P0AC4 , P1700 , P1E00 , P2561 , P25A2 , P25AF , P25C9 , P26C8 , or P26C9
P1000	Engine Controls and Fuel - 2.0L (LTG) - DTC C1201 , P1000 , P1001 , P1003 , P1008 , P1009 , P100A , P100E , P103D , P103E , P10B6-P10B9 , P10BE , P10C6-P10C8 , P10F5 , P1100 , P1103 , P117A , P11FE , P1200 , P128C-P128F , P129E , P12A8 , P130F , P135C-P135F , P1436 , P143A , P143B , P1472 , P14A0 , P14B6 , P14BD , P14CD , P14CE , P14D4-P14D6 , P150C , P151A , P151D , P153C , P153D , P155D , P1591 , P15E2 , P15F2 , P15F9 , P15FA , P15FB , P165C , P167F , P16E8 , P16FE , P175E , P1761 , P1762 , P1775 , P179B , P189C , P2544 , P308D , P30B4 , P30B5 , P30BC , P30BD , P30D5 , P30DE , P3168 , P3169 , or P316B
P1000	Engine Controls and Fuel - 3.6L (LFY) - DTC C1201 , P1000 , P1001 , P1003 , P1008 , P1009 , P100A , P100E , P103D , P103E , P10B6-P10B9 , P10BE , P10C6-P10C8 , P10F5 , P1100 , P1103 , P117A , P11FE , P1200 , P128C-P128F , P129E , P12A8 , P130F , P135C-P135F , P1436 , P143A , P143B , P1472 , P14A0 , P14B6 , P14BD , P14CD , P14CE , P14D4-P14D6 , P150C , P151A , P151D , P153C , P153D , P155D , P1591 , P15E2 , P15F2 , P15F9 , P15FA , P15FB , P165C , P167F , P16E8 , P16FE , P175E , P1761 , P1762 , P1775 , P179B , P189C , P2544 , P308D , P30B4 , P30B5 , P30BC , P30BD , P30D5 , P30DE , P3168 , P3169 , or P316B
P1001	Engine Controls and Fuel - 2.0L (LTG) - DTC C1201 , P1000 , P1001 , P1003 , P1008 , P1009 , P100A , P100E , P103D , P103E , P10B6-P10B9 , P10BE , P10C6-P10C8 , P10F5 , P1100 , P1103 , P117A , P11FE , P1200 , P128C-P128F , P129E , P12A8 , P130F , P135C-P135F , P1436 , P143A , P143B , P1472 , P14A0 , P14B6 , P14BD , P14CD , P14CE , P14D4-P14D6 , P150C , P151A , P151D , P153C , P153D , P155D , P1591 , P15E2 , P15F2 , P15F9 , P15FA , P15FB , P165C , P167F , P16E8 , P16FE , P175E , P1761 , P1762 , P1775 , P179B , P189C , P2544 , P308D , P30B4 , P30B5 , P30BC , P30BD , P30D5 , P30DE , P3168 , P3169 , or P316B

DTC	Diagnostic Procedure
P1001	Engine Controls and Fuel - 3.6L (LFY) - <u>DTC C1201, P1000, P1001, P1003, P1008, P1009, P100A, P100E, P103D, P103E, P10B6-P10B9, P10BE, P10C6-P10C8, P10F5, P1100, P1103, P117A, P11FE, P1200, P128C-P128F, P129E, P12A8, P130F, P135C-P135F, P1436, P143A, P143B, P1472, P14A0, P14B6, P14BD, P14CD, P14CE, P14D4-P14D6, P150C, P151A, P151D, P153C, P153D, P155D, P1591, P15E2, P15F2, P15F9, P15FA, P15FB, P165C, P167F, P16E8, P16FE, P175F, P1761, P1762, P1775, P179B, P189C, P2544, P308D, P30B4, P30B5, P30BC, P30BD, P30D5, P30DE, P3168, P3169, or P316B</u>
P1002	12 V Starting and Charging - <u>DTC B1325, B1327, B1328, B1330, B1390, B1395, B1400, B1410, B1415, B1424, B1425, B1439, B1517, C0800, C0805, C0870, C0880, C0895, C0899, C0900, C1300, P0560-P0563, P0611, P1002, P129B, P129C, P1465, P1466, P15AE, P15AF, P17B0-P17B2, P17DD-P17DE, P1A0C, P1A0D, P1E19, P1E1A, or U2800</u>
P1003	Engine Controls and Fuel - 2.0L (LTG) - <u>DTC C1201, P1000, P1001, P1003, P1008, P1009, P100A, P100E, P103D, P103E, P10B6-P10B9, P10BE, P10C6-P10C8, P10F5, P1100, P1103, P117A, P11FE, P1200, P128C-P128F, P129E, P12A8, P130F, P135C-P135F, P1436, P143A, P143B, P1472, P14A0, P14B6, P14BD, P14CD, P14CE, P14D4-P14D6, P150C, P151A, P151D, P153C, P153D, P155D, P1591, P15E2, P15F2, P15F9, P15FA, P15FB, P165C, P167F, P16E8, P16FE, P175F, P1761, P1762, P1775, P179B, P189C, P2544, P308D, P30B4, P30B5, P30BC, P30BD, P30D5, P30DE, P3168, P3169, or P316B</u>
P1003	Engine Controls and Fuel - 3.6L (LFY) - <u>DTC C1201, P1000, P1001, P1003, P1008, P1009, P100A, P100E, P103D, P103E, P10B6-P10B9, P10BE, P10C6-P10C8, P10F5, P1100, P1103, P117A, P11FE, P1200, P128C-P128F, P129E, P12A8, P130F, P135C-P135F, P1436, P143A, P143B, P1472, P14A0, P14B6, P14BD, P14CD, P14CE, P14D4-P14D6, P150C, P151A, P151D, P153C, P153D, P155D, P1591, P15E2, P15F2, P15F9, P15FA, P15FB, P165C, P167F, P16E8, P16FE, P175F, P1761, P1762, P1775, P179B, P189C, P2544, P308D, P30B4, P30B5, P30BC, P30BD, P30D5, P30DE, P3168, P3169, or P316B</u>
P1008	Engine Controls and Fuel - 2.0L (LTG) - <u>DTC C1201, P1000, P1001, P1003, P1008, P1009, P100A, P100E, P103D, P103E, P10B6-P10B9, P10BE, P10C6-P10C8, P10F5, P1100, P1103, P117A, P11FE, P1200, P128C-P128F, P129E, P12A8, P130F, P135C-P135F, P1436, P143A, P143B, P1472, P14A0, P14B6, P14BD, P14CD, P14CE, P14D4-P14D6, P150C, P151A, P151D, P153C, P153D, P155D, P1591, P15E2, P15F2, P15F9, P15FA, P15FB, P165C, P167F, P16E8, P16FE, P175F, P1761, P1762, P1775, P179B, P189C, P2544, P308D, P30B4, P30B5, P30BC, P30BD, P30D5, P30DE, P3168, P3169, or P316B</u>
P1008	Engine Controls and Fuel - 3.6L (LFY) - <u>DTC C1201, P1000, P1001, P1003, P1008, P1009, P100A, P100E, P103D, P103E, P10B6-P10B9, P10BE, P10C6-P10C8, P10F5, P1100, P1103, P117A, P11FE, P1200, P128C-P128F, P129E, P12A8, P130F, P135C-P135F, P1436, P143A, P143B, P1472, P14A0, P14B6, P14BD, P14CD, P14CE, P14D4-P14D6, P150C, P151A, P151D, P153C, P153D, P155D, P1591, P15E2, P15F2, P15F9, P15FA, P15FB, P165C, P167F, P16E8, P16FE, P175F, P1761, P1762, P1775, P179B, P189C, P2544, P308D, P30B4, P30B5, P30BC, P30BD, P30D5, P30DE, P3168, P3169, or P316B</u>
P1009	Engine Controls and Fuel - 2.0L (LTG) - <u>DTC C1201, P1000, P1001, P1003, P1008, P1009, P100A, P100E, P103D, P103E, P10B6-P10B9, P10BE, P10C6-P10C8, P10F5, P1100, P1103, P117A, P11FE, P1200, P128C-P128F, P129E, P12A8, P130F, P135C-P135F, P1436, P143A, P143B, P1472, P14A0, P14B6, P14BD, P14CD, P14CE, P14D4-P14D6, P150C, P151A, P151D, P153C, P153D, P155D, P1591, P15E2, P15F2, P15F9, P15FA, P15FB, P165C, P167F, P16E8, P16FE, P175F, P1761, P1762, P1775, P179B, P189C, P2544, P308D, P30B4, P30B5, P30BC, P30BD, P30D5, P30DE, P3168, P3169, or P316B</u>

DTC	Diagnostic Procedure
P1009	Engine Controls and Fuel - 3.6L (LFY) - DTC C1201 , P1000 , P1001 , P1003 , P1008 , P1009 , P100A , P100E , P103D , P103E , P10B6-P10B9 , P10BF , P10C6-P10C8 , P10F5 , P1100 , P1103 , P117A , P11FF , P1200 , P128C-P128F , P129E , P12A8 , P130F , P135C-P135F , P1436 , P143A , P143B , P1472 , P14A0 , P14B6 , P14BD , P14CD , P14CE , P14D4-P14D6 , P150C , P151A , P151D , P153C , P153D , P155D , P1591 , P15E2 , P15F2 , P15F9 , P15FA , P15FB , P165C , P167F , P16E8 , P16FF , P175F , P1761 , P1762 , P1775 , P179B , P189C , P2544 , P308D , P30B4 , P30B5 , P30BC , P30BD , P30D5 , P30DE , P3168 , P3169 , or P316B
P100A	Engine Controls and Fuel - 2.0L (LTG) - DTC C1201 , P1000 , P1001 , P1003 , P1008 , P1009 , P100A , P100E , P103D , P103E , P10B6-P10B9 , P10BF , P10C6-P10C8 , P10F5 , P1100 , P1103 , P117A , P11FF , P1200 , P128C-P128F , P129E , P12A8 , P130F , P135C-P135F , P1436 , P143A , P143B , P1472 , P14A0 , P14B6 , P14BD , P14CD , P14CE , P14D4-P14D6 , P150C , P151A , P151D , P153C , P153D , P155D , P1591 , P15E2 , P15F2 , P15F9 , P15FA , P15FB , P165C , P167F , P16E8 , P16FF , P175F , P1761 , P1762 , P1775 , P179B , P189C , P2544 , P308D , P30B4 , P30B5 , P30BC , P30BD , P30D5 , P30DE , P3168 , P3169 , or P316B
P100A	Engine Controls and Fuel - 3.6L (LFY) - DTC C1201 , P1000 , P1001 , P1003 , P1008 , P1009 , P100A , P100E , P103D , P103E , P10B6-P10B9 , P10BF , P10C6-P10C8 , P10F5 , P1100 , P1103 , P117A , P11FF , P1200 , P128C-P128F , P129E , P12A8 , P130F , P135C-P135F , P1436 , P143A , P143B , P1472 , P14A0 , P14B6 , P14BD , P14CD , P14CE , P14D4-P14D6 , P150C , P151A , P151D , P153C , P153D , P155D , P1591 , P15E2 , P15F2 , P15F9 , P15FA , P15FB , P165C , P167F , P16E8 , P16FF , P175F , P1761 , P1762 , P1775 , P179B , P189C , P2544 , P308D , P30B4 , P30B5 , P30BC , P30BD , P30D5 , P30DE , P3168 , P3169 , or P316B
P100C	12 V Starting and Charging - DTC P100C or P100D
P100D	12 V Starting and Charging - DTC P100C or P100D
P100E	Engine Controls and Fuel - 2.0L (LTG) - DTC C1201 , P1000 , P1001 , P1003 , P1008 , P1009 , P100A , P100E , P103D , P103E , P10B6-P10B9 , P10BF , P10C6-P10C8 , P10F5 , P1100 , P1103 , P117A , P11FF , P1200 , P128C-P128F , P129E , P12A8 , P130F , P135C-P135F , P1436 , P143A , P143B , P1472 , P14A0 , P14B6 , P14BD , P14CD , P14CE , P14D4-P14D6 , P150C , P151A , P151D , P153C , P153D , P155D , P1591 , P15E2 , P15F2 , P15F9 , P15FA , P15FB , P165C , P167F , P16E8 , P16FF , P175F , P1761 , P1762 , P1775 , P179B , P189C , P2544 , P308D , P30B4 , P30B5 , P30BC , P30BD , P30D5 , P30DE , P3168 , P3169 , or P316B
P100E	Engine Controls and Fuel - 3.6L (LFY) - DTC C1201 , P1000 , P1001 , P1003 , P1008 , P1009 , P100A , P100E , P103D , P103E , P10B6-P10B9 , P10BF , P10C6-P10C8 , P10F5 , P1100 , P1103 , P117A , P11FF , P1200 , P128C-P128F , P129E , P12A8 , P130F , P135C-P135F , P1436 , P143A , P143B , P1472 , P14A0 , P14B6 , P14BD , P14CD , P14CE , P14D4-P14D6 , P150C , P151A , P151D , P153C , P153D , P155D , P1591 , P15E2 , P15F2 , P15F9 , P15FA , P15FB , P165C , P167F , P16E8 , P16FF , P175F , P1761 , P1762 , P1775 , P179B , P189C , P2544 , P308D , P30B4 , P30B5 , P30BC , P30BD , P30D5 , P30DE , P3168 , P3169 , or P316B
P103B	Engine Controls and Fuel - 2.0L (LTG) - DTC P0030-P0032 , P0036-P0038 , P0054 , P0135 , P0141 , P103B , or P103C
P103B	Engine Controls and Fuel - 3.6L (LFY) - DTC P0030-P0032 , P0036-P0038 , P0050-P0054 , P0056-P0060 , P0135 , P0141 , P0155 , P0161 , P103B , or P103C
P103C	Engine Controls and Fuel - 2.0L (LTG) - DTC P0030-P0032 , P0036-P0038 , P0054 , P0135 , P0141 , P103B , or P103C
P103C	Engine Controls and Fuel - 3.6L (LFY) - DTC P0030-P0032 , P0036-P0038 , P0050-P0054 , P0056-P0060 , P0135 , P0141 , P0155 , P0161 , P103B , or P103C
P103D	Engine Controls and Fuel - 2.0L (LTG) - DTC C1201 , P1000 , P1001 , P1003 , P1008 , P1009 , P100A , P100E , P103D , P103E , P10B6-P10B9 , P10BF , P10C6-P10C8 , P10F5 , P1100 , P1103 , P117A , P11FF , P1200 , P128C-P128F , P129E , P12A8 , P130F , P135C-P135F , P1436 , P143A , P143B , P1472 , P14A0 , P14B6 , P14BD , P14CD , P14CE , P14D4-P14D6 , P150C , P151A , P151D , P153C , P153D , P155D , P1591 , P15E2 , P15F2 , P15F9 , P15FA , P15FB , P165C , P167F , P16E8 , P16FF , P175F , P1761 , P1762 , P1775 , P179B , P189C , P2544 , P308D , P30B4 , P30B5 , P30BC , P30BD , P30D5 , P30DE , P3168 , P3169 , or P316B

DTC	Diagnostic Procedure
P103D	Engine Controls and Fuel - 3.6L (LFY) - <u>DTC C1201, P1000, P1001, P1003, P1008, P1009, P100A, P100E, P103D, P103E, P10B6-P10B9, P10BF, P10C6-P10C8, P10F5, P1100, P1103, P117A, P11FF, P1200, P128C-P128F, P129E, P12A8, P130F, P135C-P135F, P1436, P143A, P143B, P1472, P14A0, P14B6, P14BD, P14CD, P14CE, P14D4-P14D6, P150C, P151A, P151D, P153C, P153D, P155D, P1591, P15E2, P15F2, P15F9, P15FA, P15FB, P165C, P167F, P16E8, P16FF, P175F, P1761, P1762, P1775, P179B, P189C, P2544, P308D, P30B4, P30B5, P30BC, P30BD, P30D5, P30DE, P3168, P3169, or P316B</u>
P103E	Engine Controls and Fuel - 2.0L (LTG) - <u>DTC C1201, P1000, P1001, P1003, P1008, P1009, P100A, P100E, P103D, P103E, P10B6-P10B9, P10BF, P10C6-P10C8, P10F5, P1100, P1103, P117A, P11FF, P1200, P128C-P128F, P129E, P12A8, P130F, P135C-P135F, P1436, P143A, P143B, P1472, P14A0, P14B6, P14BD, P14CD, P14CE, P14D4-P14D6, P150C, P151A, P151D, P153C, P153D, P155D, P1591, P15E2, P15F2, P15F9, P15FA, P15FB, P165C, P167F, P16E8, P16FF, P175F, P1761, P1762, P1775, P179B, P189C, P2544, P308D, P30B4, P30B5, P30BC, P30BD, P30D5, P30DE, P3168, P3169, or P316B</u>
P103E	Engine Controls and Fuel - 3.6L (LFY) - <u>DTC C1201, P1000, P1001, P1003, P1008, P1009, P100A, P100E, P103D, P103E, P10B6-P10B9, P10BF, P10C6-P10C8, P10F5, P1100, P1103, P117A, P11FF, P1200, P128C-P128F, P129E, P12A8, P130F, P135C-P135F, P1436, P143A, P143B, P1472, P14A0, P14B6, P14BD, P14CD, P14CE, P14D4-P14D6, P150C, P151A, P151D, P153C, P153D, P155D, P1591, P15E2, P15F2, P15F9, P15FA, P15FB, P165C, P167F, P16E8, P16FF, P175F, P1761, P1762, P1775, P179B, P189C, P2544, P308D, P30B4, P30B5, P30BC, P30BD, P30D5, P30DE, P3168, P3169, or P316B</u>
P10B6	Engine Controls and Fuel - 2.0L (LTG) - <u>DTC C1201, P1000, P1001, P1003, P1008, P1009, P100A, P100E, P103D, P103E, P10B6-P10B9, P10BF, P10C6-P10C8, P10F5, P1100, P1103, P117A, P11FF, P1200, P128C-P128F, P129E, P12A8, P130F, P135C-P135F, P1436, P143A, P143B, P1472, P14A0, P14B6, P14BD, P14CD, P14CE, P14D4-P14D6, P150C, P151A, P151D, P153C, P153D, P155D, P1591, P15E2, P15F2, P15F9, P15FA, P15FB, P165C, P167F, P16E8, P16FF, P175F, P1761, P1762, P1775, P179B, P189C, P2544, P308D, P30B4, P30B5, P30BC, P30BD, P30D5, P30DE, P3168, P3169, or P316B</u>
P10B6	Engine Controls and Fuel - 3.6L (LFY) - <u>DTC C1201, P1000, P1001, P1003, P1008, P1009, P100A, P100E, P103D, P103E, P10B6-P10B9, P10BF, P10C6-P10C8, P10F5, P1100, P1103, P117A, P11FF, P1200, P128C-P128F, P129E, P12A8, P130F, P135C-P135F, P1436, P143A, P143B, P1472, P14A0, P14B6, P14BD, P14CD, P14CE, P14D4-P14D6, P150C, P151A, P151D, P153C, P153D, P155D, P1591, P15E2, P15F2, P15F9, P15FA, P15FB, P165C, P167F</</u>

DTC	Diagnostic Procedure
P10B8	Engine Controls and Fuel - 2.0L (LTG) - DTC C1201 , P1000 , P1001 , P1003 , P1008 , P1009 , P100A , P100E , P103D , P103E , P10B6-P10B9 , P10BF , P10C6-P10C8 , P10F5 , P1100 , P1103 , P117A , P11FF , P1200 , P128C-P128F , P129E , P12A8 , P130F , P135C-P135F , P1436 , P143A , P143B , P1472 , P14A0 , P14B6 , P14BD , P14CD , P14CE , P14D4-P14D6 , P150C , P151A , P151D , P153C , P153D , P155D , P1591 , P15E2 , P15F2 , P15F9 , P15FA , P15FB , P165C , P167F , P16E8 , P16FF , P175F , P1761 , P1762 , P1775 , P179B , P189C , P2544 , P308D , P30B4 , P30B5 , P30BC , P30BD , P30D5 , P30DE , P3168 , P3169 , or P316B
P10B8	Engine Controls and Fuel - 3.6L (LFY) - DTC C1201 , P1000 , P1001 , P1003 , P1008 , P1009 , P100A , P100E , P103D , P103E , P10B6-P10B9 , P10BF , P10C6-P10C8 , P10F5 , P1100 , P1103 , P117A , P11FF , P1200 , P128C-P128F , P129E , P12A8 , P130F , P135C-P135F , P1436 , P143A , P143B , P1472 , P14A0 , P14B6 , P14BD , P14CD , P14CE , P14D4-P14D6 , P150C , P151A , P151D , P153C , P153D , P155D , P1591 , P15E2 , P15F2 , P15F9 , P15FA , P15FB , P165C , P167F , P16E8 , P16FF , P175F , P1761 , P1762 , P1775 , P179B , P189C , P2544 , P308D , P30B4 , P30B5 , P30BC , P30BD , P30D5 , P30DE , P3168 , P3169 , or P316B
P10B9	Engine Controls and Fuel - 2.0L (LTG) - DTC C1201 , P1000 , P1001 , P1003 , P1008 , P1009 , P100A , P100E , P103D , P103E , P10B6-P10B9 , P10BF , P10C6-P10C8 , P10F5 , P1100 , P1103 , P117A , P11FF , P1200 , P128C-P128F , P129E , P12A8 , P130F , P135C-P135F , P1436 , P143A , P143B , P1472 , P14A0 , P14B6 , P14BD , P14CD , P14CE , P14D4-P14D6 , P150C , P151A , P151D , P153C , P153D , P155D , P1591 , P15E2 , P15F2 , P15F9 , P15FA , P15FB , P165C , P167F , P16E8 , P16FF , P175F , P1761 , P1762 , P1775 , P179B , P189C , P2544 , P308D , P30B4 , P30B5 , P30BC , P30BD , P30D5 , P30DE , P3168 , P3169 , or P316B
P10B9	Engine Controls and Fuel - 3.6L (LFY) - DTC C1201 , P1000 , P1001 , P1003 , P1008 , P1009 , P100A , P100E , P103D , P103E , P10B6-P10B9 , P10BF , P10C6-P10C8 , P10F5 , P1100 , P1103 , P117A , P11FF , P1200 , P128C-P128F , P129E , P12A8 , P130F , P135C-P135F , P1436 , P143A , P143B , P1472 , P14A0 , P14B6 , P14BD , P14CD , P14CE , P14D4-P14D6 , P150C , P151A , P151D , P153C , P153D , P155D , P1591 , P15E2 , P15F2 , P15F9 , P15FA , P15FB , P165C , P167F , P16E8 , P16FF , P175F , P1761 , P1762 , P1775 , P179B , P189C , P2544 , P308D , P30B4 , P30B5 , P30BC , P30BD , P30D5 , P30DE , P3168 , P3169 , or P316B
P10BF	Engine Controls and Fuel - 2.0L (LTG) - DTC C1201 , P1000 , P1001 , P1003 , P1008 , P1009 , P100A , P100E , P103D , P103E , P10B6-P10B9 , P10BF , P10C6-P10C8 , P10F5 , P1100 , P1103 , P117A , P11FF , P1200 , P128C-P128F , P129E , P12A8 , P130F , P135C-P135F , P1436 , P143A , P143B , P1472 , P14A0 , P14B6 , P14BD , P14CD , P14CE , P14D4-P14D6 , P150C , P151A , P151D , P153C , P153D , P155D , P1591 , P15E2 , P15F2 , P15F9 , P15FA , P15FB , P165C , P167F , P16E8 , P

DTC	Diagnostic Procedure
P10C6	Engine Controls and Fuel - 3.6L (LFY) - <u>DTC C1201, P1000, P1001, P1003, P1008, P1009, P100A, P100E, P103D, P103E, P10B6-P10B9, P10BF, P10C6-P10C8, P10F5, P1100, P1103, P117A, P11FF, P1200, P128C-P128F, P129E, P12A8, P130F, P135C-P135F, P1436, P143A, P143B, P1472, P14A0, P14B6, P14BD, P14CD, P14CE, P14D4-P14D6, P150C, P151A, P151D, P153C, P153D, P155D, P1591, P15E2, P15F2, P15F9, P15FA, P15FB, P165C, P167F, P16E8, P16FF, P175F, P1761, P1762, P1775, P179B, P189C, P2544, P308D, P30B4, P30B5, P30BC, P30BD, P30D5, P30DE, P3168, P3169, or P316B</u>
P10C7	Engine Controls and Fuel - 2.0L (LTG) - <u>DTC C1201, P1000, P1001, P1003, P1008, P1009, P100A, P100E, P103D, P103E, P10B6-P10B9, P10BF, P10C6-P10C8, P10F5, P1100, P1103, P117A, P11FF, P1200, P128C-P128F, P129E, P12A8, P130F, P135C-P135F, P1436, P143A, P143B, P1472, P14A0, P14B6, P14BD, P14CD, P14CE, P14D4-P14D6, P150C, P151A, P151D, P153C, P153D, P155D, P1591, P15E2, P15F2, P15F9, P15FA, P15FB, P165C, P167F, P16E8, P16FF, P175F, P1761, P1762, P1775, P179B, P189C, P2544, P308D, P30B4, P30B5, P30BC, P30BD, P30D5, P30DE, P3168, P3169, or P316B</u>
P10C7	Engine Controls and Fuel - 3.6L (LFY) - <u>DTC C1201, P1000, P1001, P1003, P1008, P1009, P100A, P100E, P103D, P103E, P10B6-P10B9, P10BF, P10C6-P10C8, P10F5, P1100, P1103, P117A, P11FF, P1200, P128C-P128F, P129E, P12A8, P130F, P135C-P135F, P1436, P143A, P143B, P1472, P14A0, P14B6, P14BD, P14CD, P14CE, P14D4-P14D6, P150C, P151A, P151D, P153C, P153D, P155D, P1591, P15E2, P15F2, P15F9, P15FA, P15FB, P165C, P167F, P16E8, P16FF, P175F, P1761, P1762, P1775, P179B, P189C, P2544, P308D, P30B4, P30B5, P30BC, P30BD, P30D5, P30DE, P3168, P3169, or P316B</u>
P10C8	Engine Controls and Fuel - 2.0L (LTG) - <u>DTC C1201, P1000, P1001, P1003, P1008, P1009, P100A, P100E, P103D, P103E, P10B6-P10B9, P10BF, P10C6-P10C8, P10F5, P1100, P1103, P117A, P11FF, P1200, P128C-P128F, P129E, P12A8, P130F, P135C-P135F, P1436, P143A, P143B, P1472, P14A0, P14B6, P14BD, P14CD, P14CE, P14D4-P14D6, P150C, P151A, P151D, P153C, P153D, P155D, P1591, P15E2, P15F2, P15F9, P15FA, P15FB, P165C, P167F, P16E8, P16FF, P175F, P1761, P1762, P1775, P179B, P189C, P2544, P308D, P30B4, P30B5, P30BC, P30BD, P30D5, P30DE, P3168, P3169, or P316B</u>
P10C8	Engine Controls and Fuel - 3.6L (LFY) - <u>DTC C1201, P1000, P1001, P1003, P1008, P1009, P100A, P100E, P103D, P103E, P10B6-P10B9, P10BF, P10C6-P10C8, P10F5, P1100, P1103, P117A, P11FF, P1200, P128C-P128F, P129E, P12A8, P130F, P135C-P135F, P1436, P143A, P143B, P1472, P14A0, P14B6, P14BD, P14CD, P14CE, P14D4-P14D6, P150C, P151A, P151D, P153C, P153D, P155D, P1591, P15E2, P15F2, P15F9, P15FA, P15FB, P165C, P167F</</u>

DTC	Diagnostic Procedure
P1100	Engine Controls and Fuel - 2.0L (LTG) - DTC C1201 , P1000 , P1001 , P1003 , P1008 , P1009 , P100A , P100E , P103D , P103E , P10B6-P10B9 , P10BF , P10C6-P10C8 , P10F5 , P1100 , P1103 , P117A , P11FF , P1200 , P128C-P128F , P129E , P12A8 , P130F , P135C-P135F , P1436 , P143A , P143B , P1472 , P14A0 , P14B6 , P14BD , P14CD , P14CE , P14D4-P14D6 , P150C , P151A , P151D , P153C , P153D , P155D , P1591 , P15E2 , P15F2 , P15F9 , P15FA , P15FB , P165C , P167F , P16E8 , P16FF , P175F , P1761 , P1762 , P1775 , P179B , P189C , P2544 , P308D , P30B4 , P30B5 , P30BC , P30BD , P30D5 , P30DE , P3168 , P3169 , or P316B
P1100	Engine Controls and Fuel - 3.6L (LFY) - DTC C1201 , P1000 , P1001 , P1003 , P1008 , P1009 , P100A , P100E , P103D , P103E , P10B6-P10B9 , P10BF , P10C6-P10C8 , P10F5 , P1100 , P1103 , P117A , P11FF , P1200 , P128C-P128F , P129E , P12A8 , P130F , P135C-P135F , P1436 , P143A , P143B , P1472 , P14A0 , P14B6 , P14BD , P14CD , P14CE , P14D4-P14D6 , P150C , P151A , P151D , P153C , P153D , P155D , P1591 , P15E2 , P15F2 , P15F9 , P15FA , P15FB , P165C , P167F , P16E8 , P16FF , P175F , P1761 , P1762 , P1775 , P179B , P189C , P2544 , P308D , P30B4 , P30B5 , P30BC , P30BD , P30D5 , P30DE , P3168 , P3169 , or P316B
P1101	Engine Controls and Fuel - 2.0L (LTG) - DTC P0068 or P1101
P1101	Engine Controls and Fuel - 3.6L (LFY) - DTC P0068 or P1101
P1103	Engine Controls and Fuel - 2.0L (LTG) - DTC C1201 , P1000 , P1001 , P1003 , P1008 , P1009 , P100A , P100E , P103D , P103E , P10B6-P10B9 , P10BF , P10C6-P10C8 , P10F5 , P1100 , P1103 , P117A , P11FF , P1200 , P128C-P128F , P129E , P12A8 , P130F , P135C-P135F , P1436 , P143A , P143B , P1472 , P14A0 , P14B6 , P14BD , P14CD , P14CE , P14D4-P14D6 , P150C , P151A , P151D , P153C , P153D , P155D , P1591 , P15E2 , P15F2 , P15F9 , P15FA , P15FB , P165C , P167F , P16E8 , P16FF , P175F , P1761 , P1762 , P1775 , P179B , P189C , P2544 , P308D , P30B4 , P30B5 , P30BC , P30BD , P30D5 , P30DE , P3168 , P3169 , or P316B
P1103	Engine Controls and Fuel - 3.6L (LFY) - DTC C1201 , P1000 , P1001 , P1003 , P1008 , P1009 , P100A , P100E , P103D , P103E , P10B6-P10B9 , P10BF , P10C6-P10C8 , P10F5 , P1100 , P1103 , P117A , P11FF , P1200 , P128C-P128F , P129E , P12A8 , P130F , P135C-P135F , P1436 , P143A , P143B , P1472 , P14A0 , P14B6 , P14BD , P14CD , P14CE , P14D4-P14D6 , P150C , P151A , P151D , P153C , P153D , P155D , P1591 , P15E2 , P15F2 , P15F9 , P15FA , P15FB , P165C , P167F , P16E8 , P16FF , P175F , P1761 , P1762 , P1775 , P179B , P189C , P2544 , P308D , P30B4 , P30B5 , P30BC , P30BD , P30D5 , P30DE , P3168 , P3169 , or P316B
P111E	Engine Heating and Cooling - DTC P111E
P111F	Engine Controls and Fuel - 3.6L (LFY) - DTC P0182 , P0183 , P0187 , P0188 , P0191 , P0192 , P111F , P126E , P126F , P127C , P128A , P128B , P16E4 , or P16E5 (LFY)
P117A	Engine Controls and Fuel - 2.0L (LTG) - DTC C1201 , P1000 , P1001 , P1003 , P1008 , P1009 , P100A , P100E , P103D , P103E , P10B6-P10B9 , P10BF , P10C6-P10C8 , P10F5 , P1100 , P1103 , P117A , P11FF , P1200 , P128C-P128F , P129E , P12A8 , P130F , P135C-P135F , P1436 , P143A , P143B , P1472 , P14A0 , P14B6 , P14BD , P14CD , P14CE , P14D4-P14D6 , P150C , P151A , P151D , P153C , P153D , P155D , P1591 , P15E2 , P15F2 , P15F9 , P15FA , P15FB , P165C , P167F , P16E8 , P16FF , P175F , P1761 , P1762 , P1775 , P179B , P189C , P2544 , P308D , P30B4 , P30B5 , P30BC , P30BD , P30D5 , P30DE , P3168 , P3169 , or P316B
P117A	Engine Controls and Fuel - 3.6L (LFY) - DTC C1201 , P1000 , P1001 , P1003 , P1008 , P1009 , P100A , P100E , P103D , P103E , P10B6-P10B9 , P10BF , P10C6-P10C8 , P10F5 , P1100 , P1103 , P117A , P11FF , P1200 , P128C-P128F , P129E , P12A8 , P130F , P135C-P135F , P1436 , P143A , P143B , P1472 , P14A0 , P14B6 , P14BD , P14CD , P14CE , P14D4-P14D6 , P150C , P151A , P151D , P153C , P153D , P155D , P1591 , P15E2 , P15F2 , P15F9 , P15FA , P15FB , P165C , P167F , P16E8 , P16FF , P175F , P1761 , P1762 , P1775 , P179B , P189C , P2544 , P308D , P30B4 , P30B5 , P30BC , P30BD , P30D5 , P30DE , P3168 , P3169 , or P316B

DTC	Diagnostic Procedure
P11FF	Engine Controls and Fuel - 2.0L (LTG) - DTC C1201 , P1000 , P1001 , P1003 , P1008 , P1009 , P100A , P100E , P103D , P103E , P10B6-P10B9 , P10BF , P10C6-P10C8 , P10F5 , P1100 , P1103 , P117A , P11FF , P1200 , P128C-P128F , P129E , P12A8 , P130F , P135C-P135F , P1436 , P143A , P143B , P1472 , P14A0 , P14B6 , P14BD , P14CD , P14CE , P14D4-P14D6 , P150C , P151A , P151D , P153C , P153D , P155D , P1591 , P15E2 , P15F2 , P15F9 , P15FA , P15FB , P165C , P167F , P16E8 , P16FF , P175F , P1761 , P1762 , P1775 , P179B , P189C , P2544 , P308D , P30B4 , P30B5 , P30BC , P30BD , P30D5 , P30DE , P3168 , P3169 , or P316B
P11FF	Engine Controls and Fuel - 3.6L (LFY) - DTC C1201 , P1000 , P1001 , P1003 , P1008 , P1009 , P100A , P100E , P103D , P103E , P10B6-P10B9 , P10BF , P10C6-P10C8 , P10F5 , P1100 , P1103 , P117A , P11FF , P1200 , P128C-P128F , P129E , P12A8 , P130F , P135C-P135F , P1436 , P143A , P143B , P1472 , P14A0 , P14B6 , P14BD , P14CD , P14CE , P14D4-P14D6 , P150C , P151A , P151D , P153C , P153D , P155D , P1591 , P15E2 , P15F2 , P15F9 , P15FA , P15FB , P165C , P167F , P16E8 , P16FF , P175F , P1761 , P1762 , P1775 , P179B , P189C , P2544 , P308D , P30B4 , P30B5 , P30BC , P30BD , P30D5 , P30DE , P3168 , P3169 , or P316B
P1200	Engine Controls and Fuel - 2.0L (LTG) - DTC C1201 , P1000 , P1001 , P1003 , P1008 , P1009 , P100A , P100E , P103D , P103E , P10B6-P10B9 , P10BF , P10C6-P10C8 , P10F5 , P1100 , P1103 , P117A , P11FF , P1200 , P128C-P128F , P129E , P12A8 , P130F , P135C-P135F , P1436 , P143A , P143B , P1472 , P14A0 , P14B6 , P14BD , P14CD , P14CE , P14D4-P14D6 , P150C , P151A , P151D , P153C , P153D , P155D , P1591 , P15E2 , P15F2 , P15F9 , P15FA , P15FB , P165C , P167F , P16E8 , P16FF , P175F , P1761 , P1762 , P1775 , P179B , P189C , P2544 , P308D , P30B4 , P30B5 , P30BC , P30BD , P30D5 , P30DE , P3168 , P3169 , or P316B
P1200	Engine Controls and Fuel - 3.6L (LFY) - DTC C1201 , P1000 , P1001 , P1003 , P1008 , P1009 , P100A , P100E , P103D , P103E , P10B6-P10B9 , P10BF , P10C6-P10C8 , P10F5 , P1100 , P1103 , P117A , P11FF , P1200 , P128C-P128F , P129E , P12A8 , P130F , P135C-P135F , P1436 , P143A , P143B , P1472 , P14A0 , P14B6 , P14BD , P14CD , P14CE , P14D4-P14D6 , P150C , P151A , P151D , P153C , P153D , P155D , P1591 , P15E2 , P15F2 , P15F9 , P15FA , P15FB , P165C , P167F , P16E8 , P16FF , P175F , P1761 , P1762 , P1775 , P179B , P189C , P2544 , P308D , P30B4 , P30B5 , P30BC , P30BD , P30D5 , P30DE , P3168 , P3169 , or P316B
P1248	Engine Controls and Fuel - 2.0L (LTG) - DTC P0201-P0204 , P0261 , P0262 , P0264 , P0265 , P0267 , P0268 , P0270 , P0271 , P1248 , P1249 , P124A , P124B , P2147 , P2148 , P2150 , P2151 , P2153 , P2154 , P2156 , or P2157
P1248	Engine Controls and Fuel - 3.6L (LFY) - DTC P1248-P124D
P1249	Engine Controls and Fuel - 2.0L (LTG) - DTC P0201-P0204 , P0261 , P0262 , P0264 , P0265 , P0267 , P0268 , P0270 , P0271 , P1248 , P1249 , P124A , P124B , P2147 , P2148 , P2150 , P2151 , P2153 , P2154 , P2156 , or P2157
P1249	Engine Controls and Fuel - 3.6L (LFY) - DTC P1248-P124D
P124A	Engine Controls and Fuel - 2.0L (LTG) - DTC P0201-P0204 , P0261 , P0262 , P0264 , P0265 , P0267 , P0268 , P0270 , P0271 , P1248 , P1249 , P124A , P124B , P2147 , P2148 , P2150 , P2151 , P2153 , P2154 , P2156 , or P2157
P124A	Engine Controls and Fuel - 3.6L (LFY) - DTC P1248-P124D
P124B	Engine Controls and Fuel - 2.0L (LTG) - DTC P0201-P0204 , P0261 , P0262 , P0264 , P0265 , P0267 , P0268 , P0270 , P0271 , P1248 , P1249 , P124A , P124B , P2147 , P2148 , P2150 , P2151 , P2153 , P2154 , P2156 , or P2157
P124B	Engine Controls and Fuel - 3.6L (LFY) - DTC P1248-P124D
P124C	Engine Controls and Fuel - 3.6L (LFY) - DTC P1248-P124D
P124D	Engine Controls and Fuel - 3.6L (LFY) - DTC P1248-P124D
P1255	Engine Controls and Fuel - 2.0L (LTG) - DTC P1255
P1255	Engine Controls and Fuel - 3.6L (LFY) - DTC P1255
P1258	Engine Heating and Cooling - DTC P1258
P126E	Engine Controls and Fuel - 3.6L (LFY) - DTC P0182 , P0183 , P0187 , P0188 , P0191 , P0192 , P111F , P126E , P126F , P127C , P128A , P128B , P16E4 , or P16E5 (LFY)

DTC	Diagnostic Procedure
P126F	Engine Controls and Fuel - 3.6L (LFY) - DTC P0182, P0183, P0187, P0188, P0191, P0192, P111F, P126E, P126F, P127C, P128A, P128B, P16E4, or P16E5 (LFY) .
P127C	Engine Controls and Fuel - 2.0L (LTG) - DTC P127C, P128A, P128B, P16E4, or P16E5
P127C	Engine Controls and Fuel - 3.6L (LFY) - DTC P0182, P0183, P0187, P0188, P0191, P0192, P111F, P126E, P126F, P127C, P128A, P128B, P16E4, or P16E5 (LFY) .
P128A	Engine Controls and Fuel - 2.0L (LTG) - DTC P127C, P128A, P128B, P16E4, or P16E5
P128A	Engine Controls and Fuel - 3.6L (LFY) - DTC P0182, P0183, P0187, P0188, P0191, P0192, P111F, P126E, P126F, P127C, P128A, P128B, P16E4, or P16E5 (LFY) .
P128B	Engine Controls and Fuel - 2.0L (LTG) - DTC P127C, P128A, P128B, P16E4, or P16E5
P128B	Engine Controls and Fuel - 3.6L (LFY) - DTC P0182, P0183, P0187, P0188, P0191, P0192, P111F, P126E, P126F, P127C, P128A, P128B, P16E4, or P16E5 (LFY) .
P128C	Engine Controls and Fuel - 2.0L (LTG) - DTC C1201, P1000, P1001, P1003, P1008, P1009, P100A, P100E, P103D, P103E, P10B6-P10B9, P10BF, P10C6-P10C8, P10F5, P1100, P1103, P117A, P11FF, P1200, P128C-P128F, P129E, P12A8, P130F, P135C-P135F, P1436, P143A, P143B, P1472, P14A0, P14B6, P14BD, P14CD, P14CE, P14D4-P14D6, P150C, P151A, P151D, P153C, P153D, P155D, P1591, P15E2, P15F2, P15F9, P15FA, P15FB, P165C, P167F, P16E8, P16FF, P175F, P1761, P1762, P1775, P179B, P189C, P2544, P308D, P30B4, P30B5, P30BC, P30BD, P30D5, P30DE, P3168, P3169, or P316B
P128C	Engine Controls and Fuel - 3.6L (LFY) - DTC C1201, P1000, P1001, P1003, P1008, P1009, P100A, P100E, P103D, P103E, P10B6-P10B9, P10BF, P10C6-P10C8, P10F5, P1100, P1103, P117A, P11FF, P1200, P128C-P128F, P129E, P12A8, P130F, P135C-P135F, P1436, P143A, P143B, P1472, P14A0, P14B6, P14BD, P14CD, P14CE, P14D4-P14D6, P150C, P151A, P151D, P153C, P153D, P155D, P1591, P15E2, P15F2, P15F9, P15FA, P15FB, P165C, P167F, P16E8, P16FF, P175F, P1761, P1762, P1775, P179B, P189C, P2544, P308D, P30B4, P30B5, P30BC, P30BD, P30D5, P30DE, P3168, P3169, or P316B
P128D	Engine Controls and Fuel - 2.0L (LTG) - DTC C1201, P1000, P1001, P1003, P1008, P1009, P100A, P100E, P103D, P103E, P10B6-P10B9, P10BF, P10C6-P10C8, P10F5, P1100, P1103, P117A, P11FF, P1200, P128C-P128F, P129E, P12A8, P130F, P135C-P135F, P1436, P143A, P143B, P1472, P14A0, P14B6, P14BD, P14CD, P14CE, P14D4-P14D6, P150C, P151A, P151D, P153C, P153D, P155D, P1591, P15E2, P15F2, P15F9, P15FA, P15FB, P165C, P167F, P16E8, P16FF, P175F, P1761, P1762, P1775, P179B, P189C, P2544, P308D, P30B4, P30B5, P30BC, P30BD, P30D5, P30DE, P3168, P3169, or P316B
P128D	Engine Controls and Fuel - 3.6L (LFY) - DTC C1201, P1000, P1001, P1003, P1008, P1009, P100A, P100E, P103D, P103E, P10B6-P10B9, P10BF, P10C6-P10C8, P10F5, P1100, P1103, P117A, P11FF, P1200, P128C-P128F, P129E, P12A8, P130F, P135C-P135F, P1436, P143A, P143B, P1472, P14A0, P14B6, P14BD, P14CD, P14CE, P14D4-P14D6, P150C, P151A, P151D, P153C, P153D, P155D, P1591, P15E2, P15F2, P15F9, P15FA, P15FB, P165C, P167F, P16E8, P16FF, P175F, P1761, P1762, P1775, P179B, P189C, P2544, P308D, P30B4, P30B5, P30BC, P30BD, P30D5, P30DE, P3168, P3169, or P316B
P128E	Engine Controls and Fuel - 2.0L (LTG) - DTC C1201, P1000, P1001, P1003, P1008, P1009, P100A, P100E, P103D, P103E, P10B6-P10B9, P10BF, P10C6-P10C8, P10F5, P1100, P1103, P117A, P11FF, P1200, P128C-P128F, P129E, P12A8, P130F, P135C-P135F, P1436, P143A, P143B, P1472, P14A0, P14B6, P14BD, P14CD, P14CE, P14D4-P14D6, P150C, P151A, P151D, P153C, P153D, P155D, P1591, P15E2, P15F2, P15F9, P15FA, P15FB, P165C, P167F, P16E8, P16FF, P175F, P1761, P1762, P1775, P179B, P189C, P2544, P308D, P30B4, P30B5, P30BC, P30BD, P30D5, P30DE, P3168, P3169, or P316B

DTC	Diagnostic Procedure
P128E	Engine Controls and Fuel - 3.6L (LFY) - DTC C1201 , P1000 , P1001 , P1003 , P1008 , P1009 , P100A , P100E , P103D , P103E , P10B6-P10B9 , P10BF , P10C6-P10C8 , P10F5 , P1100 , P1103 , P117A , P11FF , P1200 , P128C-P128F , P129E , P12A8 , P130F , P135C-P135F , P1436 , P143A , P143B , P1472 , P14A0 , P14B6 , P14BD , P14CD , P14CE , P14D4-P14D6 , P150C , P151A , P151D , P153C , P153D , P155D , P1591 , P15E2 , P15F2 , P15F9 , P15FA , P15FB , P165C , P167F , P16E8 , P16FF , P175F , P1761 , P1762 , P1775 , P179B , P189C , P2544 , P308D , P30B4 , P30B5 , P30BC , P30BD , P30D5 , P30DE , P3168 , P3169 , or P316B
P128F	Engine Controls and Fuel - 2.0L (LTG) - DTC C1201 , P1000 , P1001 , P1003 , P1008 , P1009 , P100A , P100E , P103D , P103E , P10B6-P10B9 , P10BF , P10C6-P10C8 , P10F5 , P1100 , P1103 , P117A , P11FF , P1200 , P128C-P128F , P129E , P12A8 , P130F , P135C-P135F , P1436 , P143A , P143B , P1472 , P14A0 , P14B6 , P14BD , P14CD , P14CE , P14D4-P14D6 , P150C , P151A , P151D , P153C , P153D , P155D , P1591 , P15E2 , P15F2 , P15F9 , P15FA , P15FB , P165C , P167F , P16E8 , P16FF , P175F , P1761 , P1762 , P1775 , P179B , P189C , P2544 , P308D , P30B4 , P30B5 , P30BC , P30BD , P30D5 , P30DE , P3168 , P3169 , or P316B
P128F	Engine Controls and Fuel - 3.6L (LFY) - DTC C1201 , P1000 , P1001 , P1003 , P1008 , P1009 , P100A , P100E , P103D , P103E , P10B6-P10B9 , P10BF , P10C6-P10C8 , P10F5 , P1100 , P1103 , P117A , P11FF , P1200 , P128C-P128F , P129E , P12A8 , P130F , P135C-P135F , P1436 , P143A , P143B , P1472 , P14A0 , P14B6 , P14BD , P14CD , P14CE , P14D4-P14D6 , P150C , P151A , P151D , P153C , P153D , P155D , P1591 , P15E2 , P15F2 , P15F9 , P15FA , P15FB , P165C , P167F , P16E8 , P16FF , P175F , P1761 , P1762 , P1775 , P179B , P189C , P2544 , P308D , P30B4 , P30B5 , P30BC , P30BD , P30D5 , P30DE , P3168 , P3169 , or P316B
P129B	12 V Starting and Charging - DTC B1325 , B1327 , B1328 , B1330 , B1390 , B1395 , B1400 , B1410 , B1415 , B1424 , B1425 , B1439 , B1517 , C0800 , C0805 , C0870 , C0880 , C0895 , C0899 , C0900 , C1300 , P0560-P0563 , P0611 , P1002 , P129B , P129C , P1465 , P1466 , P15AE , P15AF , P17B0-P17B2 , P17DD-P17DE , P1A0C , P1A0D , P1E19 , P1E1A , or U2800
P129C	12 V Starting and Charging - DTC B1325 , B1327 , B1328 , B1330 , B1390 , B1395 , B1400 , B1410 , B1415 , B1424 , B1425 , B1439 , B1517 , C0800 , C0805 , C0870 , C0880 , C0895 , C0899 , C0900 , C1300 , P0560-P0563 , P0611 , P1002 , P129B , P129C , P1465 , P1466 , P15AE , P15AF , P17B0-P17B2 , P17DD-P17DE , P1A0C , P1A0D , P1E19 , P1E1A , or U2800
P129D	Engine Controls and Fuel - 2.0L (LTG) - DTC P129D
P129D	Engine Controls and Fuel - 3.6L (LFY) - DTC P129D
P129E	Engine Controls and Fuel - 2.0L (LTG) - DTC C1201 , P1000 , P1001 , P1003 , P1008 , P1009 , P100A , P100E , P103D , P103E , P10B6-P10B9 , P10BF , P10C6-P10C8 , P10F5 , P1100 , P1103 , P117A , P11FF , P1200 , P128C-P128F , P129E , P12A8 , P130F , P135C-P135F , P1436 , P143A , P143B , P1472 , P14A0 , P14B6 , P14BD , P14CD , P14CE , P14D4-P14D6 , P150C , P151A , P151D , P153C , P153D , P155D , P1591 , P15E2 , P15F2 , P15F9 , P15FA , P15FB , P165C , P167F , P16E8 , P16FF , P175F , P1761 , P1762 , P1775 , P179B , P189C , P2544 , P308D , P30B4 , P30B5 , P30BC , P30BD , P30D5 , P30DE , P3168 , P3169 , or P316B
P129E	Engine Controls and Fuel - 3.6L (LFY) - DTC C1201 , P1000 , P1001 , P1003 , P1008 , P1009 , P100A , P100E , P103D , P103E , P10B6-P10B9 , P10BF , P10C6-P10C8 , P10F5 , P1100 , P1103 , P117A , P11FF , P1200 , P128C-P128F , P129E , P12A8 , P130F , P135C-P135F , P1436 , P143A , P143B , P1472 , P14A0 , P14B6 , P14BD , P14CD , P14CE , P14D4-P14D6 , P150C , P151A , P151D , P153C , P153D , P155D , P1591 , P15E2 , P15F2 , P15F9 , P15FA , P15FB , P165C , P167F , P16E8 , P16FF , P175F , P1761 , P1762 , P1775 , P179B , P189C , P2544 , P308D , P30B4 , P30B5 , P30BC , P30BD , P30D5 , P30DE , P3168 , P3169 , or P316B
P12A6	Engine Controls and Fuel - 2.0L (LTG) - DTC P12A6
P12A6	Engine Controls and Fuel - 3.6L (LFY) - DTC P12A6

DTC	Diagnostic Procedure
P12A8	Engine Controls and Fuel - 2.0L (LTG) - DTC C1201 , P1000 , P1001 , P1003 , P1008 , P1009 , P100A , P100E , P103D , P103E , P10B6-P10B9 , P10BF , P10C6-P10C8 , P10F5 , P1100 , P1103 , P117A , P11FF , P1200 , P128C-P128F , P129E , P12A8 , P130F , P135C-P135F , P1436 , P143A , P143B , P1472 , P14A0 , P14B6 , P14BD , P14CD , P14CE , P14D4-P14D6 , P150C , P151A , P151D , P153C , P153D , P155D , P1591 , P15E2 , P15F2 , P15F9 , P15FA , P15FB , P165C , P167F , P16E8 , P16FF , P175F , P1761 , P1762 , P1775 , P179B , P189C , P2544 , P308D , P30B4 , P30B5 , P30BC , P30BD , P30D5 , P30DE , P3168 , P3169 , or P316B
P12A8	Engine Controls and Fuel - 3.6L (LFY) - DTC C1201 , P1000 , P1001 , P1003 , P1008 , P1009 , P100A , P100E , P103D , P103E , P10B6-P10B9 , P10BF , P10C6-P10C8 , P10F5 , P1100 , P1103 , P117A , P11FF , P1200 , P128C-P128F , P129E , P12A8 , P130F , P135C-P135F , P1436 , P143A , P143B , P1472 , P14A0 , P14B6 , P14BD , P14CD , P14CE , P14D4-P14D6 , P150C , P151A , P151D , P153C , P153D , P155D , P1591 , P15E2 , P15F2 , P15F9 , P15FA , P15FB , P165C , P167F , P16E8 , P16FF , P175F , P1761 , P1762 , P1775 , P179B , P189C , P2544 , P308D , P30B4 , P30B5 , P30BC , P30BD , P30D5 , P30DE , P3168 , P3169 , or P316B
P130F	Engine Controls and Fuel - 2.0L (LTG) - DTC C1201 , P1000 , P1001 , P1003 , P1008 , P1009 , P100A , P100E , P103D , P103E , P10B6-P10B9 , P10BF , P10C6-P10C8 , P10F5 , P1100 , P1103 , P117A , P11FF , P1200 , P128C-P128F , P129E , P12A8 , P130F , P135C-P135F , P1436 , P143A , P143B , P1472 , P14A0 , P14B6 , P14BD , P14CD , P14CE , P14D4-P14D6 , P150C , P151A , P151D , P153C , P153D , P155D , P1591 , P15E2 , P15F2 , P15F9 , P15FA , P15FB , P165C , P167F , P16E8 , P16FF , P175F , P1761 , P1762 , P1775 , P179B , P189C , P2544 , P308D , P30B4 , P30B5 , P30BC , P30BD , P30D5 , P30DE , P3168 , P3169 , or P316B
P130F	Engine Controls and Fuel - 3.6L (LFY) - DTC C1201 , P1000 , P1001 , P1003 , P1008 , P1009 , P100A , P100E , P103D , P103E , P10B6-P10B9 , P10BF , P10C6-P10C8 , P10F5 , P1100 , P1103 , P117A , P11FF , P1200 , P128C-P128F , P129E , P12A8 , P130F , P135C-P135F , P1436 , P143A , P143B , P1472 , P14A0 , P14B6 , P14BD , P14CD , P14CE , P14D4-P14D6 , P150C , P151A , P151D , P153C , P153D , P155D , P1591 , P15E2 , P15F2 , P15F9 , P15FA , P15FB , P165C , P167F , P16E8 , P16FF , P175F , P1761 , P1762 , P1775 , P179B , P189C , P2544 , P308D , P30B4 , P30B5 , P30BC , P30BD , P30D5 , P30DE , P3168 , P3169 , or P316B
P135A	Engine Controls and Fuel - 2.0L (LTG) - DTC P135A
P135A	Engine Controls and Fuel - 3.6L (LFY) - DTC P135A or P135B
P135B	Engine Controls and Fuel - 3.6L (LFY) - DTC P135A or P135B
P135C	Engine Controls and Fuel - 2.0L (LTG) - DTC C1201 , P1000 , P1001 , P1003 , P1008 , P1009 , P100A , P100E , P103D , P103E , P10B6-P10B9 , P10BF , P10C6-P10C8 , P10F5 , P1100 , P1103 , P117A , P11FF , P1200 , P128C-P128F , P129E , P12A8 , P130F , P135C-P135F , P1436 , P143A , P143B , P1472 , P14A0 , P14B6 , P14BD , P14CD , P14CE , P14D4-P14D6 , P150C ,

DTC	Diagnostic Procedure
P135D	Engine Controls and Fuel - 3.6L (LFY) - DTC C1201 , P1000 , P1001 , P1003 , P1008 , P1009 , P100A , P100E , P103D , P103E , P10B6-P10B9 , P10BF , P10C6-P10C8 , P10F5 , P1100 , P1103 , P117A , P11FF , P1200 , P128C-P128F , P129E , P12A8 , P130F , P135C-P135F , P1436 , P143A , P143B , P1472 , P14A0 , P14B6 , P14BD , P14CD , P14CE , P14D4-P14D6 , P150C , P151A , P151D , P153C , P153D , P155D , P1591 , P15E2 , P15F2 , P15F9 , P15FA , P15FB , P165C , P167F , P16E8 , P16FF , P175F , P1761 , P1762 , P1775 , P179B , P189C , P2544 , P308D , P30B4 , P30B5 , P30BC , P30BD , P30D5 , P30DE , P3168 , P3169 , or P316B
P135E	Engine Controls and Fuel - 2.0L (LTG) - DTC C1201 , P1000 , P1001 , P1003 , P1008 , P1009 , P100A , P100E , P103D , P103E , P10B6-P10B9 , P10BF , P10C6-P10C8 , P10F5 , P1100 , P1103 , P117A , P11FF , P1200 , P128C-P128F , P129E , P12A8 , P130F , P135C-P135F , P1436 , P143A , P143B , P1472 , P14A0 , P14B6 , P14BD , P14CD , P14CE , P14D4-P14D6 , P150C , P151A , P151D , P153C , P153D , P155D , P1591 , P15E2 , P15F2 , P15F9 , P15FA , P15FB , P165C , P167F , P16E8 , P16FF , P175F , P1761 , P1762 , P1775 , P179B , P189C , P2544 , P308D , P30B4 , P30B5 , P30BC , P30BD , P30D5 , P30DE , P3168 , P3169 , or P316B
P135E	Engine Controls and Fuel - 3.6L (LFY) - DTC C1201 , P1000 , P1001 , P1003 , P1008 , P1009 , P100A , P100E , P103D , P103E , P10B6-P10B9 , P10BF , P10C6-P10C8 , P10F5 , P1100 , P1103 , P117A , P11FF , P1200 , P128C-P128F , P129E , P12A8 , P130F , P135C-P135F , P1436 , P143A , P143B , P1472 , P14A0 , P14B6 , P14BD , P14CD , P14CE , P14D4-P14D6 , P150C , P151A , P151D , P153C , P153D , P155D , P1591 , P15E2 , P15F2 , P15F9 , P15FA , P15FB , P165C , P167F , P16E8 , P16FF , P175F , P1761 , P1762 , P1775 , P179B , P189C , P2544 , P308D , P30B4 , P30B5 , P30BC , P30BD , P30D5 , P30DE , P3168 , P3169 , or P316B
P135F	Engine Controls and Fuel - 2.0L (LTG) - DTC C1201 , P1000 , P1001 , P1003 , P1008 , P1009 , P100A , P100E , P103D , P103E , P10B6-P10B9 , P10BF , P10C6-P10C8 , P10F5 , P1100 , P1103 , P117A , P11FF , P1200 , P128C-P128F , P129E , P12A8 , P130F , P135C-P135F , P1436 , P143A , P143B , P1472 , P14A0 , P14B6 , P14BD , P14CD , P14CE , P14D4-P14D6 , P150C , P151A , P151D , P153C , P153D , P155D , P1591 , P15E2 , P15F2 , P15F9 , P15FA , P15FB , P165C , P167F , P16E8 , P16FF , P175F , P1761 , P1762 , P1775 , P179B , P189C , P2544 , P308D , P30B4 , P30B5 , P30BC , P30BD , P30D5 , P30DE , P3168 , P3169 , or P316B
P135F	Engine Controls and Fuel - 3.6L (LFY) - DTC C1201 , P1000 , P1001 , P1003 , P1008 , P1009 , P100A , P100E , P103D , P103E , P10B6-P10B9 , P10BF , P10C6-P10C8 , P10F5 , P1100 , P1103 , P117A , P11FF , P1200 , P128C-P128F , P129E , P12A8 , P130F , P135C-P135F , P1436 , P143A , P143B , P1472 , P14A0 , P14B6 , P14BD , P14CD , P14CE , P14D4-P14D6 , P150C , P151A , P151D , P153C , P153D , P155D , P1591 , P15E2 , P15F2 , P15F9 , P15FA , P15FB , P165C , P167F , P16E8 ,

DTC	Diagnostic Procedure
P143A	Engine Controls and Fuel - 2.0L (LTG) - <u>DTC C1201, P1000, P1001, P1003, P1008, P1009, P100A, P100E, P103D, P103E, P10B6-P10B9, P10BE, P10C6-P10C8, P10F5, P1100, P1103, P117A, P11FE, P1200, P128C-P128E, P129E, P12A8, P130F, P135C-P135E, P1436, P143A, P143B, P1472, P14A0, P14B6, P14BD, P14CD, P14CE, P14D4-P14D6, P150C, P151A, P151D, P153C, P153D, P155D, P1591, P15E2, P15F2, P15F9, P15FA, P15FB, P165C, P167F, P16E8, P16FE, P175F, P1761, P1762, P1775, P179B, P189C, P2544, P308D, P30B4, P30B5, P30BC, P30BD, P30D5, P30DE, P3168, P3169, or P316B</u>
P143A	Engine Controls and Fuel - 3.6L (LFY) - <u>DTC C1201, P1000, P1001, P1003, P1008, P1009, P100A, P100E, P103D, P103E, P10B6-P10B9, P10BE, P10C6-P10C8, P10F5, P1100, P1103, P117A, P11FE, P1200, P128C-P128E, P129E, P12A8, P130F, P135C-P135E, P1436, P143A, P143B, P1472, P14A0, P14B6, P14BD, P14CD, P14CE, P14D4-P14D6, P150C, P151A, P151D, P153C, P153D, P155D, P1591, P15E2, P15F2, P15F9, P15FA, P15FB, P165C, P167F, P16E8, P16FE, P175F, P1761, P1762, P1775, P179B, P189C, P2544, P308D, P30B4, P30B5, P30BC, P30BD, P30D5, P30DE, P3168, P3169, or P316B</u>
P143B	Engine Controls and Fuel - 2.0L (LTG) - <u>DTC C1201, P1000, P1001, P1003, P1008, P1009, P100A, P100E, P103D, P103E, P10B6-P10B9, P10BE, P10C6-P10C8, P10F5, P1100, P1103, P117A, P11FE, P1200, P128C-P128E, P129E, P12A8, P130F, P135C-P135E, P1436, P143A, P143B, P1472, P14A0, P14B6, P14BD, P14CD, P14CE, P14D4-P14D6, P150C, P151A, P151D, P153C, P153D, P155D, P1591, P15E2, P15F2, P15F9, P15FA, P15FB, P165C, P167F, P16E8, P16FE, P175F, P1761, P1762, P1775, P179B, P189C, P2544, P308D, P30B4, P30B5, P30BC, P30BD, P30D5, P30DE, P3168, P3169, or P316B</u>
P143B	Engine Controls and Fuel - 3.6L (LFY) - <u>DTC C1201, P1000, P1001, P1003, P1008, P1009, P100A, P100E, P103D, P103E, P10B6-P10B9, P10BE, P10C6-P10C8, P10F5, P1100, P1103, P117A, P11FE, P1200, P128C-P128E, P129E, P12A8, P130F, P135C-P135E, P1436, P143A, P143B, P1472, P14A0, P14B6, P14BD, P14CD, P14CE, P14D4-P14D6, P150C, P151A, P151D, P153C, P153D, P155D, P1591, P15E2, P15F2, P15F9, P15FA, P15FB, P165C, P167F, P16E8, P16FE, P175F, P1761, P1762, P1775, P179B, P189C, P2544, P308D, P30B4, P30B5, P30BC, P30BD, P30D5, P30DE, P3168, P3169, or P316B</u>
P1465	12 V Starting and Charging - <u>DTC B1325, B1327, B1328, B1330, B1390, B1395, B1400, B1410, B1415, B1424, B1425, B1439, B1517, C0800, C0805, C0870, C0880, C0895, C0899, C0900, C1300, P0560-P0563, P0611, P1002, P129B, P129C, P1465, P1466, P15AE, P15AF, P17B0-P17B2, P17DD-P17DE, P1A0C, P1A0D, P1E19, P1E1A, or U2800</u>
P1466	12 V Starting and Charging - <u>DTC B1325, B1327, B1328, B1330, B1390, B1395, B1400, B1410, B1415, B1424, B1425, B1439, B1517, C0800, C0805, C0870, C0880, C0895, C0899, C0900, C1300, P0560-P0563, P0611, P1002, P129B, P129C, P1465, P1466, P15AE, P15AF, P17B0-P17B2, P17DD-P17DE, P1A0C, P1A0D, P1E19, P1E1A, or U2800</u>
P1472	Engine Controls and Fuel - 2.0L (LTG) - <u>DTC C1201, P1000, P1001, P1003, P1008, P1009, P100A, P100E, P103D, P103E, P10B6-P10B9, P10BE, P10C6-P10C8, P10F5, P1100, P1103, P117A, P11FE, P1200, P128C-P128E, P129E, P12A8, P130F, P135C-P135E, P1436, P143A, P143B, P1472, P14A0, P14B6, P14BD, P14CD, P14CE, P14D4-P14D6, P150C, P151A, P151D, P153C, P153D, P155D, P1591, P15E2, P15F2, P15F9, P15FA, P15FB, P165C, P167F, P16E8, P16FE, P175F, P1761, P1762, P1775, P179B, P189C, P2544, P308D, P30B4, P30B5, P30BC, P30BD, P30D5, P30DE, P3168, P3169, or P316B</u>
P1472	Engine Controls and Fuel - 3.6L (LFY) - <u>DTC C1201, P1000, P1001, P1003, P1008, P1009, P100A, P100E, P103D, P103E, P10B6-P10B9, P10BE, P10C6-P10C8, P10F5, P1100, P1103, P117A, P11FE, P1200, P128C-P128E, P129E, P12A8, P130F, P135C-P135E, P1436, P143A, P143B, P1472, P14A0, P14B6, P14BD, P14CD, P14CE, P14D4-P14D6, P150C, P151A, P151D, P153C, P153D, P155D, P1591, P15E2, P15F2, P15F9, P15FA, P15FB, P165C, P167F, P16E8, P16FE, P175F, P1761, P1762, P1775, P179B, P189C, P2544, P308D, P30B4, P30B5, P30BC, P30BD, P30D5, P30DE, P3168, P3169, or P316B</u>

DTC	Diagnostic Procedure
P14A0	Engine Controls and Fuel - 2.0L (LTG) - DTC C1201 , P1000 , P1001 , P1003 , P1008 , P1009 , P100A , P100E , P103D , P103E , P10B6-P10B9 , P10BF , P10C6-P10C8 , P10F5 , P1100 , P1103 , P117A , P11FF , P1200 , P128C-P128F , P129E , P12A8 , P130F , P135C-P135F , P1436 , P143A , P143B , P1472 , P14A0 , P14B6 , P14BD , P14CD , P14CE , P14D4-P14D6 , P150C , P151A , P151D , P153C , P153D , P155D , P1591 , P15E2 , P15F2 , P15F9 , P15FA , P15FB , P165C , P167F , P16E8 , P16FF , P175E , P1761 , P1762 , P1775 , P179B , P189C , P2544 , P308D , P30B4 , P30B5 , P30BC , P30BD , P30D5 , P30DE , P3168 , P3169 , or P316B
P14A0	Engine Controls and Fuel - 3.6L (LFY) - DTC C1201 , P1000 , P1001 , P1003 , P1008 , P1009 , P100A , P100E , P103D , P103E , P10B6-P10B9 , P10BF , P10C6-P10C8 , P10F5 , P1100 , P1103 , P117A , P11FF , P1200 , P128C-P128F , P129E , P12A8 , P130F , P135C-P135F , P1436 , P143A , P143B , P1472 , P14A0 , P14B6 , P14BD , P14CD , P14CE , P14D4-P14D6 , P150C , P151A , P151D , P153C , P153D , P155D , P1591 , P15E2 , P15F2 , P15F9 , P15FA , P15FB , P165C , P167F , P16E8 , P16FF , P175E , P1761 , P1762 , P1775 , P179B , P189C , P2544 , P308D , P30B4 , P30B5 , P30BC , P30BD , P30D5 , P30DE , P3168 , P3169 , or P316B
P14B6	Engine Controls and Fuel - 2.0L (LTG) - DTC C1201 , P1000 , P1001 , P1003 , P1008 , P1009 , P100A , P100E , P103D , P103E , P10B6-P10B9 , P10BF , P10C6-P10C8 , P10F5 , P1100 , P1103 , P117A , P11FF , P1200 , P128C-P128F , P129E , P12A8 , P130F , P135C-P135F , P1436 , P143A , P143B , P1472 , P14A0 , P14B6 , P14BD , P14CD , P14CE , P14D4-P14D6 , P150C , P151A , P151D , P153C , P153D , P155D , P1591 , P15E2 , P15F2 , P15F9 , P15FA , P15FB , P165C , P167F , P16E8 , P16FF , P175E , P1761 , P1762 , P1775 , P179B , P189C , P2544 , P308D , P30B4 , P30B5 , P30BC , P30BD , P30D5 , P30DE , P3168 , P3169 , or P316B
P14B6	Engine Controls and Fuel - 3.6L (LFY) - DTC C1201 , P1000 , P1001 , P1003 , P1008 , P1009 , P100A , P100E , P103D , P103E , P10B6-P10B9 , P10BF , P10C6-P10C8 , P10F5 , P1100 , P1103 , P117A , P11FF , P1200 , P128C-P128F , P129E , P12A8 , P130F , P135C-P135F , P1436 , P143A , P143B , P1472 , P14A0 , P14B6 , P14BD , P14CD , P14CE , P14D4-P14D6 , P150C , P151A , P151D , P153C , P153D , P155D , P1591 , P15E2 , P15F2 , P15F9 , P15FA , P15FB , P165C , P167F , P16E8 , P16FF , P175E , P1761 , P1762 , P1775 , P179B , P189C , P2544 , P308D , P30B4 , P30B5 , P30BC , P30BD , P30D5 , P30DE , P3168 , P3169 , or P316B
P14BD	Engine Controls and Fuel - 2.0L (LTG) - DTC C1201 , P1000 , P1001 , P1003 , P1008 , P1009 , P100A , P100E , P103D , P103E , P10B6-P10B9 , P10BF , P10C6-P10C8 , P10F5 , P1100 , P1103 , P117A , P11FF , P1200 , P128C-P128F , P129E , P12A8 , P130F , P135C-P135F , P1436 , P143A , P143B , P1472 , P14A0 , P14B6 , P14BD , P14CD , P14CE , P14D4-P14D6 , P150C , P151A , P151D , P153C , P153D , P155D , P1591 , P15E2 , P15F2 , P15F9 , P15FA , P15FB , P165C , P167F , P16E8 , P

DTC	Diagnostic Procedure
P14CD	Engine Controls and Fuel - 3.6L (LFY) - DTC C1201 , P1000 , P1001 , P1003 , P1008 , P1009 , P100A , P100E , P103D , P103E , P10B6-P10B9 , P10BF , P10C6-P10C8 , P10F5 , P1100 , P1103 , P117A , P11FF , P1200 , P128C-P128F , P129E , P12A8 , P130F , P135C-P135F , P1436 , P143A , P143B , P1472 , P14A0 , P14B6 , P14BD , P14CD , P14CE , P14D4-P14D6 , P150C , P151A , P151D , P153C , P153D , P155D , P1591 , P15E2 , P15F2 , P15F9 , P15FA , P15FB , P165C , P167F , P16E8 , P16FF , P175F , P1761 , P1762 , P1775 , P179B , P189C , P2544 , P308D , P30B4 , P30B5 , P30BC , P30BD , P30D5 , P30DE , P3168 , P3169 , or P316B
P14CE	Engine Controls and Fuel - 2.0L (LTG) - DTC C1201 , P1000 , P1001 , P1003 , P1008 , P1009 , P100A , P100E , P103D , P103E , P10B6-P10B9 , P10BF , P10C6-P10C8 , P10F5 , P1100 , P1103 , P117A , P11FF , P1200 , P128C-P128F , P129E , P12A8 , P130F , P135C-P135F , P1436 , P143A , P143B , P1472 , P14A0 , P14B6 , P14BD , P14CD , P14CE , P14D4-P14D6 , P150C , P151A , P151D , P153C , P153D , P155D , P1591 , P15E2 , P15F2 , P15F9 , P15FA , P15FB , P165C , P167F , P16E8 , P16FF , P175F , P1761 , P1762 , P1775 , P179B , P189C , P2544 , P308D , P30B4 , P30B5 , P30BC , P30BD , P30D5 , P30DE , P3168 , P3169 , or P316B
P14CE	Engine Controls and Fuel - 3.6L (LFY) - DTC C1201 , P1000 , P1001 , P1003 , P1008 , P1009 , P100A , P100E , P103D , P103E , P10B6-P10B9 , P10BF , P10C6-P10C8 , P10F5 , P1100 , P1103 , P117A , P11FF , P1200 , P128C-P128F , P129E , P12A8 , P130F , P135C-P135F , P1436 , P143A , P143B , P1472 , P14A0 , P14B6 , P14BD , P14CD , P14CE , P14D4-P14D6 , P150C , P151A , P151D , P153C , P153D , P155D , P1591 , P15E2 , P15F2 , P15F9 , P15FA , P15FB , P165C , P167F , P16E8 , P16FF , P175F , P1761 , P1762 , P1775 , P179B , P189C , P2544 , P308D , P30B4 , P30B5 , P30BC , P30BD , P30D5 , P30DE , P3168 , P3169 , or P316B
P14D4	Engine Controls and Fuel - 2.0L (LTG) - DTC C1201 , P1000 , P1001 , P1003 , P1008 , P1009 , P100A , P100E , P103D , P103E , P10B6-P10B9 , P10BF , P10C6-P10C8 , P10F5 , P1100 , P1103 , P117A , P11FF , P1200 , P128C-P128F , P129E , P12A8 , P130F , P135C-P135F , P1436 , P143A , P143B , P1472 , P14A0 , P14B6 , P14BD , P14CD , P14CE , P14D4-P14D6 , P150C , P151A , P151D , P153C , P153D , P155D , P1591 , P15E2 , P15F2 , P15F9 , P15FA , P15FB , P165C , P167F , P16E8 , P16FF , P175F , P1761 , P1762 , P1775 , P179B , P189C , P2544 , P308D , P30B4 , P30B5 , P30BC , P30BD , P30D5 , P30DE , P3168 , P3169 , or P316B
P14D4	Engine Controls and Fuel - 3.6L (LFY) - DTC C1201 , P1000 , P1001 , P1003 , P1008 , P1009 , P100A , P100E , P103D , P103E , P10B6-P10B9 , P10BF , P10C6-P10C8 , P10F5 , P1100 , P1103 , P117A , P11FF , P1200 , P128C-P128F , P129E , P12A8 , P130F , P135C-P135F , P1436 , P143A , P143B , P1472 , P14A0 , P14B6 , P14BD , P14CD , P14CE , P14D4-P14D6 , P150C , P151A , P151D , P153C , P153D , P155D , P1591 , P15E2 , P15F2 , P15F9 , P15FA , P15FB , P165C , P167F , P16E8 , P16

DTC	Diagnostic Procedure
P14D6	Engine Controls and Fuel - 2.0L (LTG) - DTC C1201 , P1000 , P1001 , P1003 , P1008 , P1009 , P100A , P100E , P103D , P103E , P10B6-P10B9 , P10BF , P10C6-P10C8 , P10F5 , P1100 , P1103 , P117A , P11FF , P1200 , P128C-P128F , P129E , P12A8 , P130F , P135C-P135F , P1436 , P143A , P143B , P1472 , P14A0 , P14B6 , P14BD , P14CD , P14CE , P14D4-P14D6 , P150C , P151A , P151D , P153C , P153D , P155D , P1591 , P15E2 , P15F2 , P15F9 , P15FA , P15FB , P165C , P167F , P16E8 , P16FF , P175F , P1761 , P1762 , P1775 , P179B , P189C , P2544 , P308D , P30B4 , P30B5 , P30BC , P30BD , P30D5 , P30DE , P3168 , P3169 , or P316B
P14D6	Engine Controls and Fuel - 3.6L (LFY) - DTC C1201 , P1000 , P1001 , P1003 , P1008 , P1009 , P100A , P100E , P103D , P103E , P10B6-P10B9 , P10BF , P10C6-P10C8 , P10F5 , P1100 , P1103 , P117A , P11FF , P1200 , P128C-P128F , P129E , P12A8 , P130F , P135C-P135F , P1436 , P143A , P143B , P1472 , P14A0 , P14B6 , P14BD , P14CD , P14CE , P14D4-P14D6 , P150C , P151A , P151D , P153C , P153D , P155D , P1591 , P15E2 , P15F2 , P15F9 , P15FA , P15FB , P165C , P167F , P16E8 , P16FF , P175F , P1761 , P1762 , P1775 , P179B , P189C , P2544 , P308D , P30B4 , P30B5 , P30BC , P30BD , P30D5 , P30DE , P3168 , P3169 , or P316B
P150C	Engine Controls and Fuel - 2.0L (LTG) - DTC C1201 , P1000 , P1001 , P1003 , P1008 , P1009 , P100A , P100E , P103D , P103E , P10B6-P10B9 , P10BF , P10C6-P10C8 , P10F5 , P1100 , P1103 , P117A , P11FF , P1200 , P128C-P128F , P129E , P12A8 , P130F , P135C-P135F , P1436 , P143A , P143B , P1472 , P14A0 , P14B6 , P14BD , P14CD , P14CE , P14D4-P14D6 , P150C , P151A , P151D , P153C , P153D , P155D , P1591 , P15E2 , P15F2 , P15F9 , P15FA , P15FB , P165C , P167F , P16E8 , P16FF , P175F , P1761 , P1762 , P1775 , P179B , P189C , P2544 , P308D , P30B4 , P30B5 , P30BC , P30BD , P30D5 , P30DE , P3168 , P3169 , or P316B
P150C	Engine Controls and Fuel - 3.6L (LFY) - DTC C1201 , P1000 , P1001 , P1003 , P1008 , P1009 , P100A , P100E , P103D , P103E , P10B6-P10B9 , P10BF , P10C6-P10C8 , P10F5 , P1100 , P1103 , P117A , P11FF , P1200 , P128C-P128F , P129E , P12A8 , P130F , P135C-P135F , P1436 , P143A , P143B , P1472 , P14A0 , P14B6 , P14BD , P14CD , P14CE , P14D4-P14D6 , P150C , P151A , P151D , P153C , P153D , P155D , P1591 , P15E2 , P15F2 , P15F9 , P15FA , P15FB , P165C , P167F , P16E8 , P16FF , P175F , P1761 , P1762 , P1775 , P179B , P189C , P2544 , P308D , P30B4 , P30B5 , P30BC , P30BD , P30D5 , P30DE , P3168 , P3169 , or P316B
P1516	Engine Controls and Fuel - 2.0L (LTG) - DTC P1516 , P2101 , P2119 , or P2176
P1516	Engine Controls and Fuel - 3.6L (LFY) - DTC P1516 , P2101 , P2119 , or P2176
P151A	Engine Controls and Fuel - 2.0L (LTG) - DTC C1201 , P1000 , P1001 , P1003 , P1008 , P1009 , P100A , P100E , P103D , P103E , P10B6-P10B9 , P10BF , P10C6-P10C8 , P10F5 , P1100 , P1103 , P117A , P11FF , P1200 , P128C-P128F , P129E , P12A8 , P130F , P135C-P135F , P1436 , P143A , P143B , P1472 , P14A0 , P14B6 , P14BD , P14CD , P14CE , P14D4-P14D6 , P150C ,

DTC	Diagnostic Procedure
P151D	Engine Controls and Fuel - 3.6L (LFY) - DTC C1201 , P1000 , P1001 , P1003 , P1008 , P1009 , P100A , P100E , P103D , P103E , P10B6-P10B9 , P10BE , P10C6-P10C8 , P10F5 , P1100 , P1103 , P117A , P11FE , P1200 , P128C-P128F , P129E , P12A8 , P130F , P135C-P135F , P1436 , P143A , P143B , P1472 , P14A0 , P14B6 , P14BD , P14CD , P14CE , P14D4-P14D6 , P150C , P151A , P151D , P153C , P153D , P155D , P1591 , P15E2 , P15F2 , P15F9 , P15FA , P15FB , P165C , P167F , P16E8 , P16FE , P175F , P1761 , P1762 , P1775 , P179B , P189C , P2544 , P308D , P30B4 , P30B5 , P30BC , P30BD , P30D5 , P30DE , P3168 , P3169 , or P316B
P151E	Bumpers and Fascias - DTC P059F or P151E
P151F	Bumpers and Fascias - DTC P05AE or P151F
P153C	Engine Controls and Fuel - 2.0L (LTG) - DTC C1201 , P1000 , P1001 , P1003 , P1008 , P1009 , P100A , P100E , P103D , P103E , P10B6-P10B9 , P10BE , P10C6-P10C8 , P10F5 , P1100 , P1103 , P117A , P11FE , P1200 , P128C-P128F , P129E , P12A8 , P130F , P135C-P135F , P1436 , P143A , P143B , P1472 , P14A0 , P14B6 , P14BD , P14CD , P14CE , P14D4-P14D6 , P150C , P151A , P151D , P153C , P153D , P155D , P1591 , P15E2 , P15F2 , P15F9 , P15FA , P15FB , P165C , P167F , P16E8 , P16FE , P175F , P1761 , P1762 , P1775 , P179B , P189C , P2544 , P308D , P30B4 , P30B5 , P30BC , P30BD , P30D5 , P30DE , P3168 , P3169 , or P316B
P153C	Engine Controls and Fuel - 3.6L (LFY) - DTC C1201 , P1000 , P1001 , P1003 , P1008 , P1009 , P100A , P100E , P103D , P103E , P10B6-P10B9 , P10BE , P10C6-P10C8 , P10F5 , P1100 , P1103 , P117A , P11FE , P1200 , P128C-P128F , P129E , P12A8 , P130F , P135C-P135F , P1436 , P143A , P143B , P1472 , P14A0 , P14B6 , P14BD , P14CD , P14CE , P14D4-P14D6 , P150C , P151A , P151D , P153C , P153D , P155D , P1591 , P15E2 , P15F2 , P15F9 , P15FA , P15FB , P165C , P167F , P16E8 , P16FE , P175F , P1761 , P1762 , P1775 , P179B , P189C , P2544 , P308D , P30B4 , P30B5 , P30BC , P30BD , P30D5 , P30DE , P3168 , P3169 , or P316B
P153D	Engine Controls and Fuel - 2.0L (LTG) - DTC C1201 , P1000 , P1001 , P1003 , P1008 , P1009 , P100A , P100E , P103D , P103E , P10B6-P10B9 , P10BE , P10C6-P10C8 , P10F5 , P1100 , P1103 , P117A , P11FE , P1200 , P128C-P128F , P129E , P12A8 , P130F , P135C-P135F , P1436 , P143A , P143B , P1472 , P14A0 , P14B6 , P14BD , P14CD , P14CE , P14D4-P14D6 , P150C , P151A , P151D , P153C , P153D , P155D , P1591 , P15E2 , P15F2 , P15F9 , P15FA , P15FB , P165C , P167F , P16E8 , P16FE , P175F , P1761 , P1762 , P1775 , P179B , P189C , P2544 , P308D , P30B4 , P30B5 , P30BC , P30BD , P30D5 , P30DE , P3168 , P3169 , or P316B
P153D	Engine Controls and Fuel - 3.6L (LFY) - DTC C1201 , P1000 , P1001 , P1003 , P1008 , P1009 , P100A , P100E , P103D , P103E , P10B6-P10B9 , P10BE , P10C6-P10C8 , P10F5 , P1100 , P1103 , P117A , P11FE , P1200 , P128C-P128F , P129E , P12A8 , P130F , P135C-P135F , P1436 , P143A , P143B , P1472 , P14A0 , P14B6 , P14BD , P14CD , P14CE , P14D4-P14D6 , P150C , P151A , P151D , P153C , P153D , P155D , P1591 , P15E2 , P15F2 , P15F9 , P15FA , P15FB , P165C , P167F , P16E8 , P16FE , P175F , P1761 , P1762 , P1775 , P179B , P189C , P2544 , P308D , P30B4 , P30B5 , P30BC , P30BD , P30D5 , P30DE , P3168 , P3169 , or P316B
P155A	Cruise Control - Cruise Control Malfunction - DTC B3794 , P0564 , P0565 , P0567 , P0568 , P056C , P0580 , P0581 , P155A-P155C , or P162C
P155B	Cruise Control - Cruise Control Malfunction - DTC B3794 , P0564 , P0565 , P0567 , P0568 , P056C , P0580 , P0581 , P155A-P155C , or P162C
P155C	Cruise Control - Cruise Control Malfunction - DTC B3794 , P0564 , P0565 , P0567 , P0568 , P056C , P0580 , P0581 , P155A-P155C , or P162C
P155D	Engine Controls and Fuel - 2.0L (LTG) - DTC C1201 , P1000 , P1001 , P1003 , P1008 , P1009 , P100A , P100E , P103D , P103E , P10B6-P10B9 , P10BE , P10C6-P10C8 , P10F5 , P1100 , P1103 , P117A , P11FE , P1200 , P128C-P128F , P129E , P12A8 , P130F , P135C-P135F , P1436 , P143A , P143B , P1472 , P14A0 , P14B6 , P14BD , P14CD , P14CE , P14D4-P14D6 , P150C , P151A , P151D , P153C , P153D , P155D , P1591 , P15E2 , P15F2 , P15F9 , P15FA , P15FB , P165C , P167F , P16E8 , P16FE , P175F , P1761 , P1762 , P1775 , P179B , P189C , P2544 , P308D , P30B4 , P30B5 , P30BC , P30BD , P30D5 , P30DE , P3168 , P3169 , or P316B

DTC	Diagnostic Procedure
P155D	Engine Controls and Fuel - 3.6L (LFY) - DTC C1201 , P1000 , P1001 , P1003 , P1008 , P1009 , P100A , P100E , P103D , P103E , P10B6-P10B9 , P10BF , P10C6-P10C8 , P10F5 , P1100 , P1103 , P117A , P11FF , P1200 , P128C-P128F , P129E , P12A8 , P130F , P135C-P135F , P1436 , P143A , P143B , P1472 , P14A0 , P14B6 , P14BD , P14CD , P14CE , P14D4-P14D6 , P150C , P151A , P151D , P153C , P153D , P155D , P1591 , P15E2 , P15F2 , P15F9 , P15FA , P15FB , P165C , P167F , P16E8 , P16FF , P175F , P1761 , P1762 , P1775 , P179B , P189C , P2544 , P308D , P30B4 , P30B5 , P30BC , P30BD , P30D5 , P30DE , P3168 , P3169 , or P316B
P155E	12 V Starting and Charging - DTC P155E , P155E , or P156E
P155F	12 V Starting and Charging - DTC P155E , P155E , or P156E
P156D	12 V Starting and Charging - DTC P156D
P156E	12 V Starting and Charging - DTC P155E , P155E , or P156E
P158A	Cruise Control - DTC P158A
P1591	Engine Controls and Fuel - 2.0L (LTG) - DTC C1201 , P1000 , P1001 , P1003 , P1008 , P1009 , P100A , P100E , P103D , P103E , P10B6-P10B9 , P10BF , P10C6-P10C8 , P10F5 , P1100 , P1103 , P117A , P11FF , P1200 , P128C-P128F , P129E , P12A8 , P130F , P135C-P135F , P1436 , P143A , P143B , P1472 , P14A0 , P14B6 , P14BD , P14CD , P14CE , P14D4-P14D6 , P150C , P151A , P151D , P153C , P153D , P155D , P1591 , P15E2 , P15F2 , P15F9 , P15FA , P15FB , P165C , P167F , P16E8 , P16FF , P175F , P1761 , P1762 , P1775 , P179B , P189C , P2544 , P308D , P30B4 , P30B5 , P30BC , P30BD , P30D5 , P30DE , P3168 , P3169 , or P316B
P1591	Engine Controls and Fuel - 3.6L (LFY) - DTC C1201 , P1000 , P1001 , P1003 , P1008 , P1009 , P100A , P100E , P103D , P103E , P10B6-P10B9 , P10BF , P10C6-P10C8 , P10F5 , P1100 , P1103 , P117A , P11FF , P1200 , P128C-P128F , P129E , P12A8 , P130F , P135C-P135F , P1436 , P143A , P143B , P1472 , P14A0 , P14B6 , P14BD , P14CD , P14CE , P14D4-P14D6 , P150C , P151A , P151D , P153C , P153D , P155D , P1591 , P15E2 , P15F2 , P15F9 , P15FA , P15FB , P165C , P167F , P16E8 , P16FF , P175F , P1761 , P1762 , P1775 , P179B , P189C , P2544 , P308D , P30B4 , P30B5 , P30BC , P30BD , P30D5 , P30DE , P3168 , P3169 , or P316B
P159F	Secondary and Configurable Customer Controls - DTC P159F , P15A0 , or P15A1
P159F	Engine Controls and Fuel - 3.6L (LFY) - DTC P159F or P15A0
P15A0	Secondary and Configurable Customer Controls - DTC P159F , P15A0 , or P15A1
P15A0	Engine Controls and Fuel - 3.6L (LFY) - DTC P159F or P15A0
P15A1	Engine Controls and Fuel - 3.6L (LFY) - DTC P15A1
P15A1	Secondary and Configurable Customer Controls - DTC P159F , P15A0 , or P15A1
P15AE	12 V Starting and Charging - DTC B1325 , B1327 , B1328 , B1330 , B1390 , B1395 , B1400 , B1410 , B1415 , B1424 , B1425 , B1439 , B1517 , C0800 , C0805 , C0870 , C0880 , C0895 , C0899 , C0900 , C1300 , P0560-P0563 , P0611 , P1002 , P129B , P129C , P1465 , P1466 , P15AE , P15AF , P17B0-P17B2 , P17DD-P17DF , P1A0C , P1A0D , P1E19 , P1E1A , or U2800
P15AF	12 V Starting and Charging - DTC B1325 , B1327 , B1328 , B1330 , B1390 , B1395 , B1400 , B1410 , B1415 , B1424 , B1425 , B1439 , B1517 , C0800 , C0805 , C0870 , C0880 , C0895 , C0899 , C0900 , C1300 , P0560-P0563 , P0611 , P1002 , P129B , P129C , P1465 , P1466 , P15AE , P15AF , P17B0-P17B2 , P17DD-P17DF , P1A0C , P1A0D , P1E19 , P1E1A , or U2800
P15E2	Engine Controls and Fuel - 2.0L (LTG) - DTC C1201 , P1000 , P1001 , P1003 , P1008 , P1009 , P100A , P100E , P103D , P103E , P10B6-P10B9 , P10BF , P10C6-P10C8 , P10F5 , P1100 , P1103 , P117A , P11FF , P1200 , P128C-P128F , P129E , P12A8 , P130F , P135C-P135F , P1436 , P143A , P143B , P1472 , P14A0 , P14B6 , P14BD , P14CD , P14CE , P14D4-P14D6 , P150C , P151A , P151D , P153C , P153D , P155D , P1591 , P15E2 , P15F2 , P15F9 , P15FA , P15FB , P165C , P167F , P16E8 , P16FF , P175F , P1761 , P1762 , P1775 , P179B , P189C , P2544 , P308D , P30B4 , P30B5 , P30BC , P30BD , P30D5 , P30DE , P3168 , P3169 , or P316B

DTC	Diagnostic Procedure
P15E2	Engine Controls and Fuel - 3.6L (LFY) - <u>DTC C1201, P1000, P1001, P1003, P1008, P1009, P100A, P100E, P103D, P103E, P10B6-P10B9, P10BF, P10C6-P10C8, P10F5, P1100, P1103, P117A, P11FF, P1200, P128C-P128F, P129E, P12A8, P130F, P135C-P135F, P1436, P143A, P143B, P1472, P14A0, P14B6, P14BD, P14CD, P14CE, P14D4-P14D6, P150C, P151A, P151D, P153C, P153D, P155D, P1591, P15E2, P15F2, P15F9, P15FA, P15FB, P165C, P167F, P16E8, P16FF, P175F, P1761, P1762, P1775, P179B, P189C, P2544, P308D, P30B4, P30B5, P30BC, P30BD, P30D5, P30DE, P3168, P3169, or P316B</u>
P15F2	Engine Controls and Fuel - 2.0L (LTG) - <u>DTC C1201, P1000, P1001, P1003, P1008, P1009, P100A, P100E, P103D, P103E, P10B6-P10B9, P10BF, P10C6-P10C8, P10F5, P1100, P1103, P117A, P11FF, P1200, P128C-P128F, P129E, P12A8, P130F, P135C-P135F, P1436, P143A, P143B, P1472, P14A0, P14B6, P14BD, P14CD, P14CE, P14D4-P14D6, P150C, P151A, P151D, P153C, P153D, P155D, P1591, P15E2, P15F2, P15F9, P15FA, P15FB, P165C, P167F, P16E8, P16FF, P175F, P1761, P1762, P1775, P179B, P189C, P2544, P308D, P30B4, P30B5, P30BC, P30BD, P30D5, P30DE, P3168, P3169, or P316B</u>
P15F2	Engine Controls and Fuel - 3.6L (LFY) - <u>DTC C1201, P1000, P1001, P1003, P1008, P1009, P100A, P100E, P103D, P103E, P10B6-P10B9, P10BF, P10C6-P10C8, P10F5, P1100, P1103, P117A, P11FF, P1200, P128C-P128F, P129E, P12A8, P130F, P135C-P135F, P1436, P143A, P143B, P1472, P14A0, P14B6, P14BD, P14CD, P14CE, P14D4-P14D6, P150C, P151A, P151D, P153C, P153D, P155D, P1591, P15E2, P15F2, P15F9, P15FA, P15FB, P165C, P167F, P16E8, P16FF, P175F, P1761, P1762, P1775, P179B, P189C, P2544, P308D, P30B4, P30B5, P30BC, P30BD, P30D5, P30DE, P3168, P3169, or P316B</u>
P15F6	Driver Assistance Systems - <u>DTC P15F6</u>
P15F7	Driver Assistance Systems - <u>DTC P15F7</u>
P15F8	Antilock Brake System - <u>DTC P15F8</u>
P15F9	Engine Controls and Fuel - 2.0L (LTG) - <u>DTC C1201, P1000, P1001, P1003, P1008, P1009, P100A, P100E, P103D, P103E, P10B6-P10B9, P10BF, P10C6-P10C8, P10F5, P1100, P1103, P117A, P11FF, P1200, P128C-P128F, P129E, P12A8, P130F, P135C-P135F, P1436, P143A, P143B, P1472, P14A0, P14B6, P14BD, P14CD, P14CE, P14D4-P14D6, P150C, P151A, P151D, P153C, P153D, P155D, P1591, P15E2, P15F2, P15F9, P15FA, P15FB, P165C, P167F, P16E8, P16FF, P175F, P1761, P1762, P1775, P179B, P189C, P2544, P308D, P30B4, P30B5, P30BC, P30BD, P30D5, P30DE, P3168, P3169, or P316B</u>
P15F9	Engine Controls and Fuel - 3.6L (LFY) - <u>DTC C1201, P1000, P1001, P1003, P1008, P1009, P100A, P100E, P103D, P103E, P10B6-P10B9, P10BF, P10C6-P10C8, P10F5, P1100, P1103, P117A, P11FF, P1200, P128C-P128F, P129E, P12A8, P130F, P135C-P135F, P1436, P143A, P143B, P1472, P14A0, P14B6, P14BD, P14CD, P14CE, P14D4-P14D6, P150C, P151A, P151D, P153C, P153D, P155D, P1591, P15E2, P15F2, P15F9, P15FA, P15FB, P165C, P167F, P16E8, P16FF, P175F, P1761, P1762, P1775, P179B, P189C, P2544, P308D, P30B4, P30B5, P30BC, P30BD, P30D5, P30DE, P3168, P3169, or P316B</u>
P15FA	Engine Controls and Fuel - 2.0L (LTG) - <u>DTC C1201, P1000, P1001, P1003, P1008, P1009, P100A, P100E, P103D, P103E, P10B6-P10B9, P10BF, P10C6-P10C8, P10F5, P1100, P1103, P117A, P11FF, P1200, P128C-P128F, P129E, P12A8, P130F, P135C-P135F, P1436, P143A, P143B, P1472, P14A0, P14B6, P14BD, P14CD, P14CE, P14D4-P14D6, P150C, P151A, P151D, P153C, P153D, P155D, P1591, P15E2, P15F2, P15F9, P15FA, P15FB, P165C, P167F, P16E8, P16FF, P175F, P1761, P1762, P1775, P179B, P189C, P2544, P308D, P30B4, P30B5, P30BC, P30BD, P30D5, P30DE, P3168, P3169, or P316B</u>
P15FA	Engine Controls and Fuel - 3.6L (LFY) - <u>DTC C1201, P1000, P1001, P1003, P1008, P1009, P100A, P100E, P103D, P103E, P10B6-P10B9, P10BF, P10C6-P10C8, P10F5, P1100, P1103, P117A, P11FF, P1200, P128C-P128F, P129E, P12A8, P130F, P135C-P135F, P1436, P143A, P143B, P1472, P14A0, P14B6, P14BD, P14CD, P14CE, P14D4-P14D6, P150C, P151A, P151D, P153C, P153D, P155D, P1591, P15E2, P15F2, P15F9, P15FA, P15FB, P165C, P167F, P16E8, P16FF, P175F, P1761, P1762, P1775, P179B, P189C, P2544, P308D, P30B4, P30B5, P30BC, P30BD, P30D5, P30DE, P3168, P3169, or P316B</u>

DTC	Diagnostic Procedure
P15FB	Engine Controls and Fuel - 2.0L (LTG) - DTC C1201 , P1000 , P1001 , P1003 , P1008 , P1009 , P100A , P100E , P103D , P103E , P10B6-P10B9 , P10BF , P10C6-P10C8 , P10F5 , P1100 , P1103 , P117A , P11FF , P1200 , P128C-P128F , P129E , P12A8 , P130F , P135C-P135F , P1436 , P143A , P143B , P1472 , P14A0 , P14B6 , P14BD , P14CD , P14CE , P14D4-P14D6 , P150C , P151A , P151D , P153C , P153D , P155D , P1591 , P15E2 , P15F2 , P15F9 , P15FA , P15FB , P165C , P167F , P16E8 , P16FF , P175F , P1761 , P1762 , P1775 , P179B , P189C , P2544 , P308D , P30B4 , P30B5 , P30BC , P30BD , P30D5 , P30DE , P3168 , P3169 , or P316B
P15FB	Engine Controls and Fuel - 3.6L (LFY) - DTC C1201 , P1000 , P1001 , P1003 , P1008 , P1009 , P100A , P100E , P103D , P103E , P10B6-P10B9 , P10BF , P10C6-P10C8 , P10F5 , P1100 , P1103 , P117A , P11FF , P1200 , P128C-P128F , P129E , P12A8 , P130F , P135C-P135F , P1436 , P143A , P143B , P1472 , P14A0 , P14B6 , P14BD , P14CD , P14CE , P14D4-P14D6 , P150C , P151A , P151D , P153C , P153D , P155D , P1591 , P15E2 , P15F2 , P15F9 , P15FA , P15FB , P165C , P167F , P16E8 , P16FF , P175F , P1761 , P1762 , P1775 , P179B , P189C , P2544 , P308D , P30B4 , P30B5 , P30BC , P30BD , P30D5 , P30DE , P3168 , P3169 , or P316B
P15FD	Antilock Brake System - DTC P15FD
P15FF	12 V Starting and Charging - DTC P15FF
P1629	Immobilizer - DTC P1629
P162B	Immobilizer - DTC P162B
P162C	Cruise Control - Cruise Control Malfunction - DTC B3794 , P0564 , P0565 , P0567 , P0568 , P056C , P0580 , P0581 , P155A-P155C , or P162C
P1631	Immobilizer - DTC P1631
P163A	Engine Controls and Fuel - 2.0L (LTG) - DTC P163A
P163A	Engine Controls and Fuel - 3.6L (LFY) - DTC P163A
P1649	Immobilizer - DTC P1649
P165C	Engine Controls and Fuel - 2.0L (LTG) - DTC C1201 , P1000 , P1001 , P1003 , P1008 , P1009 , P100A , P100E , P103D , P103E , P10B6-P10B9 , P10BF , P10C6-P10C8 , P10F5 , P1100 , P1103 , P117A , P11FF , P1200 , P128C-P128F , P129E , P12A8 , P130F , P135C-P135F , P1436 , P143A , P143B , P1472 , P14A0 , P14B6 , P14BD , P14CD , P14CE , P14D4-P14D6 , P150C , P151A , P151D , P153C , P153D , P155D , P1591 , P15E2 , P15F2 , P15F9 , P15FA , P15FB , P165C , P167F , P16E8 , P16FF , P175F , P1761 , P1762 , P1775 , P179B , P189C , P2544 , P308D , P30B4 , P30B5 , P30BC , P30BD , P30D5 , P30DE , P3168 , P3169 , or P316B
P165C	Engine Controls and Fuel - 3.6L (LFY) - DTC C1201 , P1000 , P1001 , P1003 , P1008 , P1009 , P100A , P100E , P103D , P103E , P10B6-P10B9 , P10BF , P10C6-P10C8 , P10F5 , P1100 , P1103 , P117A , P11FF , P1200 , P128C-P128F , P129E , P12A8 , P130F , P135C-P135F , P1436 , P143A , P143B , P1472 , P14A0 , P14B6 , P14BD , P14CD , P14CE , P14D4-P14D6 , P150C , P151A , P151D , P153C , P153D , P155D , P1591 , P15E2 , P15F2 , P15F9 , P15FA , P15FB , P165C , P167F , P16E8 , P16FF , P175F , P1761 , P1762 , P1775 , P179B , P189C , P2544 , P308D , P30B4 , P30B5 , P30BC , P30BD , P30D5 , P30DE , P3168 , P3169 , or P316B
P167F	Engine Controls and Fuel - 2.0L (LTG) - DTC C1201 , P1000 , P1001 , P1003 , P1008 , P1009 , P100A , P100E , P103D , P103E , P10B6-P10B9 , P10BF , P10C6-P10C8 , P10F5 , P1100 , P1103 , P117A , P11FF , P1200 , P128C-P128F , P129E , P12A8 , P130F , P135C-P135F , P1436 , P143A , P143B , P1472 , P14A0 , P14B6 , P14BD , P14CD , P14CE , P14D4-P14D6 , P150C , P151A , P151D , P153C , P153D , P155D , P1591 , P15E2 , P15F2 , P15F9 , P15FA , P15FB , P165C , P167F , P16E8 , P16FF , P175F , P1761 , P1762 , P1775 , P179B , P189C , P2544 , P308D , P30B4 , P30B5 , P30BC , P30BD , P30D5 , P30DE , P3168 , P3169 , or P316B
P167F	Engine Controls and Fuel - 3.6L (LFY) - DTC C1201 , P1000 , P1001 , P1003 , P1008 , P1009 , P100A , P100E , P103D , P103E , P10B6-P10B9 , P10BF , P10C6-P10C8 , P10F5 , P1100 , P1103 , P117A , P11FF , P1200 , P128C-P128F , P129E , P12A8 , P130F , P135C-P135F , P1436 , P143A , P143B , P1472 , P14A0 , P14B6 , P14BD , P14CD , P14CE , P14D4-P14D6 , P150C , P151A , P151D , P153C , P153D , P155D , P1591 , P15E2 , P15F2 , P15F9 , P15FA , P15FB , P165C , P167F , P16E8 , P16FF , P175F , P1761 , P1762 , P1775 , P179B , P189C , P2544 , P308D , P30B4 , P30B5 , P30BC , P30BD , P30D5 , P30DE , P3168 , P3169 , or P316B

DTC	Diagnostic Procedure
P1682	Engine Controls and Fuel - 2.0L (LTG) - <u>DTC P0685-P0687, P0689, P0690, or P1682</u>
P1682	Engine Controls and Fuel - 3.6L (LFY) - <u>DTC P0685-P0687, P0689, P0690, or P1682</u>
P16A0	Engine Controls and Fuel - 2.0L (LTG) - <u>DTC P0121-P0123, P0222, P0223, P16A0-P16A2, or P2135</u>
P16A0	Engine Controls and Fuel - 3.6L (LFY) - <u>DTC P0121-P0123, P0222, P0223, P16A0-P16A2, or P2135</u>
P16A1	Engine Controls and Fuel - 2.0L (LTG) - <u>DTC P0121-P0123, P0222, P0223, P16A0-P16A2, or P2135</u>
P16A1	Engine Controls and Fuel - 3.6L (LFY) - <u>DTC P0121-P0123, P0222, P0223, P16A0-P16A2, or P2135</u>
P16A2	Engine Controls and Fuel - 2.0L (LTG) - <u>DTC P0121-P0123, P0222, P0223, P16A0-P16A2, or P2135</u>
P16A2	Engine Controls and Fuel - 3.6L (LFY) - <u>DTC P0121-P0123, P0222, P0223, P16A0-P16A2, or P2135</u>
P16A7	Engine Controls and Fuel - 2.0L (LTG) - <u>DTC P16A7, P16AF, or P16B3</u>
P16A7	Engine Controls and Fuel - 3.6L (LFY) - <u>DTC P16A7, P16AF, or P16B3</u>
P16AF	Engine Controls and Fuel - 2.0L (LTG) - <u>DTC P16A7, P16AF, or P16B3</u>
P16AF	Engine Controls and Fuel - 3.6L (LFY) - <u>DTC P16A7, P16AF, or P16B3</u>
P16B3	Engine Controls and Fuel - 2.0L (LTG) - <u>DTC P16A7, P16AF, or P16B3</u>
P16B3	Engine Controls and Fuel - 3.6L (LFY) - <u>DTC P16A7, P16AF, or P16B3</u>
P16D4	12 V Starting and Charging - <u>DTC P058A-P058F, P16D4-P16D6, P16DC-P16DF, or P16E1-P16E3</u>
P16D5	12 V Starting and Charging - <u>DTC P058A-P058F, P16D4-P16D6, P16DC-P16DF, or P16E1-P16E3</u>
P16D6	12 V Starting and Charging - <u>DTC P058A-P058F, P16D4-P16D6, P16DC-P16DF, or P16E1-P16E3</u>
P16DC	12 V Starting and Charging - <u>DTC P058A-P058F, P16D4-P16D6, P16DC-P16DF, or P16E1-P16E3</u>
P16DD	12 V Starting and Charging - <u>DTC P058A-P058F, P16D4-P16D6, P16DC-P16DF, or P16E1-P16E3</u>
P16DE	12 V Starting and Charging - <u>DTC P058A-P058F, P16D4-P16D6, P16DC-P16DF, or P16E1-P16E3</u>
P16DF	12 V Starting and Charging - <u>DTC P058A-P058F, P16D4-P16D6, P16DC-P16DF, or P16E1-P16E3</u>
P16E1	12 V Starting and Charging - <u>DTC P058A-P058F, P16D4-P16D6, P16DC-P16DF, or P16E1-P16E3</u>
P16E2	12 V Starting and Charging - <u>DTC P058A-P058F, P16D4-P16D6, P16DC-P16DF, or P16E1-P16E3</u>
P16E3	12 V Starting and Charging - <u>DTC P058A-P058F, P16D4-P16D6, P16DC-P16DF, or P16E1-P16E3</u>
P16E4	Engine Controls and Fuel - 2.0L (LTG) - <u>DTC P127C, P128A, P128B, P16E4, or P16E5</u>
P16E4	Engine Controls and Fuel - 3.6L (LFY) - <u>DTC P0182, P0183, P0187, P0188, P0191, P0192, P111F, P126E, P126F, P127C, P128A, P128B, P16E4, or P16E5 (LFY)</u>
P16E5	Engine Controls and Fuel - 2.0L (LTG) - <u>DTC P127C, P128A, P128B, P16E4, or P16E5</u>
P16E5	Engine Controls and Fuel - 3.6L (LFY) - <u>DTC P0182, P0183, P0187, P0188, P0191, P0192, P111F, P126E, P126F, P127C, P128A, P128B, P16E4, or P16E5 (LFY)</u>

DTC	Diagnostic Procedure
P16E8	Engine Controls and Fuel - 2.0L (LTG) - DTC C1201 , P1000 , P1001 , P1003 , P1008 , P1009 , P100A , P100E , P103D , P103E , P10B6-P10B9 , P10BF , P10C6-P10C8 , P10F5 , P1100 , P1103 , P117A , P11FF , P1200 , P128C-P128F , P129E , P12A8 , P130F , P135C-P135F , P1436 , P143A , P143B , P1472 , P14A0 , P14B6 , P14BD , P14CD , P14CE , P14D4-P14D6 , P150C , P151A , P151D , P153C , P153D , P155D , P1591 , P15E2 , P15F2 , P15F9 , P15FA , P15FB , P165C , P167F , P16E8 , P16FF , P175F , P1761 , P1762 , P1775 , P179B , P189C , P2544 , P308D , P30B4 , P30B5 , P30BC , P30BD , P30D5 , P30DE , P3168 , P3169 , or P316B
P16E8	Engine Controls and Fuel - 3.6L (LFY) - DTC C1201 , P1000 , P1001 , P1003 , P1008 , P1009 , P100A , P100E , P103D , P103E , P10B6-P10B9 , P10BF , P10C6-P10C8 , P10F5 , P1100 , P1103 , P117A , P11FF , P1200 , P128C-P128F , P129E , P12A8 , P130F , P135C-P135F , P1436 , P143A , P143B , P1472 , P14A0 , P14B6 , P14BD , P14CD , P14CE , P14D4-P14D6 , P150C , P151A , P151D , P153C , P153D , P155D , P1591 , P15E2 , P15F2 , P15F9 , P15FA , P15FB , P165C , P167F , P16E8 , P16FF , P175F , P1761 , P1762 , P1775 , P179B , P189C , P2544 , P308D , P30B4 , P30B5 , P30BC , P30BD , P30D5 , P30DE , P3168 , P3169 , or P316B
P16E9	Data Communications - DTC P0601-P0607 , P060A-P060C , P0610 , P062F , P16E9-P16F3 , P262B , or P30D6-P30DD
P16F0	Data Communications - DTC P0601-P0607 , P060A-P060C , P0610 , P062F , P16E9-P16F3 , P262B , or P30D6-P30DD
P16F3	Automatic Transmission - 9T65 (M3V) - DTC P0601-P0604 , P0606 , P062F , P16F3 , or P16FB
P16F3	Engine Controls and Fuel - 3.6L (LFY) - DTC P0601-P0604 , P0606 , P062B , P062F , P0630 , P16F3 , or P262B
P16F3	Engine Controls and Fuel - 2.0L (LTG) - DTC P0601-P0604 , P0606 , P062B , P062F , P0630 , P064D , P16F3 , or P262B
P16FB	Automatic Transmission - 9T65 (M3V) - DTC P0601-P0604 , P0606 , P062F , P16F3 , or P16FB
P16FF	Engine Controls and Fuel - 2.0L (LTG) - DTC C1201 , P1000 , P1001 , P1003 , P1008 , P1009 , P100A , P100E , P103D , P103E , P10B6-P10B9 , P10BF , P10C6-P10C8 , P10F5 , P1100 , P1103 , P117A , P11FF , P1200 , P128C-P128F , P129E , P12A8 , P130F , P135C-P135F , P1436 , P143A , P143B , P1472 , P14A0 , P14B6 , P14BD , P14CD , P14CE , P14D4-P14D6 , P150C , P151A , P151D , P153C , P153D , P155D , P1591 , P15E2 , P15F2 , P15F9 , P15FA , P15FB , P165C , P167F , P16E8 , P16FF , P175F , P1761 , P1762 , P1775 , P179B , P189C , P2544 , P308D , P30B4 , P30B5 , P30BC , P30BD , P30D5 , P30DE , P3168 , P3169 , or P316B
P16FF	Engine Controls and Fuel - 3.6L (LFY) - DTC C1201 , P1000 , P1001 , P1003 , P1008 , P1009 , P100A , P100E , P103D , P103E , P10B6-P10B9 , P10BF , P10C6-P10C8 , P10F5 , P1100 , P1103 , P117A , P11FF , P1200 , P128C-P128F , P129E , P12A8 , P130F , P135C-P135F , P1436 , P143A , P143B , P1472 , P14A0 , P14B6 , P14BD , P14CD , P14CE , P14D4-P14D6 , P150C , P151A , P151D , P153C , P153D , P155D , P1591 , P15E2 , P15F2 , P15F9 , P15FA , P15FB , P165C , P167F , P16E8 , P16FF , P175F , P1761 , P1762 , P1775 , P179B , P189C , P2544 , P308D , P30B4 , P30B5 , P30BC , P30BD , P30D5 , P30DE , P3168 , P3169 , or P316B
P171A	Automatic Transmission - 9T65 (M3V) - DTC P171A-P171C
P171B	Automatic Transmission - 9T65 (M3V) - DTC P171A-P171C
P171C	Automatic Transmission - 9T65 (M3V) - DTC P171A-P171C
P171D	Automatic Transmission - 9T65 (M3V) - DTC P171D
P175E	Automatic Transmission - 9T65 (M3V) - DTC P175E
P175F	Automatic Transmission - 9T65 (M3V) - DTC P175E
P175F	Engine Controls and Fuel - 2.0L (LTG) - DTC C1201 , P1000 , P1001 , P1003 , P1008 , P1009 , P100A , P100E , P103D , P103E , P10B6-P10B9 , P10BF , P10C6-P10C8 , P10F5 , P1100 , P1103 , P117A , P11FF , P1200 , P128C-P128F , P129E , P12A8 , P130F , P135C-P135F , P1436 , P143A , P143B , P1472 , P14A0 , P14B6 , P14BD , P14CD , P14CE , P14D4-P14D6 , P150C , P151A , P151D , P153C , P153D , P155D , P1591 , P15E2 , P15F2 , P15F9 , P15FA , P15FB , P165C , P167F , P16E8 , P16FF , P175F , P1761 , P1762 , P1775 , P179B , P189C , P2544 , P308D , P30B4 , P30B5 , P30BC , P30BD , P30D5 , P30DE , P3168 , P3169 , or P316B

DTC	Diagnostic Procedure
P175F	Engine Controls and Fuel - 3.6L (LFY) - DTC C1201 , P1000 , P1001 , P1003 , P1008 , P1009 , P100A , P100E , P103D , P103E , P10B6-P10B9 , P10BF , P10C6-P10C8 , P10F5 , P1100 , P1103 , P117A , P11FF , P1200 , P128C-P128F , P129E , P12A8 , P130F , P135C-P135F , P1436 , P143A , P143B , P1472 , P14A0 , P14B6 , P14BD , P14CD , P14CE , P14D4-P14D6 , P150C , P151A , P151D , P153C , P153D , P155D , P1591 , P15E2 , P15F2 , P15F9 , P15FA , P15FB , P165C , P167F , P16E8 , P16FF , P175F , P1761 , P1762 , P1775 , P179B , P189C , P2544 , P308D , P30B4 , P30B5 , P30BC , P30BD , P30D5 , P30DE , P3168 , P3169 , or P316B
P1761	Automatic Transmission - 9T65 (M3V) - DTC P1761
P176B	Automatic Transmission - 9T65 (M3V) - DTC P176B-P176D , P178F , P17C4 , or P17D3
P176C	Automatic Transmission - 9T65 (M3V) - DTC P176B-P176D , P178F , P17C4 , or P17D3
P176D	Automatic Transmission - 9T65 (M3V) - DTC P176B-P176D , P178F , P17C4 , or P17D3
P178F	Automatic Transmission - 9T65 (M3V) - DTC P176B-P176D , P178F , P17C4 , or P17D3
P17B0	12 V Starting and Charging - DTC B1325 , B1327 , B1328 , B1330 , B1390 , B1395 , B1400 , B1410 , B1415 , B1424 , B1425 , B1439 , B1517 , C0800 , C0805 , C0870 , C0880 , C0895 , C0899 , C0900 , C1300 , P0560-P0563 , P0611 , P1002 , P129B , P129C , P1465 , P1466 , P15AE , P15AF , P17B0-P17B2 , P17DD-P17DF , P1A0C , P1A0D , P1E19 , P1E1A , or U2800
P17B1	12 V Starting and Charging - DTC B1325 , B1327 , B1328 , B1330 , B1390 , B1395 , B1400 , B1410 , B1415 , B1424 , B1425 , B1439 , B1517 , C0800 , C0805 , C0870 , C0880 , C0895 , C0899 , C0900 , C1300 , P0560-P0563 , P0611 , P1002 , P129B , P129C , P1465 , P1466 , P15AE , P15AF , P17B0-P17B2 , P17DD-P17DF , P1A0C , P1A0D , P1E19 , P1E1A , or U2800
P17B2	12 V Starting and Charging - DTC B1325 , B1327 , B1328 , B1330 , B1390 , B1395 , B1400 , B1410 , B1415 , B1424 , B1425 , B1439 , B1517 , C0800 , C0805 , C0870 , C0880 , C0895 , C0899 , C0900 , C1300 , P0560-P0563 , P0611 , P1002 , P129B , P129C , P1465 , P1466 , P15AE , P15AF , P17B0-P17B2 , P17DD-P17DF , P1A0C , P1A0D , P1E19 , P1E1A , or U2800
P17C4	Automatic Transmission - 9T65 (M3V) - DTC P176B-P176D , P178F , P17C4 , or P17D3
P17D3	Automatic Transmission - 9T65 (M3V) - DTC P176B-P176D , P178F , P17C4 , or P17D3
P17DD	12 V Starting and Charging - DTC B1325 , B1327 , B1328 , B1330 , B1390 , B1395 , B1400 , B1410 , B1415 , B1424 , B1425 , B1439 , B1517 , C0800 , C0805 , C0870 , C0880 , C0895 , C0899 , C0900 , C1300 , P0560-P0563 , P0611 , P1002 , P129B , P129C , P1465 , P1466 , P15AE , P15AF , P17B0-P17B2 , P17DD-P17DF , P1A0C , P1A0D , P1E19 , P1E1A , or U2800
P17DE	12 V Starting and Charging - DTC B1325 , B1327 , B1328 , B1330 , B1390 , B1395 , B1400 , B1410 , B1415 , B1424 , B1425 , B1439 , B1517 , C0800 , C0805 , C0870 , C0880 , C0895 , C0899 , C0900 , C1300 , P0560-P0563 , P0611 , P1002 , P129B , P129C , P1465 , P1466 , P15AE , P15AF , P17B0-P17B2 , P17DD-P17DF , P1A0C , P1A0D , P1E19 , P1E1A , or U2800
P17DF	12 V Starting and Charging - DTC B1325 , B1327 , B1328 , B1330 , B1390 , B1395 , B1400 , B1410 , B1415 , B1424 , B1425 , B1439 , B1517 , C0800 , C0805 , C0870 , C0880 , C0895 , C0899 , C0900 , C1300 , P0560-P0563 , P0611 , P1002 , P129B , P129C , P1465 , P1466 , P15AE , P15AF , P17B0-P17B2 , P17DD-P17DF , P1A0C , P1A0D , P1E19 , P1E1A , or U2800
P188B	Automatic Transmission - 9T65 (M3V) - DTC P188B
P18CB	Parking Assistance Systems - DTC P18CB
P1A0C	12 V Starting and Charging - DTC B1325 , B1327 , B1328 , B1330 , B1390 , B1395 , B1400 , B1410 , B1415 , B1424 , B1425 , B1439 , B1517 , C0800 , C0805 , C0870 , C0880 , C0895 , C0899 , C0900 , C1300 , P0560-P0563 , P0611 , P1002 , P129B , P129C , P1465 , P1466 , P15AE , P15AF , P17B0-P17B2 , P17DD-P17DF , P1A0C , P1A0D , P1E19 , P1E1A , or U2800

DTC	Diagnostic Procedure
P1A0D	12 V Starting and Charging - DTC B1325, B1327, B1328, B1330, B1390, B1395, B1400, B1410, B1415, B1424, B1425, B1439, B1517, C0800, C0805, C0870, C0880, C0895, C0899, C0900, C1300, P0560-P0563, P0611, P1002, P129B, P129C, P1465, P1466, P15AE, P15AF, P17B0-P17B2, P17DD-P17DF, P1A0C, P1A0D, P1E19, P1E1A, or U2800
P1E00	Engine Controls and Fuel - 2.0L (LTG) - DTC P00FF, P069E, P06EC, P0700, P0800, P0AC4, P1700, P1E00, P2561, P25A2, P25AF, P25C9, P26C8, or P26C9
P1E00	Engine Controls and Fuel - 3.6L (LFY) - DTC P00FF, P069E, P06EC, P0700, P0800, P0AC4, P1700, P1E00, P2561, P25A2, P25AF, P25C9, P26C8, or P26C9
P1E19	12 V Starting and Charging - DTC B1325, B1327, B1328, B1330, B1390, B1395, B1400, B1410, B1415, B1424, B1425, B1439, B1517, C0800, C0805, C0870, C0880, C0895, C0899, C0900, C1300, P0560-P0563, P0611, P1002, P129B, P129C, P1465, P1466, P15AE, P15AF, P17B0-P17B2, P17DD-P17DF, P1A0C, P1A0D, P1E19, P1E1A, or U2800
P1E1A	12 V Starting and Charging - DTC B1325, B1327, B1328, B1330, B1390, B1395, B1400, B1410, B1415, B1424, B1425, B1439, B1517, C0800, C0805, C0870, C0880, C0895, C0899, C0900, C1300, P0560-P0563, P0611, P1002, P129B, P129C, P1465, P1466, P15AE, P15AF, P17B0-P17B2, P17DD-P17DF, P1A0C, P1A0D, P1E19, P1E1A, or U2800
P2066	Displays and Gauges - DTC P0461-P0464, P2066, P2067, or P2068 (with F48)
P2067	Displays and Gauges - DTC P0461-P0464, P2066, P2067, or P2068 (with F48)
P2068	Displays and Gauges - DTC P0461-P0464, P2066, P2067, or P2068 (with F48)
P2088	Engine Controls and Fuel - 2.0L (LTG) - DTC P0010, P0013, or P2088-P2091
P2088	Engine Controls and Fuel - 3.6L (LFY) - DTC P0010, P0011, P0013, P0014, P0020, P0021, P0023, P0024, or P2088-P2095
P2089	Engine Controls and Fuel - 2.0L (LTG) - DTC P0010, P0013, or P2088-P2091
P2089	Engine Controls and Fuel - 3.6L (LFY) - DTC P0010, P0011, P0013, P0014, P0020, P0021, P0023, P0024, or P2088-P2095
P2090	Engine Controls and Fuel - 2.0L (LTG) - DTC P0010, P0013, or P2088-P2091
P2090	Engine Controls and Fuel - 3.6L (LFY) - DTC P0010, P0011, P0013, P0014, P0020, P0021, P0023, P0024, or P2088-P2095
P2091	Engine Controls and Fuel - 2.0L (LTG) - DTC P0010, P0013, or P2088-P2091
P2091	Engine Controls and Fuel - 3.6L (LFY) - DTC P0010, P0011, P0013, P0014, P0020, P0021, P0023, P0024, or P2088-P2095
P2092	Engine Controls and Fuel - 3.6L (LFY) - DTC P0010, P0011, P0013, P0014, P0020, P0021, P0023, P0024, or P2088-P2095
P2093	Engine Controls and Fuel - 3.6L (LFY) - DTC P0010, P0011, P0013, P0014, P0020, P0021, P0023, P0024, or P2088-P2095
P2094	Engine Controls and Fuel - 3.6L (LFY) - DTC P0010, P0011, P0013, P0014, P0020, P0021, P0023, P0024, or P2088-P2095
P2095	Engine Controls and Fuel - 3.6L (LFY) - DTC P0010, P0011, P0013, P0014, P0020, P0021, P0023, P0024, or P2088-P2095
P2096	Engine Controls and Fuel - 2.0L (LTG) - DTC P2096 or P2097
P2096	Engine Controls and Fuel - 3.6L (LFY) - DTC P2096 or P2098
P2097	Engine Controls and Fuel - 3.6L (LFY) - DTC P2097 or P2099
P2097	Engine Controls and Fuel - 2.0L (LTG) - DTC P2096 or P2097
P2098	Engine Controls and Fuel - 3.6L (LFY) - DTC P2096 or P2098
P2099	Engine Controls and Fuel - 3.6L (LFY) - DTC P2097 or P2099
P2101	Engine Controls and Fuel - 2.0L (LTG) - DTC P1516, P2101, P2119, or P2176
P2101	Engine Controls and Fuel - 3.6L (LFY) - DTC P1516, P2101, P2119, or P2176
P2119	Engine Controls and Fuel - 2.0L (LTG) - DTC P1516, P2101, P2119, or P2176
P2119	Engine Controls and Fuel - 3.6L (LFY) - DTC P1516, P2101, P2119, or P2176
P2122	Engine Controls and Fuel - 2.0L (LTG) - DTC P2122, P2123, P2127, P2128, or P2138

[illegible]

DTC	Diagnostic Procedure
P2157	Engine Controls and Fuel - 3.6L (LFY) - DTC P2147, P2148, P2150, P2151, P2153, P2154, P2156, P2157, P216B, P216C, P216E, or P216F
P2157	Engine Controls and Fuel - 2.0L (LTG) - DTC P0201-P0204, P0261, P0262, P0264, P0265, P0267, P0268, P0270, P0271, P1248, P1249, P124A, P124B, P2147, P2148, P2150, P2151, P2153, P2154, P2156, or P2157
P216B	Engine Controls and Fuel - 3.6L (LFY) - DTC P2147, P2148, P2150, P2151, P2153, P2154, P2156, P2157, P216B, P216C, P216E, or P216F
P216C	Engine Controls and Fuel - 3.6L (LFY) - DTC P2147, P2148, P2150, P2151, P2153, P2154, P2156, P2157, P216B, P216C, P216E, or P216F
P216E	Engine Controls and Fuel - 3.6L (LFY) - DTC P2147, P2148, P2150, P2151, P2153, P2154, P2156, P2157, P216B, P216C, P216E, or P216F
P216F	Engine Controls and Fuel - 3.6L (LFY) - DTC P2147, P2148, P2150, P2151, P2153, P2154, P2156, P2157, P216B, P216C, P216E, or P216F
P2176	Engine Controls and Fuel - 2.0L (LTG) - DTC P1516, P2101, P2119, or P2176
P2176	Engine Controls and Fuel - 3.6L (LFY) - DTC P1516, P2101, P2119, or P2176
P2199	Engine Controls and Fuel - 2.0L (LTG) - DTC P2199
P2199	Engine Controls and Fuel - 3.6L (LFY) - DTC P2199
P219A	Engine Controls and Fuel - 2.0L (LTG) - DTC P219A
P219A	Engine Controls and Fuel - 3.6L (LFY) - DTC P219A or P219B
P219B	Engine Controls and Fuel - 3.6L (LFY) - DTC P219A or P219B
P2227	Engine Controls and Fuel - 2.0L (LTG) - DTC P2227-P2230
P2227	Engine Controls and Fuel - 3.6L (LFY) - DTC P2227-P2230
P2228	Engine Controls and Fuel - 2.0L (LTG) - DTC P2227-P2230
P2228	Engine Controls and Fuel - 3.6L (LFY) - DTC P2227-P2230
P2229	Engine Controls and Fuel - 2.0L (LTG) - DTC P2227-P2230
P2229	Engine Controls and Fuel - 3.6L (LFY) - DTC P2227-P2230
P2230	Engine Controls and Fuel - 2.0L (LTG) - DTC P2227-P2230
P2230	Engine Controls and Fuel - 3.6L (LFY) - DTC P2227-P2230
P223C	Engine Controls and Fuel - 2.0L (LTG) - DTC P0131, P0132, P015A, P015B, P223C, or P223E
P223E	Engine Controls and Fuel - 2.0L (LTG) - DTC P0131, P0132, P015A, P015B, P223C, or P223E
P2261	Engine Controls and Fuel - 2.0L (LTG) - DTC P2261
P2270	Engine Controls and Fuel - 3.6L (LFY) - DTC P0133, P013A-P013F, P014A, P014B, P0153, P015A-P015D, or P2270-P2273
P2270	Engine Controls and Fuel - 2.0L (LTG) - DTC P0137, P0138, P013A, P013B, P013E, P013F, P2270, or P2271
P2271	Engine Controls and Fuel - 3.6L (LFY) - DTC P0133, P013A-P013F, P014A, P014B, P0153, P015A-P015D, or P2270-P2273
P2271	Engine Controls and Fuel - 2.0L (LTG) - DTC P0137, P0138, P013A, P013B, P013E, P013F, P2270, or P2271
P2272	Engine Controls and Fuel - 3.6L (LFY) - DTC P0133, P013A-P013F, P014A, P014B, P0153, P015A-P015D, or P2270-P2273
P2273	Engine Controls and Fuel - 3.6L (LFY) - DTC P0133, P013A-P013F, P014A, P014B, P0153, P015A-P015D, or P2270-P2273
P228C	Engine Controls and Fuel - 2.0L (LTG) - DTC P0089, P00C6, P228C, P228D, or P2C1E-P2C20
P228C	Engine Controls and Fuel - 3.6L (LFY) - DTC P0089, P00C6, P228C, P228D, or P2C1E-P2C20
P228D	Engine Controls and Fuel - 2.0L (LTG) - DTC P0089, P00C6, P228C, P228D, or P2C1E-P2C20
P228D	Engine Controls and Fuel - 3.6L (LFY) - DTC P0089, P00C6, P228C, P228D, or P2C1E-P2C20
P2300	Engine Controls and Fuel - 2.0L (LTG) - DTC P0351-P0354, P2300, P2301, P2303, P2304, P2306, P2307, P2309, or P2310

DTC	Diagnostic Procedure
P2300	Engine Controls and Fuel - 3.6L (LFY) - DTC P0351-P0356 , P2300 , P2301 , P2303 , P2304 , P2306 , P2307 , P2309 , P2310 , P2312 , P2313 , P2315 , or P2316
P2301	Engine Controls and Fuel - 2.0L (LTG) - DTC P0351-P0354 , P2300 , P2301 , P2303 , P2304 , P2306 , P2307 , P2309 , or P2310
P2301	Engine Controls and Fuel - 3.6L (LFY) - DTC P0351-P0356 , P2300 , P2301 , P2303 , P2304 , P2306 , P2307 , P2309 , P2310 , P2312 , P2313 , P2315 , or P2316
P2303	Engine Controls and Fuel - 2.0L (LTG) - DTC P0351-P0354 , P2300 , P2301 , P2303 , P2304 , P2306 , P2307 , P2309 , or P2310
P2303	Engine Controls and Fuel - 3.6L (LFY) - DTC P0351-P0356 , P2300 , P2301 , P2303 , P2304 , P2306 , P2307 , P2309 , P2310 , P2312 , P2313 , P2315 , or P2316
P2304	Engine Controls and Fuel - 2.0L (LTG) - DTC P0351-P0354 , P2300 , P2301 , P2303 , P2304 , P2306 , P2307 , P2309 , or P2310
P2304	Engine Controls and Fuel - 3.6L (LFY) - DTC P0351-P0356 , P2300 , P2301 , P2303 , P2304 , P2306 , P2307 , P2309 , P2310 , P2312 , P2313 , P2315 , or P2316
P2306	Engine Controls and Fuel - 2.0L (LTG) - DTC P0351-P0354 , P2300 , P2301 , P2303 , P2304 , P2306 , P2307 , P2309 , or P2310
P2306	Engine Controls and Fuel - 3.6L (LFY) - DTC P0351-P0356 , P2300 , P2301 , P2303 , P2304 , P2306 , P2307 , P2309 , P2310 , P2312 , P2313 , P2315 , or P2316
P2307	Engine Controls and Fuel - 2.0L (LTG) - DTC P0351-P0354 , P2300 , P2301 , P2303 , P2304 , P2306 , P2307 , P2309 , or P2310
P2307	Engine Controls and Fuel - 3.6L (LFY) - DTC P0351-P0356 , P2300 , P2301 , P2303 , P2304 , P2306 , P2307 , P2309 , P2310 , P2312 , P2313 , P2315 , or P2316
P2309	Engine Controls and Fuel - 2.0L (LTG) - DTC P0351-P0354 , P2300 , P2301 , P2303 , P2304 , P2306 , P2307 , P2309 , or P2310
P2309	Engine Controls and Fuel - 3.6L (LFY) - DTC P0351-P0356 , P2300 , P2301 , P2303 , P2304 , P2306 , P2307 , P2309 , P2310 , P2312 , P2313 , P2315 , or P2316
P2310	Engine Controls and Fuel - 2.0L (LTG) - DTC P0351-P0354 , P2300 , P2301 , P2303 , P2304 , P2306 , P2307 , P2309 , or P2310
P2310	Engine Controls and Fuel - 3.6L (LFY) - DTC P0351-P0356 , P2300 , P2301 , P2303 , P2304 , P2306 , P2307 , P2309 , P2310 , P2312 , P2313 , P2315 , or P2316
P2312	Engine Controls and Fuel - 3.6L (LFY) - DTC P0351-P0356 , P2300 , P2301 , P2303 , P2304 , P2306 , P2307 , P2309 , P2310 , P2312 , P2313 , P2315 , or P2316
P2313	Engine Controls and Fuel - 3.6L (LFY) - DTC P0351-P0356 , P2300 , P2301 , P2303 , P2304 , P2306 , P2307 , P2309 , P2310 , P2312 , P2313 , P2315 , or P2316
P2315	Engine Controls and Fuel - 3.6L (LFY) - DTC P0351-P0356 , P2300 , P2301 , P2303 , P2304 , P2306 , P2307 , P2309 , P2310 , P2312 , P2313 , P2315 , or P2316
P2316	Engine Controls and Fuel - 3.6L (LFY) - DTC P0351-P0356 , P2300 , P2301 , P2303 , P2304 , P2306 , P2307 , P2309 , P2310 , P2312 , P2313 , P2315 , or P2316
P250A	Displays and Gauges - DTC P250A
P2534	Wiring Systems and Power Management - DTC P2534 or P2535
P2535	Wiring Systems and Power Management - DTC P2534 or P2535
P2537	Wiring Systems and Power Management - DTC P2537
P2544	Engine Controls and Fuel - 2.0L (LTG) - DTC C1201 , P1000 , P1001 , P1003 , P1008 , P1009 , P100A , P100E , P103D , P103E , P10B6-P10B9 , P10BF , P10C6-P10C8 , P10F5 , P1100 , P1103 , P117A , P11FE , P1200 , P128C-P128F , P129E , P12A8 , P130F , P135C-P135F , P1436 , P143A , P143B , P1472 , P14A0 , P14B6 , P14BD , P14CD , P14CE , P14D4-P14D6 , P150C , P151A , P151D , P153C , P153D , P155D , P1591 , P15E2 , P15F2 , P15F9 , P15FA , P15FB , P165C , P167F , P16E8 , P16FE , P175F , P1761 , P1762 , P1775 , P179B , P189C , P2544 , P308D , P30B4 , P30B5 , P30BC , P30BD , P30D5 , P30DE , P3168 , P3169 , or P316B

DTC	Diagnostic Procedure
P2544	Engine Controls and Fuel - 3.6L (LFY) - DTC C1201 , P1000 , P1001 , P1003 , P1008 , P1009 , P100A , P100E , P103D , P103E , P10B6-P10B9 , P10BE , P10C6-P10C8 , P10F5 , P1100 , P1103 , P117A , P11FE , P1200 , P128C-P128F , P129E , P12A8 , P130F , P135C-P135F , P1436 , P143A , P143B , P1472 , P14A0 , P14B6 , P14BD , P14CD , P14CE , P14D4-P14D6 , P150C , P151A , P151D , P153C , P153D , P155D , P1591 , P15E2 , P15F2 , P15F9 , P15FA , P15FB , P165C , P167F , P16E8 , P16FE , P175F , P1761 , P1762 , P1775 , P179B , P189C , P2544 , P308D , P30B4 , P30B5 , P30BC , P30BD , P30D5 , P30DE , P3168 , P3169 , or P316B
P2561	Engine Controls and Fuel - 2.0L (LTG) - DTC P00FE , P069E , P06EC , P0700 , P0800 , P0AC4 , P1700 , P1E00 , P2561 , P25A2 , P25AF , P25C9 , P26C8 , or P26C9
P2561	Engine Controls and Fuel - 3.6L (LFY) - DTC P00FE , P069E , P06EC , P0700 , P0800 , P0AC4 , P1700 , P1E00 , P2561 , P25A2 , P25AF , P25C9 , P26C8 , or P26C9
P257D	Bolted Exterior Body Panels and Closures - DTC P257D-P257F
P257E	Bolted Exterior Body Panels and Closures - DTC P257D-P257F
P257F	Bolted Exterior Body Panels and Closures - DTC P257D-P257F
P25A2	Engine Controls and Fuel - 2.0L (LTG) - DTC P00FE , P069E , P06EC , P0700 , P0800 , P0AC4 , P1700 , P1E00 , P2561 , P25A2 , P25AF , P25C9 , P26C8 , or P26C9
P25A2	Engine Controls and Fuel - 3.6L (LFY) - DTC P00FE , P069E , P06EC , P0700 , P0800 , P0AC4 , P1700 , P1E00 , P2561 , P25A2 , P25AF , P25C9 , P26C8 , or P26C9
P25AF	Engine Controls and Fuel - 2.0L (LTG) - DTC P00FE , P069E , P06EC , P0700 , P0800 , P0AC4 , P1700 , P1E00 , P2561 , P25A2 , P25AF , P25C9 , P26C8 , or P26C9
P25AF	Engine Controls and Fuel - 3.6L (LFY) - DTC P00FE , P069E , P06EC , P0700 , P0800 , P0AC4 , P1700 , P1E00 , P2561 , P25A2 , P25AF , P25C9 , P26C8 , or P26C9
P25C9	Engine Controls and Fuel - 2.0L (LTG) - DTC P00FE , P069E , P06EC , P0700 , P0800 , P0AC4 , P1700 , P1E00 , P2561 , P25A2 , P25AF , P25C9 , P26C8 , or P26C9
P25C9	Engine Controls and Fuel - 3.6L (LFY) - DTC P00FE , P069E , P06EC , P0700 , P0800 , P0AC4 , P1700 , P1E00 , P2561 , P25A2 , P25AF , P25C9 , P26C8 , or P26C9
P2618	Engine Controls and Fuel - 2.0L (LTG) - DTC P2618 or P2619
P2618	Engine Controls and Fuel - 3.6L (LFY) - DTC P2618 or P2619
P2619	Engine Controls and Fuel - 2.0L (LTG) - DTC P2618 or P2619
P2619	Engine Controls and Fuel - 3.6L (LFY) - DTC P2618 or P2619
P262B	Data Communications - DTC P0601-P0607 , P060A-P060C , P0610 , P062F , P16E9-P16F3 , P262B , or P30D6-P30DD
P262B	Engine Controls and Fuel - 3.6L (LFY) - DTC P0601-P0604 , P0606 , P062B , P062F , P0630 , P16F3 , or P262B
P262B	Engine Controls and Fuel - 2.0L (LTG) - DTC P0601-P0604 , P0606 , P062B , P062F , P0630 , P064D , P16F3 , or P262B
P2635	Engine Controls and Fuel - 2.0L (LTG) - DTC P2635
P2635	Engine Controls and Fuel - 3.6L (LFY) - DTC P2635
P263A	Engine Controls and Fuel - 2.0L (LTG) - DTC P0650 , P263A , or P263B
P263A	Engine Controls and Fuel - 3.6L (LFY) - DTC P0650 , P263A , or P263B
P263B	Engine Controls and Fuel - 2.0L (LTG) - DTC P0650 , P263A , or P263B
P263B	Engine Controls and Fuel - 3.6L (LFY) - DTC P0650 , P263A , or P263B
P2670	Automatic Transmission - 9T65 (M3V) - DTC P0960 , P0962-P0964 , P0966-P0968 , P0970 , P0971 , P2670 , P2671 , P2718 , P2720 , P2721 , P2812 , P2814 , P2815 , P281B , P281D , or P281E
P2671	Automatic Transmission - 9T65 (M3V) - DTC P0960 , P0962-P0964 , P0966-P0968 , P0970 , P0971 , P2670 , P2671 , P2718 , P2720 , P2721 , P2812 , P2814 , P2815 , P281B , P281D , or P281E
P26C8	Engine Controls and Fuel - 2.0L (LTG) - DTC P00FE , P069E , P06EC , P0700 , P0800 , P0AC4 , P1700 , P1E00 , P2561 , P25A2 , P25AF , P25C9 , P26C8 , or P26C9
P26C8	Engine Controls and Fuel - 3.6L (LFY) - DTC P00FE , P069E , P06EC , P0700 , P0800 , P0AC4 , P1700 , P1E00 , P2561 , P25A2 , P25AF , P25C9 , P26C8 , or P26C9
P26C9	Engine Controls and Fuel - 2.0L (LTG) - DTC P00FE , P069E , P06EC , P0700 , P0800 , P0AC4 , P1700 , P1E00 , P2561 , P25A2 , P25AF , P25C9 , P26C8 , or P26C9

DTC	Diagnostic Procedure
P26C9	Engine Controls and Fuel - 3.6L (LFY) - DTC P00FE , P069E , P06EC , P0700 , P0800 , P0AC4 , P1700 , P1E00 , P2561 , P25A2 , P25AF , P25C9 , P26C8 , or P26C9
P26E4	12 V Starting and Charging - DTC P26E4-P26E6
P26E5	12 V Starting and Charging - DTC P26E4-P26E6
P26E6	12 V Starting and Charging - DTC P26E4-P26E6
P2714	Automatic Transmission - 9T65 (M3V) - DTC P2714 or P2715
P2715	Automatic Transmission - 9T65 (M3V) - DTC P2714 or P2715
P2718	Automatic Transmission - 9T65 (M3V) - DTC P0960 , P0962-P0964 , P0966-P0968 , P0970 , P0971 , P2670 , P2671 , P2718 , P2720 , P2721 , P2812 , P2814 , P2815 , P281B , P281D , or P281E
P2720	Automatic Transmission - 9T65 (M3V) - DTC P0960 , P0962-P0964 , P0966-P0968 , P0970 , P0971 , P2670 , P2671 , P2718 , P2720 , P2721 , P2812 , P2814 , P2815 , P281B , P281D , or P281E
P2721	Automatic Transmission - 9T65 (M3V) - DTC P0960 , P0962-P0964 , P0966-P0968 , P0970 , P0971 , P2670 , P2671 , P2718 , P2720 , P2721 , P2812 , P2814 , P2815 , P281B , P281D , or P281E
P2723	Automatic Transmission - 9T65 (M3V) - DTC P2723 or P2724
P2724	Automatic Transmission - 9T65 (M3V) - DTC P2723 or P2724
P2727	Automatic Transmission - 9T65 (M3V) - DTC P0658 , P0659 , P2727 , P2729 , P2730 , P2736 , P2738 , P2739 , P2826 , P2827 , P282F , or P2830
P2729	Automatic Transmission - 9T65 (M3V) - DTC P0658 , P0659 , P2727 , P2729 , P2730 , P2736 , P2738 , P2739 , P2826 , P2827 , P282F , or P2830
P2730	Automatic Transmission - 9T65 (M3V) - DTC P0658 , P0659 , P2727 , P2729 , P2730 , P2736 , P2738 , P2739 , P2826 , P2827 , P282F , or P2830
P2731	Automatic Transmission - 9T65 (M3V) - DTC P2731-P2733
P2732	Automatic Transmission - 9T65 (M3V) - DTC P2731-P2733
P2733	Automatic Transmission - 9T65 (M3V) - DTC P2731-P2733
P2736	Automatic Transmission - 9T65 (M3V) - DTC P0658 , P0659 , P2727 , P2729 , P2730 , P2736 , P2738 , P2739 , P2826 , P2827 , P282F , or P2830
P2738	Automatic Transmission - 9T65 (M3V) - DTC P0658 , P0659 , P2727 , P2729 , P2730 , P2736 , P2738 , P2739 , P2826 , P2827 , P282F , or P2830
P2739	Automatic Transmission - 9T65 (M3V) - DTC P0658 , P0659 , P2727 , P2729 , P2730 , P2736 , P2738 , P2739 , P2826 , P2827 , P282F , or P2830
P27A7	Automatic Transmission - 9T65 (M3V) - DTC P27A7-P27AE
P27A8	Automatic Transmission - 9T65 (M3V) - DTC P27A7-P27AE
P27A9	Automatic Transmission - 9T65 (M3V) - DTC P27A7-P27AE
P27AA	Automatic Transmission - 9T65 (M3V) - DTC P27A7-P27AE
P27AB	Automatic Transmission - 9T65 (M3V) - DTC P27A7-P27AE
P27AC	Automatic Transmission - 9T65 (M3V) - DTC P27A7-P27AE
P27AD	Automatic Transmission - 9T65 (M3V) - DTC P27A7-P27AE
P27AE	Automatic Transmission - 9T65 (M3V) - DTC P27A7-P27AE
P2802	Automatic Transmission - 9T65 (M3V) - DTC P0707 , P0708 , P2802 , P2803 , or P2805
P2803	Automatic Transmission - 9T65 (M3V) - DTC P0707 , P0708 , P2802 , P2803 , or P2805
P2805	Automatic Transmission - 9T65 (M3V) - DTC P0707 , P0708 , P2802 , P2803 , or P2805
P2812	Automatic Transmission - 9T65 (M3V) - DTC P0960 , P0962-P0964 , P0966-P0968 , P0970 , P0971 , P2670 , P2671 , P2718 , P2720 , P2721 , P2812 , P2814 , P2815 , P281B , P281D , or P281E
P2814	Automatic Transmission - 9T65 (M3V) - DTC P0960 , P0962-P0964 , P0966-P0968 , P0970 , P0971 , P2670 , P2671 , P2718 , P2720 , P2721 , P2812 , P2814 , P2815 , P281B , P281D , or P281E

DTC	Diagnostic Procedure
P2815	Automatic Transmission - 9T65 (M3V) - DTC P0960 , P0962-P0964 , P0966-P0968 , P0970 , P0971 , P2670 , P2671 , P2718 , P2720 , P2721 , P2812 , P2814 , P2815 , P281B , P281D , or P281E
P2817	Automatic Transmission - 9T65 (M3V) - DTC P0741 , P2817 , or P2818
P2818	Automatic Transmission - 9T65 (M3V) - DTC P0741 , P2817 , or P2818
P281B	Automatic Transmission - 9T65 (M3V) - DTC P0960 , P0962-P0964 , P0966-P0968 , P0970 , P0971 , P2670 , P2671 , P2718 , P2720 , P2721 , P2812 , P2814 , P2815 , P281B , P281D , or P281E
P281D	Automatic Transmission - 9T65 (M3V) - DTC P0960 , P0962-P0964 , P0966-P0968 , P0970 , P0971 , P2670 , P2671 , P2718 , P2720 , P2721 , P2812 , P2814 , P2815 , P281B , P281D , or P281E
P281E	Automatic Transmission - 9T65 (M3V) - DTC P0960 , P0962-P0964 , P0966-P0968 , P0970 , P0971 , P2670 , P2671 , P2718 , P2720 , P2721 , P2812 , P2814 , P2815 , P281B , P281D , or P281E
P2820	Automatic Transmission - 9T65 (M3V) - DTC P2820 or P2821
P2821	Automatic Transmission - 9T65 (M3V) - DTC P2820 or P2821
P2826	Automatic Transmission - 9T65 (M3V) - DTC P0658 , P0659 , P2727 , P2729 , P2730 , P2736 , P2738 , P2739 , P2826 , P2827 , P282F , or P2830
P2827	Automatic Transmission - 9T65 (M3V) - DTC P0658 , P0659 , P2727 , P2729 , P2730 , P2736 , P2738 , P2739 , P2826 , P2827 , P282F , or P2830
P282F	Automatic Transmission - 9T65 (M3V) - DTC P0658 , P0659 , P2727 , P2729 , P2730 , P2736 , P2738 , P2739 , P2826 , P2827 , P282F , or P2830
P2830	Automatic Transmission - 9T65 (M3V) - DTC P0658 , P0659 , P2727 , P2729 , P2730 , P2736 , P2738 , P2739 , P2826 , P2827 , P282F , or P2830
P2C1E	Engine Controls and Fuel - 2.0L (LTG) - DTC P0089 , P00C6 , P228C , P228D , or P2C1E-P2C20
P2C1E	Engine Controls and Fuel - 3.6L (LFY) - DTC P0089 , P00C6 , P228C , P228D , or P2C1E-P2C20
P2C1F	Engine Controls and Fuel - 2.0L (LTG) - DTC P0089 , P00C6 , P228C , P228D , or P2C1E-P2C20
P2C1F	Engine Controls and Fuel - 3.6L (LFY) - DTC P0089 , P00C6 , P228C , P228D , or P2C1E-P2C20
P2C20	Engine Controls and Fuel - 2.0L (LTG) - DTC P0089 , P00C6 , P228C , P228D , or P2C1E-P2C20
P2C20	Engine Controls and Fuel - 3.6L (LFY) - DTC P0089 , P00C6 , P228C , P228D , or P2C1E-P2C20
P3051	12 V Starting and Charging - DTC P3051 , P3053 , or P3055
P3052	12 V Starting and Charging - DTC P3052 , P3054 , or P3056
P3053	12 V Starting and Charging - DTC P3051 , P3053 , or P3055
P3054	12 V Starting and Charging - DTC P3052 , P3054 , or P3056
P3055	12 V Starting and Charging - DTC P3051 , P3053 , or P3055
P3056	12 V Starting and Charging - DTC P3052 , P3054 , or P3056
P305B	Wiring Systems and Power Management - DTC P305B or P305C
P305C	Wiring Systems and Power Management - DTC P305B or P305C
P305D	12 V Starting and Charging - DTC P305D or P305E
P305E	12 V Starting and Charging - DTC P305D or P305E
P30B4	Engine Controls and Fuel - 2.0L (LTG) - DTC C1201 , P1000 , P1001 , P1003 , P1008 , P1009 , P100A , P100E , P103D , P103E , P10B6-P10B9 , P10BE , P10C6-P10C8 , P10F5 , P1100 , P1103 , P117A , P11FE , P1200 , P128C-P128E , P129E , P12A8 , P130F , P135C-P135F , P1436 , P143A , P143B , P1472 , P14A0 , P14B6 , P14BD , P14CD , P14CE , P14D4-P14D6 , P150C , P151A , P151D , P153C , P153D , P155D , P1591 , P15E2 , P15F2 , P15F9 , P15FA , P15FB , P165C , P167F , P16E8 , P16FE , P175F , P1761 , P1762 , P1775 , P179B , P189C , P2544 , P308D , P30B4 , P30B5 , P30BC , P30BD , P30D5 , P30DE , P3168 , P3169 , or P316B

DTC	Diagnostic Procedure
P30B4	Engine Controls and Fuel - 3.6L (LFY) - DTC C1201 , P1000 , P1001 , P1003 , P1008 , P1009 , P100A , P100E , P103D , P103E , P10B6-P10B9 , P10BF , P10C6-P10C8 , P10F5 , P1100 , P1103 , P117A , P11FF , P1200 , P128C-P128F , P129E , P12A8 , P130F , P135C-P135F , P1436 , P143A , P143B , P1472 , P14A0 , P14B6 , P14BD , P14CD , P14CE , P14D4-P14D6 , P150C , P151A , P151D , P153C , P153D , P155D , P1591 , P15E2 , P15F2 , P15F9 , P15FA , P15FB , P165C , P167F , P16E8 , P16FF , P175F , P1761 , P1762 , P1775 , P179B , P189C , P2544 , P308D , P30B4 , P30B5 , P30BC , P30BD , P30D5 , P30DE , P3168 , P3169 , or P316B
P30B5	Engine Controls and Fuel - 2.0L (LTG) - DTC C1201 , P1000 , P1001 , P1003 , P1008 , P1009 , P100A , P100E , P103D , P103E , P10B6-P10B9 , P10BF , P10C6-P10C8 , P10F5 , P1100 , P1103 , P117A , P11FF , P1200 , P128C-P128F , P129E , P12A8 , P130F , P135C-P135F , P1436 , P143A , P143B , P1472 , P14A0 , P14B6 , P14BD , P14CD , P14CE , P14D4-P14D6 , P150C , P151A , P151D , P153C , P153D , P155D , P1591 , P15E2 , P15F2 , P15F9 , P15FA , P15FB , P165C , P167F , P16E8 , P16FF , P175F , P1761 , P1762 , P1775 , P179B , P189C , P2544 , P308D , P30B4 , P30B5 , P30BC , P30BD , P30D5 , P30DE , P3168 , P3169 , or P316B
P30B5	Engine Controls and Fuel - 3.6L (LFY) - DTC C1201 , P1000 , P1001 , P1003 , P1008 , P1009 , P100A , P100E , P103D , P103E , P10B6-P10B9 , P10BF , P10C6-P10C8 , P10F5 , P1100 , P1103 , P117A , P11FF , P1200 , P128C-P128F , P129E , P12A8 , P130F , P135C-P135F , P1436 , P143A , P143B , P1472 , P14A0 , P14B6 , P14BD , P14CD , P14CE , P14D4-P14D6 , P150C , P151A , P151D , P153C , P153D , P155D , P1591 , P15E2 , P15F2 , P15F9 , P15FA , P15FB , P165C , P167F , P16E8 , P16FF , P175F , P1761 , P1762 , P1775 , P179B , P189C , P2544 , P308D , P30B4 , P30B5 , P30BC , P30BD , P30D5 , P30DE , P3168 , P3169 , or P316B
P30BC	Engine Controls and Fuel - 2.0L (LTG) - DTC C1201 , P1000 , P1001 , P1003 , P1008 , P1009 , P100A , P100E , P103D , P103E , P10B6-P10B9 , P10BF , P10C6-P10C8 , P10F5 , P1100 , P1103 , P117A , P11FF , P1200 , P128C-P128F , P129E , P12A8 , P130F , P135C-P135F , P1436 , P143A , P143B , P1472 , P14A0 , P14B6 , P14BD , P14CD , P14CE , P14D4-P14D6 , P150C , P151A , P151D , P153C , P153D , P155D , P1591 , P15E2 , P15F2 , P15F9 , P15FA , P15FB , P165C , P167F , P16E8 , P16FF , P175F , P1761 , P1762 , P1775 , P179B , P189C , P2544 , P308D , P30B4 , P30B5 , P30BC , P30BD , P30D5 , P30DE , P3168 , P3169 , or P316B
P30BC	Engine Controls and Fuel - 3.6L (LFY) - DTC C1201 , P1000 , P1001 , P1003 , P1008 , P1009 , P100A , P100E , P103D , P103E , P10B6-P10B9 , P10BF , P10C6-P10C8 , P10F5 , P1100 , P1103 , P117A , P11FF , P1200 , P128C-P128F , P129E , P12A8 , P130F , P135C-P135F , P1436 , P143A , P143B , P1472 , P14A0 , P14B6 , P14BD , P14CD , P14CE , P14D4-P14D6 , P150C , P151A , P151D , P153C , P153D , P155D , P1591 , P15E2 , P15F2 , P15F9 , P15FA , P15FB , P165C , P167F , P16E8 , P1

DTC	Diagnostic Procedure
P30D5	Engine Controls and Fuel - 2.0L (LTG) - DTC C1201 , P1000 , P1001 , P1003 , P1008 , P1009 , P100A , P100E , P103D , P103E , P10B6-P10B9 , P10BF , P10C6-P10C8 , P10F5 , P1100 , P1103 , P117A , P11FF , P1200 , P128C-P128F , P129E , P12A8 , P130F , P135C-P135F , P1436 , P143A , P143B , P1472 , P14A0 , P14B6 , P14BD , P14CD , P14CE , P14D4-P14D6 , P150C , P151A , P151D , P153C , P153D , P155D , P1591 , P15E2 , P15F2 , P15F9 , P15FA , P15FB , P165C , P167F , P16E8 , P16FF , P175F , P1761 , P1762 , P1775 , P179B , P189C , P2544 , P308D , P30B4 , P30B5 , P30BC , P30BD , P30D5 , P30DE , P3168 , P3169 , or P316B
P30D5	Engine Controls and Fuel - 3.6L (LFY) - DTC C1201 , P1000 , P1001 , P1003 , P1008 , P1009 , P100A , P100E , P103D , P103E , P10B6-P10B9 , P10BF , P10C6-P10C8 , P10F5 , P1100 , P1103 , P117A , P11FF , P1200 , P128C-P128F , P129E , P12A8 , P130F , P135C-P135F , P1436 , P143A , P143B , P1472 , P14A0 , P14B6 , P14BD , P14CD , P14CE , P14D4-P14D6 , P150C , P151A , P151D , P153C , P153D , P155D , P1591 , P15E2 , P15F2 , P15F9 , P15FA , P15FB , P165C , P167F , P16E8 , P16FF , P175F , P1761 , P1762 , P1775 , P179B , P189C , P2544 , P308D , P30B4 , P30B5 , P30BC , P30BD , P30D5 , P30DE , P3168 , P3169 , or P316B
P30DE	Engine Controls and Fuel - 2.0L (LTG) - DTC C1201 , P1000 , P1001 , P1003 , P1008 , P1009 , P100A , P100E , P103D , P103E , P10B6-P10B9 , P10BF , P10C6-P10C8 , P10F5 , P1100 , P1103 , P117A , P11FF , P1200 , P128C-P128F , P129E , P12A8 , P130F , P135C-P135F , P1436 , P143A , P143B , P1472 , P14A0 , P14B6 , P14BD , P14CD , P14CE , P14D4-P14D6 , P150C , P151A , P151D , P153C , P153D , P155D , P1591 , P15E2 , P15F2 , P15F9 , P15FA , P15FB , P165C , P167F , P16E8 , P16FF , P175F , P1761 , P1762 , P1775 , P179B , P189C , P2544 , P308D , P30B4 , P30B5 , P30BC , P30BD , P30D5 , P30DE , P3168 , P3169 , or P316B
P30DE	Engine Controls and Fuel - 3.6L (LFY) - DTC C1201 , P1000 , P1001 , P1003 , P1008 , P1009 , P100A , P100E , P103D , P103E , P10B6-P10B9 , P10BF , P10C6-P10C8 , P10F5 , P1100 , P1103 , P117A , P11FF , P1200 , P128C-P128F , P129E , P12A8 , P130F , P135C-P135F , P1436 , P143A , P143B , P1472 , P14A0 , P14B6 , P14BD , P14CD , P14CE , P14D4-P14D6 , P150C , P151A , P151D , P153C , P153D , P155D , P1591 , P15E2 , P15F2 , P15F9 , P15FA , P15FB , P165C , P167F , P16E8 , P16FF , P175F , P1761 , P1762 , P1775 , P179B , P189C , P2544 , P308D , P30B4 , P30B5 , P30BC , P30BD , P30D5 , P30DE , P3168 , P3169 , or P316B
U0020	Data Communications - DTC U0020
U0028	Data Communications - DTC U0028
U0029	Data Communications - DTC U0029
U0073	Data Communications - DTC U0073 or U2100
U0074	Data Communications - DTC U0074
U0075	Data Communications - DTC U0075
U0077	Data Communications - DTC U0077
U0078	Data Communications - DTC U0078
U007B	Data Communications - DTC U007B
U007C	Data Communications - DTC U007C
U007D	Data Communications - DTC U007D
U0100-U02FF	Data Communications - DTC U0100-U02FF
U01B0	Data Communications - DTC U01B0
U0300-U0336	Data Communications - DTC U0300-U0336
U0400-U05FF	Data Communications - DTC U0400-U05FF
U1026	Data Communications - DTC U1026
U1340-U135F	Data Communications - DTC U1340-U135F
U1500-U15FF	Data Communications - DTC U1500-U15FF
U1653	Data Communications - DTC U1653
U1814	Data Communications - DTC U1814

DTC	Diagnostic Procedure
U1833	Data Communications - DTC U1833
U184A	Data Communications - DTC U184A
U18A2	Data Communications - DTC U18A2
U18A6	Data Communications - DTC U18A6
U18A7	Data Communications - DTC U18A7
U18B9-U18BF	Data Communications - DTC U18B9-U18BF
U2098	Data Communications - DTC U2098
U2099	Data Communications - DTC U2099
U209E	Data Communications - DTC U209E
U209F	Data Communications - DTC U209F
U2100	Data Communications - DTC U0073 or U2100
U2160-U2231	Data Communications - DTC U2160-U2231
U2500-U25FF	Data Communications - DTC U2500-U25FF
U2616	Data Communications - DTC U2616
U2800	12 V Starting and Charging - DTC B1325, B1327, B1328, B1330, B1390, B1395, B1400, B1410, B1415, B1424, B1425, B1439, B1517, C0800, C0805, C0870, C0880, C0895, C0899, C0900, C1300, P0560-P0563, P0611, P1002, P129B, P129C, P1465, P1466, P15AE, P15AF, P17B0-P17B2, P17DD-P17DE, P1A0C, P1A0D, P1E19, P1E1A, or U2800
U3000	Data Communications - DTC U3000
U3012	Data Communications - DTC U3012

SYMPTOM BYTE LIST

Symptom Byte	Symptom Byte Description	Symptom Byte Definition
(00 - 0F) General Electrical Failures		
This category includes standard wiring failure modes (for example, shorts and opens), direct current (DC) quantities related by Ohm's Law and quantities related to amplitude, frequency or rate of change, and wave shape.		
00	-	This sub type is used for failures that cannot be assigned to a specific sub type. No additional information is available.
01	Short to Battery	This sub type is used for failures where the Electronic Control Unit measures vehicle system (battery positive) potential for greater than a specified time period or when some other value is expected.
02	Short to Ground	This sub type is used for failures where the Electronic Control Unit measures ground (battery negative) potential for greater than a specified time period or when some other value is expected.
03	Low Voltage	This sub type is used for failures where the Electronic Control Unit measures a voltage below a specified range but not necessarily a short to ground.
04	Open	This sub type is used for failures where the Electronic Control Unit determines an open circuit via lack of bias voltage, low current flow, no change in state of an input in response to an output, etc.

Symptom Byte	Symptom Byte Description	Symptom Byte Definition
05	High Voltage/Open	This sub type is used for failures where the condition detected by the Electronic Control Unit is the same for either indicated failure mode.
06	Low Voltage/Open	This sub type is used for failures where the condition detected by the Electronic Control Unit is the same for either indicated failure mode.
07	High Voltage	This sub type is used for failures where the Electronic Control Unit measures a voltage above a specified range but not necessarily a short to battery.
08	Performance - Signal Invalid	This sub type is used for failures where the value of the signal is not plausible given the operating conditions.
09	Too Fast Transitions	This sub type is used for failures where the signal transitions more quickly than is reasonably allowed.
0A	Too Slow Transitions	This sub type is used for failures where the signal transitions more slowly than is reasonably allowed.
0B	High Current	This sub type is used for failures where the Electronic Control Unit measures current flow above a specified range.
0C	Low Current	This sub type is used for failures where the Electronic Control Unit measures current flow below a specified range.
0D	High Resistance	This sub type is used for failures where the Electronic Control Unit infers a circuit resistance above a specified range.
0E	Low Resistance	This sub type is used for failures where the Electronic Control Unit infers a circuit resistance below a specified range.
0F	Signal Erratic	This sub type is used for failures where the signal is momentarily implausible (not long enough for Signal Invalid) or discontinuous.

(10 - 1F) Additional General Electrical Failures

This category includes the overflow from category 0.

10	-	Currently not used.
11	High Input	This sub type is used for failures where some circuit quantity is above a specified range.
12	Low Input	This sub type is used for failures where some circuit quantity is below a specified range.
13	Low Voltage/High Temperature	This sub type is used for failures where a temperature sensor with a negative temperature coefficient detects a voltage below a specified range.
14	High Voltage/Low Temperature	This sub type is used for failures where a temperature sensor with a negative temperature coefficient detects a voltage above a specified range.
15	Performance - Signal Rising Time Failure	This sub type is used for failures where the signal rise time is outside a specified range.

Symptom Byte	Symptom Byte Description	Symptom Byte Definition
16	Performance - Signal Falling Time Failure	This sub type is used for failures where the signal fall time is outside a specified range.
17	Performance - Signal Shape/Waveform Failure	This sub type is used for failures where the shape of the signal (plot of the amplitude with respect to time) is not correct (for example, improper circuit impedance.)
18	Low Signal Amplitude	This sub type is used for failures where the Electronic Control Unit measures a signal voltage below a specified range but not necessarily a short to ground (for example, gain too low).
19	High Signal Amplitude	This sub type is used for failures where the Electronic Control Unit measures a signal voltage above a specified range but not necessarily a short to battery (for example, gain too high).
1A	Performance - Bias Level Out of Range	This sub type is used for failures where the Electronic Control Unit applies a bias voltage to a circuit upon which is superimposed a signal voltage (for example, Oxygen Sensor Circuit.)
1B	Signal Cross Coupled	This sub type is used for failures where the Electronic Control Unit detects a circuit shorted to another circuit when both circuits are controlled by the Electronic Control Unit.
1C	-	Currently not used.
1D	-	Currently not used.
1E	-	Currently not used.
1F	Erratic	This sub type is used for failures where the Electronic Control Unit momentarily detects one of the conditions defined above but not long enough to set a specific sub type.
(20 - 2F) FM / PWM Failures This category includes faults related to Frequency Modulated (FM) and Pulse Width Modulated (PWM) inputs and outputs of the Electronic Control Unit and faults where position is determined by counts.		
20	-	Currently not used.
21	Incorrect Period	This sub type is used for failures where the Electronic Control Unit measures an incorrect duration for one cycle of the output.
22	Too Short Low-Time	This sub type is used for failures where the Electronic Control Unit detects the low pulse is too narrow with respect to time.
23	Too Long Low-Time	This sub type is used for failures where the Electronic Control Unit detects the low pulse is too wide with respect to time.
24	Too Short High-Time	This sub type is used for failures where the Electronic Control Unit detects the high pulse is too narrow with respect to time.
25	Too Long High-Time	This sub type is used for failures where the Electronic Control Unit detects the high pulse is too wide with respect to time.
26	Low Frequency	This sub type is used for failures where the Electronic Control Unit detects too few cycles in a given time period.

Symptom Byte	Symptom Byte Description	Symptom Byte Definition
27	High Frequency	This sub type is used for failures where the Electronic Control Unit detects too many cycles in a given time period.
28	Incorrect Frequency	This sub type is used for failures where the Electronic Control Unit measures an incorrect number of cycles in a given time period.
29	Too Few Pulses	This sub type is used for failures where the Electronic Control Unit measures too few pulses (for example, position is calibrated in counts from one extreme to the other).
2A	Too Many Pulses	This sub type is used for failures where the Electronic Control Unit measures too many pulses (for example, position is calibrated in counts from one extreme to the other).
2B	Missing Reference	This sub type is used for failures where the Electronic Control Unit does not detect a reference for a signal circuit or a group of signal circuits.
2C	-	Currently not used.
2D	-	Currently not used.
2E	-	Currently not used.
2F	-	Currently not used.
(30 - 3F) Electronic Control Unit Internal Failures		
This category includes faults related to memory, software, and internal electrical circuitry; requiring component replacement.		
30	-	Currently not used.
31	Internal Checksum Error	This sub type is used by the Electronic Control Unit to indicate an incorrect checksum calculation where memory type is not specified.
32	General Memory Malfunction	This sub type is used by the Electronic Control Unit to indicate a memory failure where memory type is not specified.
33	Special Memory Malfunction	This sub type is used by the Electronic Control Unit to indicate a memory failure where the specific memory type is not defined in this category.
34	RAM Malfunction	This sub type is used by the Electronic Control Unit to indicate a Random Access Memory (RAM) failure.
35	ROM Malfunction	This sub type is used by the Electronic Control Unit to indicate a Read Only Memory (ROM) failure.
36	EEPROM Performance/Malfunction	This sub type is used by the Electronic Control Unit to indicate an Electrically Erasable Programmable Read Only Memory (EEPROM) failure.
37	Software Malfunction	This sub type is used by the Electronic Control Unit to indicate a failure in the execution of operational software
38	Supervision Software Malfunction	This sub type is used by the Electronic Control Unit to indicate a loop time error in the execution of the operational software.

Symptom Byte	Symptom Byte Description	Symptom Byte Definition
39	Internal Malfunction	This sub type is used by the Electronic Control Unit to indicate the detection of an internal circuit failure.
3A	Incorrect Component Installed	This sub type is used by the Electronic Control Unit to indicate a mismatch between the hardware connected to the Electronic Control Unit and the hardware expected by the Electronic Control Unit.
3B	Self-Test Malfunction	This sub type is used by the Electronic Control Unit to indicate a sensor self-test failure launched by an Electronic Control Unit command.
3C	Internal Communication Malfunction	This sub type is used by the Electronic Control Unit to indicate loss of an internal communication line, for example, between microprocessors in a dual microprocessor configuration.
3D	-	Currently not used.
3E	-	Currently not used.
3F	-	Currently not used.

(40 - 4F) Electronic Control Unit Programming Failures

This category includes faults related to operational software, calibrations, and options; remedied by programming the Electronic Control Unit.

40	-	Currently not used.
41	Not Programmed	This sub type is used to indicate that only boot software is present in the Electronic Control Unit.
42	Calibration Not Programmed	This sub type is used to indicate that operational software is present but calibration data is not.
43	EEPROM Incorrect Programming	This sub type is used to indicate an EEPROM error that may be remedied by reprogramming the module.
44	Security Access Not Activated	This sub type is used to indicate that programming was attempted without unlocking the Electronic Control Unit.
45	Variant Not Programmed	This sub type is used to indicate the need to enter (program) the sub system option content.
46	Configuration Not Programmed	This sub type is used to indicate the need to enter (program) the vehicle option content.
47	VIN Not Programmed	This sub type is used to indicate the need to enter (program) the vehicle identification number (VIN).
48	Security Code Not Programmed	This sub type is used to indicate the need to enter (program) the theft / security code.
49	RAM Incorrect Programming	This sub type is used by the Electronic Control Unit to indicate a Random Access Memory (RAM) error remedied by reprogramming.
4A	Programming Checksum Error	This sub type is used by the Electronic Control Unit to indicate an incorrect checksum calculation where memory type is not specified.

Symptom Byte	Symptom Byte Description	Symptom Byte Definition
4B	Calibration Not Learned	This sub type is used by the Electronic Control Unit to indicate that a password, operational range, etc. for a sensor or actuator must be learned by the Electronic Control Unit.
4C	DTC Memory Full	This sub type is used by the Electronic Control Unit to indicate that more DTCs have been detected than can be accommodated by the memory allocated for DTC storage.
4D	Stack Overflow	This subtype is used by the Electronic Control Unit to indicate that more memory has been used in a stack than is allocated to a program.
4E	-	Currently not used.
4F	-	Currently not used.
(50 - 5F) Algorithm Based Failures		
This category includes faults based on comparing two or more input parameters for plausibility or comparing a single parameter to itself with respect to time.		
50	-	Currently not used.
51	-	Currently not used.
52	-	Currently not used.
53	Low Temperature	This sub type is used for failures where the Electronic Control Unit calculates a low temperature condition based upon the duration of certain operating parameters.
54	High Temperature	This sub type is used for failures where the Electronic Control Unit calculates a high temperature condition based upon the duration of certain operating parameters.
55	Too Few Transitions	This sub type is used for failures where the Electronic Control Unit monitors a parameter over time within specified limits and detects fewer than the expected number of transitions.
56	Too Many Transitions	This sub type is used for failures where the Electronic Control Unit monitors a parameter over time within specified limits and detects more than the expected number of transitions.
57	-	Currently not used.
58	Performance	This sub type is used for failures where the Electronic Control Unit does not see the expected change to a parameter or group of parameters in response to a particular event.
59	Protection Time-Out	This sub type is used for failures where the Electronic Control Unit detects a function is active for greater than a specified time period.
5A	Not Plausible	This sub type is used for failures where the Electronic Control Unit compares two or more input parameters for plausibility.
5B	-	Currently not used.
5C	-	Currently not used.
5D	-	Currently not used.
5E	-	Currently not used.

Symptom Byte	Symptom Byte Description	Symptom Byte Definition
5F	-	Currently not used.
(60 - 6F) Mechanical Failures This category includes faults detected by inappropriate motion in response to an Electronic Control Unit controlled output.		
60	-	Currently not used.
61	Stuck	This sub type is used for failures where the Electronic Control Unit does not detect any motion in response to energizing a motor, solenoid, relay, etc.
62	Stuck Open	This sub type is used for failures where the Electronic Control Unit does not detect any motion upon commanding the operation of a motor, solenoid, relay, etc., to close some piece of equipment.
63	Stuck Closed	This sub type is used for failures where the Electronic Control Unit does not detect any motion upon commanding the operation of a motor, solenoid, relay, etc., to open some piece of equipment.
64	Slip Detected	This sub type is used for failures where the Electronic Control Unit detects excessive duration to command a motor, solenoid, relay, etc., to move a piece of equipment to a desired position.
65	Emergency Position Not Achievable	This sub type is used for failures where the Electronic Control Unit is unable to command a motor, solenoid, relay, etc., to move a piece of equipment to the emergency position.
66	Incorrect Mounting	This sub type is used for failures where the server detects incorrectly mounted components, for example, acceleration sensor showing a position error of 90°.
67	Incorrect Assembly	This sub type is used for failures where the control module has detected that the component has been incorrectly installed (for example, hydraulic pipes crossed over, circuits cross wired) or polarity errors.
68	-	Currently not used.
69	-	Currently not used.
6A	-	Currently not used.
6B	-	Currently not used.
6C	-	Currently not used.
6D	-	Currently not used.
6E	-	Currently not used.
6F	-	Currently not used.
(70 - 7F) Bus Signal / Message Failures This category includes faults related to bus hardware and signal integrity. This category is also used when the physical input for a signal is located in one Electronic Control Unit and another Electronic Control Unit diagnoses the circuit.		
70	-	Currently not used.
71	Invalid Data	This sub type is used by the Electronic Control Unit to indicate a signal was received with the corresponding validity bit equal to Invalid or post processing of the signal determines it is invalid.

Symptom Byte	Symptom Byte Description	Symptom Byte Definition
72	Message Counter Incorrect	This sub type is used by the Electronic Control Unit to indicate a signal was received without the corresponding rolling count value being properly updated.
73	Parity Error	This sub type is used by the Electronic Control Unit to indicate a message was processed with an incorrect parity calculation.
74	Bus Signal Checksum Error	This sub type is used by the Electronic Control Unit to indicate a message was processed with an incorrect protection (checksum) calculation.
75	Serial Data Link High Input	This sub type is used for failures where some circuit quantity, reported via serial data, is above a specified range.
76	Serial Data Link Low Input	This sub type is used for failures where some circuit quantity, reported via serial data, is below a specified range.
77	-	Currently not used.
78	-	Currently not used.
79	-	Currently not used.
7A	-	Currently not used.
7B	-	Currently not used.
7C	-	Currently not used.
7D	-	Currently not used.
7E	-	Currently not used.
7F	Bus Signal Erratic	This sub type is used for failures where the signal, reported via serial data, is momentarily implausible or discontinuous.
(80 - FF) Reserved Unique System Specific - See specific diagnostic procedures for symptom byte information if these symptom bytes are used.		

SYMPTOMS - VEHICLE

Body Repair

- [Symptoms - Bolted Exterior Body Panels and Closures](#)
- [Symptoms - Active Grille Air Shutter](#)

Body Systems

- [Symptoms - Fixed and Moveable Windows](#)
- [Symptoms - Horns](#)
- [Symptoms - Lighting](#)
- [Symptoms - Mirrors](#)
- [Symptoms - Vehicle Access](#)
- [Symptoms - Wiper/Washer Systems](#)

Brakes

- [Symptoms - Antilock Brake System](#)
- [Symptoms - Hydraulic Brakes](#)
- [Symptoms - Park Brake](#)

Driveline/Axle

- [Symptoms - Propeller Shaft](#)
- [Symptoms - Rear Differential Carrier](#)

Driver Information and Entertainment

- [Symptoms - Cellular Communication](#)
- [Symptoms - Entertainment](#)
- [Symptoms - Displays and Gauges](#)
- [Symptoms - Secondary and Configurable Customer Controls](#)

Engine

- [Symptoms - Engine Electrical](#)
- [Symptoms - Stop/Start System](#)
- [Symptoms - Cruise Control](#)
- [Symptoms - Engine Controls](#) - 3.6L (LFY)Engine
- [Symptoms - Engine Cooling](#)
- [Symptoms - Engine Mechanical](#) - 2.0L (LTG)Engine
- [Symptoms - Engine Mechanical](#) - 3.6L (LFY)Engine
- [Symptoms - Engine Exhaust](#)

General Information

[Symptoms - Vibration Diagnosis and Correction](#)

HVAC

- [Symptoms - Heating, Ventilation, and Air Conditioning](#)
- [Symptoms - HVAC Systems - Automatic](#)

Power and Signal Distribution

- [Symptoms - Data Communications](#)
- [Symptoms - Mobile Device Wireless Charger](#)
- [Symptoms - Power Outlets](#)
- [Symptoms - Wiring Systems](#)

Roof

[Symptoms - Roof](#)

Safety and Security

- [Symptoms - Driver Assistance Systems](#)
- [Symptoms - Parking Assistance Systems](#)
- [Symptoms - Remote Functions](#)
- [Symptoms - Seat Belts](#)
- [Symptoms - SIR](#)
- [Symptoms - Theft Deterrent](#)

Seats

- [Symptoms - Power Seats](#)
- [Symptoms - Seat Heating and Cooling](#)

Steering

- [Symptoms - Power Steering System](#)
- [Symptoms - Steering Wheel and Column](#)

Suspension

- [Symptoms - Suspension General Diagnosis](#)
- [Symptoms - Tire Pressure Monitoring](#)

Transmission

- [Symptoms - Automatic Transmission](#) - 9T65 (M3V)Transmission
- [Symptoms - Automatic Transmission Shift Lock Control](#)
- [Symptoms - Power Transfer Unit Case](#)

ENGINE DOES NOT CRANK

Refer to the appropriate diagnostic procedure below for the symptom observed.

- [Starter Solenoid Does Not Click](#)
- [Starter Solenoid Clicks, Engine Does Not Crank](#)
- [Engine Cranks Slowly](#).

ENGINE CRANKS BUT DOES NOT RUN

Refer to the appropriate diagnostic procedure below for the vehicle being serviced.

- [Engine Cranks But Does Not Run](#) - 3.6L (LFY)Engine

INSPECTION/MAINTENANCE SYSTEM CHECK

Refer to the appropriate diagnostic procedure below for the vehicle being serviced.

- [Inspection/Maintenance System Check](#) - 3.6L (LFY)Engine

DIAGNOSTIC REPAIR VERIFICATION

NOTE: After a repair has been made, some DTCs require the ignition to be turned Off and then back On before the scan tool function will clear the DTC.

1. Ignition/Vehicle - Off
2. Install any components or connectors that have been removed or replaced during diagnosis.
3. Perform any adjustment, programming or setup procedures that are required when a component or module is removed or replaced.
4. Ignition - On / Vehicle - In Service Mode
5. Perform the following action:Clear the DTCs.
6. Ignition/Vehicle - Off - For greater than 60 s
7. Perform the Circuit/System Verification and verify the result ends with an All OK. - If available

or

If the repair was related to a DTC, duplicate the Conditions for Running the DTC and use the Freeze Frame/Failure Records, if applicable, in order to verify the DTC does not set.If the DTC sets or another DTC is present - Refer to:[Diagnostic Trouble Code \(DTC\) List - Vehicle](#)

or

If the repair was symptom related, duplicate the conditions under which the customer concern occurred to verify the repair. If the customer concern reoccurs or another symptom is present - Refer to:[Symptoms - Vehicle](#)

PROACTIVE ALERTS LIST

This master list includes all applicable Proactive Alert Identifiers in alphanumeric order.

Proactive Alert Service Message	Diagnostic Procedure
SAC001	12 V Starting and Charging- <u>Proactive Alert Identifier SAC001</u>
SAC002	12 V Starting and Charging- <u>Proactive Alert Identifier SAC002</u>
SAC003	12 V Starting and Charging- <u>Proactive Alert Identifier SAC003</u>
SAC004	12 V Starting and Charging- <u>Proactive Alert Identifier SAC004</u>
SAC005	12 V Starting and Charging- <u>Proactive Alert Identifier SAC005</u>

mcx30.com