

2018 GENERAL INFORMATION**Vehicle Diagnostic Information - Specifications - Traverse****SPECIFICATIONS****A11 RADIO: SCAN TOOL INFORMATION (IO5/IO6)****Radio Scan Tool Data Parameters**

Parameter	Expected Value	Definition
Operating Conditions: Ignition ON		
Battery Voltage	Varies	The scan tool displays volts. This is the voltage at the input to the radio via high speed GMLAN.
System Power Mode	Run	The scan tool displays Off, Accessory, Run or Crank Request. This is the vehicle power mode status as received by the radio.
Date	Varies	The scan tool displays the current date set in the radio.
Time	Varies	The scan tool displays the current time set in the radio in 24 hour format HHMMSS
Radio Band	Varies	The scan tool displays AM, AM High Definition, FM, FM High Definition, Digital Audio broadcast, or XM. This is the broadcast radio band currently selected.
Audio Source Status	Varies	This parameter displays the currently selected audio source
Current FM Frequency	Varies	When tuned to an FM station, the scan tool displays the currently selected frequency in MHz
Current AM Frequency	Varies	When tuned to an AM station, the scan tool displays the currently selected frequency in kHz
Volume Control	Varies	The scan tools displays the current volume setting in counts.
Mute Status	Off	The scan tool displays On or Off. This is the currently selected audio mute mode.
Surround Sound	Varies	The scan tool displays On or Off. This is the currently selected surround sound mode.
Equalizer Preset	Varies	The scan tool displays the currently selected preset equalizer mode
Radio Power Button	On	The scan tool displays On or Off. This is the currently selected radio power mode.
Remote CD	Varies based on vehicle equipment	The scan tool displays Present or Not Present. This parameter displays present when the infotainment system is equipped with the remote cd player.
Rear Seat Entertainment	Varies based on vehicle equipment	The scan tool displays Present or Not Present. This parameter displays present when the infotainment system is equipped with the rear seat entertainment system.
Remote Enable Circuit	On	The scan tool displays On or Off. This is the current state of the remote enable output as commanded by the radio.
Front 3.5 mm AUX Input	Varies	The scan tool displays Present or Not Present. This parameter displays Present when a device is connected to the front auxiliary input jack.

Parameter	Expected Value	Definition
Rear 3.5 mm AUX Input	Varies	The scan tool displays Present or Not Present. This parameter displays Present when a device is connected to the rear auxiliary input jack.
Front USB Receptacle	Varies	The scan tool displays Present or Not Present. This parameter displays Present when a front USB receptacle is present.
Rear USB Receptacle	Varies	The scan tool displays Present or Not Present. This parameter displays Present when a rear USB receptacle is present.
Front SD Card Receptacle	Varies	The scan tool displays Present or Not Present. This parameter displays Present when a front SD card receptacle is present.
Rear SD Card Receptacle	Varies	The scan tool displays Present or Not Present. This parameter displays Present when a rear SD card receptacle is present.
Radio Theft Lock Status	Unlocked	The scan tool displays Locked or Unlocked. This is the state of the theft lock system.
Theft Lock Armed	VIN Learned	The scan tool displays VIN Learned or No VIN. This is the state of the VIN programming in the radio.
Test Bench Mode	Inactive	The scan tool displays Active or Inactive. This is the state of the test bench mode.
Valet Mode	Inactive	The scan tool displays Active or Inactive. This is the state of the valet mode.
XM Subscription Status	Varies	This parameter displays the country and type of XM service.
High Definition Signal	Varies	The scan tool displays Present or Not Present. This parameter displays Present when a high definition signal is being received.
Digital Audio Signal	Varies	The scan tool displays Present or Not Present. This parameter displays Present when a digital audio signal is being received.
Alternative Frequency Status	Varies	The scan tool displays Active or Inactive. This parameter displays Active if the radio is using an alternative frequency for a radio station broadcasting simultaneously from two different stations.
Last Working MOST ID of Node 1 (Master)	Radio	The scan tool displays the name of the ECU in the MOST BUS Node 1 position that was assigned when the MOST BUS was operational without any faults.
Last Working MOST ID of Node 2	Varies based on vehicle equipment	The scan tool displays the name of the ECU in the MOST BUS Node 2 position that was assigned when the MOST BUS was operational without any faults.
Last Working MOST ID of Node 3	Varies based on vehicle equipment	The scan tool displays the name of the ECU in the MOST BUS Node 3 position that was assigned when the MOST BUS was operational without any faults.
Last Working MOST ID of Node 4	Varies based on vehicle equipment	The scan tool displays the name of the ECU in the MOST BUS Node 4 position that was assigned when the MOST BUS was operational without any faults.
Last Working MOST ID of Node 5	Varies based on vehicle equipment	The scan tool displays the name of the ECU in the MOST BUS Node 5 position that was assigned when the MOST BUS was operational without any faults.
Last Working MOST ID of Node 6	Varies based on vehicle equipment	The scan tool displays the name of the ECU in the MOST BUS Node 6 position that was assigned when the MOST BUS was operational without any faults.
Last Working MOST ID of Node 7	Varies based on vehicle equipment	The scan tool displays the name of the ECU in the MOST BUS Node 7 position that was assigned when the MOST BUS was operational without any faults.

Parameter	Expected Value	Definition
Last Working MOST ID of Node 8	Varies based on vehicle equipment	The scan tool displays the name of the ECU in the MOST BUS Node 8 position that was assigned when the MOST BUS was operational without any faults.
Last Working MOST ID of Node 9	Varies based on vehicle equipment	The scan tool displays the name of the ECU in the MOST BUS Node 9 position that was assigned when the MOST BUS was operational without any faults.
Surrogate MOST Master Node Upstream Position	Numeric	This parameter becomes available when DTC U0028 is current. The number identified is the device furthest upstream from the radio communicating on the MOST BUS when a communication fault is present.
Number of MOST Communication Breaks	Numeric	The number displayed increments each time the MOST BUS cannot communicate successfully.
Number of MOST Configuration Status Messages	Numeric	The number displayed increments each time a MOST BUS configuration status message is sent. A configuration status message is sent when the MOST BUS is initiated, including during or following a communication break.
Number of Short Term MOST Communication Breaks	Numeric	The number displayed increments each time the MOST BUS was temporarily unable to communicate successfully.
Diagnostic Data Identifier	Varies	The scan tool displays the 4 character alphanumeric device ID.
VIN Digits 2-17	Varies	The scan tool displays the learned VIN digits 2-17.
Manufacturer Enable Counter	0	The scan tool displays the counter value. This counter is used for manufacturing purposes only.
Boot Software Part Number	Varies	The scan tool displays the boot software ID number.
Diagnostic Data Identifier	Varies	Identifies a supplier and system specific data stream used by diagnostic testers to interpret a diagnostic data stream.
Calibration Part Number 1	Varies	The scan tool displays the software module ID 1.
Calibration Part Number 2	Varies	The scan tool displays the software module ID 2.
Calibration Part Number 3	Varies	The scan tool displays the software module ID 3.
Calibration Part Number 4	Varies	The scan tool displays the software module ID 4.
Calibration Part Number 5	Varies	The scan tool displays the software module ID 5.
Calibration Part Number 6	Varies	The scan tool displays the software module ID 6.
Calibration Part Number 7	Varies	The scan tool displays the software module ID 7.
Calibration Part Number 8	Varies	The scan tool displays the software module ID 8.
Calibration Part Number 9	Varies	The scan tool displays the software module ID 9.
Calibration Part Number 10	Varies	The scan tool displays the software module ID 10.
End Model Part Number	Varies	The scan tool displays the end model part number.
XM Electronic Serial Number	Varies	Identifies the integrated XM module serial number, if equipped.
HD Decoder Electronic Serial Number	Varies	Identifies the integrated HD decoder serial number, if equipped.

Parameter	Expected Value	Definition
XM Firmware Version and Date	Varies	Identifies the XM module software version and release date, if equipped.
HD Decoder System Version	Varies	Identifies the HD decoder software version, if equipped.

Radio Scan Tool Output Controls

Scan Tool Output Control	Description
Active AM/FM Antenna	This output control will command the Active AM/FM Antenna ON and OFF.
Satellite Antenna	This output control will command the Satellite Antenna ON and OFF.
Digital Audio Broadcast Antenna Power	This output control will command the Digital Audio Broadcast Antenna ON and OFF.
MOST Communication Enable Circuit	This output control will command the MOST Communication Enable Circuit ON and OFF.
MOST Bus Diagnostic Starting Point	This output control will initiate the MOST Bus Diagnostic Starting Point Display.
Erase Valet Mode Code	This output control will command the Erase Valet Mode Code function.
Control Module Reset	This output control will command the reset of the Control Module.

A11 RADIO: SCAN TOOL INFORMATION (IOA)

Radio Scan Tool Data Parameters

Parameter	Expected Value	Definition
Operating Conditions: Ignition ON		
Battery Voltage	Varies	The scan tool displays volts. This is the voltage at the input to the radio.
System Power Mode	Run	The scan tool displays Off, Accessory, Run or Crank Request. This is the current power mode of the radio.
Valet Mode	Inactive	Indicates if the system is in Valet mode.
Radio Theft Armed	Learned VIN	The scan tool displays Learned VIN or No VIN. This is the state of the VIN programming in the radio.
Radio Theft Locked	Inactive	The scan tool displays Active or Inactive. This is the state of the theft lock system. Active indicates the radio is locked. Inactive indicates the theft lock system is armed and the radio is unlocked.
Test Bench Mode	Inactive	The scan tool displays Active or Inactive. This parameter indicates if the radio is in bench or user mode.
Radio Power Button	Varies	Indicates if the Radio Power button is in the ON or OFF state.
End Model Part Number	Varies	End Model Part Number is the part number for the hardware of the control module with software and calibrations.
Base Model Part Number	Varies	Base Model Part Number is the part number for the hardware without software and calibrations.
Boot Software Part Number	Varies	The scan tool displays the boot software ID number.
Calibration Part Number 1	Varies	The scan tool displays the software module ID 1.
Calibration Part Number 2	Varies	The scan tool displays the software module ID 2.
Calibration Part Number 3	Varies	The scan tool displays the software module ID 3.
Calibration Part Number 4	Varies	The scan tool displays the software module ID 4.

Parameter	Expected Value	Definition
Calibration Part Number 5	Varies	The scan tool displays the software module ID 5.
Calibration Part Number 6	Varies	The scan tool displays the software module ID 6.
Calibration Part Number 7	Varies	The scan tool displays the software module ID 7.
Calibration Part Number 8	Varies	The scan tool displays the software module ID 8.
Calibration Part Number 9	Varies	The scan tool displays the software module ID 9.
Calibration Part Number 10	Varies	The scan tool displays the software module ID 10.
VIN Digits 2-17	Varies	The scan tool displays the learned VIN digits 2-17.

Radio Scan Tool Output Controls

Scan Tool Output Control	Description
Left Front Speaker	This output control is used to command the speaker ON and OFF. Commanding the speaker ON will generate a test tone to be generated through the selected loudspeaker.
Left Rear Speaker	This output control is used to command the speaker ON and OFF. Commanding the speaker ON will generate a test tone to be generated through the selected loudspeaker.
Right Front Speaker	This output control is used to command the speaker ON and OFF. Commanding the speaker ON will generate a test tone to be generated through the selected loudspeaker.
Right Rear Speaker	This output control is used to command the speaker ON and OFF. Commanding the speaker ON will generate a test tone to be generated through the selected loudspeaker.
Chime Function Test	This output command is used to command the chime ON and OFF.
Rear Camera Display Control	This output control will command the rear camera display ON and OFF. Commanding the rear camera on will display the rear camera image on the info display screen.
Rear Park Assist Steering Wheel Position Control	This output control will command the rear park assist steering wheel position ON and OFF. Commanding the rear park assist steering wheel position ON will display the steering wheel position guide lines on the info display screen.

A26 HVAC CONTROLS: SCAN TOOL INFORMATION

HVAC Controls Scan Tool Data Parameters

Parameter	System State	Expected Value	Description
Operating Conditions: Ignition ON/Vehicle in Service Mode			
Backlight Dimming	-	Varies	The scan tool displays % from 0 - 100 depending on the backlight dimming level.
Base Model Part Number	-	Varies	Base Model Part Number is the part number for the hardware without software and calibrations.
Battery Voltage	-	Varies	The scan tool displays V. This is the current battery voltage.
Boot Software Number	-	Varies	The scan tool displays the boot software ID number.

Parameter	System State	Expected Value	Description
Calibration Part Number 1	-	Varies	The scan tool displays the software calibration part number 1.
Calibration Part Number 2	-	Varies	The scan tool displays the software calibration part number 2.
Calibration Part Number 3	-	Varies	The scan tool displays the software calibration part number 3.
Diagnostic Data Identifier	-	Varies	The scan tool displays the 4 character alphanumeric device ID.
Driver HVAC Temperature Display	-	Varies	The scan tool displays Â°C (Â°F). This is the currently selected temperature setting.
Driver Seat Heating/Venting/Cooling Level	Driver Seat Heating/Venting/Cooling OFF	No LEDs activated.	The scan tool displays No LED Activated when the drivers seat heating/venting/cooling is OFF. When the seat is activated, the scan tool displays 1 LED Activated, 2 LEDs Activated, or 3 LEDs Activated depending on the selected level.
Driver Seat Heating/Venting/Cooling Mode	Driver Seat Heating/Venting/Cooling OFF	No LEDs activated.	The scan tool displays No LED Activated when the drivers seat heating/venting/cooling is OFF. When the seat is activated, the scan tool displays 1 LED Activated, 2 LEDs Activated, or 3 LEDs Activated depending on the selected level.
End Model Part Number	-	Varies	End Model Part Number is the part number for the hardware of the control module with software and calibrations.
HVAC Controls	No HVAC buttons active	No Button Pressed	The scan tool displays No Button Pressed or Button Pressed. Button Pressed is displayed when any HVAC button is activated.
	Any HVAC button active	Button Pressed	
HVAC Controls Dimming Level	-	Varies	The scan tool displays % from 0 - 100 depending on the backlight dimming level.
HVAC Display Dimming Level	-	Varies	The scan tool displays % from 0 - 100 depending on the display dimming level.
HVAC Indicator Dimming Level	-	Varies	The scan tool displays % from 0 - 100 depending on the indicator dimming level.

Parameter	System State	Expected Value	Description
Left Temperature Knob Position	-	Varies	The scan tool displays counts from 0 - 255, indicating the current temperature knob setting.
Passenger HVAC Temperature Display	-	Varies	The scan tool displays Â°C (Â°F). This is the currently selected temperature setting.
Passenger Seat Heating/Venting/Cooling Level	Passenger Seat Heating/Venting/Cooling OFF	No LEDs activated.	The scan tool displays No LED Activated when the passenger seat heating/venting/cooling is OFF. When the seat is activated, the scan tool displays 1 LED Activated, 2 LEDs Activated, or 3 LEDs Activated depending on the selected level.
Passenger Seat Heating/Venting/Cooling Mode	Passenger Seat Heating/Venting/Cooling OFF	No LEDs activated.	The scan tool displays No LED Activated when the passenger seat heating/venting/cooling is OFF. When the seat is activated, the scan tool displays 1 LED Activated, 2 LEDs Activated, or 3 LEDs Activated depending on the selected level.
Programming Date	-	Varies	The scan tool displays the date the module was last programmed.
Right Temperature Knob Position	-	Varies	The scan tool displays counts from 0 - 255, indicating the current temperature knob setting.
System Power Mode	-	Run	The scan tool displays: Off, Accessory, Run, or Crank indicating the current vehicle power mode.

B174W FRONTVIEW CAMERA: SCAN TOOL INFORMATION (EXCEPT UGN)

Front View Camera Module Scan Tool Data Parameters

Parameter	System State	Expected Value	Description
Operating Conditions: Ignition ON/Engine OFF/Lane Departure Warning ON			
System Voltage	-	Varies	The scan tool displays the system voltage depending of the current battery voltage.
System Power Mode	-	Varies	The scan tool displays Off, Accessory, Running, Cranking or Undefined. This is the state of the ignition switch.
Power Mode Controlled by Backup Device	-	Varies	The scan tool displays Off, Accessory, Running or Cranking depending of the current power mode.
Frontview Camera System Status	-	Varies	The scan tool displays Normal, Malfunction or Undefined depending on the state of the lane departure warning system.

Parameter	System State	Expected Value	Description
Frontview Camera Calibration Status	-	Varies	The scan tool displays Not Calibrated, Calibrated, Dynamically Calibrated or Undefined. This is the current state of the calibration.
Frontview Camera Learn Mode Status	-	Varies %	The scan tool displays varies percentage between 0 - 100% depending on the state of the frontview camera learn mode.
Lane Departure Warning Status	-	Varies	The scan tool displays Off, Disabled, Not Ready to Assist, Ready to Assist, Malfunction, Unknown or Undefined depending on the state of the lane departure warning system.
Lane Departure Warning Switch Status	-	On	The scan tool displays On or Off depending on the state of the lane departure warning switch.
Lane Departure Warning Indicator Status	-	Varies	The scan tool displays Off, On, Malfunction, Unknown or Undefined depending on the state of the lane departure warning system.
Forward Collision Alert Function Status	-	Varies	The scan tool displays Off, On, Malfunction, Unknown or Undefined depending on the state of the lane departure warning system.
Intelligent Light Ranging Status	-	Varies	The scan tool displays Off, Disabled, Malfunction, Enabled, Unknown or Undefined depending on the state of the intelligent light ranging system.
Automatic High Beam Activation Status	-	Varies	The scan tool displays Disabled, Enabled or Undefined depending on the state of the automatic high beam assist system.
Following Distance Indicator Status	-	Varies	The scan tool displays Off, Disabled, Not Ready to Assist, Ready to Assist or Undefined depending on the state of the following distance indicator status.
Frontview Camera Disable History 1 - 4	-	Varies	The scan tool displays Empty, Lane Departure Warning Indicator Malfunction, Lane Departure Warning Switch Malfunction, Sensors Obstructed, Accelerator Pedal Position Out of Range, Driven Wheel Speed Signal Invalid, Non-Driven Wheel Speed Invalid, Brake Pedal Moderate Travel Signal Invalid, Brake Pedal Initial Travel Position Achieved, Lost Communication with Steering Wheel Angle Sensor Module, Invalid Data Received From Steering Wheel Angle Sensor Module, Forward Collision Alert Switch Malfunction, Clutch Pedal Position (CPP) Sensor Performance, Transmission Gear Engaged, Acceleration Sensor Longitudinal Signal, Invalid Data Received From Yaw Rate Sensor Module, Power Mode Controlled by Backup Device, System Power Mode, Overvoltage, Undervoltage or Undefined depending on the history data of the frontview camera disable history.

Front View Camera Module Scan Tool Output Controls

Output Control	Description
Clear Disable History Data	The frontview camera control module clears all disable history buffers when commanded from the scan tool.
Forward Collision Alert Switch	The frontview camera control module switches the forward collision alert system to Near, Medium or Far when commanded from the scan tool.
High Beams	The frontview camera control module switches the high beams On or Off when commanded from the scan tool.
Lane Departure Warning Indicator	The frontview camera control module switches the lane departure warning indicator On or Off when commanded from the scan tool.
Lane Departure Warning Switch	The frontview camera control module switches the lane departure warning system On or Off when commanded from the scan tool.
Vehicle Direction Camera Learn	The frontview camera control module initializes the service point calibration of the frontview camera and switches into the learn mode when commanded from the scan tool.

B174W FRONTVIEW CAMERA: SCAN TOOL INFORMATION (UGN)

NOTE: Due to software and hardware variations, not all information may be applicable.

Front View Camera Module Scan Tool Data Parameters

Parameter	System State	Expected Value	Description
Operating Conditions: Ignition ON/Engine OFF/Lane Departure Warning ON			
System Voltage	-	Varies	The scan tool displays the system voltage depending of the current battery voltage.
System Power Mode	-	Run	The scan tool displays Off, Accessory, Run, Cranking or Undefined. This is the state of the ignition switch.
Power Mode Controlled by Backup Device	-	Run	The scan tool displays Off, Accessory, Running or Cranking depending of the current power mode.
Frontview Camera System Status	-	On	The scan tool displays Normal, Malfunction or Undefined depending on the state of the Frontview Camera System.
Frontview Camera Calibration Status	-	Learn Successful	The scan tool displays Not Calibrated, Calibrated, Dynamically Calibrated or Undefined. This is the current state of the calibration.
Frontview Camera Learn Mode Status	-	Yes	The scan tool displays percentage between 0 - 100% depending on the state of the frontview camera learn mode.
Distance to Object	-	Varies	The scan tool displays meters between 0 - 255 depending on the distance from a detectable object to the vehicle.
Lane Departure Warning Status	-	Varies	The scan tool displays Off, Disabled, Not Ready to Assist, Ready to Assist, Malfunction, Unknown or Undefined depending on the state of the lane departure warning system.
Lane Keep Assist Status	-	Varies	The scan tool displays Off, Disabled, Not Ready to Assist, Ready to Assist, Malfunction, Unknown or Undefined depending on the state of the lane keep assist system.

Parameter	System State	Expected Value	Description
Lane Departure Warning Switch Status	-	Off	The scan tool displays Off, Disabled, Not Ready to Assist, Ready to Assist, Malfunction, Unknown, Undefined depending on the state of the lane departure warning switch.
Lane Keep Assist Switch Status	-	Off	The scan tool displays Off, Disabled, Not Ready to Assist, Ready to Assist, Malfunction, Unknown, Undefined depending on the state of the lane departure warning switch.
Lane Departure Warning Indicator Status	-	Off	The scan tool displays Off, On, Malfunction, Unknown or Undefined depending on the state of the lane departure warning system.
Forward Collision Alert Function Status	-	Off	The scan tool displays Off, On, Malfunction, Unknown or Undefined depending on the state of the lane departure warning system.
Automatic High Beam Activation Status	-	Enabled	The scan tool displays Disabled, Enabled or Undefined depending on the state of the automatic high beam assist system.
Frontview Camera Disable History 1 - 4	-	Varies	The scan tool displays Empty, Lane Departure Warning Indicator Malfunction, Lane Departure Warning Switch Malfunction, Sensors Obstructed, Accelerator Pedal Position Out of Range, Driven Wheel Speed Signal Invalid, Non-Driven Wheel Speed Invalid, Brake Pedal Moderate Travel Signal Invalid, Brake Pedal Initial Travel Position Achieved, Lost Communication with Steering Wheel Angle Sensor Module, Invalid Data Received From Steering Wheel Angle Sensor Module, Forward Collision Alert Switch Malfunction, Clutch Pedal Position (CPP) Sensor Performance, Transmission Gear Engaged, Acceleration Sensor Longitudinal Signal, Invalid Data Received From Yaw Rate Sensor Module, Power Mode Controlled by Backup Device, System Power Mode, Overvoltage, Undervoltage or Undefined depending on the history data of the frontview camera disable history.
Glare Free High Beam Assist	-	Varies	The scan tool displays Off, Disabled, Malfunction, Enabled, Unknown, or Undefined.
Following Distance Indicator Status	-	Varies	The scan tool displays Disabled, Not Ready to Assist, Ready to Assist, or Undefined.
Low Beam Decision Reason	-	Varies	The scan tool displays Tail Lights, On Coming Lights, Low Speed, City, Bright Scene, Fog, High Yaw, or Adverse weather

Parameter	System State	Expected Value	Description
FCA Vehicle Type	-	Varies	The scan tool displays Unknown, Truck, Car, Motor Bike, Bicycle, Pedestrian, or Undecided. This is the Forward Collision Alert type.
FCA Number of Vehicle Detected	-	Varies	The scan tool displays the number of vehicles detected between 0 - 255 depending on the number of vehicles detected.

NOTE: Due to software and hardware variations, not all information may be applicable.

Front View Camera Module Scan Tool Output Controls

Output Control	Description
Clear Disable History Data	The frontview camera control module clears all disable history buffers when commanded from the scan tool.
Forward Collision Alert Switch	The frontview camera control module switches the forward collision alert system to Near, Medium or Far when commanded from the scan tool.
High Beams	The frontview camera control module switches the high beams On or Off when commanded from the scan tool.
Lane Departure Warning Indicator	The frontview camera control module switches the lane departure warning indicator On or Off when commanded from the scan tool.
Lane Departure Warning Switch	The frontview camera control module switches the lane departure warning system On or Off when commanded from the scan tool.
Vehicle Direction Camera Learn	The frontview camera control module initializes the service point calibration of the frontview camera and switches into the learn mode when commanded from the scan tool.

B218L SIDE OBJECT SENSOR MODULE - LEFT: SCAN TOOL INFORMATION

Side Object Detection Scan Tool Parameters

Parameter	System State	Expected Value	Definition
Operating Conditions: Ignition ON			
Manufacturer's Traceability Number	-	Varies	The scan tool displays the Manufacturer's Traceability Number
Manufacturer Enable Counter	-	Varies	The scan tool displays the Manufacturer Enable Counter
Module Diagnostic Address	-	Varies	The scan tool displays the Software Module 1 Identifier
Software Module 1 Identifier	-	Varies	The scan tool displays the Software Module 1 Identifier
Software Module 2 Identifier	-	Varies	The scan tool displays the Software Module 2 Identifier
End Model Part Number	-	Varies	The scan tool displays the End Model Part Number
Base Model Part Number	-	Varies	The scan tool displays the Base Model Part Number
Software Module 1 Identifier Alpha Code	-	Varies	The scan tool displays the Software Module 1 Identifier Alpha Code
Software Module 2 Identifier Alpha Code	-	Varies	The scan tool displays the Software Module 2 Identifier Alpha Code
End Model Part Number Alpha Code	-	Varies	The scan tool displays the End Model Part Number Alpha Code

Parameter	System State	Expected Value	Definition
Base Model Part Number Alpha Code	-	Varies	The scan tool displays the Base Model Part Number Alpha Code

Side Object Detection Module Output Controls

Scan Tool Output Control	Description
Object Detection Alert Indicators	When commanded by the scan tool, the module will provide power to illuminate the side blind zone indicators in appropriate outside rear view mirror. The outside rear view mirror indicator will illuminate.
Rear Cross Traffic Audible Alert	When commanded by the scan tool, the module will send a signal to the audio system to turn on the rear cross traffic audible alert signal. The audio system will beep.
Rear Cross Traffic Haptic Alert	When commanded by the scan tool, the module will send a signal to the memory seat module to turn on the rear cross traffic haptic alert. The driver's seat will vibrate.
Rear Cross Traffic Visual Alert	When commanded by the scan tool, the module will turn on the rear cross traffic alert indicators on infotainment display. The infotainment display will illuminate with the appropriate rear cross traffic alert.

B218R SIDE OBJECT SENSOR MODULE - RIGHT: SCAN TOOL INFORMATION

Side Object Detection Scan Tool Parameters

Parameter	System State	Expected Value	Definition
Operating Conditions: Ignition ON			
Manufacturer's Traceability Number	-	Varies	The scan tool displays the Manufacturer's Traceability Number
Manufacturer Enable Counter	-	Varies	The scan tool displays the Manufacturer Enable Counter
Module Diagnostic Address	-	Varies	The scan tool displays the Software Module 1 Identifier
Software Module 1 Identifier	-	Varies	The scan tool displays the Software Module 1 Identifier
Software Module 2 Identifier	-	Varies	The scan tool displays the Software Module 2 Identifier
End Model Part Number	-	Varies	The scan tool displays the End Model Part Number
Base Model Part Number	-	Varies	The scan tool displays the Base Model Part Number
Software Module 1 Identifier Alpha Code	-	Varies	The scan tool displays the Software Module 1 Identifier Alpha Code
Software Module 2 Identifier Alpha Code	-	Varies	The scan tool displays the Software Module 2 Identifier Alpha Code
End Model Part Number Alpha Code	-	Varies	The scan tool displays the End Model Part Number Alpha Code
Base Model Part Number Alpha Code	-	Varies	The scan tool displays the Base Model Part Number Alpha Code

Side Object Detection Module Output Controls

Scan Tool Output Control	Description
Object Detection Alert Indicators	When commanded by the scan tool, the module will provide power to illuminate the side blind zone indicators in appropriate outside rear view mirror. The outside rear view mirror indicator will illuminate.

Scan Tool Output Control	Description
Rear Cross Traffic Audible Alert	When commanded by the scan tool, the module will send a signal to the audio system to turn on the rear cross traffic audible alert signal. The audio system will beep.
Rear Cross Traffic Haptic Alert	When commanded by the scan tool, the module will send a signal to the memory seat module to turn on the rear cross traffic haptic alert. The driver's seat will vibrate.
Rear Cross Traffic Visual Alert	When commanded by the scan tool, the module will turn on the rear cross traffic alert indicators on infotainment display. The infotainment display will illuminate with the appropriate rear cross traffic alert.

B233B RADAR SENSOR MODULE - LONG RANGE: SCAN TOOL INFORMATION

Scan Tool Data Parameters

Parameter	System State	Expected Value	Description
Operating Conditions: Vehicle in Run power mode, engine off.			
Alignment Status	-	OK	The scan tool displays OK or Not OK. This is current alignment state of the module.
Long Range Radar Sensor Module Blocked	-	No	The scan tool displays Yes or No. Yes is displayed when the module has determined that it cannot effectively transmit and receive radar signals.
Long Range Radar Sensor Module Learn Status	-	Learned	The scan tool displays Not Learned, Learn In Progress, Learned or Error. This is the current learn state of the module.
Long Range Radar Sensor Module Misaligned - Angled Down	-	No	The scan tool displays Yes, or No. Yes is and indicator that the module is misaligned too low.
Long Range Radar Sensor Module Misaligned - Angled Left	-	No	The scan tool displays Yes, or No. Yes is and indicator that the module is misaligned too much to the left.
Long Range Radar Sensor Module Misaligned - Angled Right	-	No	The scan tool displays Yes, or No. Yes is and indicator that the module is misaligned too much to the right.
Long Range Radar Sensor Module Misaligned - Angled Up	-	No	The scan tool displays Yes, or No. Yes is and indicator that the module is misaligned too high.
System Power Mode	-	Run	The scan tool displays Off, Accessory, Run or Crank Request. This is the current vehicle power mode
System Voltage	-	11 - 14 V	Current Vehicle Battery Voltage

Scan Tool Output Controls

Output Control	Description
Long Range Radar Sensor Module Learn	Initializes the module learn procedure.

K9 BODY CONTROL MODULE: SCAN TOOL INFORMATION

Body Control Module Scan Tool Data Parameters

Parameter	System State	Expected Value	Definition
Operating Conditions: Ignition ON, Vehicle in Park, All Doors Closed			

Parameter	System State	Expected Value	Definition
5 V Ignition Switch	-	Accessory / Key Out	The scan tool displays Off, Accessory, Run, or Crank. This parameter displays the ignition switch mode.
Accent Lighting 1 Command	-	Varies	This parameter displays the interior lighting ambient 1 command as a percentage.
Accent Lighting 2 Command	-	Varies	This parameter displays the interior lighting ambient 2 command as a percentage.
Accessory	-	Active	The scan tool displays Active or Inactive.
Accessory Power Mode Indicator Command	-	Varies	This parameter displays ignition switch accessory LED PWM command as a percentage.
Accessory Relay Command	-	Active	The scan tool displays Active or Inactive.
Accessory/Retained Accessory Power Relay Command	-	Active	The scan tool displays Active or Inactive. This parameter displays the retained accessory power relay status.
All Doors Lock Command	-	Inactive	The scan tool displays Active or Inactive. This parameter displays the door lock status.
Ambient Light Sensor	-	Varies	The scan tool displays volts. This parameter displays the ambient light sensor signal voltage.
Ambient Light Status	-	Night	The scan tool displays Unknown, Night, or Day. This parameter displays the ambient light level status.
Automatic Headlamps Disable Switch	-	Inactive	The scan tool displays Active or Inactive. This parameter displays the headlamp disable switch status.
Automatic Transmission Manual Shift Switch	-	Off	The scan tool displays Off or On. This parameter displays the transmission tap up tap down switch status.
Backup Lamps Relay Command	-	Inactive	The scan tool displays Active or Inactive. This parameter displays the backup lamps relay status.
Battery Current Sensor	-	Varies	The scan tool displays the battery current in amperes.
Battery Low at Start	-	Inactive	The scan tool displays Active or Inactive. This parameter displays Active when the battery level is low when the vehicle starts.
Battery Reconnect Detected	-	No	The scan tool displays No or Yes when a battery disconnect/reconnect event has been detected.
Battery Voltage	-	Varies	The scan tool displays the current battery voltage.
BCM-Controlled Charging Voltage	-	Active	The scan tool displays Active or Inactive.

Parameter	System State	Expected Value	Definition
BCM-Requested Charging Voltage Reduction	-	Inactive	The scan tool displays Active or Inactive. This parameter displays Active when the BCM has detected a low battery voltage condition.
Boot Software Part Number	-	Varies	The scan tool displays the boot software part number.
Brake Lamp Command	-	Inactive	The scan tool displays Active or Inactive. This parameter displays the brake lamp command status.
Brake Pedal Applied	-	Inactive	The scan tool displays Active or Inactive.
Brake Pedal Initial Travel Position Achieved	-	No	The scan tool displays No or Yes.
Brake Pedal Position Sensor	-	Varies	This displays Counts. This numeric value is the current brake pedal position.
Brake Pedal Position Sensor High Voltage During Learn	-	No	The scan tool displays No or Yes.
Brake Pedal Position Sensor Learn	-	No	The scan tool displays No or Yes. This parameter displays Yes when the brake pedal position sensor has learned.
Brake Pedal Position Sensor Learned Home Position	-	Yes	The scan tool displays No or Yes. This parameter displays Yes when the brake pedal position sensor has learned the home position.
Brake Pedal Position Sensor Learned Released Position	-	Yes	The scan tool displays No or Yes. This parameter displays Yes when the brake pedal position sensor has learned the released position.
Brake Pedal Position Sensor Learned Released Position	-	Varies	The scan tool displays volts.
Brake Pedal Position Sensor Learned Released Position	-	Varies	The scan tool displays percentage.
Brake Pedal Position Sensor Low Voltage During Learn	-	No	The scan tool displays No or Yes.
Brake Pedal Position Sensor Move During Learn	-	No	The scan tool displays No or Yes. This parameter displays the brake pedal sensor learn status.
Brake Pedal Position Sensor Pulled Up from Home Position	-	No	The scan tool displays No or Yes.
Brake Pedal Position Sensor Reference	-	Varies	The scan tool displays the brake pedal position as voltage value. This parameter displays the current brake pedal position sensor reference.
Brake Pedal Pulled Up from Home Position	-	No	The scan tool displays No or Yes.
Brake Pedal Pulled Up from Released Position	-	No	The scan tool displays No or Yes.
Brake Transmission Shift Interlock Solenoid Actuator	-	Inactive	The scan tool displays Active or Inactive. This parameter displays the remote start diagnostic status history.

Parameter	System State	Expected Value	Definition
Brake Transmission Shift Interlock Solenoid Actuator Command	-	Inactive	The scan tool displays Active or Inactive. This parameter displays the last remote start diagnostic status history.
Calculated Brake Pedal Position	-	Varies	The scan tool displays volts.
Calculated Brake Pedal Position	-	Varies	The scan tool displays percentage.
Calibration Part Number 1-20	-	Varies	The scan tool displays the software module calibration part number.
Center Brake Lamp Command	-	Inactive	The scan tool displays Active or Inactive. This parameter displays the center brake lamp status.
Center Stop Lamp Command	-	Inactive	The scan tool displays Active or Inactive. This parameter displays the center stop lamp status.
Central Door Lock Switch on Center Console/Passenger Door Lock Switch	-	Inactive	The scan tool displays Active or Inactive. This parameter displays the driver door lock switch status.
Child Security Lock Indicator Command	-	Inactive	The scan tool displays Active or Inactive. This parameter displays the child security lock indicator command status.
Child Security Lock Motors Command	-	Inactive	The scan tool displays Active or Inactive.
Child Security Lock/Window Lockout Switch	-	Inactive	The scan tool displays Active or Inactive.
Child Security Lock/Window Lockout Switch Indicator Command	-	Inactive	The scan tool displays Active or Inactive.
Content Theft Deterrent Alarm Status	-	Disarmed	The scan tool displays Off, Armed, or Disarmed. This parameter displays the content theft alarm status.
Content Theft Deterrent Disarmed Until Vehicle Closed	-	No	The scan tool displays No or Yes. This parameter displays the content theft deterrent system status.
Content Theft Deterrent Mode	-	Inactive	The scan tool displays Active or Inactive. This parameter displays the remote start diagnostic status history or the last remote start diagnostic status history.
Content Theft Deterrent Trigger History 1-3	-	None	The scan tool displays None, Driver door, Passenger door, Left rear door, Right rear door, Rear closure, Midgate, Tonneau Cover, Hood, Ignition Voltage, Intrusion, Inclination, Telematics enhanced service alarm, Battery reconnect detected, Unauthorized PWM change, Security Indicates Tamper, or Glass Breakage. This parameter displays the content theft deterrent trigger history status.
Courtesy Lamps Duty Cycle Command	-	Varies	This parameter displays the interior lights dimming command as a percentage.

Parameter	System State	Expected Value	Definition
Crank Abort	-	Inactive	This parameter displays the remote start diagnostic status history or the last remote start diagnostic status history.
Cruise Charging Set Level	-	Varies	This parameter displays cruise charging set level.
Cruise Control Switch Status	-	OFF	The scan tool displays CANCEL, OFF, ON, RESUME, SET or ERROR. This parameter displays the cruise control switch status.
Current Content Theft Deterrent Trigger	-	None	The scan tool displays None, Driver door, Passenger door, Left rear door, Right rear door, Rear closure, Midgate, Tonneau Cover, Hood, Ignition Voltage, Intrusion, Inclination, Telematics enhanced service alarm, Battery reconnect detected, Unauthorized PWM change, Security Indicates Tamper, Glass Breakage. This parameter displays the content theft deterrent current alarm trigger.
Current Driver	-	1-8	This parameter displays the current driver in vehicle.
Disable Battery Saver Relay Command	-	Inactive	The scan tool displays Active or Inactive.
Dome Lamp Switch	-	Inactive	The scan tool displays Active or Inactive. This parameter displays the dome lamp switch status.
Door Lock Switch	-	Inactive	The scan tool displays Active or Inactive.
Driver Door Ajar Switch	-	Inactive	The scan tool displays Active or Inactive. This parameter displays the driver door Ajar switch status.
Driver Door Key Unlock Switch	-	Inactive	The scan tool displays Active or Inactive.
Driver Door Lock Switch	-	Inactive	The scan tool displays Active or Inactive.
Driver Door Unlatch Command	-	Inactive	The scan tool displays Active or Inactive.
Driver Door Unlock Command	-	Inactive	The scan tool displays Active or Inactive. This parameter displays the driver door unlock command status.
Driver Seat Heating Switch	-	Inactive	The scan tool displays Active or Inactive.
Driver Seat Heating/Venting/Cooling Mode	-	Off	The scan tool displays On or Off.
Driver Seat Ventilation Switch	-	Inactive	The scan tool displays Active or Inactive.
Driver Window Learned	-	Yes	The scan tool displays No or Yes.
Driver Window Main Control Down Switch	-	Inactive	The scan tool displays Active or Inactive. This parameter displays the driver window main control down switch input status.

Parameter	System State	Expected Value	Definition
Driver Window Main Control Express Switch	-	Inactive	The scan tool displays Active or Inactive. This parameter displays the driver window switch express input status.
Driver Window Main Control Up Switch	-	Inactive	The scan tool displays Active or Inactive. This parameter displays the driver window switch UP input status.
Driver Window Motor Mode	-	Local Switch Overridden	The scan tool displays Down, Express Down, Express, Up, Error, Inhibit, or Local Switch Overridden. This parameter displays the driver window motor mode status.
Driver Window Motor Reversing Status	-	No	The scan tool displays No or Yes.
Driver Window Motor Sensing System Fault Status	-	No	The scan tool displays No or Yes.
Driver Window Motor Undervoltage Status	-	No	The scan tool displays No or Yes.
Enable Battery Saver Relay Command	-	Inactive	The scan tool displays Active or Inactive.
End Model Part Number	-	Varies	This parameter displays the end model part number.
Engine Stalled	-	Inactive	This parameter displays the remote start diagnostic status history or the last remote start diagnostic status history.
Environment Identification	-	Unknown	The parameter displays the vehicle environment identification successful status.
Front Fog Lamps Relay Command	-	Inactive	The scan tool displays Active or Inactive. This parameter displays the front fog lamp relay status.
Front Fog Lamps Switch	-	Inactive	The scan tool displays Active or Inactive. This parameter displays the front fog lamp switch status.
Front Passenger Window Main Control Down Switch	-	Inactive	The scan tool displays Active or Inactive. This parameter displays the front passenger window down switch status.
Front Passenger Window Main Control Express Switch	-	Inactive	The scan tool displays Active or Inactive. This parameter displays the passenger window switch express input status.
Front Passenger Window Main Control Up Switch	-	Inactive	The scan tool displays Active or Inactive. This parameter displays the passenger window switch UP input status.
Front Tire Pressure on Placard	-	Varies	The scan tool displays kPa or PSI. This parameter displays the specified tire pressure placard information programmed in the BCM for tire pressure monitoring.
Fuel Economy Mode Inhibited - Low Charging Voltage	-	Inactive	The scan tool displays Active or Inactive. This parameter displays the fuel economy mode status.
Generator Regulator Setpoint	-	Varies	The scan tool displays percentage.

Parameter	System State	Expected Value	Definition
Glove Box Unlatch Switch	-	Inactive	The scan tool displays Active or Inactive. This parameter displays the instrument panel compartment release switch status.
Hazard Lamps Switch	-	Inactive	The scan tool displays Active or Inactive. This parameter displays the hazard lamps switch status.
Hazard Lamps Switch Backlight Command	-	Varies	The scan tool displays percentage. This parameter displays hazard switch backlight level PWM command status.
Headlamps On Switch	-	Inactive	The scan tool displays Active or Inactive. This parameter displays the headlamp on switch status.
Headlamps Flash Switch	-	Inactive	The scan tool displays Active or Inactive. This parameter displays the headlamps flash to pass switch status.
Headlamp Washer Relay Command	-	Inactive	The scan tool displays Active or Inactive.
High Beam Select Switch	-	Inactive	The scan tool displays Active or Inactive. This parameter displays the high beam switch status.
High Beam Command	-	Inactive	The scan tool displays Active or Inactive. This parameter displays the high beam command status.
Hood Ajar Switch	-	Inactive	This parameter display the remote start diagnostic status history or the last remote start diagnostic status history.
Hood Ajar Switch Signal 1	-	Inactive	This parameter display the remote start diagnostic status history or the last remote start diagnostic status history.
Hood Position	-	CLOSED	The scan tool displays CLOSED, AJAR, or OPENED. This parameter displays the hood position.
Horn Relay Command	-	Inactive	The scan tool displays Active or Inactive.
Horn Switch	-	Inactive	The scan tool displays Active or Inactive.
Idle Boost Level 2-3 Counter	-	Varies	This parameter displays the state of the idle boost level as counts.
Idle Charging Set Level	-	Varies	This parameter displays idle charging set level.
Ignition Mode Switch Dimming Command	-	Varies	The scan tool displays percentage.
Ignition Switch Reference	-	Varies	This parameter displays the ignition switch voltage reference.
Ignition Switch Signal Voltage	-	Varies	This parameter displays the ignition switch signal voltage.
Ignition Switch Status	-	Inactive	This parameter displays the ignition switch status.

Parameter	System State	Expected Value	Definition
Immobilizer Allows Engine To Start	-	Unknown	The scan tool displays Unknown, Incorrect, Not Allowed, or Valid. This parameter displays the immobilizer status.
Immobilizer Automatic Learn Timer	-	Inactive	The scan tool displays Active or Inactive. This parameter displays the automatic learn timer status.
Immobilizer Environment Device 1-4	-	Unknown	The scan tool displays Incorrect, Correct, Not Received, Not Programmed or Unknown. This parameter displays the immobilizer source status.
Immobilizer Password Learn	-	Inactive	The scan tool displays Active or Inactive. This parameter displays the password learn status.
Immobilizer Password Learn Scan Tool Delay	-	Varies	This parameter displays the auto learn timer status.
Immobilizer Security Code Accepted	-	No	The scan tool displays No or Yes.
Immobilizer Security Code Lockout	-	No	The scan tool displays No or Yes.
Immobilizer Security Code Programmed	-	Yes	The scan tool displays No or Yes.
In Park Switch Status	-	On	The scan tool displays On or Off. This parameter displays the park switch status.
Inadvertent Load Command	-	Active	The scan tool displays Active or Inactive.
Indicator Dimming Duty Cycle Command	-	Varies	The scan tool displays percentage. This parameter displays indicator lighting PWM command status.
Interior/Courtesy Lighting Master Switch	-	Door	The scan tool displays Door or other lighting switch status.
Interior Trunk Lid/Liftgate Window Unlatch Switch	-	Inactive	The scan tool displays Active or Inactive.
Key Capture Solenoid Actuator	-	Active	The scan tool display Active or Inactive. This parameter displays column lock input status.
Key Fob 1-4 Battery Status	-	OK	The scan tool displays OK or other key fob battery status. This parameter displays the key fob battery status.

Parameter	System State	Expected Value	Definition
Key Fob 1-4 Function	-	Undefined	The scan tool displays Inactive, Lock, Unlock Driver Door, All Door Unlock, Release Rear Closure, Actuate Left Sliding Door, Actuate Right Sliding door, Panic Alarm, Release Fuel door, Actuate Power Windows, Actuate Folding Top, Start Engine, Stop Engine, Programmed, Locator Alarm, Close Liftgate, Open Liftgate, Stop Liftgate While Closing, Stop Liftgate While opening, Deadlock All Doors, Stop Liftgate Motion, Start Liftgate Motion, Stop Left Sliding Door Motion, Stop Right Sliding Door Motion, Comfort open, or Comfort close. This parameter displays the key fob function status.
Key Fob in Vehicle	-	Inactive	This parameter displays the current key fob in the vehicle.
Key In Cylinder Switch	-	Active	The scan tool displays Active or Inactive.
Key In Cylinder Switch/Key Fob in Vehicle	-	Yes	The scan tool displays No or Yes.
Key in Ignition Status	-	Inactive	The scan tool displays Key Out or Key In. This parameter displays the key in ignition status.
Key Part Number	-	Varies	This parameter displays the key part number.
Key Type	-	Master Key	The scan tool displays Unknown, Master Key, Valet Key, Fleet Key, or Unconfigured. This parameter displays the key type.
Last Door Lock Function	-	All Doors Lock	The scan tool displays NO Action, PC UNDB Lock, PC Unlock, Unlock, Unlock Driver, Unlock Passenger, Unlock Left Rear, Unlock Right Rear, Unlock Cargo Liftgate, Unlock Driver Side, Unlock Passenger Side, Unlock Non Driver, Unlock All, Lock All, DBL Lock, or UNDBL Lock.
LED Backlight Dimming Command	-	Varies	The scan tool displays as a percentage. This parameter displays LED backlight dimming PWM command status.
Left Brake Lamp Command	-	Varies	The scan tool displays percentage. This parameter displays left brake lamp command status.
Left Dedicated Daytime Running Lamp Command	-	Varies	The scan tool displays percentage. This parameter displays left dedicated daytime running lamp command status.
Left Front Tire Pressure	-	Varies	This parameter displays left front tire pressure in PSI.
Left Front Tire Pressure Sensor Identification	-	Varies	This parameter displays left front tire pressure sensor ID.

Parameter	System State	Expected Value	Definition
Left Front Tire Pressure Sensor Location Learned	-	Yes	The scan tool displays No or Yes. This parameter display tire pressure monitor system learned status.
Left Front Tire Pressure Sensor Mode	-	Learn Mode - Pressure Triggered	The scan tool parameter displays Learn Mode, Undefined, Remeasure Data Mode, Rolling Mode, Enter Off Mode, Exit Off Mode, or Learn Mode Pressure Triggered.
Left Front Tire Pressure Sensor Rolling Count	-	Varies	This parameter displays left front tire pressure sensor rolling count percentage.
Left Front Tire Pressure Status	-	Normal	The scan tool displays Unknown, Normal, Very Low Pressure, Low, Weak Signal, or High.
Left Front Turn Signal Bulb Out Feedback	-	Inactive	The scan tool displays Active or Inactive.
Left Front Turn Signal/Hazard Lamp Command	-	Inactive	The scan tool displays Active or Inactive.
Left Low Beam/Daytime Running Lamp Command	-	Varies	The scan tool displays percentage. This parameter displays left low beam/daytime running lamp status.
Left Park Lamps Command	-	Varies	The scan tool displays percentage. This parameter displays rear exterior lighting status.
Left Rear Child Security Lock Switch	-	Inactive	This parameter displays Active or Inactive.
Left Rear Door Ajar Switch	-	Inactive	This parameter displays Active or Inactive. This parameter displays the left rear door ajar switch status.
Left Rear Tire Pressure	-	Varies	This parameter displays left rear tire pressure in PSI.
Left Rear Tire Pressure Sensor Identification	-	Varies	This parameter displays left rear tire pressure sensor ID.
Left Rear Tire Pressure Sensor Location Learned	-	Yes	The scan tool displays No or Yes. This parameter displays tire pressure monitor system learned status.
Left Rear Tire Pressure Sensor Mode	-	Stationary	The scan tool displays Learn Mode, Undefined, Remeasure Data Mode, Rolling Mode, Enter Off Mode, Exit Off Mode, or Learn Mode Pressure Triggered.
Left Rear Tire Pressure Sensor Rolling Count	-	Varies	This parameter displays left rear tire pressure sensor rolling count percentage.
Left Rear Tire Pressure Status	-	Normal	The scan tool displays Unknown, Normal, Very Low Pressure, Low, Weak Signal, or High.
Left Rear Turn Signal Bulb Out Feedback	-	Inactive	The scan tool displays Active or Inactive. The parameter displays turn lamp outage status.
Left Rear Turn Signal/Hazard Lamp Command	-	Inactive	The scan tool displays Active or Inactive.
Left Rear Window Learned	-	Yes	The scan tool displays No or Yes.

Parameter	System State	Expected Value	Definition
Left Rear Window Main Control Down Switch	-	Inactive	The scan tool display Active or Inactive. This parameter displays driver window switch inputs.
Left Rear Window Main Control Express Switch	-	Inactive	The scan tool display Active or Inactive. This parameter displays driver window switch inputs.
Left Rear Window Main Control Up Switch	-	Inactive	The scan tool displays Active or Inactive. This parameter displays driver window switch inputs.
Left Rear Window Motor Mode	-	Local Switch Overridden	The scan tool displays Down, Express, Up, Inhibit, or Local Switch Overridden.
Left Rear Window Switch at Door	-	Inactive	The scan tool displays Active or Inactive.
Left Stop Lamp Command	-	Varies	The scan tool display percentage.
Left Turn Signal Switch	-	Inactive	The scan tool displays Active or Inactive. This parameter displays the left turn signal switch status.
License Plate Lamps Command	-	Inactive	The scan tool displays Active or Inactive.
Load Reduction Level 2-3 Counter	-	Varies	The scan tool display as counts.
Low Beam Relay Command	-	Inactive	The scan tool displays Active or Inactive. This parameter displays the headlamp low beam relay status.
Manufacturers Enable Counter	-	Varies	This parameter tool displays various counter values.
Master Keys Learned	-	Varies	This parameter displays the total number of master keys learned.
Module Diagnostic Address	-	Varies	This parameter displays module diagnostic address.
Number of Key Fobs In Vehicle	-	1	This parameter displays the number of fobs located in the vehicle.
Odometer	-	Varies	This parameter displays the vehicle mileage.
Outside Rear View Mirror Courtesy Lamp Command	-	Inactive	The scan tool displays Active or Inactive. This parameter displays front exterior lighting status.
Park Brake Switch	-	Active	The scan tool displays Active or Inactive. This parameter displays front exterior lighting status.
Park Lamps Switch	-	Inactive	The scan tool displays Active or Inactive. This parameter displays Active when the parklamp switch is activated.
Passenger Door Ajar Switch	-	Inactive	The scan tool displays Active or Inactive. This parameter displays the passenger door ajar switch status.
Passenger Door Lock Switch	-	Inactive	The scan tool displays Active or Inactive. This parameter displays the passenger door lock switch status.

Parameter	System State	Expected Value	Definition
Passenger Door Unlock Switch	-	Inactive	The scan tool displays Active or Inactive. This parameter displays the passenger door unlock switch status.
Passenger Door(s) Unlatch Command	-	Inactive	The scan tool displays Active or Inactive.
Passenger Door(s) Unlock Command	-	Inactive	The scan tool displays Active or Inactive. This parameter displays the passenger door unlock status.
Passenger Seat Heating Switch	-	Inactive	The scan tool displays Active or Inactive.
Passenger Seat Heating/Venting/Cooling Mode	-	Off	The scan tool displays On or Off.
Passenger Seat Ventilation Switch	-	Inactive	The scan tool displays Active or Inactive.
Passenger Window Learned	-	Yes	The scan tool displays No or Yes. This parameter displays the passenger window learned status.
Passenger Window Motor Mode	-	Local Switch Overridden	The scan tool displays Down, Express, Up, Inhibit, or Local Switch Overridden.
Passenger Window Switch at Door	-	Inactive	The scan tool displays Active or Inactive. This parameter displays the passenger window switch status.
Pickup Bed Cargo Lamp Command	-	Varies	The scan tool displays percentage. This parameter displays pickup bed cargo lamp command status.
Previous Key Type	-	Unknown	This parameter displays previous driver identification device type.
Primary Key Status	-	Yes	The scan tool displays No or Yes.
Push Button Ignition Switch	-	Inactive	The scan tool displays Active or Inactive.
Push Button Ignition Switch Voltage	-	Varies	This parameter displays the push button ignition switch voltage.
Rain Sensor	-	Inactive	The scan tool displays Active or Inactive.
Rear Closure Ajar Switch	-	Active	The scan tool displays Active or Inactive.
Rear Closure Cylinder Lock Switch	-	Inactive	The scan tool displays Active or Inactive.
Rear Closure Cylinder Unlock Switch	-	Inactive	The scan tool displays Active or Inactive.
Rear Tire Pressure on Placard	-	Varies	This parameter displays the rear tire pressure in kPa or PSI. This parameter displays the specified tire pressure placard information programmed in the BCM for tire pressure monitoring.
Regulated Voltage Control Mode	-	Voltage	The scan tool displays voltage.
Remote Vehicle Start Attempts Exhausted	-	Varies	This parameter displays the remote start diagnostic status history or the last remote start diagnostic status history or remaining start attempts.

Parameter	System State	Expected Value	Definition
Remote Vehicle Start Crank Time	-	Inactive	This parameter displays the remote start diagnostic status history or the last remote start diagnostic status history.
Remote Vehicle Start Disabled by Driver	-	Inactive	This parameter displays the remote start diagnostic status history or the last remote start diagnostic status history.
Remote Vehicle Start Source	-	Ignition Switch Start	The scan tool displays Ignition Switch Start or Remote Vehicle Start.
Remote Vehicle Starts Exhausted	-	Varies	This parameter displays the remote start diagnostic status history or the last remote start diagnostic status history or remaining remote starts.
Right Brake Lamp Command	-	Varies	The scan tool display percentage. This parameter displays right brake lamp PWM command status.
Right Dedicated Daytime Running Lamp Command	-	Varies	The scan tool display percentage. This parameter displays right dedicated DRL PWM command status.
Right Front Tire Pressure	-	Varies	This parameter displays right front tire pressure in PSI.
Right Front Tire Pressure Sensor Identification	-	Varies	This parameter displays right front tire pressure sensor ID.
Right Front Tire Pressure Sensor Location Learned	-	Yes	The scan tool displays No or Yes.
Right Front Tire Pressure Sensor Mode	-	Stationary	The scan tool displays Learn Mode, Undefined, Remeasure Data Mode, Rolling Mode, Enter Off Mode, Exit Off Mode or Learn Mode Pressure Triggered.
Right Front Tire Pressure Sensor Rolling Count	-	Varies	This parameter displays right front tire pressure sensor rolling count percentage.
Right Front Tire Pressure Status	-	Normal	The scan tool displays Unknown, Normal, Very Low Pressure, Low, Weak Signal, or High.
Right Front Turn Signal Bulb Out Feedback	-	Inactive	The scan tool displays Active or Inactive.
Right Front Turn Signal/Hazard Lamp Command	-	Inactive	The scan tool displays Active or Inactive.
Right Low Beam/Daytime Running Lamp Command	-	Varies	The scan tool displays percentage. This parameter displays right low beam/daytime running lamp status.
Right Park Lamps Command	-	Varies	The scan tool displays percentage. This parameter displays rear exterior lighting status.
Right Rear Child Security Lock Switch	-	Inactive	The scan tool displays Active or Inactive.
Right Rear Door Ajar Switch	-	Inactive	The scan tool displays Active or Inactive.
Right Rear Tire Pressure	-	Varies	This parameter displays right rear tire pressure in PSI.

Parameter	System State	Expected Value	Definition
Right Rear Tire Pressure Sensor Identification	-	Varies	This parameter displays right rear tire pressure sensor ID.
Right Rear Tire Pressure Sensor Location Learned	-	Yes	The scan tool displays No or Yes.
Right Rear Tire Pressure Sensor Mode	-	Learn Mode - Pressure Triggered	The scan tool displays Learn Mode, Undefined, Remeasure Data Mode, Rolling Mode, Enter Off Mode, Exit Off Mode, or Learn Mode Pressure Triggered. This parameter displays the pressure sensor mode status.
Right Rear Tire Pressure Sensor Rolling Count	-	Varies	This parameter displays right rear tire pressure sensor rolling count percentage.
Right Rear Tire Pressure Status	-	Normal	The scan tool displays Unknown, Normal, Very Low Pressure, Low, Weak Signal or High. This parameter displays the right rear tire pressure status.
Right Rear Turn Signal Bulb Out Feedback	-	Inactive	The scan tool displays Active or Inactive.
Right Rear Turn Signal/Hazard Lamp Command	-	Inactive	The scan tool displays Active or Inactive.
Right Rear Window Main Control Down Switch	-	Inactive	The scan tool displays Active or Inactive.
Right Rear Window Main Control Express Switch	-	Inactive	The scan tool displays Active or Inactive.
Right Rear Window Main Control Up Switch	-	Inactive	The scan tool displays Active or Inactive.
Right Rear Window Motor Mode	-	Local Switch Overridden	The scan tool displays Down, Express, Up, Inhibit, or Local Switch Overridden.
Right Rear Window Switch at Door	-	Inactive	The scan tool displays Active or Inactive.
Right Stop Lamp Command	-	Varies	The scan tool displays percentage.
Right Turn Signal Switch	-	Inactive	The scan tool displays Active or Inactive. This parameter displays the right turn signal switch status.
Run Abort	-	Inactive	This parameter displays the remote start diagnostic status history or the last remote start diagnostic status history.
Run Relay Command	-	Active	The scan tool displays Active or Inactive.
Run/Crank	-	Inactive	The scan tool displays Active or Inactive.
Run/Crank Relay Command	-	Active	The scan tool displays Active or Inactive.
Run/Crank Power Mode Indicator Command	-	Varies	The scan tool displays percentage. This parameter displays ignition switch run LED PWM command status.
Secondary Key Status	-	No	The scan tool displays No or Yes.
Security Indicator Command	-	Varies	The scan tool displays percentage. This parameter displays security LED PWM command status.

Parameter	System State	Expected Value	Definition
Selected Front Tire Type	-	Standard Load	The scan tool displays No Tire Type, Metric Standard Load, Metric Extra Load, Load Range C, Load Range D, or Load Range E. This parameter displays the front tire type.
Selected Rear Tire Type	-	Standard Load	The scan tool displays No Tire Type, Metric Standard Load, Metric Extra Load, Load Range C, Load Range D, or Load Range E. This parameter displays the rear tire type.
Start-Up State of Charge	-	Varies	The scan tool displays percentage. This parameter displays startup state of charge status.
State of Charge	-	Varies	The scan tool displays percentage. This parameter displays state of charge status.
Sunroof Enabled	-	Active	The scan tool displays Active or Inactive.
Sunroof Motor Overtemperature	-	Inactive	The scan tool displays Active or Inactive.
Sunroof Not Learned	-	Inactive	The scan tool displays Active or Inactive.
Sunroof Position	-	Closed	The scan tool displays Closed, Open, Venting, Comfort Open, Closing, Opening. This parameter displays the current sunroof position.
Sunroof Remote Command	-	Inactive	The scan tool displays Sunroof Secure Close, Venting, Close, or Open. This parameter displays the last sunroof remote command.
Sunroof Slide Switch	-	Inactive	The scan tool displays Inactive, Express Open, Open, Express Close, Close, Short to Ground, Short to Battery, or Stuck. This parameter displays the sunroof slide switch status.
Sunroof Tilt Switch	-	Inactive	The scan tool displays Inactive, Open, Close, Short to Ground, Short to Battery or Stuck. This parameter displays the sunroof tilt switch status. When the switch experiences a malfunction Short to Ground, Short to Battery or Stuck will be displayed.
Sunroof/Sunshade Motor Overtemperature	-	Inactive	The scan tool displays Active or Inactive.
Sunroof/Sunshade Switch	-	Inactive	The scan tool displays Inactive, Express Open, Open, Express Close, Close, Short to Ground, Short to Battery, or Stuck. This parameter displays the sunroof or sunshade switch status.
Sunshade Enabled	-	Active	The scan tool displays Active or Inactive.

Parameter	System State	Expected Value	Definition
Sunshade Not Learned	-	Inactive	The scan tool displays Active or Inactive.
Sunshade Position	-	Closed	The scan tool displays Ajar, Closed, Opened, Closing, or Opening. This parameter displays the sunshade position status.
Sunshade Remote Command	-	Inactive	The scan tool displays Close or Open. This parameter displays the last sunshade remote command.
Tamper Status	-	No	The scan tool displays No or Yes.
Telematics Enhanced Service Override Active	-	No	The scan tool displays No or Yes. This parameter displays vehicle theft deterrent system status.
Total Keys Learned	-	Varies	This parameter displays the number of keys learned.
Traction Control Switch	-	Inactive	The scan tool displays Active or Inactive. This parameter displays Active when the traction control switch is active.
Transponder Authentication	-	Initializing	The scan tool displays Inactive, Initializing, ID Received, Password Received, Data Reception Complete, or Data Transmission Complete. This parameter displays the transponder key communication status.
Transponder Key Status	-	OK	The scan tool displays OK, LIN Bus Initialization Malfunction, Antenna Initialization Malfunction, Password Error, No Valid Key Detected, LIN Bus Communication Malfunction, or Antenna Malfunction. This parameter displays the transponder key communication error status.
Trunk Lamp Command	-	Varies	The scan tool displays as percentage.
Trunk Lid/Liftgate Window Exterior Unlatch Switch	-	Inactive	The scan tool displays Active or Inactive.
Trunk Lid/Liftgate Window Unlatch Command	-	Inactive	The scan tool displays Active or Inactive.
Valet Keys Learned	-	Varies	This parameter displays the number of valet keys learned.
Valet Mode Status	-	Inactive	This parameter displays the remote start diagnostic status history or the last remote start diagnostic status history.
Valet switch	-	Inactive	The scan tool displays Active or Inactive. This parameter displays Active when the valet switch is on.
Vehicle Identification Number (VIN)	-	Varies	This parameter displays the vehicle identification number.
Window Lockout Switch	-	Inactive	The scan tool displays Active or Inactive.
Window Lockout Switch Indicator Command	-	Inactive	The scan tool displays Active or Inactive.

Parameter	System State	Expected Value	Definition
Windshield Washer Relay Command	-	Inactive	The scan tool displays Active or Inactive. This parameter displays the windshield washer relay status.
Windshield Washer Switch	-	Inactive	The scan tool displays Active or Inactive. This parameter displays the windshield washer switch status.
Windshield Wiper Park Switch	-	Active	The scan tool displays Active or Inactive.
Windshield Wiper High Speed Relay Command	-	Inactive	The scan tool displays Active or Inactive.
Windshield Wiper High Speed Switch	-	Inactive	The scan tool displays Active or Inactive.
Windshield Wiper Motor Relay Command	-	Inactive	The scan tool displays Active or Inactive. This parameter displays the windshield wiper relay status.
Windshield Wiper Stalled During Sweep	-	Inactive	The scan tool displays Active or Inactive.
Windshield Wiper Stalled in Park Position	-	Inactive	The scan tool displays Active or Inactive. This parameter displays the windshield wiper stalled status.
Windshield Wiper Switch	-	Off	The scan tool displays Off, Delay 1, Delay 2, Delay 3, Delay 4, Delay 5, or Low. This parameter displays the windshield wiper switch status.

Body Control Module Scan Tool Output Controls

Scan Tool Output Control	Description
Accent Lighting 1	The BCM activates the accent lighting when you select On. The value should be 100%. All accent lighting should illuminate until commanded Off.
Accent Lighting 2	The BCM activates the accent lighting when you select On. The value should be 100%. All accent lighting should illuminate until commanded Off.
Accessory Power Mode Indicator	The BCM activates the accessory indicator when you select On. The value should be 100%. The yellow LED accessory indicator on start button should illuminate until commanded Off.
Accessory Power Relay	The BCM actuates the accessory power relay when you select On. The accessory power relay should turn on allowing specific vehicle functions to operate.
Accessory/Retained Accessory Power Relay	The BCM actuates the retained accessory power relay when you select On. The retained accessory power relay should turn on allowing specific vehicle functions to operate.
All Doors Lock	The BCM activates all doors lock when you select Lock. All doors should lock.
All Doors Lock/Unlock	The BCM activates all doors lock/unlock when you select Lock/Unlock.
Auxiliary Ignition Run Relay	The BCM controls the Ignition Run Coil Control circuit to turn it On and Off.
Backup Lamps	The BCM actuates the backup lamps relay when you select On. The backup lamps should illuminate until commanded Off. Engine must be running.
Battery Saver Relay	The BCM activates the battery saver relay when you select Enable. This command sets the low power mode relay in the state in which it does not supply power to the non-essential parts of the vehicle. This is used to prevent the battery from being depleted when the vehicle is not used for a long period of time.

Scan Tool Output Control	Description
Brake Pedal Position Sensor Learn	The BCM activates the brake pedal position sensor learn when you select Learn. The brake pedal position sensor learn procedure should start.
Brake Transmission Shift Interlock Solenoid Actuator	The BCM activates the transmission shift interlock solenoid actuator when you select On.
Brake Transmission Shift Interlock Indicator	The BCM activates the transmission range indicator when you select On. The transmission range indicator at the shifter should illuminate until commanded Off.
Center Brake Lamp	The BCM activates the center brake lamp when you select On. The center brake lamp should illuminate until commanded Off.
Center Stop Lamp	The BCM activates the center stop lamp when you select On. The center stop lamp should illuminate until commanded Off.
Child Security Lock Indicator	The BCM activates the child security lock indicator when you select On. The child security lock indicator should illuminate until commanded Off.
Child Security Lock Motors	The BCM actuates the child security door motor when you select Lock. The child security doors should lock.
Child Security Lock/Window Lockout Switch Indicator	The BCM activates the child security lock/window lockout switch indicator when you select On. The child security lock/window lockout switch indicator should illuminate until commanded Off.
Clear Driver Window Learned Values	When you select Clear the clear driver window learn procedure should start.
Clear Passenger Window Learned Values	When you select Clear the clear left rear window learn procedure should start.
Courtesy Lamps	The BCM activates the courtesy lamps when you select On. The value should be 100%. The courtesy lamps should illuminate until commanded Off.
Driver Door Unlatch	The BCM activates the output circuit to unlatch the driver door with a passive entry passive start when you select Unlatch. There is NO door handle on this type of vehicle to open the door. Instead, there is a pad that you press to unlatch the door.
Driver Door Unlock	The BCM pulses the driver door unlock motor when you select Unlock. The driver door should unlock.
Driver Window Motor	The BCM activates the driver window motor when you select Up/Down/Stop/Express Up/Express Down. The driver window should follow the appropriate command.
Driver Window Motor Mode	The BCM activates the driver window motor when you select Up/Down/Stop/Express Up/Express Down. The driver window should follow the appropriate command.
Front Fog Lamps	The BCM actuates the front fog lamps relay when you select On. The front fog lamps relay should turn on.
Generator Regulator Setpoint	The BCM changes the output of the generator.
Hazard Lamps Switch Backlight	The BCM activates the hazard lamps switch when you select On. The value should be 100%. The hazard lamps switch backlight should illuminate until commanded Off.
High Beams	The BCM activates the high beam command when you select On. The high beam lights should illuminate. The headlamps have to be on.
Horn Relay	The BCM activates the horn when you select On. The horn should sound.
Inadvertent Load	The BCM activates the inadvertent load command when you select On. (It is an electronic request to shut down an electrical or electronic device that is drawing power from the battery at a time when there should be no activity, usually after the key has been removed from the ignition for a period of time.)

Scan Tool Output Control	Description
Incandescent Dimming	The BCM activates the incandescent light dimming when you select On. The values should be 100%. The incandescent light dimming should illuminate until commanded Off.
Indicator Dimming	The BCM activates the indicator dimming when you select On. The values should be 100%. The indicator should illuminate until commanded Off.
LED Backlight Dimming	The BCM activates the LED backlight dimming when you select On. The values should be 100%. The LED backlight dimming for control switches should illuminate until commanded Off.
Left Brake Lamp	The BCM activates the left brake lamp when you select On. The values should be 100%. The left brake lamp should illuminate until commanded Off.
Left Dedicated Daytime Running Lamp	The BCM activates the left dedicated daytime running lamp when you select ON. The value changes to 100%. The left daytime running lamp should illuminate.
Left Front Park Lamp	The BCM activates the left front park lamp when you select ON with a value of 100%. The left front park lamp should illuminate.
Left Front Park Lamp/Daytime Running Lamp	The BCM activates the left front park lamp/daytime running lamp when you select ON with a value of 100%. The left front park lamp/daytime running lamp should illuminate.
Left Front Turn Signal Lamp	The BCM activates the left front turn signal lamp when you select On. The left front turn signal lamp should illuminate until commanded Off.
Left Headlamp Lamp Low Beam	The BCM activates the left headlamp low beam when you select On. The values should be 100%. The left headlamp low beam should illuminate until commanded Off.
Left Park Lamps	The BCM activates the left park lamps when you select ON with a value of 100%. The left park lamps should illuminate.
Left Rear Park Lamp	The BCM activates the left rear park lamp when you select ON with a value of 100%. The left rear park lamp should illuminate.
Left Rear Stop/Park Lamp	The BCM activates the left rear stop/park lamp when you select ON with a value of 100%. The left rear stop/park lamp should illuminate.
Left Rear Turn Signal Lamp	The BCM activates the left rear turn signal lamp when you select On. The left rear turn signal lamp should illuminate until commanded Off.
Left Rear Turn Signal/Stop Lamp	The BCM activates the left rear turn signal/stop lamp when you select On. The left rear turn signal/stop lamp should illuminate until commanded Off.
Left Rear Window Motor	The BCM activates the left rear window motor when you select Up/Down/Stop/Express Down. The left rear window should follow the appropriate command.
Left Stop Lamp	The BCM activates the left stop lamp when you select ON with a value of 100%. The left stop lamp should illuminate.
Left Trailer Turn Signal Lamp	The BCM activates the left trailer turn signal lamp when you select ON with a value of 100%. The left trailer turn signal lamp should illuminate.
License Plate Lamps	The BCM activates the license plate lamps when you select On. The license plate lights should turn on until commanded Off.
Liftgate Unlatch	The BCM actuates the rear compartment lid release actuator when you select Unlatch. The trunk or liftgate should open.
LIN Bus Device Identification Data	When you select Update the LIN Bus Device part number and calibration part number should be updated.
Low Beam Lamps	The BCM activates the low beam lamps when you select On. The low beam lamps should turn on.
Low Beam Relay	The BCM activates the low beams when you select On. The low beam lights should turn on.

Scan Tool Output Control	Description
Outside Rear View Mirror Courtesy Lamp	The BCM activates the outside rear view mirror courtesy lamp when you select On. The outside rear view mirror courtesy lamp (at the bottom) should illuminate.
Passenger Door(s) Unlatch	The BCM activates the output circuit to unlatch the passenger door with a passive entry passive start when you select Unlatch. There is NO door handle on this type of vehicle to open the door. Instead, there is a pad that you press to unlatch the door.
Passenger Door(s) Unlock	The BCM pulses the passenger door unlock motor when you select Unlock. The passenger door should unlock.
Passenger Window Motor	The BCM activates the passenger window motor when you select Up/Down/Stop/Express Up/Express Down. The passenger window should follow the appropriate command.
Pickup Bed Cargo Lamp	The BCM activates the pickup bed cargo lamp when you select On. The values should be 100%. The pickup bed cargo lamp should illuminate until commanded Off.
Rear Fog Lamp(s) Relay	The BCM activates the rear fog lamps when you select On. The rear fog lamps should turn on.
Right Brake Lamp	The BCM activates the right brake lamp when you select On. The value should be 100%. The right brake lamp should illuminate until commanded Off.
Right Dedicated Daytime Running Lamp	The BCM activates the right dedicated daytime running lamp when you select On. The value should be 100%. The right daytime running lamp should illuminate.
Right Front Park Lamp	The BCM activates the right front park lamp when you select ON with a value of 100%. The right front park lamp should illuminate.
Right Front Park Lamp/Daytime Running Lamp	The BCM activates the right front park lamp/daytime running lamp when you select ON with a value of 100%. The right front park lamp/daytime running lamp should illuminate.
Right Front Turn Signal Lamp	The BCM activates the right front turn signal lamp when you select On. The right front turn signal/hazard lamp should illuminate.
Right Headlamp Low Beam	The BCM activates the right headlamp low beam when you select On. The right headlamp low beam should illuminate.
Right Park Lamps	The BCM activates the right park lamps when you select ON with a value of 100%. The right park lamps should illuminate.
Right Rear Park Lamp	The BCM activates the right rear park lamp when you select ON with a value of 100%. The right rear park lamp should illuminate.
Right Rear Stop/Park Lamp	The BCM activates the right rear stop/park lamp when you select ON with a value of 100%. The right rear stop/park lamp should illuminate.
Right Rear Turn Signal Lamp	The BCM activates the right rear turn signal/hazard lamp when you select On. The right rear turn signal lamp should illuminate until commanded Off.
Right Rear Turn Signal/Stop Lamp	The BCM activates the right rear turn signal/stop lamp when you select On. The right rear turn signal/stop lamp should illuminate until commanded Off.
Right Rear Window Motor	The BCM activates the right rear window motor when you select Up/Down/Stop/Express Down. The right rear window should follow the appropriate command.
Right Stop Lamp	The BCM activates the right stop lamp when you select ON with a value of 100%. The right stop lamp should illuminate.
Right Trailer Turn Signal Lamp	The BCM activates the right trailer turn signal lamp when you select ON with a value of 100%. The right trailer turn signal lamp should illuminate.
Run Relay	The BCM actuates the run relay when you select On. The run relay should turn on.
Run/Crank Relay	The BCM actuates the run/crank relay when you select On. The run/crank relay should turn on.

Scan Tool Output Control	Description
Run/Start Power Mode Indicator	The BCM activates the run/start lamp when you select On. The value should be 100%. The green LED on engine start/stop button should illuminate until commanded Off.
Security Indicator	The BCM activates the security indicator command when you select On. The security indicator at center of dash (or at DRL sensor) should illuminate until commanded Off.
Stop Lamps	The BCM activates the stop lamps when you select ON with a value of 100%. The stop lamps should illuminate.
Tire Pressure Sensors Learn	The BCM activates the tire pressure sensor learn procedure when you select Learn.
Tire Type/Pressure Selection	When you select OK, you can change tire type and load range.
Trailer Backup Lamps	The BCM activates the trailer backup lamps when you select ON with a value of 100%. The trailer backup lamps should illuminate.
Trailer Park Lamps	The BCM activates the trailer park lamps when you select ON with a value of 100%. The trailer park lamps should illuminate.
Transmission Range Indicator	The BCM activates the transmission range indicator when you select On. The transmission range indicator at the shifter should illuminate until commanded Off.
Trunk Lamp	The BCM activates the trunk lamp when you select On. The value should be 100%. The trunk lamp should illuminate until commanded Off.
Trunk Lid Unlatch	The BCM activates the trunk lid unlatch when you select On. The trunk lid should unlatch.
Window Lockout Switch Indicator	The BCM activates the window lockout switch indicator when you select On. The window lockout switch indicator should illuminate until commanded Off.
Windshield Washer Relay	The BCM actuates the windshield washer relay when you select On. The windshield washer relay should turn on.
Windshield Wiper High Speed Relay	The BCM actuates the windshield wiper high speed relay when you select On. The windshield wiper high speed relay should turn on.
Windshield Wiper Motor Relay	The BCM actuates the windshield wiper motor relay when you select On. The windshield wiper motor relay should turn on.

K17 ELECTRONIC BRAKE CONTROL MODULE: SCAN TOOL INFORMATION

The Electronic Brake Control Module (EBCM) scan tool data parameters list contains all ABS related parameters that are available on the scan tool. The list is arranged in alphabetical order. A given parameter may appear in any one of the data lists.

Electronic Brake Control Module Scan Tool Data Parameters

Parameter	System State	Expected Value	Description
Operating Conditions: Ignition ON			
ABS Pump Motor Voltage	-	0 V	The scan tool displays the commanded pump motor voltage.
Acceleration Sensor Longitudinal Signal	-	Varies	The scan tool displays 0 - 5 V depending on the vehicle's longitudinal acceleration.
Antilock Braking System	-	OK	The scan tool displays OK or Malfunction. Malfunction is displayed if there is an ABS malfunction.
Brake Booster Vacuum Sensor	-	Varies	The scan tool displays kPa (psi) This is the current vacuum.
Brake Booster Vacuum Sensor Supply	-	0 V	The scan tool displays 0 - 5 V depending on the brake booster vacuum sensor supply voltage.

Parameter	System State	Expected Value	Description
Brake Fluid Level Sensor	-	OK	The scan tool displays OK when the brake fluid is at correct level and Low when the brake fluid is low.
Brake Pedal Position Sensor	Brake pedal released	Inactive	The scan tool displays Inactive or Active depending on the state of the brake pedal.
	Brake pedal applied	Active	
Brake Pressure Sensor	Brake pedal released	0 - 1 V	The scan tool displays 0 - 5 V depending on the applied hydraulic brake pressure.
	Brake pedal applied	1 - 5 V	
Brake Pressure Sensor	Brake pedal released	2000 - 3000 kPa	The scan tool displays the actual pressure applied to the brake pedal.
Delivered Torque	-	Varies	The scan tool displays 0 - 100% depending on the how much torque the engine is delivering.
Dynamic Rear Proportioning Status	-	OK	The scan tool displays OK or Malfunction. Malfunction is displayed if the EBCM disables the dynamic rear proportioning due to a fault.
Lateral Acceleration Signal	-	Varies	The scan tool displays 0 - 5 V depending on the vehicle's lateral acceleration.
Left Front Inlet Solenoid Valve Feedback	-	Inactive	The scan tool displays Inactive or Active. Active is displayed when the left front inlet solenoid valve is commanded ON.
Left Front Outlet Solenoid Valve Feedback	-	Inactive	The scan tool displays Inactive or Active. Active is displayed when the left front outlet solenoid valve is commanded ON.
Left Front Wheel Speed Sensor	-	0 km/h (0 MPH)	The scan tool displays km/h (MPH) depending on the current speed of the left front wheel speed sensor.
Left Rear Inlet Solenoid Valve Feedback	-	Inactive	The scan tool displays Inactive or Active. Active is displayed when the left rear inlet solenoid valve is commanded ON.
Left Rear Outlet Solenoid Valve Feedback	-	Inactive	The scan tool displays Inactive or Active. Active is displayed when the left rear outlet solenoid valve is commanded ON.
Left Rear Wheel Speed Sensor	-	0 km/h (0 MPH)	The scan tool displays km/h (MPH) depending on the current speed of the left rear wheel speed sensor.
Panic Brake Assist Status	-	OK	The scan tool displays OK or Malfunction. Malfunction is displayed if the EBCM disables the panic brake assist due to a fault.
Pump Motor Relay Feedback	-	Inactive	The scan tool displays Inactive or Active. Active is displayed when the pump motor is commanded ON.
Primary Isolation Solenoid Valve Feedback	-	Inactive	The scan tool displays Inactive or Active. Active is displayed when the isolation solenoid valve is commanded ON.
Primary Prime Solenoid Valve Feedback	-	Inactive	The scan tool displays Inactive or Active. Active is displayed when the prime solenoid valve is commanded ON.
Requested Torque	-	Varies	The scan tool displays 0 - 100% depending on the how much torque is requested.

Parameter	System State	Expected Value	Description
Right Front Inlet Solenoid Valve Feedback	-	Inactive	The scan tool displays Inactive or Active. Active is displayed when the right front inlet solenoid valve is commanded ON.
Right Front Outlet Solenoid Valve Feedback	-	Inactive	The scan tool displays Inactive or Active. Active is displayed when the right front outlet solenoid valve is commanded ON.
Right Front Wheel Speed Sensor	-	0 km/h (0 MPH)	The scan tool displays km/h (MPH) depending on the current speed of the right front wheel speed sensor.
Right Rear Inlet Solenoid Valve Feedback	-	Inactive	The scan tool displays Inactive or Active. Active is displayed when the right rear inlet solenoid valve is commanded ON.
Right Rear Outlet Solenoid Valve Feedback	-	Inactive	The scan tool displays Inactive or Active. Active is displayed when the right rear outlet solenoid valve is commanded ON.
Right Rear Wheel Speed Sensor	-	0 km/h (0 MPH)	The scan tool displays km/h (MPH) depending on the current speed of the right rear wheel speed sensor.
Secondary Isolation Solenoid Valve Feedback	-	Inactive	The scan tool displays Inactive or Active. Active is displayed when the isolation solenoid valve is commanded ON.
Secondary Prime Solenoid Valve Feedback	-	Inactive	The scan tool displays Inactive or Active. Active is displayed when the prime solenoid valve is commanded ON.
Steering Column Position	Steering wheel in straight position	-5 to +5°	The scan tool displays °. This is the current position of the steering angle sensor.
	Steering wheel turned left until stop	450 - 550°	
	Steering wheel turned right until stop	-550 to -450°	
System Voltage	-	11 - 14 V	The scan tool displays V. This is the current battery voltage.
Traction Control Switch	Traction control switch released	Inactive	The scan tool displays Inactive or Active depending on the traction control switch status.
	Traction control switch pressed	Active	
Traction Control System	-	OK	The scan tool displays OK or Malfunction. Malfunction is displayed if there is a traction control malfunction.
Vehicle Stability System	-	OK	The scan tool displays OK or Malfunction. Malfunction is displayed if there is a stability control malfunction.
Vehicle Stability Enhancement System Relay Feedback	-	Active	The scan tool displays Inactive or Active. Inactive is displayed when stability control is disabled.

Parameter	System State	Expected Value	Description
Vehicle Stability Enhancement System Switch	Traction control switch released	Inactive	The scan tool displays Inactive or Active depending on the traction control switch status.
	Traction control switch pressed	Active	
Yaw Rate Signal	-	Varies	The scan tool displays 0 - 5 V depending on the vehicle's yaw rate.

Electronic Brake Control Module Scan Tool Output Controls

Output Control	Description
ABS Left Front Solenoid Valves	Commands the solenoid valves ON or OFF.
ABS Left Rear Solenoid Valves	Commands the solenoid valves ON or OFF.
ABS Pump Motor	Commands the ABS pump motor Increase or Decrease.
ABS Right Front Solenoid Valves	Commands the solenoid valves ON or OFF.
ABS Right Rear Solenoid Valves	Commands the solenoid valves ON or OFF.
Automated Brake Bleed	This is used in order to bleed ABS hydraulics.
Brake Booster Electric Vacuum Pump	Commands the brake booster electric vacuum pump motor ON or OFF.
Traction Control Left Front Solenoid Valves	Commands the solenoid valves ON or OFF.
Traction Control Left Rear Solenoid Valves	Commands the solenoid valves ON or OFF.
Traction Control Right Front Solenoid Valves	Commands the solenoid valves ON or OFF.
Traction Control Right Rear Solenoid Valves	Commands the solenoid valves ON or OFF.

K19 SUSPENSION CONTROL MODULE: SCAN TOOL INFORMATION

The suspension control module scan tool data parameters list contains all suspension control related parameters that are available on the scan tool. The list is arranged in alphabetical order. A given parameter may appear in any one of the data lists.

Suspension Control Module Scan Tool Data Parameters

Parameter	System State	Expected Value	Description
Operating Conditions: Ignition ON			
Battery Voltage	-	11 - 14 V	The scan tool displays V. This is the current battery voltage.
Left Front Damper Actuator Command	-	varies	The scan tool displays mA. This is the current applied to the left front shock absorber actuator.
Left Front Suspension Position Sensor	-	.25 -.4.75 V	The scan tool displays V. This is the signal from the left front suspension position sensor.
Right Front Damper Actuator Command	-	varies	The scan tool displays mA. This is the current applied to the right front shock absorber actuator.

Parameter	System State	Expected Value	Description
Right Front Suspension Position Sensor	-	.25 -.4.75 V	The scan tool displays V. This is the signal from the Right front suspension position sensor.
Left Rear Damper Actuator Command	-	varies	The scan tool displays mA. This is the current from the left rear shock absorber actuator.
Left Rear Suspension Position Sensor	-	.25 -.4.75 V	The scan tool displays V. This is the signal from the left rear suspension position sensor.
Right Rear Damper Actuator Command	-	varies	The scan tool displays mA. This is the current from the right rear shock absorber actuator.
Right Rear Suspension Position Sensor	-	.25 -.4.75 V	The scan tool displays V. This is the signal from the right rear suspension position sensor.
Suspension System Mode	-	varies	The scan tool displays Comfort, Sport, Normal, or Hard depending on the selected mode.
Suspension Position Sensor 5 V Reference	V	4.8 - 5.2 V	The scan tool displays V. This is the suspension position sensor supply voltage.

Suspension Control Module Scan Tool Output Controls

Output Control	Description
Left Front Damper Actuator	Commands the current applied to the left front shock absorber actuator Increase or Decrease.
Left Rear Damper Actuator	Commands the current applied to the left rear shock absorber actuator Increase or Decrease.
Right Front Damper Actuator	Commands the current applied to the right front shock absorber actuator Increase or Decrease.
Right Rear Damper Actuator	Commands the current applied to the right rear shock absorber actuator Increase or Decrease.