

High line pressure	PERFORM line pressure test. REFER to: Special Testing Procedures (307-01 Automatic Transmission - 10-Speed Automatic Transmission - 10R60) .
SSC mechanically sticking	INSTALL a new solenoid. REFER to: Shift Solenoids (SS) (307-01A Automatic Transmission, Transfer Case and Power Transfer Unit - 10-Speed Automatic Transmission â€“ 10R60, Removal and Installation).
C Clutch regulator valve sticking	DISASSEMBLE, CLEAN and INSPECT the valves. If bore or valve is damaged, INSTALL a new main control valve body. REFER to: Main Control Valve Body (307-01A Automatic Transmission, Transfer Case and Power Transfer Unit - 10-Speed Automatic Transmission â€“ 10R60, Removal and Installation). PERFORM the Transmission Strategy Download, REFER to: Transmission Strategy Download (307-01 Automatic Transmission - 10-Speed Automatic Transmission - 10R60) .
C CL CONTR hydraulic circuit blocked/leaking	DISASSEMBLE and INSPECT the main control valve body and separator plate passages for debris/blockage. CLEAN as necessary. REFER to: Main Control Valve Body (307-01A Automatic Transmission, Transfer Case and Power Transfer Unit - 10-Speed Automatic Transmission â€“ 10R60, Removal and Installation).
C clutch friction plates	DISASSEMBLE and INSPECT the transmission passages for debris/blockage. CLEAN as necessary. REFER to: Transmission (307-01B Automatic Transmission, Transfer Case and Power Transfer Unit - 10-Speed Automatic Transmission â€“ 10R80, Overhaul).
C clutch piston return springs	DISASSEMBLE and INSPECT the transmission passages for debris/blockage. CLEAN as necessary. REFER to: Transmission (307-01B Automatic Transmission, Transfer Case and Power Transfer Unit - 10-Speed Automatic Transmission â€“ 10R80, Overhaul).

D Clutch

Symptom Chart

D Clutch

For D clutch operation,
REFER to: D Clutch (307-01A Automatic Transmission, Transfer Case and Power Transfer Unit - 10-Speed Automatic Transmission â€“ 10R60, Description and Operation).

D Clutch

Condition	Possible Sources	Action
D clutch does not apply	SSD is mechanically stuck OFF	INSTALL a new solenoid. REFER to: Shift Solenoids (SS) (307-01A Automatic Transmission, Transfer Case and Power Transfer Unit - 10-Speed Automatic Transmission â€“ 10R60, Removal and Installation).
	D Clutch regulator valve stuck OFF	DISASSEMBLE, CLEAN and INSPECT the regulator valve. If bore or valve is damaged, INSTALL a new main control valve body. REFER to: Main Control Valve Body (307-01A Automatic Transmission, Transfer Case and Power Transfer Unit - 10-Speed Automatic Transmission â€“ 10R60, Removal and Installation). PERFORM the Transmission Strategy Download, REFER to: Transmission Strategy Download (307-01 Automatic Transmission - 10-Speed Automatic Transmission - 10R60)
	D CL CONTR, hydraulic circuit blocked/leaking	DISASSEMBLE and INSPECT the main control valve body and separator plate passages for debris/blockage. CLEAN as necessary. REFER to: Main Control Valve Body (307-01A Automatic Transmission, Transfer Case and Power Transfer Unit - 10-Speed Automatic Transmission â€“ 10R60, Removal and Installation).
	D clutch hub	INSPECT components wear and damage. CLEAN and/or INSTALL new components as necessary. REFER to: Transmission (307-01B Automatic Transmission, Transfer Case and Power Transfer Unit - 10-Speed Automatic Transmission â€“ 10R80, Overhaul).
	D clutch friction plates	INSPECT components wear and damage. CLEAN and/or INSTALL new components as necessary. REFER to: Transmission (307-01B Automatic Transmission, Transfer Case and Power Transfer Unit - 10-Speed Automatic Transmission â€“ 10R80, Overhaul).
	D clutch piston seals	INSPECT components wear and damage. CLEAN and/or INSTALL new components as necessary. REFER to: Transmission (307-01B Automatic Transmission, Transfer Case and Power Transfer Unit - 10-Speed Automatic Transmission â€“ 10R80, Overhaul).
D clutch always applied	SSD mechanically stuck	INSTALL a new solenoid. REFER to: Shift Solenoids (SS) (307-01A Automatic Transmission, Transfer Case and Power Transfer Unit - 10-Speed Automatic Transmission â€“ 10R60, Removal and Installation).

	D Clutch regulator valve or CL D latch valve stuck ON	DISASSEMBLE, CLEAN and INSPECT the regulator valve. If bore or valve is damaged, INSTALL a new main control valve body. REFER to: Main Control Valve Body (307-01A Automatic Transmission, Transfer Case and Power Transfer Unit - 10-Speed Automatic Transmission â€“ 10R60, Removal and Installation). PERFORM the Transmission Strategy Download, REFER to: Transmission Strategy Download (307-01 Automatic Transmission - 10-Speed Automatic Transmission - 10R60) .
	D CL CONTR, hydraulic circuit cross leaks	DISASSEMBLE and INSPECT the main control valve body and separator plate passages for debris/blockage. CLEAN as necessary. REFER to: Main Control Valve Body (307-01A Automatic Transmission, Transfer Case and Power Transfer Unit - 10-Speed Automatic Transmission â€“ 10R60, Removal and Installation).
	D clutch hub, clutch and planetary carrier, No.4 ring gear	INSPECT components wear and damage. CLEAN and/or INSTALL new components as necessary. REFER to: Transmission (307-01B Automatic Transmission, Transfer Case and Power Transfer Unit - 10-Speed Automatic Transmission â€“ 10R80, Overhaul).
	D clutch friction plates	INSPECT components wear and damage. CLEAN and/or INSTALL new components as necessary. REFER to: Transmission (307-01B Automatic Transmission, Transfer Case and Power Transfer Unit - 10-Speed Automatic Transmission â€“ 10R80, Overhaul).
	D clutch piston seals	INSPECT components wear and damage. CLEAN and/or INSTALL new components as necessary. REFER to: Transmission (307-01B Automatic Transmission, Transfer Case and Power Transfer Unit - 10-Speed Automatic Transmission â€“ 10R80, Overhaul).
D clutch delayed/soft/slipping apply	Incorrect transmission strategy programmed into PCM/ TCM.	PERFORM the Transmission Strategy Download, REFER to: Transmission Strategy Download (307-01 Automatic Transmission - 10-Speed Automatic Transmission - 10R60) .
	Low line pressure	PERFORM line pressure test. REFER to: Special Testing Procedures (307-01 Automatic Transmission - 10-Speed Automatic Transmission - 10R60) .
	SSD mechanically sticking	INSTALL a new solenoid. REFER to: Shift Solenoids (SS) (307-01A Automatic Transmission, Transfer Case and Power Transfer Unit - 10-Speed Automatic Transmission â€“ 10R60, Removal and Installation).
	D Clutch regulator valve sticking	DISASSEMBLE, CLEAN and INSPECT the valve. If bore or valve is damaged, INSTALL a new main control valve body. REFER to: Main Control Valve Body (307-01A Automatic Transmission, Transfer Case and Power Transfer Unit - 10-Speed Automatic Transmission â€“ 10R60, Removal and Installation). PERFORM the Transmission Strategy Download,
	Gain control valve stuck in default position.	DISASSEMBLE, CLEAN and INSPECT the valve. If bore or valve is damaged, INSTALL a new main control valve body. REFER to: Main Control Valve Body (307-01A Automatic Transmission, Transfer Case and Power Transfer Unit - 10-Speed Automatic Transmission â€“ 10R60, Removal and Installation). PERFORM the Transmission Strategy Download, REFER to: Transmission Strategy Download (307-01 Automatic Transmission - 10-Speed Automatic Transmission - 10R60) .
	D CL CONTR, D CL-FB2 hydraulic circuits blocked/leaking	DISASSEMBLE and INSPECT the main control valve body and separator plate passages for debris/blockage. CLEAN as necessary. REFER to: Main Control Valve Body (307-01A Automatic Transmission, Transfer Case and Power Transfer Unit - 10-Speed Automatic Transmission â€“ 10R60, Removal and Installation).
	D clutch friction plates	DISASSEMBLE and INSPECT the transmission passages for debris/blockage. CLEAN as necessary. REFER to: Transmission (307-01B Automatic Transmission, Transfer Case and Power Transfer Unit - 10-Speed Automatic Transmission â€“ 10R80, Overhaul).