


Front Active Park Assist Sensors


Removal

NOTE: LH side shown, RH side similar.

1. Remove the front wheel and tire.
Refer to: Wheel and Tire (204-04A Wheels and Tires, Removal and Installation).
2. Remove the screws and position aside the front wheel arch liner.
Torque: 22 lb.in (2.5 Nm)



3. Remove the front active parking aid sensor.
 1. Disconnect the front active park assist sensor electrical connector.
 2. Release the tabs.
 3. Remove the front active parking aid sensor.



Installation

NOTE: Make sure that the isolator rings are installed correctly while installing the sensors.

1. To install, reverse the removal procedure.
2. Carry out the azimuth system check.
Refer to: Azimuth System Check (413-13C Parking Aid - Vehicles With: Active Park Assist, General Procedures).
3. If any sensor fails the checks, diagnose the sensor fault.
Refer to: Parking Aid (413-13A Parking Aid - Vehicles With: Rear Parking Aid, Diagnosis and Testing).