

LH Rear Door Ajar Switch

Positive Lead	Measurement / Action	Negative Lead
C715-1	Ω	C2280E-46

RH Rear Door Ajar Switch

Positive Lead	Measurement / Action	Negative Lead
C820-1	Ω	C2280E-19

Is the resistance less than 3 ohms?

Yes	GO to C5
No	REPAIR the door ajar input circuit in question.

C5 CHECK FOR CORRECT BCM (BODY CONTROL MODULE) OPERATION

Disconnect and inspect all BCM connectors and related in-line connectors.

Repair:

corrosion (install new connector or terminals - clean module pins)

damaged or bent pins - install new terminals/pins

pushed-out pins - install new pins as necessary

Reconnect the BCM connectors and related in-line connectors. Make sure they seat and latch correctly.

Operate the system and determine if the concern is still present.

Is the concern still present?

Yes	CHECK OASIS for any applicable Technical Service Bulletins (TSBs). If a TSB exists for this concern, DISCONTINUE this test and FOLLOW TSB instructions. If no Technical Service Bulletins (TSBs) address this concern,
No	The system is operating correctly at this time. The concern may have been caused by module connections. ADDRESS the root cause of any connector or pin issues. CLEAR the Diagnostic Trouble Codes (DTCs).

DIAGNOSIS AND TESTING > INTERIOR LIGHTING > PINPOINT TESTS > PINPOINT TEST D : THE INTERIOR COURTESY LAMPS STAY ON CONTINUOUSLY

Refer to Interior Lamps for schematic and connector information.