

Disconnect and inspect all BCM connectors and related in-line connectors.

Repair:

corrosion (install new connector or terminals - clean module pins)

damaged or bent pins - install new terminals/pins

pushed-out pins - install new pins as necessary

Reconnect the BCM connectors and related in-line connectors. Make sure they seat and latch correctly.

Operate the system and determine if the concern is still present.

Is the concern still present?

Yes	CHECK OASIS for any applicable Technical Service Bulletins (TSBs). If a TSB exists for this concern, DISCONTINUE this test and FOLLOW TSB instructions. If no Technical Service Bulletins (TSBs) address this concern,
No	The system is operating correctly at this time. The concern may have been caused by module connections. ADDRESS the root cause of any connector or pin issues. CLEAR the Diagnostic Trouble Codes (DTCs).

DIAGNOSIS AND TESTING > INTERIOR LIGHTING > PINPOINT TESTS > PINPOINT TEST E : ONE OR MORE DEMAND LAMPS ARE INOPERATIVE

Refer to Interior Lamps for schematic and connector information.

Normal Operation and Fault Conditions

REFER to: Interior Lighting - System Operation and Component Description .

Possible Sources

- Wiring, terminals or connectors
- Demand lamp
- BCM

Visual Inspection and Diagnostic Pre-checks

- Inspect the interior lamps for damage.

DIAGNOSIS AND TESTING > INTERIOR LIGHTING > PINPOINT TESTS > PINPOINT TEST E : ONE OR MORE DEMAND LAMPS ARE INOPERATIVE > PINPOINT TEST E :