

Yes	CHECK the circuit for an intermittent short to ground. If DTC U1000:00 is present in the BCM, a successful self-test must be completed before the illumination output is enabled.
No	GO to B3

B3 CHECK FOR CORRECT BCM (BODY CONTROL MODULE) OPERATION

Disconnect and inspect all BCM and related in-line connectors.

Repair:

corrosion (install new connector or terminals - clean module pins)

damaged or bent pins - install new terminals/pins

pushed-out pins - install new pins as necessary

Reconnect the BCM and related in-line connectors and all previously disconnected illumination system connectors. Make sure all connectors seat and latch correctly.

Operate the system to determine if the concern is still present.

Is the concern still present?

Yes	CHECK OASIS for any applicable Technical Service Bulletins (TSBs). If a TSB exists for this concern, DISCONTINUE this test and FOLLOW the TSB instructions. If no Technical Service Bulletins (TSBs) address this concern, .
No	The system is operating correctly at this time. The concern may have been caused by module connections. ADDRESS the root cause of any connector or pin issues.

DIAGNOSIS AND TESTING > INSTRUMENT PANEL AND INTERIOR SWITCHES ILLUMINATION > PINPOINT TEST > PINPOINT TEST C : ONE OR MORE NON-NETWORKED ILLUMINATION SOURCE IS INOPERATIVE

Refer to Cluster and Panel Illumination for schematic and connector information.

Normal Operation and Fault Conditions

The BCM supplies pulse-width modulated voltage to the non-networked illumination sources.

Possible Sources

- Wiring, terminals or connectors
- Illuminated component

DIAGNOSIS AND TESTING > INSTRUMENT PANEL AND INTERIOR SWITCHES