

Factory Mode Deactivation

Deactivation

NOTE: During vehicle build, some modules, such as the IPC and BCM module are set in **factory mode**. Factory mode reduces the drain on the battery during longer periods where the vehicle is not used. While in the factory mode, various systems may be altered or disabled and the IPC displays **FACTORY MODE CONTACT DEALER** in the message center. If the vehicle is in factory mode, the system automatically reverts to Transport mode after 60 ignition cycles. If the IPC displays **TRANSPORT MODE CONTACT DEALER**, refer to the Transport Mode Deactivation procedure in this section.

1. Place the ignition in the OFF position.
 2. Verify the battery is fully charged.
Refer to: Battery Charging (414-01 Battery, Mounting and Cables, General Procedures).
 3. Without push button start, cycle the ignition from off to on 60 times.
 4. **NOTE:** One IKT **must** be in the vehicle.

With push button start, press the Engine Start/Stop button 120 times.
 5. Refer to the Transport Mode Deactivation procedure in this section.
Refer to: Transport Mode Deactivation (419-10 Multifunction Electronic Modules, General Procedures).
-