

Reference Value Symptom Chart

The Reference Value Symptom Chart provides guidance in selecting the appropriate parameter identification (PID) or measured signal related to the fault area. Select a symptom from the symptom chart along with the category number and go to the PID/Measured Signal Chart. For multiple symptoms, select the symptom that is the most evident.

Symptom Chart

Symptom Occurs During	Symptom	Category Number
Startup:	No start/Normal crank	1
	Hard start/Long crank	2
	Stall after start	3
	Diesels/Runs on	4
Idle:	MIL	5
	Stalls/Quits	6
	Slow	7
	Slow return	8
	Rolling	9
	Fast	10
	Rough	11
	Misses	12
Acceleration:	Stalls/Quits	6
	Misses	12
	Bucks/Jerks	13
	Hesitation	14
	Lack/Loss of power	15
	Surge	16
	Cooling system temperature	17
	Poor fuel economy	18
Cruise:	Stalls/Quits	6
	Misses	12
	Bucks/Jerks	13
	Lack/Loss of power	15
	Surge	16
	Cooling system temperature	17
	Poor fuel economy	18
Deceleration:	Stalls/Quits	6

mcx30.com