

Powertrain/Drivetrain Mount Neutralizing

Adjustment

NOTE: Refer to the appropriate section and procedure for special instructions on loosening and tightening mount fasteners.

1. Refer to: Jacking and Lifting - Overview (100-02 Jacking and Lifting, Description and Operation).
2. Loosen, but do not remove, the powertrain/drivetrain mount fasteners.
3. Lower the vehicle.
4. **NOTE:** Do not twist or strain the powertrain/drivetrain mounts or damage to the mounts may occur.

Start the vehicle and move it in forward 0.6 m (1.97 ft) - 1.2 m (3.94 ft). Then move the vehicle in reverse the same distance.

5. Refer to: Jacking and Lifting - Overview (100-02 Jacking and Lifting, Description and Operation).
 6. Tighten the powertrain/drivetrain mount fasteners.
 7. Lower the vehicle.
 8. Test the system for normal operation.
-