




REMOVAL AND INSTALLATION > CYLINDER HEAD TEMPERATURE (CHT) SENSOR > INSTALLATION

1.

To install, reverse the removal procedure.

REMOVAL AND INSTALLATION > HEATED OXYGEN SENSOR (HO2S)

Special Tool(s) / General Equipment

 E172696	303-476 (T94P-9472-A) Socket, Exhaust Gas Oxygen Sensor TKIT-1994-F TKIT-1994-FLM/FM TKIT-1994-LM/M
--	---

Materials

Name	Specification
High Temperature Nickel Anti-Seize Lubricant XL-2	-
Penetrating and Lock Lubricant XL-1	-

REMOVAL AND INSTALLATION > HEATED OXYGEN SENSOR (HO2S) > REMOVAL

All sensors