

REFERENCE VALUE SYMPTOM CHART

The Reference Value Symptom Chart provides guidance in selecting the appropriate parameter identification (PID) or measured signal related to the fault area. Select a symptom from the symptom chart along with the category number and go to the PID/MEASURED SIGNAL CHART . For multiple symptoms, select the symptom that is the most evident.

REFERENCE VALUE SYMPTOM CHART > SYMPTOM CHART

Symptom Occurs During	Symptom	Category Number
Startup:	No start/Normal crank	1
	Hard start/Long crank	2
	Stall after start	3
	Diesels/Runs on	4
Idle:	MIL	5
	Stalls/Quits	6
	Slow	7
	Slow return	8
	Rolling	9
	Fast	10
	Rough	11
	Misses	12
	Backfires	13
	Stalls/Quits	6
	Misses	12
	Bucks/Jerks	14
Acceleration:	Backfires	13
	Hesitation	15
	Lack/Loss of power	16
	Surge	17
	Spark knock	18
	Cooling system temperature	19
	Poor fuel economy	20
	Emissions compliance	21