

Yes	REMOVE the fused jumper wire. INSTALL a new generator. REFER to: Generator - 3.7L Duratec (227kW/301PS) .
No	REMOVE the fused jumper wire. GO to F9

F9 CHECK FOR CORRECT PCM (POWERTRAIN CONTROL MODULE) OPERATION

Ignition OFF.

Disconnect and inspect all PCM connectors.

Repair:

corrosion (install new connector or terminals - clean module pins)

damaged or bent pins - install new terminals/pins

pushed-out pins - install new pins as necessary

Reconnect the PCM connectors. Make sure they seat and latch correctly.

Operate the system and determine if the concern is still present.

Is the concern still present?

Yes	CHECK OASIS for any applicable Technical Service Bulletins (TSBs). If a TSB exists for this concern, DISCONTINUE this test and FOLLOW the TSB instructions. If no Technical Service Bulletins (TSBs) address this concern, INSTALL a new PCM. REFER to: Powertrain Control Module (PCM) . CLEAR all Diagnostic Trouble Codes (DTCs) in all modules.
No	The system is operating correctly at this time. The concern may have been caused by module connections. ADDRESS the root cause of any connector or pin issues.

DIAGNOSIS AND TESTING > CHARGING SYSTEM - 3.7L DURATEC (227KW 301PS) > PINPOINT TESTS (3.7L) > PINPOINT TEST G : DTC P0625 OR P0626

Refer to Charging System for schematic and connector information.

Normal Operation and Fault Conditions

The PCM monitors the generator output via the generator monitor (GENMON) circuit (generator field terminal circuit). If the PCM cannot read the GENMON circuit due to an open or short to ground, when the engine speed is greater than 2, 000 RPM, the generator defaults to a steady voltage of 13.5 volts and the PCM sends a request to the IPC to illuminate the charging system warning indicator. A GENMON duty cycle of 3% or less indicates a short to ground fault is present and results in DTC P0625 setting in the PCM. A GENMON duty cycle of 98% or more indicates an open or short to voltage fault is present and results in DTC P0626 setting in the PCM.

Diagnostic Trouble Code (DTC) Fault Trigger Conditions

DTC	Description	Fault Trigger Conditions
-----	-------------	--------------------------