

Removal and Installation

Removal

NOTE: Removal steps in this procedure may contain installation details.

1.



2. Torque: 40 Nm



Installation

1. To install, reverse the removal procedure.