

INSTRUMENT PANEL: REMOVAL - REFITTING



Note, one or more warnings are present in this procedure



Equipment required

Diagnostic tool

Locations and specifications (tightening torques, parts to always be replaced, etc.) [Dashboard assembly: Exploded view](#) .

REMOVAL

1. REMOVAL PREPARATION OPERATION

- Apply the before repair procedure using the Diagnostic tool [Diagnostic tool : Use](#) :
 - Computer concerned by the Before repair procedure:
 - "Instrument panel" .

WARNING

DANGER : Risk of serious injury due to short-circuiting or untimely triggering of an electrical system (pyrotechnic components, windscreen wiper motor, fan assembly etc.) following possible re-supply of the 12-volt supply circuit by the voltage converter.



Please follow the instructions regarding disconnection of the 12-volt supply circuit.

If the procedure fails, do not continue with your task and ask an employee who is qualified and authorised to work on a high-voltage onboard network to perform fault finding [Vehicle: Precautions for the repair](#) .

- Lockout the 12V supply circuit [12 V supply circuit : Lockout - Removal of lockout](#) .
- Unclip the dashboard centre front panel trim [Dashboard assembly: Exploded view](#) .
- Disconnect:
 - the navigation keypad connector,
 - the control panel connector.
- Remove [Dashboard assembly: Exploded view](#) :

- the dashboard centre front panel trim,
- the multifunction screen,
- the centre front panel support bolts,
- the central door locking switch,
- the hazard warning light switch,
- the centre front panel support.

- Unclip the dashboard left-hand trim [Dashboard assembly: Exploded view](#) .
- Remove the instrument panel front visor bolts [Dashboard assembly: Exploded view](#) .
- Move aside the instrument panel front visor.
- Disconnect the switch connector.
- Remove the instrument panel front visor [Dashboard assembly: Exploded view](#) .

2. REMOVAL OPERATION

- Remove the instrument panel screws [Dashboard assembly: Exploded view](#) .
- Disconnect the instrument panel connector.
- Remove the instrument panel [Dashboard assembly: Exploded view](#) .

REFITTING

1. REFITTING OPERATION

- Proceed in the reverse order to removal.

2. FINAL OPERATION

- Remove the lockout of the 12V supply circuit [12 V supply circuit : Lockout - Removal of lockout](#) .
- Apply the after repair procedure using the Diagnostic tool [Diagnostic tool : Use](#) :
-Computer concerned by the After repair procedure:
 - "Instrument panel" .

