

REAR SIDE OPENING ELEMENT: ADJUSTMENT

Location and specifications (tightening torques, parts always to be replaced, etc.)(see **Opening mechanism assembly of rear side opening element: Exploded view**) .


ADJUSTMENT VALUES

■ For information on the side opening element adjustment values(see **Vehicle panel gaps: Adjustment value**) .

■ There are two options for adjusting the rear side door:

- using the rear side door mountings,
- using the rear side door striker plates.

ADJUSTMENT




■ Respect the adjustment order of zones(1) , (2) , (3) , (4) and (5) .



Note:

Adjustment of zones (4) and (5) is only valid if the front door is correctly adjusted.



109496


□ Symbols A, B, C and D show the adjustment options.

The black dot in the centre represents the body of the bolt.

The grey section represents the component to be adjusted.

The white section represents the adjustment area.

1. HEIGHT AND LENGTH ADJUSTMENT



156967




Note:

Adjustment of zones (4) and (5) is dependent on the adjustment of the front side opening element ([see 47A, Side opening elements, Front side opening element: Adjustment](#)).

Adjust in the following order:

- the height of zones(1) and (2) .
- the length of zones(3) , (4) and (5) .

2. DEPTH ADJUSTMENT



156967



Note:

Adjustment of zones (4) and (5) is dependent on the adjustment of the front side opening element ([see 47A, Side opening elements, Front side opening element: Adjustment](#)).

Adhere to the following adjustment sequence:

- adjust the depth of zones(1), (4) and (5),
- adjust the height of the striker panel in relation to the lock to prevent them touching,
- adjust the depth of zones(2) (3).



Repair-40x10x04x08-01x67-1-5-1.xml



XSL version : 3.02 du 22/07/11