

PUBLISHED: 25-MAR-2020
2020.0 DEFENDER (LE), 501-05

INTERIOR TRIM AND ORNAMENTATION

RIGHT LOADSPACE TRIM PANEL - [+] 7 SEAT CONFIGURATION, 110 (G2417276)


mcx30.com

REMOVAL

 NOTE:


- This procedure contains some variation in the illustrations depending on the vehicle specification, but the essential information is always correct.
- This procedure contains illustrations showing certain components removed to provide extra clarity.

1.




Remove the loadspace floor trim.

2.




- Remove the 2 bolts.
- Release the 3 clips.
- Remove the loadspace lower side trim.

3.



- Remove the 2 bolts.
- Release the 4 clips.
- Remove the loadspace treadplate.

4.



- Remove the coat hanger in the sequence shown.
- Remove the bolt.

5.




- Release the 2 clips.
- Remove the domestic voltage socket trim panel.

6.

Remove the C-pillar upper trim panel.


Refer to: [C-Pillar Upper Trim Panel - 110](#) (501-05 Interior Trim and Ornamentation, Removal and Installation).

7.




- Release the 6 clips.
- Remove the Rear Junction Box (RJB) access cover.

8.



- Remove the nut.
- Release the 12 clips.
- Release the loadspace side trim panel.



- Disconnect the 3 electrical connectors.
- Remove the loadspace side trim panel.

INSTALLATION

1.



NOTE:

Make sure that the trim is correctly installed to the clips.

- Connect the 3 electrical connectors to the loadspace trim panel.
- Install the loadspace side trim panel.
- Install the 12 clips.
- Install and tighten the nut.

Torque: 4.1Nm

2.

- Install the Rear Junction Box (RJB) access cover.
- Install the 6 clips.

3.

Install the C-pillar upper trim panel.

Refer to: [C-Pillar Upper Trim Panel - 110](#) (501-05 Interior Trim and Ornamentation, Removal and Installation).

4.

- Install the domestic voltage socket trim panel.
- Install the 2 clips.

5.

- Install and tighten the coat hanger bolt.

Torque: 4.1Nm


- Install the coat hanger.

6.

- Install the loadspace treadplate.
- Install the 4 clips.
- Install and tighten the 2 bolts.

Torque: 4.1Nm

7.



Reposition the tailgate aperture seal into the correct location.

8.

- Install the loadspace lower side trim.
- Install the 3 lower clips.
- Install and tighten the 2 bolts.

Torque: 24Nm

9.

Install the loadspace floor trim.