

2022 CHEVROLET CORVETTE SERVICE MANUAL

- **SEARCH**

1. **Power and Signal Distribution**

2. **Wire and Connector Repair**

3. **Repair Instructions**

- 4.

150 Metri-Pack Series Connectors (Female)

Special Tools

- J-38125-12A

For equivalent regional tools, refer to Special Tools.

Terminal Removal Procedure

1. Click here for full size
2. Using a small screwdriver, push down on the Terminal Position Assurance (TPA) locks one at a time to remove the TPA from the connector.
3.
 - Click here for full size
 - (1) Terminal
 - (2) Connector Flex Lock
4. Once the TPA has been fully removed, locate and release the connector flex lock (2) using the terminal removal tool J-38125-12A.
5. Click here for full size
6. While terminal release tool is inserted, gently pull on the wire to remove it from the connector housing.

Terminal Installation Procedure

- Click here for full size
 - (1) Terminal
 - (2) Connector Flex Lock
1. Use the figure above to correctly orient the terminal (1) to the connector housing flex lock (2), Once the correct terminal orientation has been determined, insert the terminal (1) into the connector body until it is fully seated against the flex lock (2), an audible click should be heard or felt.
 2. Reinstall the TPA in until both tabs are fully seated in the locked position, an audible click should be heard or felt.
 3. Gently pull on the wire to ensure the locking tab is fully engaged.