

2022 CHEVROLET CORVETTE SERVICE MANUAL

- **SEARCH**

1. **Roof**
2. **Folding Top**
3. **Repair Instructions**
- 4.

Folding Top Rear Weatherstrip Replacement

Removal Procedure

1. Click here for full size
2. Headlining Rear Trim Panel (2) >> Remove - Headlining Rear Trim Panel Replacement
3. Click here for full size
4. Folding Top Rear Weatherstrip Nut (1) >> Remove [4x]
5. Click here for full size
6. Folding Top Rear Weatherstrip Bolt (1) >> Remove [2x]
7. Click here for full size
8. Folding Top Rear Weatherstrip (1) >> Remove
9. Clean the mounting area using a lint-free cloth dampened with a 50/50 mixture of isopropyl alcohol and water.

Installation Procedure

1. Click here for full size
2. Folding Top Rear Weatherstrip (1) >> Install
3. Click here for full size
4. If NEW threaded components are being installed, loosen the adhesive using a metal pick or similar tool before proceeding. If threaded components are reused, prepare the threaded components using the following steps:
5.
 1. Remove any loose cured adhesive from the external threads of the components using a lint free cloth.
 2. Thread the cleaned components into the internal mating threads and remove to loosen trapped cured adhesive.
 3. Apply thread locking adhesive to the external threads of the components. Adhesives, Fluids, Lubricants, and Sealers
 4. Ensure there are no gaps in the thread locking adhesive once applied to the component.
6. Caution:

Refer to Fastener Caution.
7. Folding Top Rear Weatherstrip Bolt (1) >> Install and tighten [2x]1.8N-m (16 lb in)
8. Click here for full size
9. Folding Top Rear Weatherstrip Nut (1) >> Install and tighten [4x]1.8N-m (16 lb in)
10. Click here for full size
11. Headlining Rear Trim Panel (2) >> Install - Headlining Rear Trim Panel Replacement
12. Water test and inspect the folding top for proper operation.