

2022 CHEVROLET CORVETTE SERVICE MANUAL

- **SEARCH**

1. [Body Repair](#)
2. [Collision Repair](#)
3. [Repair Instructions](#)
- 4.

Body Upper Rear Panel Support Replacement

Materials

- Sheet Molded Compound (SMC) Sheet Molded Compound (SMC) Panel Bonding

Removal Procedure

1. Click here for full size
2. Warning:

Refer to Approved Equipment for Collision Repair Warning
3. Warning:

Refer to Collision Sectioning Warning
4. Warning:

Refer to Glass and Sheet Metal Handling Warning.
5. Note:

The body upper rear panel support is made of (SMC), and is bonded to the rear structure. Sheet Molded Compound (SMC) Panel Bonding
6. Disable the SIR system. SIR Disabling and Enabling.
7. Remove all related panels and components.
8. Remove the sealers and anti-corrosion materials from the repair area as necessary. Anti-Corrosion Treatment and Repair
9. Click here for full size
10. Note:

Do not use open flame.
11. Note:

Heat slowly and focus heat on panel being replaced.
12. Note:

Excessive prying force may damage surrounding structure.
13. Apply heat to release adhesive (1).
14. Click here for full size
15. Note:

Excessive prying force may damage attaching panels.
16. Remove body upper rear panel support (1) from vehicle.
17. Note:

The location of adhesive for installation.
18. Note:

Do not damage body structure when removing adhesive.

19. Remove remaining adhesive from body structure.

Installation Procedure

1. [Click here for full size](#)
2. Note:

Temporarily install replacement part.

3. Position body upper rear panel support (1) on vehicle using three-dimensional measuring equipment.
4. Remove body upper rear panel support (1) from vehicle.
5. [Click here for full size](#)
6. Note:

Shims may be necessary to achieve proper panel alignment. Use care to keep shims out of adhesive path.

7. Note:

Accurate and timely assembly methods must be used in order to meet proper bonding requirements.

8. Note:

Dry fit all parts with proper clamping devices prior to final assembly to ensure full understanding of the assembly process.

9. Note:

When using adhesive, ensure all necessary tools and materials are in place prior to final assembly.

10. Clean and prepare mating surfaces on structure and replacement part according to adhesive manufacturer's recommendations. Sheet Molded Compound (SMC) Panel Bonding
11. Apply structural adhesive (1) to mating surfaces on structure and replacement part according to adhesive manufacturer's recommendations. Sheet Molded Compound (SMC) Panel Bonding
12. [Click here for full size](#)
13. Install body upper rear panel support (1) on vehicle and clamp into place.
14. Remove excess adhesive.
15. Apply the sealers and anti-corrosion materials to the repair area as necessary. Anti-Corrosion Treatment and Repair
16. Paint the repaired area. Basecoat/Clearcoat Paint Systems.
17. Install all related panels and components.
18. Enable the SIR System. SIR Disabling and Enabling.