

2022 CHEVROLET CORVETTE SERVICE MANUAL

- **SEARCH**

1. **Body Systems**
2. **Lighting**
3. **Repair Instructions**
- 4.

Front Headlamp Adjustment

1. Headlamp Bolt @ Front Headlamp >> Loosen [3x]
2. Headlamp Bolt @ Front Headlamp Compensation Nut >> Loosen
3. Click here for full size
4. Adjust the headlamp (1) in order to obtain an even gap between the headlamp (1) and the fender, Fascia, and the hood and so that the headlamp (1) is flush with the fender, Fascia, and the hood.
5.
 - Headlamp to fender (A) to (B) 1.5 mm $\tilde{\Delta}\pm 1.0$ mm (0.019 in $\tilde{\Delta}\pm 0.098$ in)
 - Headlamp to fender (B) to (C) 2.8 mm $\tilde{\Delta}\pm 1.0$ mm (0.070 in $\tilde{\Delta}\pm 0.149$ in)
 - Headlamp to fender (C) to (D) 1.5 mm $\tilde{\Delta}\pm 1.0$ mm (0.019 in $\tilde{\Delta}\pm 0.098$ in)
 - Headlamp to fascia (F) 1.5 mm $\tilde{\Delta}\pm 1.0$ mm (0.019 in $\tilde{\Delta}\pm 0.098$ in)
 - Headlamp to fascia (E) 1.5 mm $\tilde{\Delta}\pm 1.0$ mm (0.019 in $\tilde{\Delta}\pm 0.098$ in)
6. Caution:
Refer to Fastener Caution.
7. Headlamp Bolt @ Front Headlamp Compensation Nut >> Install and tighten 9>N-m (80 lb in)
8. Headlamp Bolt @ Front Headlamp >> Install and tighten [3x]2.5N-m (22 lb in)
9. Adjust the front fascia and fender as necessary.