

2022 CHEVROLET CORVETTE SERVICE MANUAL

- **SEARCH**

1. **Engine/Propulsion**
2. **Engine Controls and Fuel - 6.2L (LT2)**
3. **Repair Instructions**
- 4.

Evaporative Emission Canister Purge Front Pipe Replacement (Convertible)

Warning:

Refer to Diesel/Gasoline Vapors Warning.

Warning:

Refer to Safety Glasses Warning.

Removal Procedure

1. Click here for full size
2. Rear Window Panel (2>) >> Remove - Rear Window Panel Replacement
3. Disconnect the evaporative emission canister purge solenoid valve electrical connector.
4. Click here for full size
5. Evaporative Emission Canister Purge Solenoid Valve Bolt (1>) >> Remove
6. Click here for full size
7. Evaporative Emission Canister Purge Front Pipe (1>) @ Evaporative Emission Canister Vent Pipe Clip (2>) >> Remove [4>x]
8. Click here for full size
9. Evaporative Emission Canister Vent Pipe Clip (1>) >> Remove
10. Click here for full size
11. Fuel Feed and Evaporative Emission Pipe Clip Nut (1>) >> Remove
12. Evaporative Emission Canister Purge Front Pipe (2>) >> Disconnect - Metal Collar Quick Connect Fitting Service
13. Click here for full size
14. Remove the evaporative emission canister purge front pipe and evaporative emission canister purge solenoid valve (1) together as an assembly.

Installation Procedure

1. Click here for full size
2. Install the evaporative emission canister purge front pipe and evaporative emission canister purge solenoid valve (1) together as an assembly.
3. Click here for full size
4. Evaporative Emission Canister Purge Front Pipe (2>) >> Connect - Metal Collar Quick Connect Fitting Service
5. **Caution:**
Refer to Fastener Caution.
6. Fuel Feed and Evaporative Emission Pipe Clip Nut (1>) >> Install and tighten 4.7N-m (42 lb in)
7. Click here for full size
8. Evaporative Emission Canister Vent Pipe Clip (1>) >> Install

8. Evaporative Emission Canister Vent Pipe Clip (1>) >> Install
9. [Click here for full size](#)
10. Evaporative Emission Canister Purge Front Pipe (1>) @ Evaporative Emission Canister Vent Pipe Clip (2>) >> Install [4>x]
11. [Click here for full size](#)
12. Evaporative Emission Canister Purge Solenoid Valve Bolt (1>) >> Install and tighten 10N-m (89 lb in)
13. Connect the evaporative emission canister purge solenoid valve electrical connector.
14. [Click here for full size](#)
15. Rear Window Panel (2>) >> Install - Rear Window Panel Replacement

mcx30.com