

continue. If directed to this step from the above alarm activation steps for vehicles without a keyless entry keypad, select "Erase Keys."

6. **NOTE:** *If programming a passive key (vehicles with push-button start), refer to the Owner's Literature for the passive key backup starting location. The passive key must be placed in this location to successfully program.*

Return to the diagnostic scan tool window and follow the on-screen instructions. The door locks and hazard flashers cycle to indicate when a key is successfully programmed. After programming the first key and selecting OK, place the second key in the backup starting location and select "Program Key" to program the second key. Start the vehicle; if it will not start, select PATS Functions and perform a parameter reset or module initialization for the BCM, the PCM, SOBDMC (if equipped), or the ABS module (if equipped) as necessary. If the vehicle will still not start, perform the procedure again starting at step 1.

mcx30.com