



Pickup Bed Upper Rail Moulding

6.

Using a non-marring trim tool, carefully detach the retainers along the length of the moulding and remove the moulding.



REMOVAL AND INSTALLATION > BODYSIDE MOULDING > INSTALLATION

1.

To install, reverse the removal procedure.

REMOVAL AND INSTALLATION > FRONT DOOR UPPER MOULDING > REMOVAL



NOTE: Removal steps in this procedure may include installation details.

LH side shown, RH side similar.

All vehicles

1.

Lower the door window glass.