

REMOVAL AND INSTALLATION > TURBOCHARGER COOLANT SUPPLY TUBE RH

Materials

Name	Specification
Motorcraft® Orange Concentrated Antifreeze/Coolant VC-3-B	WSS-M97B44-D

REMOVAL AND INSTALLATION > TURBOCHARGER COOLANT SUPPLY TUBE RH > REMOVAL



NOTE: Whenever turbocharger air intake system components are removed, always cover open ports to protect from debris. It is important that no foreign material enter the system. The turbocharger compressor vanes are susceptible to damage from even small particles. All components should be inspected and cleaned, if necessary, prior to installation or reassembly.

1.

With the vehicle in NEUTRAL, position it on a hoist. REFER to: Jacking and Lifting - Overview .

2.

If equipped, remove the retainers and the transmission housing cover.



3.



NOTE: Vehicles come with a skid plate or a splash shield.



NOTE: Skid plate shown in illustration, splash shield similar.

If equipped, remove the bolts and the skid plate or splash shield.