

B-Pillar Trim Panel - SuperCab

Base Part Number: Base Part Number: 24356


Removal

NOTE: LH side shown, RH side similar.


NOTE: Removal steps in this procedure may contain installation details.

1. **NOTE:** The seat is removed for clarity.


Release the clips and remove the scuff plate trim panel.



2. Position aside the rear door weatherstrip.




E193482



3. Remove the bolt and position aside the seatbelt.
Torque: 30 lb.ft (40 Nm)



E193479




4. **NOTE:** If the tether clip is damaged during removal, a new clip must be installed prior to installation of the panel.

NOTE: During installation make sure to install the clip by the scuffplate trim panel first and work upward on the trim panel to connect the other clips.

Remove the B-pillar trim panel.

1. Release the clips.
2. Release the tether clip and remove the B-pillar trim panel.





Installation

1. **NOTE:** *During installation, make sure the seatbelt webbing is not twisted and the seatbelts and buckles are accessible to the occupants.*

To install, reverse the removal procedure.

Copyright © 2018 Ford Motor Company

mcx30.com