



Front Toe Adjustment - F-250/F-350, RWD

Adjustment


1. Using alignment equipment and the manufacturer's instructions, measure the toe settings.
 - Refer to Alignment Specifications in the Specifications portion of this section for optimal alignment settings.
Refer to: Front Toe Adjustment - F-250/F-350, RWD (204-00 Suspension System - General Information, General Procedures).
 - If the toe settings are not within specification, go to the next step.
2. Start the engine and center the steering wheel.
3. Steering wheel in straight ahead position.



4. On both sides. Loosen the tie rod adjuster sleeve nuts.
Torque: 41 lb.ft (55 Nm)



5. On both sides. Rotate the tie rod adjusting sleeve to obtain the correct toe setting.



6. Verify the toe settings and adjust as necessary.

mcx30.com