

Intermediate pipe: Removal - Refitting

K9K

REFITTING

I - REFITTING OPERATION

- ☐ Refit the intermediate pipe.
- ☐ Refit the exhaust sleeves (see **19B, Exhaust, Exhaust: Precautions for the repair**, page **19B-6**).

WARNING

Make sure:

- that the sleeve nut-bolt tightening assembly is vertical, with the nut facing downwards, to prevent any risk of underbody contact,
- that you position the new component in a way that the cutting area marks are aligned,
- that the two marks are flush with the two ends of the sleeve,
- that an old sleeve is not reused.

- ☐ Torque tighten the **exhaust sleeve bolts (25 N.m)**.
- ☐ Refit the rubber mounting bush of the intermediate pipe.

II - FINAL OPERATION

- ☐ Check:
 - that all the exhaust pipe heat shields are in place and properly attached,
 - that there is no contact with the underbody.