

Expansion chamber: Removal - Refitting

II - FINAL OPERATION.

☐ Check:

- that all the exhaust pipe heat shields are in place and properly attached,
- that there is no contact with the underbody.

WARNING

Make sure:

- that the sleeve « nut-bolt tightening » assembly is vertical, with the nut facing downwards, to prevent any risk of underbody contact,
- that you position the new component in a way that the cutting area marks are aligned,
- that the two marks are flush with the two ends of the sleeve,
- that an old sleeve is not reused.
- that the bolts securing the rubber mounting bushes to the exhaust pipe have been replaced with new ones.