



Component Location



1. Crash pad air vent [LH]

2. Crash pad air vent [RH]

Rate this Document

☐ Document Type : SHOP

☐ Document Rating :

Please rate the above contents on a scale of 1 to 5.

Little Value	1	2	3	4	5	Excellent Value