

FRONT DISC BRAKE (G2400937)

DIAGNOSIS AND TESTING

PRINCIPLES OF OPERATION

For additional diagnosis and testing information, refer to the relevant Diagnosis and Testing section in the workshop manual. REFER to: [Brake System](#) (206-00 Brake System - General Information, Diagnosis and Testing).

DTC INDEX

For a list of diagnostic trouble codes (DTCs) that could be set on this vehicle, please refer to Section 100-00. REFER to: [Diagnostic Trouble Code Index - DTC: Anti-Lock Brake System Control Module \(ABS\)](#) (100-00 General Information, Description and Operation).