

STEERING COLUMN (G2344337)


SPECIFICATIONS

Torque Specifications

NOTE:

Numbers with a green background are a single use component.

COMPONENT TORQUE LOCATION



	DESCRIPTION	NM	LB-FT	LB-IN
1	Steering column flexible coupling bolt	30	22	-
2	Steering column retaining bolts	20	15	-
3	Steering wheel bolt	47	35	-
4	Steering column multifunction switch retaining bolts	10	-	88
5	Steering column lower trim panel mounting bolts	2	-	44