

PUBLISHED: 24-SEP-2019
2020.0 DEFENDER (LE), 415-01

INFORMATION AND ENTERTAINMENT SYSTEM

LOADSPACE SPEAKER (G2414942)

mcx30.com

REMOVAL


 NOTE:

- This procedure contains some variation in the illustrations depending on the vehicle specification, but the essential information is always correct.
- This procedure contains illustrations showing certain components removed to provide extra clarity.
- This procedure contains illustrations for the left side components, right side components are similar.

1. Remove the headliner.

Refer to: [Headliner - 110](#) (501-05 Interior Trim and Ornamentation, Removal and Installation).

- 2.



- Disconnect the electrical connector.
- Remove the 3 bolts.
- Remove the loadspace speaker.

INSTALLATION

1.

- Install the loadspace speaker.

- Install and tighten the 3 bolts.

Torque: 1.7Nm

- Connect the electrical connector to the loadspace speaker.

2.

Install the headliner.

Refer to: [Headliner - 110](#) (501-05 Interior Trim and Ornamentation, Removal and Installation).

cmjjaGFyZG1vcnRvbjsyMDIwLTASLTE4VDEwOjE4OjA2LjMxOFo7OTluND AuMTg5LjUzOw==

mcx30.com