

PUBLISHED: 24-JUL-2020
2020.0 DEFENDER (LE), 415-01

INFORMATION AND ENTERTAINMENT SYSTEM

WIFI ANTENNA – RIGHT HAND DRIVE (G2725742)

mcx30.com

REMOVAL

 CAUTION:

Do not use excessive force to remove the component. Make sure that all fixings are fully released.

 NOTE:

- This procedure contains illustrations showing certain components removed to provide extra clarity.
- This procedure contains some variation in the illustrations depending on the vehicle specification, but the essential information is always correct.
- Make sure that the retaining clips are correctly installed.


1. Disconnect the startup battery ground cable.

Refer to: [Startup Battery Disconnect and Connect](#) (414-00 Battery and Charging System - General Information, General Procedures).

2. Remove the instrument panel lower trim.

Refer to: [Instrument Panel Lower Trim](#) (501-12 Instrument Panel and Console, Removal and Installation).

3.



- Release the 2 clips.
- Remove the WiFi antenna.

INSTALLATION

1. Install the WiFi antenna.

2. Install the instrument panel lower trim.

Refer to: [Instrument Panel Lower Trim](#) (501-12 Instrument Panel and Console, Removal and Installation).

3. Connect the startup battery ground cable.

Refer to: [Startup Battery Disconnect and Connect](#) (414-00 Battery and Charging System - General Information, General Procedures).