

PUBLISHED: 19-NOV-2019
2020.0 DEFENDER (LE), 501-10

SEATING

FRONT ROW SEAT BACKREST HEATER ELEMENT

[G2413865]

mcx30.com

REMOVAL

 NOTE:

- This procedure contains illustrations showing certain components removed to provide extra clarity.
- This procedure contains some variation in the illustrations depending on the vehicle specification, but the essential information is always correct.


1. Disconnect the startup battery ground cable.

Refer to: [Startup Battery Disconnect and Connect](#) (414-00 Battery and Charging System - General Information, General Procedures).

2. Remove the front row seat backrest cover.

Refer to: [Front Row Seat Backrest Cover](#) (501-10 Seating, Removal and Installation).

- 3.



Disconnect the electrical connector.

4.



Remove the front row seat backrest heater element.

INSTALLATION

1. Install the heater element to the seat backrest.

2. Connect the electrical connector to the heater element.

3. Install the front row seat backrest cover.

Refer to: [Front Row Seat Backrest Cover](#) (501-10 Seating, Removal and Installation).

4. Connect the startup battery ground cable.

Refer to: [Startup Battery Disconnect and Connect](#) (414-00 Battery and Charging System - General Information, General Procedures).