

PUBLISHED: 20-JAN-2020
2020.0 DEFENDER (LE), 501-10

SEATING

SECOND ROW SEAT BACKREST HEATER ELEMENT

[G2414594]

mcx30.com

REMOVAL

 NOTE:


- This procedure contains illustrations showing certain components removed to provide extra clarity.
- This procedure contains some variation in the illustrations depending on the vehicle specification, but the essential information is always correct.
- This procedure contains illustrations for right side components, left side components are similar.

1. Disconnect the startup battery ground cable.

Refer to: [Startup Battery Disconnect and Connect](#) (414-00 Battery and Charging System - General Information, General Procedures).


2. Remove the second row seat backrest cover.

Refer to: [Second Row Seat Backrest Cover - 110](#) (501-10 Seating, Removal and Installation).



- Disconnect the electrical connector.
- Remove the second row seat backrest.

4.



Remove the second row seat backrest heater element.

INSTALLATION

1. Install the second row seat backrest heater element.

- 2.
- Connect the electrical connector to second row seat.
 - Install the second row seat backrest.

3. Install the second row seat backrest cover.

Refer to: [Second Row Seat Backrest Cover - 110](#) (501-10 Seating, Removal and Installation).

4. Connect the startup battery ground cable.

Refer to: [Startup Battery Disconnect and Connect](#) (414-00 Battery and Charging System - General Information, General Procedures).