

2022 CHEVROLET CORVETTE SERVICE MANUAL

- SEARCH

1. Body Hardware and Trim
2. Instrument Panel and Console Trim
3. Description and Operation
- 4.

Front Floor Console Description and Operation

Front Floor Console System Components

- Body control module (BCM)
- Floor console lock actuator

The locking and unlocking of the front floor console is a function of the power door lock system. The floor console lock actuator is supplied by the door lock control circuit and the driver door unlock control circuit. The BCM, upon receipt of a lock switch lock or unlock signal, will supply battery voltage to the door lock actuator lock or unlock control circuits. Since the opposite side of the lock actuator is connected to ground through the other lock actuator control circuit, the doors and front floor console will then lock or unlock as commanded.