

2022 CHEVROLET CORVETTE SERVICE MANUAL

- SEARCH

1. Body Hardware and Trim
2. Instrument Panel and Console Trim
3. Description and Operation
- 4.

Instrument Panel Compartment Description and Operation

Instrument Panel Compartment Door Release System Components

- Body control module (BCM)
- Instrument panel compartment door release switch
- Instrument panel compartment door latch actuator
- Instrument panel compartment door latch actuator relay

Instrument Panel Compartment Door Release Operation

Note :

This function may be disabled if the valet mode has been activated

When the instrument panel compartment door release switch is pressed, the instrument panel compartment release switch signal circuit is switched to ground. The BCM responds by applying battery voltage to the relay control circuit which energizes the relay, the relay switch contacts close allowing battery voltage to be supplied to the instrument panel compartment door latch actuator causing the actuator to release.