

2022 CHEVROLET CORVETTE SERVICE MANUAL

- **SEARCH**

1. [Engine/Propulsion](#)
2. [Exhaust](#)
3. [Repair Instructions](#)
- 4.

Exhaust Manifold Lower Heat Shield Replacement - Upper Right Side (Convertible)

Warning:


In order to avoid being burned, do not service the exhaust system while it is still hot. Service the system when it is cool.

Warning:


Avoid contact with HOT components. Wear safety glasses and protective gloves to avoid personal injury.

Removal Procedure


1. [Click here for full size](#)
2. [Rear Window Panel \(2\) >> Remove - Rear Window Panel Replacement](#)



3. [Click here for full size](#)
4. [Load Floor Panel Rear Cross Bar - Right Side \(1\) >> Remove - Load Floor Panel Rear Cross Bar Replacement - Right Side](#)



5. [Click here for full size](#)
6. Exhaust Manifold Inner Heat Shield - Right Side (1) >> Remove - Exhaust Manifold Inner Heat Shield Replacement - Right Side




7. [Click here for full size](#)
8. Exhaust Manifold Heat Shield Bolt (1) >> Remove [2x]
9. [Click here for full size](#)
10. Exhaust Manifold Lower Heat Shield - Lower Right Side (1) >> Remove - Exhaust Manifold Lower Heat Shield Replacement - Lower

Right Side


11. [Click here for full size](#)
12. Exhaust Manifold Lower Heat Shield - Upper Right Side (1) >> Remove

Installation Procedure

1. [Click here for full size](#)
2. Exhaust Manifold Lower Heat Shield - Upper Right Side (1) >> Install
3. [Click here for full size](#)
4. Exhaust Manifold Lower Heat Shield - Lower Right Side (1) >> Install - Exhaust Manifold Lower Heat Shield Replacement - Lower Right Side




5. [Click here for full size](#)
6. Caution:
Refer to Fastener Caution.
7. Exhaust Manifold Heat Shield Bolt (1) >> Install and tighten [2x]10 N-m (89 lb in)



8.
[Click here for full size](#)

9. Exhaust Manifold Inner Heat Shield - Right Side (1) >> [Install - Exhaust Manifold Inner Heat Shield Replacement - Right Side](#)



10.
[Click here for full size](#)

11. Load Floor Panel Rear Cross Bar - Right Side (1) >> [Install - Load Floor Panel Rear Cross Bar Replacement - Right Side](#)

12. [Click here for full size](#)

13. Rear Window Panel (2) >> [Install - Rear Window Panel Replacement](#)

