

2022 CHEVROLET CORVETTE SERVICE MANUAL

- SEARCH

1. General Information

2. Maintenance and Lubrication

3. Maintenance

- 4.

GM Air Filter Life System Resetting (With Scan Tool)

Description

This feature provides the engine air filter's remaining life and best timing for a change. The timing to change an engine air filter depends on driving and environmental conditions. When the Driver Information Center (DIC) displays a message to replace the engine air filter at the next oil change, follow this timing. When the DIC displays a message to replace the engine air filter soon, replace the engine air filter at the earliest convenience. The system must be reset after the engine air filter is changed. If the DIC displays a message to check the engine air filter system, reset the system on DIC or use Scan Tool to reset.

When to Perform the Procedure

Perform this procedure when the following component has been serviced:

- K20 Engine Control Module - Replaced
- Engine - Air Cleaner Element >> Replaced

Conditions for Running the Procedure

- Engine = Off
- Ignition = On
- Vehicle Speed = 0> km/h (0> MPH)

(If applicable) With Scan Tool

Note:

If the system can not be reset on DIC, use Scan Tool to reset

1. Ignition >> On / Vehicle >> In Service Mode
2. Select: Module Diagnostics
3. Select: K20 Engine Control Module
4. Select: Control Functions
5. Select: Engine Air Filter Monitor Setup
6. Select: Reset