


2022 CHEVROLET CORVETTE SERVICE MANUAL

- SEARCH


1. HVAC
2. **Heating, Ventilation, and Air Conditioning**
3. **Repair Instructions**
- 4.

Front Floor Console Auxiliary Cooling Duct Replacement (K4C)


Removal Procedure



1.
[Click here for full size](#)
2. Remove the left instrument panel outer trim cover (1). Instrument Panel Outer Trim Cover Replacement



3.
[Click here for full size](#)
4. Instrument Panel Knee Bolster (2) >> Remove - Instrument Panel Knee Bolster Replacement




5.
[Click here for full size](#)

6. Radio Rear Quarter Trim Panel Speaker Grille (1) >> Remove - Radio Rear Quarter Trim Panel Speaker Grille Replacement




7.
[Click here for full size](#)

8. Rear Compartment Closeout Panel (1) >> Remove - Rear Compartment Closeout Panel Replacement




9.
[Click here for full size](#)

10. Front Floor Rear Console Side Trim Panel - Left Side (1) >> Remove - Front Floor Rear Console Side Trim Panel Replacement - Left Side




11.
[Click here for full size](#)

12. Front Floor Rear Console Side Trim Panel - Right Side (1) >> Remove - Front Floor Rear Console Side Trim Panel Replacement - Right Side




13.
[Click here for full size](#)

14. Front Floor Console Applique - Left Side (2) >>> Remove - Front Floor Console Applique Replacement - Left Side




15.
[Click here for full size](#)


16. Front Floor Console Extension Panel (2) >>> Remove - Front Floor Console Extension Panel Replacement



17. [Click here for full size](#)
18. Disconnect the electrical connectors.
19. Front Floor Console Compartment (1) >> Remove - Front Floor Console Compartment Replacement




20. [Click here for full size](#)
21. Front Floor Console Auxiliary Cooling Duct Retainer (1) >> Remove [2x]
22. Front Floor Console Rear Air Duct Bolt (2) >> Remove [2x]



23.
[Click here for full size](#)


24. Front Floor Console Auxiliary Cooling Duct (1) >> Remove

Installation Procedure




1.
[Click here for full size](#)


2. Front Floor Console Auxiliary Cooling Duct (1) >> Install



3. [Click here for full size](#)
4. Caution:
Refer to Fastener Caution.
5. Front Floor Console Rear Air Duct Bolt (2) >> Install and tighten [2x]2.5 N-m (22 lb in)
6. Front Floor Console Auxiliary Cooling Duct Retainer (1) >> Install [2x]




7. [Click here for full size](#)
8. Front Floor Console Compartment (1) >> Install - Front Floor Console Compartment Replacement
9. Connect the electrical connectors.




10.
[Click here for full size](#)

11. Front Floor Console Extension Panel (2) >>> Install - Front Floor Console Extension Panel Replacement




12.
[Click here for full size](#)

13. Front Floor Console Applique - Left Side (2) >>> Install - Front Floor Console Applique Replacement - Left Side




14. [Click here for full size](#)

15. Front Floor Rear Console Side Trim Panel - Right Side (1) >> Install - Front Floor Rear Console Side Trim Panel Replacement - Right Side




16. [Click here for full size](#)

17. Front Floor Rear Console Side Trim Panel - Left Side (1) >> Install - Front Floor Rear Console Side Trim Panel Replacement - Left Side




18.
[Click here for full size](#)

19. Rear Compartment Closeout Panel (1) >> Install - Rear Compartment Closeout Panel Replacement




20.
[Click here for full size](#)

21. Radio Rear Quarter Trim Panel Speaker Grille (1) >> Install - Radio Rear Quarter Trim Panel Speaker Grille Replacement



22.
[Click here for full size](#)

23. Instrument Panel Knee Bolster (2) >> Install - Instrument Panel Knee Bolster Replacement



24.
[Click here for full size](#)

25. Install the left instrument panel outer trim cover (1).Instrument Panel Outer Trim Cover Replacement