


2022 CHEVROLET CORVETTE SERVICE MANUAL

- SEARCH


1. HVAC
2. **HVAC - Automatic**
3. **Repair Instructions**
- 4.

Floor Air Temperature Sensor Replacement - Left Side


Removal Procedure



1.
Click here for full size
2. Remove the left and right instrument panel outer trim cover (1). Instrument Panel Outer Trim Cover Replacement



3.
Click here for full size
4. Instrument Panel Knee Bolster (2) >> Remove - Instrument Panel Knee Bolster Replacement




5.
[Click here for full size](#)

6. Radio Rear Quarter Trim Panel Speaker Grille (1) >> Remove - Radio Rear Quarter Trim Panel Speaker Grille Replacement




7.
[Click here for full size](#)

8. Rear Compartment Closeout Panel (1) >> Remove - Rear Compartment Closeout Panel Replacement




9.
[Click here for full size](#)

10. Front Floor Console Applique - Left Side (2) >>> Remove - Front Floor Console Applique Replacement - Left Side




11.
[Click here for full size](#)

12. Front Floor Console Extension Panel (2) >>> Remove - Front Floor Console Extension Panel Replacement




13.
[Click here for full size](#)

14. Front Floor Console Compartment (1) >> Remove - Front Floor Console Compartment Replacement




15.
[Click here for full size](#)

16. Instrument Panel Compartment (1) >> Remove - Instrument Panel Compartment Replacement




17.
[Click here for full size](#)

18. Radio Front Center Speaker Grille (1) >> Remove - Radio Front Center Speaker Grille Replacement




19.
[Click here for full size](#)

20. Instrument Panel Instrument Cluster Hood (1) >> Remove - Instrument Panel Instrument Cluster Hood Replacement




21.
[Click here for full size](#)

22. Instrument Panel Extension (1) >> Remove - Instrument Panel Extension Replacement




23.
[Click here for full size](#)

24. Instrument Panel Upper Trim Panel (1) >> Remove - Instrument Panel Upper Trim Panel Replacement




25.
[Click here for full size](#)

26. Instrument Panel Trim Pad (2) >> Remove - Instrument Panel Trim Pad Replacement




27.
[Click here for full size](#)

28. Instrument Panel Air Outlet Bezel - Right Side (2) >> Remove - Instrument Panel Air Outlet Bezel Replacement - Right Side




29.
[Click here for full size](#)

30. Instrument Panel Cluster Trim Plate (1) >>> Remove - Instrument Panel Cluster Trim Plate Replacement




31.
[Click here for full size](#)

32. Instrument Panel Air Outlet Bezel - Left Side (2) >>> Remove - Instrument Panel Air Outlet Bezel Replacement - Left Side




33.
[Click here for full size](#)

34. Radio Control (1) >> Remove - Radio Control Replacement




35.
[Click here for full size](#)

36. Instrument Cluster (2) >> Remove - Instrument Cluster Replacement




37.
[Click here for full size](#)

38. Instrument Panel Upper Trim Panel Cover (1) >> Remove - Instrument Panel Upper Trim Panel Cover Replacement




39.
[Click here for full size](#)

40. Body Control Module (1) >> Remove - Body Control Module Replacement



41.
[Click here for full size](#)

42. Steering Column (1) >> Remove - Steering Column Replacement




43.
[Click here for full size](#)

44. Note:


With the aid of an assistant, remove the instrument panel carrier assembly from the vehicle.

45. Instrument Panel Carrier (1) >> Remove - Instrument Panel Carrier Replacement




46.
[Click here for full size](#)

47. Floor Front Air Outlet Duct - Left Side (1) >> Remove - Floor Front Air Outlet Duct Replacement - Left Side



48.
[Click here for full size](#)

49. Front Floor Console Auxiliary Cooling Intermediate Duct (1) >> Remove - Front Floor Console Auxiliary Cooling Intermediate Duct Replacement




50.
[Click here for full size](#)

51. Disconnect the electrical connector. (1)

52. Floor Air Temperature Sensor - Left Side (2) >> Remove


Installation Procedure



1.
[Click here for full size](#)


2. Floor Air Temperature Sensor - Left Side (2) >> Install

3. Connect the electrical connector. (1)




4.
[Click here for full size](#)

5. Front Floor Console Auxiliary Cooling Intermediate Duct (1) >> Install - Front Floor Console Auxiliary Cooling Intermediate Duct Replacement



6.
[Click here for full size](#)


7. Floor Front Air Outlet Duct - Left Side (1) >> Install - Floor Front Air Outlet Duct Replacement - Left Side




8. [Click here for full size](#)
9. Note:

With the aid of an assistant, remove the instrument panel carrier assembly from the vehicle.

10. Instrument Panel Carrier (1) >> Install - Instrument Panel Carrier Replacement




11. [Click here for full size](#)
12. Steering Column (1) >> Install - Steering Column Replacement




13.
[Click here for full size](#)

14. Body Control Module (1) >> Install - Body Control Module Replacement




15.
[Click here for full size](#)

16. Instrument Panel Upper Trim Panel Cover (1) >> Install - Instrument Panel Upper Trim Panel Cover Replacement




17.
[Click here for full size](#)

18. Instrument Cluster (2) >> Install - Instrument Cluster Replacement




19.
[Click here for full size](#)

20. Radio Control (1) >> Install - Radio Control Replacement




21.
[Click here for full size](#)

22. Instrument Panel Air Outlet Bezel - Left Side (2) >> Install - Instrument Panel Air Outlet Bezel Replacement - Left Side




23.
[Click here for full size](#)

24. Instrument Panel Cluster Trim Plate (1) >> Install - Instrument Panel Cluster Trim Plate Replacement




25.
[Click here for full size](#)

26. Instrument Panel Air Outlet Bezel - Right Side (2) >> Install - Instrument Panel Air Outlet Bezel Replacement - Right Side




27.
[Click here for full size](#)

28. Instrument Panel Trim Pad (2) >> Install - Instrument Panel Trim Pad Replacement




29.
[Click here for full size](#)

30. Instrument Panel Upper Trim Panel (1) >> Install - Instrument Panel Upper Trim Panel Replacement




31.
[Click here for full size](#)

32. Instrument Panel Extension (1) >> Install - Instrument Panel Extension Replacement




33.
[Click here for full size](#)

34. Instrument Panel Instrument Cluster Hood (1) >> Install - Instrument Panel Instrument Cluster Hood Replacement




35.
[Click here for full size](#)

36. Radio Front Center Speaker Grille (1) >> Install - Radio Front Center Speaker Grille Replacement




37.
[Click here for full size](#)

38. Instrument Panel Compartment (1) >> Install - Instrument Panel Compartment Replacement




39.
[Click here for full size](#)

40. Front Floor Console Compartment (1) >> Install - Front Floor Console Compartment Replacement




41.
[Click here for full size](#)

42. Front Floor Console Extension Panel (2) >>> Install - Front Floor Console Extension Panel Replacement




43.
[Click here for full size](#)

44. Front Floor Console Applique - Left Side (2) >>> Install - Front Floor Console Applique Replacement - Left Side




45.
[Click here for full size](#)

46. Rear Compartment Closeout Panel (1) >> Install - Rear Compartment Closeout Panel Replacement




47.
[Click here for full size](#)

48. Radio Rear Quarter Trim Panel Speaker Grille (1) >> Install - Radio Rear Quarter Trim Panel Speaker Grille Replacement



49.
[Click here for full size](#)

50. Instrument Panel Knee Bolster (2) >> Install - Instrument Panel Knee Bolster Replacement



51.
[Click here for full size](#)

52. Install the left and right instrument panel outer trim cover (1). Instrument Panel Outer Trim Cover Replacement

53. Clear the DTCs.