

2022 CHEVROLET CORVETTE SERVICE MANUAL

- **SEARCH**

1. **Power and Signal Distribution**
2. **Wire and Connector Repair**
3. **Repair Instructions**
- 4.

Bosch Connectors (2.8 JPT)

Special Tools

- *EL-38125-550*™, ™ Terminal Release Tool Kit
- *EL-38125-580*™, ™ Terminal Release Tool Kit
- *J-38125-557*™, ™ Terminal Release Tool

For equivalent regional tools, refer to Special Tools.

Terminal Removal Procedure

1. Pull out the slider on the connector position assurance (CPA) until it is at the end of its travel.
2. Disconnect the connector from the component.
3. Remove the wire dress cover, if necessary.
4. Push the wire side of the terminal that is being removed toward the connector and hold it in position.
5.
Click here for full size
6. Insert the J-38125-557 into the 2 cavities on each side of the terminal at the front of the connector and push until you feel the tool disengage the terminal retainers.
7. Carefully pull the terminal out of the connector. Always remember never use force when pulling a terminal out of a connector. If the terminal is difficult to remove, repeat the entire procedure.
8. Repair the terminal by following the Repairing Connector Terminals procedure.
9. Insert the repaired terminal back into the cavity. Repeat the diagnostic procedure to verify the repair and reconnect the connector bodies.