

2022 CHEVROLET CORVETTE SERVICE MANUAL

- **SEARCH**

1. **Power and Signal Distribution**

2. **Wire and Connector Repair**

3. **Repair Instructions**

- 4.

Tyco/AMP Connectors (Door Module)

Special Tools

- *EL-38125-550*™,™ Terminal Release Tool Kit
- *EL-38125-580*™,™ Terminal Release Tool Kit
- *J-38125-12A*™,™ Terminal Release Tool

For equivalent regional tools, refer to Special Tools.

Terminal Removal Procedure

Click here for full size

Side view of connector.

Click here for full size

View of top of connector.

1. Locate the assist lever and lock on the top of the connector.
2.
Click here for full size
3. While depressing the lock, pull the lever over and past the lock.
4.
Click here for full size
5. Disconnect the connector from the component.
6.
Click here for full size
7. Locate the dress cover locking tabs at the rear of the connector. Use a small flat-blade tool to release the locking tabs. Repeat this procedure for the other locking tab.
8.
Click here for full size
9. Once the locking tabs are unlocked, slide the inner connector out of the rear of the connector housing.
10.
Click here for full size
11. Use the J-38125-12A tool to release the terminals by pressing on the tang.
12. While holding the removal tool in place, gently pull the wire out of the back of the connector. Always remember never use force when pulling a terminal out of a connector.
13. Repair the terminal by following the Repairing Connector Terminals procedure.
14. Insert the repaired terminal back into the cavity. Repeat the diagnostic procedure to verify the repair and reconnect the connector bodies.